

IMPORTANT INFORMATION

- Do not play with RC Tire Twister™ Lights in the street or where there is vehicular traffic or in heavily traveled areas with pedestrians.
- Do not stand on, sit on or throw RC Tire Twister™ Lights as doing so can result in injury to the person and irreversible damage to the unit.
- Do not attempt to use the "tire" portion of this toy as a wheel on any other toy or vehicle such as a wagon, tricycle, etc. or in any manner other than the manner described in this manual.
- Do not run car/tire into furniture, walls, pets, people etc., as doing so may cause injury to the people and pets and irreparable damage to the unit.
- Do not allow long hair or loose apparel such as shoestrings near the turning wheels of the car.
- Do not drive car/tire through water, mud, etc.

BATTERY SAFETY INFORMATION

- Use only size "AA" (LR6) alkaline batteries (6 required).
- Charging of rechargeable batteries should only be done under adult supervision with batteries removed from product.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Be sure to insert the batteries correctly and follow the toy and battery manufacturer's instruction.
- Always remove exhausted or dead batteries from the product.
- Dispose of dead batteries properly: do not burn or bury them.
- Do not attempt to recharge non-rechargeable batteries.
- Avoid short-circuiting battery terminals.
- Remove batteries before placing the unit into storage for a prolonged period of time.

FCC COMPLIANCE

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Modifications not authorized by the manufacturer may void users authority to operate this device.
CAN ICES-3 (B)/NMB-3(B).

LIMITED WARRANTY

The Little Tikes Company makes fun, high quality toys. We warrant to the original purchaser that this product is free of defects in materials or workmanship for one year * from the date of purchase (dated sales receipt is required for proof of purchase). At the sole election of The Little Tikes Company, the only remedies available under this warranty will be the replacement of the defective part or replacement of the product. This warranty is valid only if the product has been assembled and maintained per the instructions. This warranty does not cover abuse, accident, cosmetic issues such as fading or scratches from normal wear, or any other cause not arising from defects in material and workmanship. *The warranty period is three (3) months for daycare or commercial purchasers. U.S.A and Canada: For warranty service or replacement part information, please visit our website at www.littletikes.com, call 1-800-321-0183 or write to: Consumer Service, The Little Tikes Company, 2180 Barlow Road, Hudson OH 44236, U.S.A. Some replacement parts may be available for purchase after warranty expires—contact us for details. Outside U.S.A and Canada: Contact place of purchase for warranty service. This warranty gives you specific legal rights, and you may also have other rights, which vary from country/state to country/state. Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.



'Let's care for the environment!'

The wheelie bin symbol indicates that the product must not be disposed of with other household waste. Please use designated collection points or recycling facilities when disposing of the item. Do not treat old batteries as household waste. Take them to a designated recycling facility.

Please keep this manual as it contains important information.



© The Little Tikes Company,
an MGA Entertainment company.
LITTLE TIKES® is a trademark of Little Tikes in
the U.S. and other countries. All logos, names, characters,
likenesses, images, slogans, and packaging appearance are the
property of Little Tikes.
Little Tikes Consumer Service
2180 Barlow Road Hudson, Ohio 44236 U.S.A.
1-800-321-0183
Printed in China

MGA Entertainment UK Ltd
50 Presley Way
Crownhill
Milton Keynes
MK8 0ES
Bucks, UK
0800 521 558

www.littletikes.com
www.littletikes.co.uk



Visit our website at
www.littletikes.com
to register your product and
to enter our sweepstakes.
(No purchase necessary)



Tire Twister™ Lights

AGES 3+ YEARS

ADULT SUPERVISION RECOMMENDED.
ADULT BATTERY INSTALLATION REQUIRED.

SKU: 643309

CONTENTS

- A. 1 Little Tikes® RC Tire Twister™ Car
- B. 1 Monster Tire
- C. 1 Remote Control



A.



B.



C.

Illustrations are for reference only. Styles may vary from actual contents.

BATTERY INSTALLATION


RACE CAR

Before playing, an adult must install fresh alkaline batteries in the car and remote. Here's how:

1. Using a Phillips screwdriver (not included) remove the screw and battery compartment cover from the underside of the car.
2. Install four (4) fresh 1.5V AA alkaline batteries (not included) in the car making sure the (+) and (-) ends face the proper direction as indicated inside the battery compartment.


NOTE: Car batteries are layered with two batteries inserted on the bottom layer and two remaining batteries above it. Position ribbon inside the battery compartment as shown before installing batteries. Ribbon will aid in battery removal when batteries need to be replaced.

3. Replace the compartment cover and tighten the screw.



REMOTE CONTROL

1. Using a Phillips screwdriver (not included) remove the screw and battery compartment cover from the underside of the remote.
2. Install two (2) fresh 1.5V AA alkaline batteries (not included) making sure the (+) and (-) ends face the proper direction as indicated inside the battery compartment.
3. Replace the compartment cover and tighten the screw.



IMPORTANT NOTE:

In the event of a malfunction, reset the item by removing and replacing the batteries. If function is still not restored, replace the batteries with fresh alkaline batteries.

QUICK START

DRIVE IT, SPIN IT, FLIP IT !

DRIVING THE TIRE TWISTER

1. Set the car inside the monster tire making sure the car tires straddle the ribs inside the monster tire.
2. Place the monster tire on the floor.
3. To assure your car will pick up the correct frequency, switch the car ON first, then switch the remote control ON.
4. Follow the remote control patterns below. As the car inside the monster tire moves, the monster tire will turn, twist and spin!

5. While going forward, reverse the direction and the car will flip backward and forward inside the monster tire.

NOTE: When finished playing, first turn off the car, then turn off the remote control.

DRIVING THE RC CAR

1. To assure your car will pick up the correct frequency, switch the car ON first, then switch the remote control ON.
2. Place the car on the floor.
3. Press the buttons on the remote control as shown in the diagrams below.

NOTE: When finished playing, first turn off the car, then turn off the remote control.



Press both buttons up, car will move forward. (Press both buttons down, car will reverse.)



Press right button up, car will turn right. (Press right button down, car will reverse to the right.)



Press left button up, car will turn left. (Press left button down, car will reverse to the left.)



Press and hold buttons as shown, car will spin in a circle. (Press and hold opposite buttons, car will spin in the opposite direction.)

