

Register your products and get support at
www.philips.com/welcome

4000 Series

Quick start guide

PHILIPS



C:100 M:44 Y:0 K:0




English Before using your product, read all accompanying safety information.
(The relevant parameters of instructions are variable, without prior notice, if there is any discrepancy, please in accordance with actual object.)

Türkçe Ürününüzü kullanmadan önce, beraberindeki tüm güvenlik bilgilerini okuyun.
(Talimatların ilgili parametreleri önceden bildirimde bulunmaksızın değiştirilebilir; herhangi bir tutarsızlık olması halinde, lütfen gerçek ürünü dikkate alın.)







English What's in the box
Türkçe Kutu içerikleri

32"/43"



32"

43"





(4 pcs)

1




English Mount the stand
Türkçe Standı monte edin
32"


1




2



3




4




English Mount the stand
Türkçe Standı monte edin

43"


1



2




3




2





English Connect
Türkçe Bağlan
32"







English Connect
Türkçe Bağlan

43"











3

English Insert batteries
Türkçe Pilleri takın






English To wall mount, purchase a suitable bracket.
Türkçe Duvara monte etmek için, uygun bir braket satın alın.



Display	H	V
80 cm / 32"	100 mm	100 mm
108 cm / 43"	400 mm	200 mm


4

English Press the "OK" key on the backcover of the display or on the remote control to turn on the display.
Türkçe Ekranı açmak için ekranın arka kısmındaki veya uzaktan kumandadaki "OK" düğmesine basın.



English If the indicator is off, please insert the display power cord into a power outlet. Press the power switch to turn on the display as shown in the figure.
When the indicator is on, press the Φ key on the bottom panel of the display or on the remote control to turn on the display.

Türkçe Gösterge kapalıysa, lütfen ekran güç kablosunu prize takın. Ekranı şekilde görüldüğü gibi açmak için güç düğmesine basın.
Gösterge açıkken, ekranı açmak için ekranın alt panelindeki veya uzaktan kumandadaki Φ düğmesine basın.





English Please refer to the User's Manual and the Philips support website for more operating instructions.
Türkçe Daha fazla çalıştırma talimatı için lütfen Kullanım Kılavuzuna ve Philips destek web sitesine bakın.



7314-3200K3-134FLP11



All registered and unregistered trademarks are the property of their respective owners. Specifications are subject to change without notice.

Philips and the Philips' shield emblem are registered trademarks of Koninklijke Philips N.V. and are used under license from Koninklijke Philips N.V.

2017© TPVision Netherlands B.V. All rights reserved.

philips.com

