

PHILIPS

Plastrejsetui

Philips Sonicare

Hvid

CP0546/01



Tag din tandbørste med dig,

Tjek kompatibilitet herunder

Dette rejsetui i plastik giver robust og hygiejnisk opbevaring af din Philips Sonicare eltandbørste. Tag den med overalt.

Specifikationer

Reservedel

Passer til mundhygiejne: HX8273/20,

HX8454/81, HX8911/30, HX8912/02, HX8915/01, HX8918/10, HX8923/34, HX8932/74, HX8932/75, HX8932/76, HX8941/10, HX8981/02, HX9110/02, HX9111/12, HX9112/02, HX9112/12, HX9112/52, HX9114/37, HX9141/07, HX9141/51, HX9142/10, HX9142/32, HX9170/10, HX9172/10, HX9172/14, HX9172/38, HX9182/10, HX9192/29, HX9192/30, HX9193/03, HX9193/04, HX9193/05, HX9193/07, HX9194/08, HX9194/53, HX9194/54, HX8911/35

Passer til mundplejeprodukter: HX6632/21,

HX6652/70, HX6681/07, HX6711/64, HX6711/65, HX6711/68, HX6712/06, HX6712/66, HX6712/67, HX6713/11, HX6721/33, HX6721/35, HX6721/45, HX6730/33, HX6731/02, HX6731/03, HX6731/33, HX6732/02, HX6732/37, HX6732/38,

HX6732/42, HX6732/74, HX6732/75, HX6761/03, HX6782/33, HX6782/34, HX6908/84, HX6911/07, HX6911/29, HX6911/77, HX6911/80, HX6912/21, HX6912/32, HX6912/44, HX6921, HX6921/02, HX6921/04, HX6921/30, HX6921/31, HX6922/39, HX6932, HX6932/10, HX6932/34, HX6932/36, HX6938/48, HX6942, HX6942/04, HX6942/14, HX6942/20, HX6952/71, HX6962/70, HX6962/73, HX6963/74, HX6972/10, HX6972/31, HX6972/34, HX6972/35, HX6973/35, HX6982, HX6982/03, HX6982/10, HX6986, HX6986/03, HX6992/01, HX6992/03, HX6993/03

Passer til produkttypen: HX1000/01,

HX6211/05, HX6221/22, HX6234, HX6234/35, HX6235, HX6235/36, HX6252/70, HX6252/71, HX6252/72, HX6252/73, HX6252/86, HX6253/81, HX6253/82, HX6253/83, HX6254/81, HX6315/71, HX6322/29,

HX6325/70, HX6352/45, HX6511/30, HX6512/59, HX6513/08, HX6513/09, HX6552/76, HX6552/77, HX6557/76, HX6582/51, HX6589/37, HX6601/03, HX6601/29, HX6611/27, HX6612/26, HX6616/50, HX6616/51, HX6616/52, HX6631/02, HX6631/13, HX6631/24, HX6631/30, HX6632/15, HX6632/22, HX6632/24, HX6632/25, HX6921/06, HX6921/43, HX6922/03, HX6971/33, HX6972/03, HX8911/01, HX8911/02, HX8911/04, HX8911/22, HX8922/37, HX8922/90, HX8962/05, HX8982/02, HX9111/20, HX9111/21, HX9112/13, HX9141/20, HX9142/31, HX9172/15, HX9172/19, HX9182/18, HX9182/32, HX9182/34, HX9191/06, HX9191/07, HX9192/01, HX9192/02

