

© Arlo Technologies, Inc. Arlo, Arlo logo, and Every Angle Covered are trademarks of Arlo Technologies, Inc. App Store is a service mark of Apple Inc. Google Play and the Google Play logo are trademarks of Google LLC. Other trademarks are for reference purposes.

Si ce produit est vendu au Canada, vous pouvez accéder à ce document en français canadien à [arlo.com/docs](https://www.arlo.com/docs).

(If this product is sold in Canada, you can access this document in Canadian French at [arlo.com/docs](https://www.arlo.com/docs).)

For regulatory compliance information including the EU Declaration of Conformity, visit www.arlo.com/about/regulatory/.



Arlo Technologies Intl. Ltd.
Ground Floor, Building 3
University Technology Center
Curraheen Road, Cork, T12 EF21
Ireland

Arlo Technologies, Inc.
2200 Faraday Avenue, Suite 150
Carlsbad, CA 92008 USA

October 2019




2C1-50249-01



Set up your Arlo Pro 2 Wire-Free System

1. Connect the power adapter and the Ethernet cable to your Arlo Base Station.




2. Download the Arlo app and follow the setup instructions for a wire-free camera.




Download on the
App Store

GET IT ON
Google Play

3. Insert the battery into your camera.



What's in the box




Base Station
with Siren




Pro 2 Wire-Free
Camera



Rechargeable
battery



Base station
power adapter



Ethernet cable



Mount and
mounting screw



Camera power
adapter



Camera power
adapter cable

Need help?

We are here for you.

Visit www.arlo.com/support for quick answers and resources:

- How-to videos
- Troubleshooting tips
- The Arlo Support phone number for your location