

Instruction manual

Retro roller model F1 898

Imported by Van der Meulen.
www.retroroller.eu

PLEASE NOTE! Assembly must be done by an adult. Keep out of reach of young children because of the small parts.


IMPORTANT:

1. For the child's safety, all assembly steps must be carried out properly. Incorrect assembly could cause injury.
2. Lubricate moving parts regularly or after long-term use.
3. Ensure that all nuts and bolts have been tightened before use. Check nuts and bolts regularly and tighten where necessary.
4. Components showing signs of wear should be replaced immediately.
5. The child should never be left unattended when riding in the vehicle.



1

Tool required:



3

HARWARE SET COMPONENTS


No.	Qty	Description	Spec.
*898.8001	1	Hexagon locknut	M4
*898.8002	8	Hexagon locknut	Ø3/16"
*898.8003	1	Machine screw	M4x24mm
*898.8004	8	Machine screw	Ø3/16x13mm
*898.8005	4	Self tapping screw	Ø4/13mm
*898.8006	4	Hub cap	Ø10mm

* Standard hardware items may be purchased locally


2

Part no x Qty


Some parts may have already been pre-assembled upon receipt.




2



4



5



Adult supervision is required! Please make certain that anyone who uses this vehicle has been fully instructed as to the operations of the vehicle.

WARNING: This vehicle does not have a braking system. Do not ride on steep hills, staircases or on or near water. Never use vehicle on rough terrain, for jumping or other stunts. No more than one child can be on the vehicle at any time (single passenger only). Shoes and helmet should be worn at all times, to prevent injuries.

Suitable for children over 24 months.

© 2014

