



Original HP Media InkJet

April 2018

CISMEA



HP DeskJet Printers

HP DeskJet Printers	
HP DeskJet F370/F375/F380/F390	• • • • •
HP DeskJet 450ci/450cbi/450wbt	• • • • •
HP DeskJet 460c/cb/wbt/wf	• • • • •
HP DeskJet 5440	• • • • •
HP DeskJet 710c/720c/722c/815c	• • • • •
HP DeskJet 810c	• • • • •
HP DeskJet 820cXi/850c/870cXi	• • • • •
HP DeskJet 816c/825c/840c/843c/845c	• • • • •
HP DeskJet 880c/890c/895cXi	• • • • •
HP DeskJet 916c/920c/940c/HP Color Copier 310	• • • • •
HP Color Copier 290	• • • • •
HP DeskJet 930c/cm /950c/959c	• • • • •
HP DeskJet 960c/970cXi/980cXi/990cXi/cm /995c	• • • • •
HP DeskJet 1000, 1050/1050se/2000/1515 AiO/2050/2050se/3000/3050/3050se/3050ve	• • • • •
HP DeskJet 1010/1050A/1510 AiO/1512/1514/2050A/2054A/2540-e-AiO/2542/2544/2549/3050A/3052A/3054A	• • • • •
HP DeskJet 2510/2514/3055A/3057/3059 ¹²	• • • • •
HP DeskJet 3070A	• • • • •
HP DeskJet 1100c/1120c/1125c	• • • • •
HP DeskJet 1200c/ps	• • • • •
HP DeskJet 1180c/1220c/1220c/ps/1280	• • • • •
HP DeskJet 1600c/cm	• • • • •
HP DeskJet 2130	• • • • •
HP DeskJet 3320/3325/3420/3425 series	• • • • •
HP DeskJet 3520 e-AiO	• • • • •
HP DeskJet 3520/3535/3550/3745	• • • • •
HP DeskJet 3645/3647/3650/3845	• • • • •
HP DeskJet 3810/3816/3820/3822 series	• • • • •
HP DeskJet 3920/3940	• • • • •
HP DeskJet 5145/5150/5151/5550/5552	• • • • •
HP DeskJet 5650/5652/5655	• • • • •
HP DeskJet 5740/5745	• • • • •
HP DeskJet 5850	• • • • •
HP DeskJet 5940	• • • • •
HP DeskJet 6122/6127	• • • • •
HP DeskJet 6520/6540/6540d/6620/6840/9800/9800d	• • • • •
HP DeskJet 6940/6980	• • • • •
HP DeskJet 9300	• • • • •
HP DeskJet 9650/9670/9680/9680gp	• • • • •
HP DeskJet D1360/D1460/D1470/D1560	• • • • •
HP DeskJet D230/D2360/D2430/D2460	• • • • •
HP DeskJet D1660/D2560/D2660/D5560	• • • • •
HP DeskJet D4160/D4260/D4360	• • • • •
HP DeskJet F2180/F2187/F2200/F2290	• • • • •
HP DeskJet F2224	• • • • •
HP DeskJet F2420/F2480/F2492/F4140/F4172/F4180/F4190/F4210/F4272/F4280/F4580	• • • • •
HP DeskJet F4224	• • • • •
HP DeskJet Ink Advantage F735	• • • • •
HP DeskJet Ink Advantage (K209g)	• • • • •
HP DeskJet Ink Advantage 2060 K110	• • • • •
HP DeskJet Ink Advantage 1515 AiO/1516/2515/2645 AiO/2646/3515 e-AiO ¹¹	• • • • •
HP DeskJet Ink Advantage 3525/4615/4625 e-AiO/5525/6525 ¹¹	• • • • •
HP Fax 3180	• • • • •
HP Digital Copier 410	• • • • •



Premium Photo Paper
Print your photos in the most convenient quality and size.
Choose among 10x15, 13x18, A4 and A3.



Social Media Snapshots
Print photos from your smartphone, then stick to decorate. Removes easily!¹¹



Everyday Photo Paper
Discover our 100 sheets box to benefit from more savings than the 25 sheet box.



Zink Photo Paper
Print wherever you are to hand photos to friends or decorate spaces.²³

Please recycle your used cartridges



www.hp.com/recycle



Original HP Media InkJet

April 2018

CISMEA




HP OfficeJet Printers

HP OfficeJet Printers		Q5451A	A4	HP Everyday Photo Paper
HP 910 InkJet Printer	•	CR757A	10 x 15	HP Everyday Photo Paper
HP CopyJet /M	•	Q2510A	10 x 15	HP Everyday Photo Paper
HP Color InkJet CP 1700 series/ HP Business InkJet 2600 series	•	Q8691A	10 x 15	HP Everyday Photo Paper
HP Business InkJet 1000 series	•	Q8698A	10 x 15	HP Everyday Photo Paper
HP Business InkJet 1100 series	•	Q8692A	13 x 18	HP Advanced Photo Paper
HP Business InkJet 1200 series	•	Q5456A	A4	HP Advanced Photo Paper
HP Business InkJet 2200 series/2300 series	•	Q8698A	A4	HP Advanced Photo Paper
HP Business InkJet 2800 series	•	Q8697A	A3	HP Advanced Photo Paper
HP Business InkJet 3000	•	CR677A	10 x 15	HP Premium Plus Photo Paper
HP OfficeJet i45/t65/r45/r/65	•	CR676A	13 x 18	HP Premium Plus Photo Paper
HP OfficeJet g55/g85/g95/k60/k80	•	CR673A	A4	HP Premium Plus Photo Paper
HP OfficeJet Pro 1150c	•	CR674A	A4	HP Premium Plus Photo Paper
HP OfficeJet Pro 1170c/1175c	•	CR672A	A3	HP Premium Plus Photo Paper
HP OfficeJet Pro 251dw/276dw	•	CR675A	A3	HP Premium Plus Photo Paper
HP OfficeJet 6000/6500/7000 series	•	W2650A*	10 x 13	HP Social Media Snapshots
HP OfficeJet Pro 6230 ePrinter, 6830 e-AiO	•	Q6593A	A4 120 g	HP Professional Paper
HP OfficeJet 6500A/6500A Plus	•	Q6594A	A3 120 g	HP Professional Paper
HP OfficeJet 7100 WF e-Printer/7500A WF	•	Q6592A	A4 180 g	HP Professional Paper
HP OfficeJet Pro 8000/8500 series/ 8500A/8500A Plus	•	Q6819A	A4 180 g	HP Professional Paper
HP OfficeJet 3630/J3680/3830	•	C6521A	A3 180 g	HP Iron-on Transfers
HP OfficeJet 4105/4110/4212/4215/4219/ 4252/4255/4315/4355	•	C5977B	A4 90 g	HP Bright White InkJet Paper
HP OfficeJet 4500 G510 a/g/n	•	C1825A	A3 90 g	HP Bright White InkJet Paper
HP OfficeJet 4620, 4622 e-AiO ¹²	•	C1858A	A3 90 g	HP Bright White InkJet Paper
HP OfficeJet 2620, 2622, 2624 AiO, 4630, 4634, 4636 e-AiO	•	CHP110	A4 80 g	HP Office Paper
HP OfficeJet 4650	•	CHP112	A4 80 g	HP Office Paper
HP OfficeJet Pro X451 dw, X551 dw, X476 dw MFP, X576 dw MFP	•	CHP113	A3 80 g	HP Office Paper
HP OfficeJet H470/b/wbt/100 mobile/150 mobile	•	CHP120	A3 80 g	HP Office Paper
HP OfficeJet J4524/J4535/J4580/J4624/J4660/J4680	•	CHP150	A4 80 g	HP Home & Office
HP OfficeJet 5110/v30/v40/v45/ PSC 750/950/HP Fax 1230	•	CHP152	A4 80 g	HP Home & Office
HP OfficeJet 5505/5510/5515	•	CHP650	A4 75 g	HP Everyday
HP OfficeJet 5605/5607/5610/5615	•	CHP660	A3 75 g	HP Everyday
HP OfficeJet J5730/J5780/J5785/J6410/J6415/J6424	•	CHP850-5	A4	HP Premium
HP OfficeJet 5740 e-AiO	•	CHP860-2	A3	HP Premium
HP OfficeJet 6100 e-Printer/6600 e-AiO/ 6700 Premium e-AiO	•	CHP215	A4 80 g	HP Printing Paper
HP OfficeJet 6110	•	CHP220	A3 80 g	HP Printing Paper
HP OfficeJet 6205/6210/6215	•	CHP235	A4 90 g	HP Multipurpose Paper
HP OfficeJet 6310/6315	•	CHP25	A4 80 g	HP All-in-One Printing Paper
HP OfficeJet 6950	•	CHP710	A4 80 g	HP All-in-One Printing Paper
HP OfficeJet Pro 6960 / 6970	•	CHP712	A4 80 g	HP All-in-One Printing Paper
HP OfficeJet K7100	•	CHP810	A4 100 g	HP Premium Choice Paper
HP OfficeJet 7210	•	CHP812	A4 80 g	HP Recycled
HP OfficeJet 7310/7410	•	CHP830	A4 80 g	HP Copy Paper
HP OfficeJet Pro 8210/8218	•	CHP910	A4 80 g	HP Copy Paper
HP OfficeJet Pro 8710/8715/8718/8719	•	CHP920	A3 80 g	HP ZINK® Sticky-backed Photo Paper**
HP OfficeJet Pro 8720/8725/8730/8740	•	W42713A	5 x 7.6	HP ZINK® Sticky-backed Photo Paper**
HP OfficeJet Pro 7740 WF	•	1D377A		
HP OfficeJet 7100 WF e-Printer/ 7510 WF/7610 WF e-AiO/7612 WF	•	1R737A		
HP OfficeJet 9100 series	•	2LY72A	5.8 x 8.7	HP Sprocket Plus Photo Paper
HP OfficeJet Pro K550/K5400	•	2LY74A		
HP OfficeJet Pro L7480/L7580/L7590/ L7680/L7780/K8600	•			
HP OfficeJet Pro K850 series	•			
HP OfficeJet Pro 8600 e-AiO/ 8600 Plus e-AiO/8610/8615/8620	•			
HP OfficeJet Pro 8100 e-Printer (N811a)	•			



Premium Photo Paper
Print your photos in the most convenient quality and size.
Choose among 10x15, 13x18, A4 and A3.



Social Media Snapshots
Print photos from your smartphone, then stick to decorate. Removes easily!¹¹



Everyday Photo Paper
Discover our 100 sheets box to benefit from more savings than the 25 sheet box.



Zink Photo Paper
Print wherever you are to hand photos to friends or decorate spaces.²³

Please recycle your used cartridges



www.hp.com/recycle



Original HP Media InkJet

April 2018




CISMFA

HP Photosmart Printers



**Premium
Photo Paper**
Print your photos in
the most convenient
quality and size.
Choose among 10x15,
13x18, A4 and A3.



**Social Media
Snapshots**
Print photos from
your smartphone,
then stick to decorate.
Removes easily!¹¹



**Everyday
Photo Paper**
Discover our 100 sheets
box to benefit from
more savings than
the 25 sheet box.



Zink Photo Paper
Print wherever
you are to hand
photos to friends or
decorate spaces ^{2,3}

Please recycle your
used cartridges





Original HP Media InkJet

April 2018



CISMEA

HP ENVY Printers

HP ENVY Printers					
05451A Q5510A	A4 10 x 15	HP Everyday Photo Paper	• •	05451A Q2510A	A4 10 x 15
CR757A			• •	CR757A	10 x 15
08691A Q8090A	A4 10 x 15		• •	08691A Q8090A	10 x 15
Q8692A			• •	Q8692A	10 x 15
08696A	A4 13 x 18	HP Advanced Photo Paper	• •	08696A	13 x 18
05456A Q8698A	A4 A3		• •	Q5456A Q8698A	A4 A3
08697A			• •	08697A CR677A	A3 10 x 15
CR677A	A4 10 x 15		• •	CR677A CR695A	10 x 15
CR676A	A4 13 x 18	HP Premium Plus Photo Paper	• •	CR676A CR672A	13 x 18
CR673A	A4 A3		• •	CR673A CR672A	A4 A3
CR674A			• •	CR674A CR675A	10 x 15
CR675A	A4 A3	HP Iron-on Transfers	• •	CR675A CR650A	A4 10 x 13
CR650A*	A4 10 x 13	HP Social Media Snapshots	• •	W2660A*	10 x 13
Q6593A	A4 120 g		• •	Q6593A	A4 120 g
Q6594A	A3 120 g		• •	Q6594A	A3 120 g
Q6593A	A4 180 g	HP Professional Paper	• •	Q6593A C6818A	A4 180 g
C6818A	A3 180 g		• •	C6821A	A3 180 g
C5977B	A4 90 g	HP Bright White Inkjet Paper	• •	C5977B C1825A	A4 90 g
C1825A	A3 90 g		• •	C1825A C1838A	A3 90 g
CHP110	A4 80 g	HP Professional Paper	• •	CHP110 CHP112	A4 80 g
CHP112	A4 80 g		• •	CHP112 CHP113	A4 80 g
CHP113	A3 80 g	HP Office Paper	• •	CHP113 CHP120	A3 80 g
CHP120	A3 80 g		• •	CHP120 CHP150	A3 80 g
CHP150	A4 80 g	HP Home & Office	• •	CHP150 CHP152	A4 80 g
CHP152	A4 75 g		• •	CHP152 CHP550	A4 75 g
CHP550	A4 75 g	HP Everyday	• •	CHP550 CHP660	A4 75 g
CHP660	A3 75 g		• •	CHP660 CHP850-5	A4 75 g
CHP850-5	A4 75 g	HP Premium	• •	CHP850-5 CHP860-2	A4 75 g
CHP860-2	A3 80 g		• •	CHP860-2 CHP210	A3 80 g
CHP210	A4 80 g	HP Printing Paper	• •	CHP210 CHP215	A4 80 g
CHP215	A4 80 g		• •	CHP215 CHP220	A4 80 g
CHP220	A3 80 g	HP Premium Choice Paper	• •	CHP220 CHP235	A4 80 g
CHP235	A4 90 g	HP Recycled	• •	CHP235 CHP250	A4 80 g
CHP250	A4 80 g	HP Multipurpose Paper	• •	CHP250 CHP710	A4 80 g
CHP710	A4 80 g	HP All-in-One Printing Paper	• •	CHP710 CHP712	A4 80 g
CHP712	A4 80 g		• •	CHP712 CHP810	A4 80 g
CHP810	A4 100 g	HP Premium Choice Paper	• •	CHP810 CHP812	A4 100 g
CHP812	A4 100 g		• •	CHP812 CHP830	A4 100 g
CHP830	A4 80 g	HP Copy Paper	• •	CHP830 CHP910	A4 80 g
CHP910	A4 80 g		• •	CHP910 CHP920	A4 80 g
CHP920	A3 80 g	HP Copy Paper	• •	CHP920 W4213A	A4 80 g
W4213A	5 x 7.6	HP ZINK® Sticky-backed Photo Paper**	• •	W4213A 1DE37A	5 x 7.6
1DE37A			• •	1DE37A 1RF37A	HP ZINK® Sticky-backed Photo Paper**
1RF37A			• •	1RF37A 2LY72A	2LY72A
2LY72A	5.8 x 8.7	HP Sprocket Plus Photo Paper	• •	2LY72A 2LY74A	5.8 x 8.7
2LY74A			• •	2LY74A	HP Sprocket Plus Photo Paper



Premium Photo Paper
Print your photos in the most convenient quality and size.
Choose among 10x15, 13x18, A4 and A3.



Social Media Snapshots
Print photos from your smartphone, then stick to decorate. Removes easily!¹¹



Everyday Photo Paper
Discover our 100 sheets box to benefit from more savings than the 25 sheet box.



Zink Photo Paper
Print wherever you are to hand photos to friends or decorate spaces.²³

Please recycle your used cartridges



¹ Local printing requires mobile device and printer be on the same network or have a direct wireless connection. Mobile printing supported on iPhone®, iPad®, and iPod Touch® using AirPrint™ on iOS v7.1 and higher. Android™ printing supported on Android devices using OS v4.4 and higher and may require the installation of a printer service plug-in from the Google™ Play Store. For details on how to print, see hp.com/go/mobileprinting. AirPrint is a trademark of Apple, Inc. and Android and Google Play Store are trademarks of Google, Inc.

² HP Sprocket app required.

³ The ZINK Technology™ and ZINK Trademarks™ are owned by ZINK Holdings LLC. Used under license.

⁴ Use with the HP Social Media Snapshot App and wireless / AirPrint / Google Print Plugin capable InkJet printers.

⁵ ** For use with HP Sprocket Photo Printer and HP Sprocket Photo Printer 2-in-1 only.

⁶ *** Available only in Spain and Italy.

⁷ **** New DeskJet Ink Advantage printers available in new Zone C (CISMEA countries plus selected CEE/MENA countries that so far were part of EU+).

⁸ ***** Printers only available in new Zone 2.1 countries (EU+ countries excluding all CEE & MENA countries).

hp.com/go/learnaboutsupplies