

PowerEdge T640

Left External Fan Installation Guide

NOTE: Install the left external fan when the second General Purpose Graphics Processing Unit (GPGPU) is installed in the server.



