


# Quick start guide

- 1 Connectivity
- 2 Installation
- 3 Ergonomic Adjustments



Display design may differ from that illustrated



## 1 Connectivity

**A Monitor Connections**

- 1 DVI-D input
- 2 VGA input
- 3 AC power input
- 4 Kensington anti-theft lock
- 5 USB upstream

**B VGA**      **DVI**

For best performance, use your DVI input and ensure that your display settings are set at 1680 x 1050 @60Hz

**C Power**      **D USB**

## 2 Installation

**A Base install to Monitor**

Do not release the pin before the base stand is firmly fixed to the base column

Place the monitor face down on a smooth surface taking care to avoid scratching or damaging the screen.

**B Attach stand**

Hold the monitor base with both hands and firmly fix the base stand into four-pronged base attachments

Fastening base stand with the monitor

**Warning**

Yes      Insert the pin before lifting Monitor

No      Base stand may eject without pin

Please follow the instruction on the above illustrations, before lifting your monitor. Not following the recommended way may cause injury

Using two hands to lift your monitor is strongly recommended

## 3 Ergonomic Adjustments

**A Tilt**      **B Swivel**

**C Height adjustment**

130mm

**D Portrait display**

**E Quick reference for control buttons**

- 1 To switch monitor's power on and off
- 2 To access OSD menu
- 3 To adjust OSD menu
- 4 To adjust brightness of the display
- 5 To adjust OSD menu
- 6 AUTO Automatically adjust the horizontal position, vertical position, phase and clock settings

## What's in the box

Monitor      base stand

Quick Start Guide      EDPU CD

Power cord      VGA cable      DVI cable

USB cable

www.philips.com

© 2006 Koninklijke Philips Electronics N.V. All rights reserved.

Trademarks are property of Koninklijke Philips Electronics N.V. or their respective owners.


Trademarks are subject to change without notice.

Need help?      User manual      See the digital      Online help: www.philips.com

H7200WBQ3

# Quick start guide

Guide de démarrage rapide / Guía rápida / Kurzanleitung / Guida rapida / 快速入门指南 / 快速入门指南



## 1 Connectivité / Conectividad / Verbindungsfähigkeit / Connettività / 连接性 / 連接

**A Connexions du moniteur / Conexiones de monitor / Monitoranschlüsse / Conessioni del monitor / 监视器连接 / 显示器连接**

- 1 Entrée DVI-D
- 2 Entrée VGA
- 3 Entrée alimentation CA
- 4 Verrouillage anti-vol Kensington
- 5 Port USB en amont

**B VGA**      **DVI**

Pour les performances optimales, utilisez votre entrée DVI et vérifiez que vos paramètres d'affichage sont réglés sur 1680x1050@60Hz

**C Power**      **D USB**

## 2 Installation / Instalación / Installation / Installazione / 安裝 / 安裝

**A Pour installer la base / Per installare la base / Um den Monitorfuß zu montieren / Para instalar la base / 如何安装底座 / 安装底座步骤**

Do not release the pin before the base stand is firmly fixed to the base column

Place the monitor face down on a smooth surface taking care to avoid scratching or damaging the screen.

**B fixer le support / conectar soporte / Ständer anbringen / attacco supporto / 连接支架 / 連接架**

Hold the monitor base with both hands and firmly fix the base stand into four-pronged base attachments

Fastening base stand with the monitor

**AVERTISSEMENT / ADVERTENCIA / WARNUNG / AVVERTENZA / 小心 / 注意**

Yes      Insert the pin before lifting the monitor

No      Base stand may eject without pin

Please follow the instructions on the above illustrations, before lifting your monitor. Not following the recommended way may cause injury

Using two hands to lift your monitor is strongly recommended

## 3 Réglages ergonomiques / Ajustes ergonómicos / Ergonomische Einstellmöglichkeiten / Regolazioni ergonomiche / 人体工学调整 / 人體工學調整

**A Réglage de l'inclinaison / Inclinação / control / Kurzreferenz für Bedientasten / Referimenti rapidi per i tasti di controllo / 控制按钮简介 / 可快速参考控制按钮**

**B Affichage format portrait / Posición vertical / Hochformatdarstellung / Display verticalezza / 垂直显示 / 垂直显示**

**C Réglage en hauteur / Regulación de altura / Höheneinstellung / Regolazione altezza / 高度调整 / 高度调整**

**D Référence rapide pour les boutons de contrôle / Guía Rápida para los botones de control / Kurzreferenz für Bedientasten / Referimenti rapidi per i tasti di controllo / 控制按钮简介 / 可快速参考控制按钮**

- 1 Mise sous tension (ON) et hors tension (OFF) du moniteur
- 2 Accès au menu OSD
- 3 Réglage de la luminosité de l'écran
- 4 Réglage de la luminosité de l'écran
- 5 Réglage de la luminosité de l'écran
- 6 Réglage automatique de la position horizontale, de la position verticale, de la phase et de l'horloge

## Contenu de la boîte / Contenido del embalaje / Lieferumfang / Contenuto della confezione / 包装盒内的物品清单 / 包装盒内物品清单

Monitor      Support de base      Guide de démarrage rapide

Manuel utilisateur      Support de base      Kurzanleitung

Manuel de l'utilisateur      Support de base      Guida rapida

Manual de usuario      Support de base      Kurzanleitung

Manual de usuario      Support de base      Guida rapida

Manual de usuario      Support de base      Kurzanleitung

Manual de usuario      Support de base      Guida rapida

**Besoin d'aide? / Necesita ayuda? / Benötigen Sie Hilfe? / Benutzerhandbuch**

Manuel utilisateur / Manual de l'utilisateur / Manual de usuario / Manual de usuario

Manuel de l'utilisateur / Manual de l'utilisateur / Manual de usuario / Manual de usuario

Manuel de l'utilisateur / Manual de l'utilisateur / Manual de usuario / Manual de usuario

Manuel de l'utilisateur / Manual de l'utilisateur / Manual de usuario / Manual de usuario