


58.812

58.813

58.912

58.913








v1.0


Installation manual/Installatie handleiding
Installations-handbuch/Manuel d'installation
Manuale d'installazione/Manual de instalación
Copyright © 2018 – Dataflex International BV









T +31 180 515444
F +31 180 518540
info@dataflex-int.com
www.dataflex-int.com


Parts/Onderdelen/Teile/Pièces/Parti/Partes





 1x	 1x	 1x	 1x	 1x	 1x	 1x	 1x	 1x
 1x	 1x	 1x	 1x	 1x	 1x	 EUR/UK 1x	 1x	 6 mm 1x
 5 mm 1x	 2 mm 1x							

Required tools/Benodigd gereedschap/Benötigtes Werkzeug/Outils requis/Strumenti necessari/Herramientas necesarias









No rights can be derived from this publication/
Aan deze uitgave kunnen geen rechten worden
ontleend/Aus dieser Ausgabe können keine
Rechte abgeleitet werden/Aucun droit ne peut
découler de cette publication/Dal presente
documento non deriva alcun diritto/Del
contenido de esta publicación no podrá
derivarse ningún derecho