





Quick Start Guide

Version 1.0.0



Packing List



Device*1



QSG*1



Installation Position Map*1



Power Adapter*1





Screw Package*1




Waterproof Connector *1

Product Appearance



Lower Cover



Note:
To reset, long press for 10 seconds till the light is off, to enable WPS, just press the button.

The following table shows more information about status of indicator light

Indicator Light Status	Device Status
Red light stably on	Booting
Green light slow flashing	Booting completed, await Wi-Fi config, enter smart config status;
Green light quick flashing	WPS connecting (The device is trying to connect to Wi-Fi via WPS).
Green light stably on	Wi-Fi connection succeeded, operate normally.
Red and green lights flash alternately	Device upgrade
Red light slow flashing	Network disconnection
Red light quick flashing	Device fail to boot up; SD card does not work



Disclaimer

- This quick start guide is for reference only. Minor difference might be found in user interface.
- All the design and software here are subject to change without prior written notice.
- All trademarks and registered trademarks mentioned are the properties of their respective owners.
- Please visit our website or contact your local service engineer for more information.
- If there is any uncertainty or controversy, please refer to our final explanation.

Operation by Lechange App

Step 1

Power on your camera with power adapter.

Step 2

Connect your smartphone to your Wi-Fi network, scan "Lechange" QR on the packing box, download and install Lechange App.



Step 3

Run Lechange App, and register account for first use.

Step 4

Follow the steps below to add your camera.


Note:

- If you have more cameras, please follow step 4 to add them one by one.
- If you want to change the Wi-Fi signal, please reset the camera to factory default and repeat step 4 to add the camera.

Device Installation

Note:

Please make sure the mounting surface can sustain at least 3X weight of the camera and the bracket.




Step1 Dig holes on the installation surface (wall or ceiling).

Step2 Open accessories bag, take out expansion bolt and insert it into the hole you just dug.

Step3 Open accessories bag, take out self-tapping screws. Tighten the screws to fix the device on the installation surface (wall or ceiling).

Step4 Connect external wiring of the device properly.



Step1 Use screwdriver to loosen adjusting screw.

Step2 Adjust the device in all possible directions, and set its monitoring direction according to the requirements.

Step3 Use screwdriver to tighten the adjusting screws firmly.