




ICY BOX®

Quick installation guide IB-HUB1425-C3

USB 3.0 Type-C™ USB HUB with 4 USB ports

Product overview / Produktübersicht



EN

1. USB 3.0 Type-C™ interface to host computer
2. 4 x USB 3.0 Type-A interface up to 5 Gbit/s

DE

1. USB 3.0 Type-C™ Anschluss zum Hostcomputer
2. 4 x USB 3.0 Type-A Anschluss bis zu 5 Gbit/s



ICY BOX®

Safety information

Please read carefully the following information to prevent injuries, damage to material and device as well as data loss:

Warning levels

Signal words and safety codes indicate the warning level and provide immediate information in terms of the probability of occurrence as well as the type and severity of the consequences if the measures to prevent hazards are not complied with.



Warns of a **directly** hazardous situation causing **death or serious injury**.



Warns of a **potentially** hazardous situation that **may** cause death or serious injury.



Warns of a **potentially** hazardous situation that **may** cause minor injury.



Warns of a **potential** situation that **may** cause material or environmental damage and disrupt operative processes.

1. Risk of electrical shock



Contact with parts conducting electricity

Risk of death by electrical shock

- Read the operating instructions prior to use
- Make sure the device has been de-energised prior to working on it
- Do not remove contact protection panels
- Avoid contact with conducting parts
- Do not bring plug contacts in contact with pointed and metal objects
- Use in intended environments only
- Operate the device using a power unit meeting the specifications of the type plate only!
- Keep the device/power unit away from humidity, liquid, vapour and dust
- Do not modify the device
- Do not connect the device during thunderstorms
- Approach specialist retailers if you require repairs

2. Hazards during assembly (if intended)



Sharp components

Potential injuries to fingers or hands during assembly (if intended)

- Read the operating instructions prior to assembly
- Avoid coming into contact with sharp edges or pointed components
- Do not force components together
- Use suitable tools
- Use potentially enclosed accessories and tools only

3. Hazards caused by a development of heat



Insufficient device/power unit ventilation

Overheating and failure of the device/power unit

- Prevent externally heating up components and ensure an exchange of air
- Do not cover the fan outlet and passive cooling elements
- Avoid direct sunlight on the device/power unit
- Guarantee sufficient ambient air for the device/power unit
- Do not place objects on the device/power unit



ICY BOX®

Safety information

4. Hazards caused by very small parts and packaging



WARNING

Risk of suffocation

Risk of death by suffocation or swallowing

- Keep small parts and accessories away from children
- Store/dispose of plastic bags and packaging in an area that is inaccessible to children
- Do not hand over small parts and packaging to children

5. Potential data loss

IMPORTANT

Data lost during commissioning

Potentially irreversible data loss

- Always comply with the information in the operating instructions/quick installation guide
- Exclusively use the product once the specifications have been met
- Back up data prior to commissioning
- Back up data prior to connecting new hardware
- Use accessories enclosed with the product

6. Cleaning the device

IMPORTANT

Harmful cleaning agents

Scratches, discolouration, damage caused by moisture or short circuit in the device

- Disconnect the device prior to cleaning
- Aggressive or intense cleaning agents and solvents are unsuitable
- Make sure there is no residual moisture after cleaning
- We recommend cleaning devices using a dry, anti-static cloth

7. Disposing of the device

IMPORTANT

Environmental pollution, unsuitable for recycling

Potential environmental pollution caused by components, recycling circle interrupted



This icon on product and packaging indicates that this product must not be disposed of as part of domestic waste. In compliance with the Waste Electrical and Electronic Equipment Directive (**WEEE**) this electrical device and potentially included batteries must not be disposed of in conventional, domestic waste or **recycling waste**. If you would like to dispose of this product and potentially included batteries, please return it to the retailer or your local waste disposal and recycling point.

If you have any questions, please do not hesitate to contact our support at support@raidsonic.de or visit our website at www.raidsonic.de.



ICY BOX®

Sicherheitshinweise

Zur Vermeidung körperlicher Schäden, sowie von Sach-, Geräteschäden und Datenverlust beachten Sie bitte folgende Hinweise:

Warnstufen

Signalwort und Sicherheitszeichen kennzeichnen die Warnstufe und geben einen sofortigen Hinweis auf a)Wahrscheinlichkeit, Art und Schwere der Folgen, wenn die Maßnahmen zur Vermeidung der Gefahr nicht befolgt werden.



GEFAHR

warnet vor einer **unmittelbar** gefährlichen Situation, die zum Tod oder zu schweren Verletzungen führen **wird**.



WARNUNG

warnet vor einer **möglicherweise** gefährlichen Situation, die zum Tod oder zu schweren Verletzungen führen **kann**.



VORSICHT

warnet vor einer **möglicherweise** gefährlichen Situation, die zu leichten Verletzungen führen **kann**.



ACHTUNG

warnet vor einer **möglichen** Situation, die zu Sach- und Umweltschäden führen und den Betriebsablauf stören **kann**.

1. Gefahren durch elektrische Spannung



WARNUNG

Kontakt mit elektrisch leitenden Teilen

Lebensgefahr durch Stromschlag

- vor Benutzung Betriebsanleitung lesen
- vor Arbeiten am Gerät, Spannungsfreiheit sicherstellen
- Kontaktschutzblenden nicht entfernen
- Kontakt mit Spannungsführenden Komponenten vermeiden.
- Steckkontakte nicht mit spitzen und metallischen Gegenständen berühren
- Verwendung nur in dafür vorgesehenen Umgebungen
- Gerät ausschließlich mit Typenschildkonformen Netzteil betreiben!
- Gerät/Netzteil fern von Feuchtigkeit, Flüssigkeit, Dampf und Staub halten
- Eigenständige Modifikationen sind unzulässig
- Gerät nicht während eines Gewitters anschließen
- Geben Sie Ihr Gerät im Reparaturfall in den Fachhandel

2. Gefahren während Montage (wenn vorgesehen)



VORSICHT

Scharfkantige Bauteile

Finger- oder Handverletzungen bei Zusammenbau (wenn vorgesehen) möglich

- vor Montage, Betriebsanleitung lesen
- Kontakt mit scharfen Kanten oder spitzen Bauteilen vermeiden
- Bauteile nicht mit Gewalt zusammensetzen
- geeignetes Werkzeug verwenden
- nur gegebenenfalls mitgeliefertes Zubehör und Werkzeug verwenden

3. Gefahren durch Wärmeentwicklung



ACHTUNG

Mangelhafte Belüftung des Geräts/Netzteils

Überhitzung und Ausfall des Geräts/Netzteils

- externe Erwärmung vermeiden und Luftaustausch zulassen
- Lüfter-Auslass und passive Kühlkörper freihalten
- direkte Sonneneinstrahlung auf Gerät/Netzteil vermeiden
- ausreichend Umgebungsluft für Gerät/Netzteil sicherstellen



ICy BOX®

Sicherheitshinweise

- keine Gegenstände auf dem Gerät/Netzteil abstellen

4. Gefahren durch Kleinstteile und Verpackung



WARNUNG

Ersticken Gefahr

Lebensgefahr durch Erstickten oder Verschlucken

- Kleinteile, Zubehör für Kinder unzugänglich verwahren
- Plastiktüten und Verpackung für Kinder unzugänglich verwahren/entsorgen
- Kleinteile und Verpackungen nicht in Kinderhände geben

5. Möglicher Datenverlust

ACHTUNG

Datenverlust bei Inbetriebnahme

Unwiederbringlicher Datenverlust möglich

- Unbedingt Hinweise in der Bedienungsanleitung/Schnellinstallationsanleitung beachten
- Produkt nur verwenden, wenn Spezifikationen erfüllt sind
- Datensicherung vor Inbetriebnahme durchführen
- Datensicherung vor Anschluss neuer Hardware durchführen
- dem Produkt beiliegendes Zubehör verwenden

6. Reinigung des Gerätes

ACHTUNG

Schädigende Reinigungsmittel

Kratzer, Farbveränderungen, Feuchteschäden oder Kurzschluss am Gerät

- vor Reinigung, das Gerät außer Betrieb nehmen
- aggressive bzw. scharfe Reinigungs- und Lösungsmittel sind ungeeignet
- nach der Reinigung sicherstellen, dass keine Restfeuchtigkeit vorhanden ist
- Reinigung der Geräte am besten mit trockenem Antistatiktuch durchführen

7. Entsorgung des Gerätes

ACHTUNG

Umweltverschmutzung, Wiederverwertung nicht möglich

Mögliche Umweltbelastung durch Bestandteile, Recyclingkreislauf unterbrochen



Dieses auf dem Produkt und der Verpackung angebrachte Symbol zeigt an, dass dieses Produkt nicht mit dem Hausmüll entsorgt werden darf. In Übereinstimmung mit der Richtlinie über Elektro- und Elektronik-Altgeräte (**WEEE**) darf dieses Elektrogerät und ggf. enthaltene Batterien nicht im normalen Hausmüll oder dem **Gelben Sack** entsorgt werden. Wenn Sie dieses Produkt und ggf. enthaltene Batterien entsorgen möchten, bringen Sie diese bitte zur Verkaufsstelle zurück oder zum Recycling-Sammelpunkt Ihrer Gemeinde.

Bei Fragen kontaktieren Sie gerne unseren Support unter support@raidsonic.de oder besuchen Sie unsere Internetseite www.raidsonic.de.

**ICY BOX®**

Quick installation guide IB-HUB1425-C3

Important product information

Dear customer,
please note the following information about the compatibility of USB Type-C™ hubs and adapters, including this device!

- Your host computer must have a USB Type C™ interface.
- The IB-HUB1425-C3 also works with computers and notebooks with USB 3.0/2.0/1.1 Type-A interfaces if the appropriate adapter is available.
- The hub also works on devices with the USB 3.1 (Gen2) and Thunderbolt 3 interface with the transfer rate of 5 Gbit/s specified by USB 3.0.
- The Type-C™ interface can be connected with USB 2.0 standard in some notebooks and computers. The hub only supplies the full speed of 5 Gbit/s to USB 3.0 Type-C™ interfaces.
- The following operating systems are supported: Windows®, macOS®

Packing content:

1x IB-HUB1425-C3, 1x quick installation guide

Description:

The IB-HUB1425-C3 is a four port USB 3.0 hub that can be easily connected easily to a USB 3.0 Type-C™ port on a laptop or computer. The hub is light, compact and in an elegant design. The integrated USB 3.0 cable allows connection without having to carry additional cables around.

Key features:

- USB Type-C™ hub with four additional ports
- 4 x USB 3.0 Type-A with a transfer rate up to 5 Gbit/s
- USB 3.0 downwards compatible to USB 2.0
- Housing made of high-grade aluminium and plastic compound
- Integrated USB cable - length 20 cm



ICY BOX®

Quick installation guide IB-HUB1425-C3

Wichtige Produktinformationen

Sehr geehrter Kunde,

Nehmen Sie bitte folgende Informationen zur Kompatibilität von USB Type-C™ Hubs und Adaptern, inklusive diesem Gerät, zur Kenntnis!

- Ihr Hostcomputer muss über eine USB Type-C™ Schnittstelle verfügen.
- Die IB-HUB1425-C3 arbeitet auch mit Notebooks und Computern mit USB 3.0/2.0/1.1 Type-A Schnittstellen sofern der passende Adapter vorhanden ist.
- Der Hub arbeitet auch an Geräten mit der USB 3.1 (Gen2) und Thunderbolt™ 3 Schnittstelle mit der von USB 3.0 angegebenen Transferrate von 5 Gbit/s.
- Die Type-C™ Schnittstelle kann in einigen Notebooks und Computern mit USB 2.0 angebunden sein. Der Hub liefert nur an USB 3.0 Type-C™ die volle Geschwindigkeit von 5 Gbit/s.
- Folgende Betriebssysteme werden grundsätzlich unterstützt: Windows®, macOS®

Verpackungsinhalt:

1x IB-HUB1425-C3, 1x Schnellinstallationsanleitung

Beschreibung:


Der IB-HUB1425-C3 ist ein vierfach USB 3.0 Hub, der einfach über einen USB 3.0 Type-C™ Anschluss am Notebook oder Computer angeschlossen werden kann. Der Hub ist leicht, kompakt und im eleganten Design. Das integrierte USB 3.0 Kabel erlaubt das Anschließen, ohne weitere Kabel mit sich herumtragen zu müssen.

Hauptmerkmale

- USB Type-C™ Hub mit vier weiteren Anschlüssen
- 4x USB 3.0 Type-A mit einer Übertragungsrate von bis zu 5 Gbit/s
- USB 3.0 abwärtskompatibel zu USB 2.0
- Gehäuse aus hochwertigem Aluminium und Kunststoff
- Integriertes USB Kabel - Länge 20 cm

Quick installation guide IB-HUB1425-C3

Usage / Verwendung



1. Plug the IB-HUB1425-C3 into the Type-C™ port of your host computer.
1. Stecken Sie den IB-HUB1425-C3 in den Type-C™ Anschluss Ihres Hostcomputers.
2. When the IB-HUB1425-C3 has been plugged correctly the LED will turn on blue!
2. Wurde die IB-HUB1425-C3 richtig eingesteckt, leuchtet die LED blau auf.
3. Connect your USB Type-C™ and Type-A devices to the appropriate ports.
3. Verbinden Sie Ihre USB Type-C™ und Type-A Geräte mit den entsprechenden Anschlüssen.



ICy BOX®



© Copyright 2018 by RaidSonic Technology GmbH. All Rights Reserved

Apple and macOS, MAC, iTunes and Macintosh are registered trademarks of Apple Computer Inc. Microsoft, Windows and the Windows logo are registered trademarks of Microsoft Corporation. The information contained in this manual is believed to be accurate and reliable. RaidSonic Technology GmbH assumes no responsibility for any errors contained in this manual. RaidSonic Technology GmbH reserves the right to make changes in the specifications and/or design of the above mentioned product without prior notice. The diagrams contained in this manual may also not fully represent the product that you are using and are there for illustration purposes only. RaidSonic Technology GmbH assumes no responsibility for any differences between the product mentioned in this manual and the product you may have.