


Installation Guide

Smart-UPS SMTL750RM2UC and SMTL1000RM2UC with Lithium-ion Batteries and APCTM SmartConnect


Inventory




Operation Manual
Manuel d'utilisation
Manual de operaciones

www.apc.com/wp/?um=350


UPS Installation



APCTM SmartConnect Installation



Display Interface



- | | |
|-----------------------|--------------------------------|
| 1 UPS ON/OFF | 6 Multi-lingual display screen |
| 2 Online LED | 7 ESCAPE |
| 3 On battery LED | 8 ENTER |
| 4 Error detected LED | 9 UP/DOWN Selection arrows |
| 5 Replace battery LED | |

SmartConnect.apc.com

- Firmware update notifications
- Power event notifications
- Advanced support



By connecting this product to the Internet using APC SmartConnect port, you are agreeing to APC SmartConnect Terms of Use, as found at smartconnect.apc.com

Schneider Electric Data Privacy Policy can also be found at smartconnect.apc.com

En connectant ce produit à l'Internet en utilisant le port du SmartConnect d'APC, vous acceptez les conditions d'utilisation de SmartConnect d'APC, telles que décrites sur le site smartconnect.apc.com

La politique de Schneider sur la confidentialité des données électriques est également décrite sur le site smartconnect.apc.com

Al conectar este producto a Internet utilizando el puerto APC SmartConnect, usted acepta los Términos de uso de APC SmartConnect, que se encuentran en smartconnect.apc.com

La Política de Privacidad de Datos de Schneider Electric también se puede encontrar en smartconnect.apc.com