

# GEIST™ TEMPERATURE SENSOR



## Quick Installation Guide

### Part Number:

SRT 1.25/4/10

### Description

The SRT sensor probe is used to monitor temperature in critical environments.


**NOTE:** The SRT sensor and cable assembly can span a total cable distance up to 600 ft from the Geist environmental monitoring device.

**NOTE:** Three sensor sizes are available. The standard temperature probe measures 1.25 inches (3.18 cm) in length. The 4-inch (10.16 cm) and 10-inch (25.4 cm) probe options are available for customers wanting to submerge these probes in water or glycol for liquid temperature monitoring.


### Installation

1. Mount the temperature sensor anywhere in the data center with zip ties or Velcro tape.
2. Plug the uplink cable into the sensor port (RJ12/ⓐ) of the Geist environmental monitoring device or rack PDU.

Once connected, the Geist environmental monitoring device automatically detects and identifies the sensor.



Typical Error Curve





**To contact Vertiv Technical Support: visit [www.VertivCo.com](http://www.VertivCo.com)**

© 2019 Vertiv Co. All rights reserved. Vertiv and the Vertiv logo are trademarks or registered trademarks of Vertiv Co. All other names and logos referred to are trade names, trademarks or registered trademarks of their respective owners. While every precaution has been taken to ensure accuracy and completeness herein, Vertiv Co. assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Specifications are subject to change without notice.

