

Product overview / Produktübersicht



EN

1. USB 2.0 Type-A interface to host computer or charger
2. USB 2.0 Type-C™ connection to smartphone

DE

1. USB 2.0 Type-A Schnittstelle zum Host Computer oder Ladegerät
2. USB 2.0 Type-C™ Anschluss zum Smartphone



© Copyright 2019 by RaidSonic Technology GmbH. All Rights Reserved

The information contained in this manual is believed to be accurate and reliable. RaidSonic Technology GmbH assumes no responsibility for any errors contained in this manual. RaidSonic Technology GmbH reserves the right to make changes in the specifications and/or design of the above mentioned product without prior notice. The diagrams contained in this manual may also not fully represent the product that you are using and are there for illustration purposes only. RaidSonic Technology GmbH assumes no responsibility for any differences between the product mentioned in this manual and the product you may have.



ICY BOX®



ICY BOX®



ICY BOX®

Quick installation guide IB-CB022EL-C

Important product information

Dear customer,

Please take note of the following information to the use of the cable:

- In dangerous situations, do not allow the cable lighting to distract you. Only use this cable if there is no danger to third parties.
- Not every smartphone has the ability to interrupt the charging current when the battery is fully charged and thus to stop the cable lighting. Please check the technical specifications of your device.

Packing content: 1x IB-CB022EL, 1x quick installation guide

USB 2.0 Type-A to Type-C™ electroluminescent cable

The solid material inside the cable is made to illuminate by applying an electric field. This results in a flowing spiral light pulse which makes the data transfer or charging process of your USB Type-C™ devices astonishing – without the loss of energy.

Key features:

- Synchronizes the floating light pulse to the power current
- Turns off light when fully charged
- Spirally illuminated cable, 85 cm length
- Data transfer rate with up to 480 Mbit/s, optimized for smartphone

Schnellinstallationsanleitung IB-CB022EL-C

Wichtige Produktinformationen

Sehr geehrter Kunde,

nehmen Sie bitte folgende Informationen zum Gebrauch des Kabels zur Kenntnis:

- Bitte lassen Sie sich in gefährlichen Situationen nicht von der Beleuchtung des Kabels ablenken. Nutzen Sie dieses Kabel nur dann, wenn eine Gefahr für Dritte ausgeschlossen ist.
- Nicht jedes Smartphone besitzt die Fähigkeit, den Ladestrom bei vollständig geladenem Akku zu unterbrechen und somit die Beleuchtung des Kabels zu beenden. Bitte prüfen Sie die technischen Spezifikationen Ihres Gerätes.

Verpackungsinhalt: 1x IB-CB022EL-C, 1x Schnellinstallationsanleitung

USB 2.0 Type-A to Type-C™ elektrolumineszentes Kabel

Das feste Material im Inneren des Kabels wird durch Anlegen eines elektrischen Feldes beleuchtet. Daraus resultiert ein fließender spiralförmiger Lichtimpuls, der den Datentransfer – oder Ladevorgang Ihrer USB-Geräte über Type-C™ ein wenig spannender macht - und das ohne Energieverlust.

Hauptmerkmale:

- Synchronisiert den Lichtimpuls mit dem Leistungsstrom
- Deaktiviert die Beleuchtung, wenn das Endgerät vollständig geladen ist
- Spiralförmig und fließend beleuchtetes Kabel, 85 cm Länge
- Datenübertragungsrate mit bis zu 480 Mbit/s, optimiert für Smartphones

Quick installation guide IB-CB022EL-C

USB 2.0 Type-A to Type-C™ electroluminescent cable

DE

USB 2.0 Type-A zu Type-C™ elektrolumineszentes Kabel

FR

Câble électroluminescent USB 2.0 Type-A vers Type-C™

ES

Cable electroluminiscente USB 2.0 Type-A a Type-C™

IT

Cavo elettroluminescente USB 2.0 Type-A a Type-C™

GR

Καλώδιο ηλεκτροφωταύγειας USB 2.0 Type-A to Type-C™

PL

USB 2.0 Type-A do Type-C™ Kabel elektroluminescencyjny

CZ

USB 2.0 Type-A až Type-C™ elektroluminescenční kabel

NL

USB 2.0 Type-A naar Type-C™ Elektroluminescente kabel

HU

USB 2.0 Type-A Type-C™ elektrolumineszcens kábelek

Sicherheitshinweise

Zur Vermeidung körperlicher Schäden, sowie von Sach-, Geräteschäden und Datenverlust beachten Sie bitte folgende Hinweise:

Warnstufen

Signalwort und Sicherheitszeichen kennzeichnen die Warnstufe und geben einen sofortigen Hinweis auf Wahrscheinlichkeit, Art und Schwere der Folgen, wenn die Maßnahmen zur Vermeidung der Gefahr nicht befolgt werden.

 **GEFAHR**

warnet vor einer **unmittelbar** gefährlichen Situation, die zum Tod oder zu schweren Verletzungen führen **wird**.

 **WARNUNG**

warnet vor einer **möglicherweise** gefährlichen Situation, die zum Tod oder zu schweren Verletzungen führen **kann**.

 **VORSICHT**

warnet vor einer **möglicherweise** gefährlichen Situation, die zu leichten Verletzungen führen **kann**.

 **ACHTUNG**

warnet vor einer **möglichen** Situation, die zu Sach- und Umweltschäden führen und den Betriebsablauf stören **kann**.

1. Gefahren durch elektrische Spannung

 **WARNUNG**

Kontakt mit elektrisch leitenden Teilen
Lebensgefahr durch Stromschlag

- vor Benutzung Betriebsanleitung lesen
- vor Arbeiten am Gerät, Spannungsfreiheit sicherstellen
- Kontaktschutzblenden nicht entfernen
- Kontakt mit Spannungsführenden Komponenten vermeiden.
- Steckkontakte nicht mit spitzen und metallischen Gegenständen berühren
- Verwendung nur in dafür vorgesehenen Umgebungen
- Gerät ausschließlich mit Typenschildkonformen Netzteil betreiben!
- Gerät/Netzteil fern von Feuchtigkeit, Flüssigkeit, Dampf und Staub halten
- Eigenständige Modifikationen sind unzulässig
- Gerät nicht während eines Gewitters anschließen
- Geben Sie Ihr Gerät im Reparaturfall in den Fachhandel

2. Gefahren während Montage (wenn vorgesehen)

 **VORSICHT**

Scharfkantige Bauteile
Finger- oder Handverletzungen bei Zusammenbau (wenn vorgesehen) möglich

- vor Montage, Betriebsanleitung lesen
- Kontakt mit scharfen Kanten oder spitzen Bauteilen vermeiden
- Bauteile nicht mit Gewalt zusammensetzen
- geeignetes Werkzeug verwenden
- nur gegebenenfalls mitgeliefertes Zubehör und Werkzeug verwenden

3. Gefahren durch Wärmeentwicklung

 **ACHTUNG**

Mangelhafte Belüftung des Geräts/Netzteils
Überhitzung und Ausfall des Geräts/Netzteils

- externe Erwärmung vermeiden und Luftaustausch zulassen
- Lüfter-Auslass und passive Kühlkörper freihalten
- direkte Sonneneinstrahlung auf Gerät/Netzteil vermeiden
- ausreichend Umgebungsluft für Gerät/Netzteil sicherstellen
- keine Gegenstände auf dem Gerät/Netzteil abstellen

4. Gefahren durch Kleinstteile und Verpackung

 **WARNUNG**

Erstickungsgefahr
Lebensgefahr durch Erstickten oder Verschlucken

- Kleinteile, Zubehör für Kinder unzugänglich verwahren
- Plastiktüten und Verpackung für Kinder unzugänglich verwahren/entsorgen
- Kleinteile und Verpackungen nicht in Kinderhände geben

5. Möglicher Datenverlust

 **ACHTUNG**

Datenverlust bei Inbetriebnahme
Unwiederbringlicher Datenverlust möglich

- Unbedingt Hinweise in der Bedienungsanleitung/Schnellinstallationsanleitung beachten
- Produkt nur verwenden, wenn Spezifikationen erfüllt sind
- Datensicherung vor Inbetriebnahme durchführen
- Datensicherung vor Anschluss neuer Hardware durchführen
- dem Produkt beiliegendes Zubehör verwenden

6. Reinigung des Gerätes

 **ACHTUNG**

Schädigende Reinigungsmittel
Kratzer, Farbveränderungen, Feuchteschäden oder Kurzschluss am Gerät

- vor Reinigung, das Gerät außer Betrieb nehmen
- aggressive bzw. scharfe Reinigungs- und Lösungsmittel sind ungeeignet
- nach der Reinigung sicherstellen, dass keine Restfeuchtigkeit vorhanden ist
- Reinigung der Geräte am besten mit trockenem Antistatiktuch durchführen

7. Entsorgung des Gerätes

Umweltverschmutzung, Wiederverwertung nicht möglich

 **ACHTUNG**

Mögliche Umweltbelastung durch Bestandteile, Recyclingkreislauf unterbrochen

Dieses auf dem Produkt und der Verpackung angebrachte Symbol zeigt an, dass dieses Produkt nicht mit dem Hausmüll entsorgt werden darf. In Übereinstimmung mit der Richtlinie über Elektro- und Elektronik-Altgeräte (WEEE) darf dieses Elektrogerät und ggf. enthaltene Batterien nicht im normalen Hausmüll oder dem **Gelben Sack** entsorgt werden. Wenn Sie dieses Produkt und ggf. enthaltene Batterien entsorgen möchten, bringen Sie diese bitte zur Verkaufsstelle zurück oder zum Recycling-Sammelpunkt Ihrer Gemeinde.



Bei Fragen kontaktieren Sie gerne unseren Support unter support@raidsonic.de oder besuchen Sie unsere Internetseite www.raidsonic.de.

Safety information

Please read carefully the following information to prevent injuries, damage to material and device as well as data loss:

Warning levels

Signal words and safety codes indicate the warning level and provide immediate information in terms of the probability of occurrence as well as the type and severity of the consequences if the measures to prevent hazards are not complied with.

 **DANGER**

Warns of a **directly** hazardous situation causing **death or serious injury**.

 **WARNING**

Warns of a **potentially** hazardous situation that **may** cause death or serious injury.

 **CAUTION**

Warns of a **potentially** hazardous situation that **may** cause minor injury.

 **IMPORTANT**

Warns of a **potential** situation that **may** cause material or environmental damage and disrupt operative processes.

1. Risk of electrical shock

 **WARNING**

Contact with parts conducting electricity
Risk of death by electrical shock

- Read the operating instructions prior to use
- Make sure the device has been de-energised prior to working on it
- Do not remove contact protection panels
- Avoid contact with conducting parts
- Do not bring plug contacts in contact with pointed and metal objects
- Use in intended environments only
- Operate the device using a power unit meeting the specifications of the type plate only!
- Keep the device/power unit away from humidity, liquid, vapour and dust
- Do not modify the device
- Do not connect the device during thunderstorms
- Approach specialist retailers if you require repairs

2. Hazards during assembly (if intended)

 **CAUTION**

Sharp components
Potential injuries to fingers or hands during assembly (if intended)

- Read the operating instructions prior to assembly
- Avoid coming into contact with sharp edges or pointed components
- Do not force components together
- Use suitable tools
- Use potentially enclosed accessories and tools only

3. Hazards caused by a development of heat

 **IMPORTANT**

Insufficient device/power unit ventilation
Overheating and failure of the device/power unit

- Prevent externally heating up components and ensure an exchange of air
- Do not cover the fan outlet and passive cooling elements
- Avoid direct sunlight on the device/power unit
- Guarantee sufficient ambient air for the device/power unit
- Do not place objects on the device/power unit

4. Hazards caused by very small parts and packaging

 **WARNING**

Risk of suffocation
Risk of death by suffocation or swallowing

- Keep small parts and accessories away from children
- Store/dispose of plastic bags and packaging in an area that is inaccessible to children
- Do not hand over small parts and packaging to children

5. Potential data loss

 **IMPORTANT**

Data lost during commissioning
Potentially irreversible data loss

- Always comply with the information in the operating instructions/quick installation guide
- Exclusively use the product once the specifications have been met
- Back up data prior to commissioning
- Back up data prior to connecting new hardware
- Use accessories enclosed with the product

6. Cleaning the device

 **IMPORTANT**

Harmful cleaning agents
Scratches, discolouration, damage caused by moisture or short circuit in the device

- Disconnect the device prior to cleaning
- Aggressive or intense cleaning agents and solvents are unsuitable
- Make sure there is no residual moisture after cleaning
- We recommend cleaning devices using a dry, anti-static cloth

7. Disposing of the device

Environmental pollution, unsuitable for recycling

 **IMPORTANT**

Potential environmental pollution caused by components, recycling circle interrupted



This icon on product and packaging indicates that this product must not be disposed of as part of domestic waste. In compliance with the Waste Electrical and Electronic Equipment Directive (WEEE) this electrical device and potentially included batteries must not be disposed of in conventional, domestic waste or **recycling waste**. If you would like to dispose of this product and potentially included batteries, please return it to the retailer or your local waste disposal and recycling point.

If you have any questions, please do not hesitate to contact our support at support@raidsonic.de or visit our website at www.raidsonic.de.