

Philips
Rechargeable Stick
Accessory

Micro-fibre pads

XV1700/01



Shiny, cleaner floors with the power of water

Microfibre pads for optimal wetness control

Microfibre pads to effectively remove dirt and stains. Compatible with all Philips cordless stick vacuum cleaners with vacuum and mop system. Replace every 6 months for optimal performance.

Philips Original accessories

- 2 gentle microfibre pads for delicate floors
- 2 regular microfibre pads
- Replace every 6 months
- Washable and reusable pads

PHILIPS

Specifications


General specifications

- Suitable for: FC6404, FC6405, FC6407-FC6409,

FC6728(/01), FC6729, FC6901-FC6904, FC6908, XC8147, XC8149

Highlights

2 gentle microfibre pads



The soft microfibre material gently loosens, lifts and absorbs dust and dirt. Particularly designed to clean delicate surfaces, such as wooden surfaces. Removing dirt and stains effectively and thoroughly

2 regular microfibre pads



The microfibre material loosens, lifts and absorbs dust and dirt. Removing dirt and stains effectively and thoroughly.

Replace every 6 months



Replace every 6 months to maintain your appliance's optimal cleaning performance.

Washable and reusable pads

The microfibre pads are machine-washable and easy to attach and remove



Issue date 2023-02-22

Version: 2.2.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com