


PHILIPS

Lid for water
container

Intense coffeemaker

CP9074



Essential part of your coffee maker

Please check specs for compatible products

A water container and it's lid should be cleaned regularly. Whenever that's the case, you'll be happy not to miss your coffee moment by having an extra cover for your water container.

Ease of using Philips spare parts

- Easy renew your product with original Philips parts

Highlights

Easy renew of product parts

From time to time your product needs a facelift but it was never so easy like with Philips consumer replacement parts to renew your product. This all with guaranteed Philips quality.

Specifications

Suitable for:

Intense coffeemaker: HD7685/30, HD7685/90, HD7695/90, HD7696/90, HD7697/90

