


Philips
Lid for water
container

• Intense coffee maker

CP9074



Essential part of your coffee maker

Please check the specs for compatible products

The water container and its lid should be cleaned regularly. Whenever the lid needs cleaned, you'll be happy not to miss your coffee moment by having an extra cover for your water container.

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

PHILIPS

Lid for water container
Intense coffee maker

CP9074/01

Specifications

Highlights

Suitable for:

- Intense coffee maker: HD7685/30, HD7685/90,

HD7695/90, HD7696/90, HD7697/90

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.



Issue date 2024-02-28

Version: 6.6.1

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com