


# Pole / DuraTilt™ / MultiGrip™ Solutions

## Installation Guide




### Parts List



1 x Pole



1 x Flange Cover




1 x DuraTilt™



1 x MultiGrip™

### Fixing bag for pole




4 x self tapper screws



1 x 4mm Hex key

### Fixing bag for MultiGrip™



2 x (M4x10mm) screws




1 x 2,5mm Hex key

### Assembly note

For DuraTilt™, use M4x10mm TufLok screws, hexagonal recess.

Recommended torque:  
1,8 -- 2,6 Nm







### Standard Solutions


Pole + DuraTilt™ + MultiGrip™

DuraTilt™ + MultiGrip™


MultiGrip™




### Movement range




### Cable management




## 1 Drilling the mounting holes



## 2 Pole orientation




## 3 Screws and flange cover



## 4 Mounting DuraTilt™




Slide the DuraTilt™ module down the pole until fully located. Fully tighten the M6/6 screw using the 4mm hex key, until rotation is limited to 210°



## 5 Mounting MultiGrip™

Use the M4/10mm screws and the 2,5mm hex key to attach the MultiGrip™ plate to the DuraTilt™ module.



## 6 Mounting the payment terminal

