iDRAC9 with Lifecycle Controller Version 3.30.30.30

Attribute Registry

Notes, cautions, and warnings

NOTE: A NOTE indicates important information that helps you make better use of your product.

CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

© 2018 - 2019 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

2019 - 03

Rev. A00

Contents

1 iDRAC Property Database Group and Object Descriptions..... 49

2 iDRAC Attributes..... 50

iDRAC.ActiveDirectory..... 51

iDRAC.ActiveDirectory.AuthTimeout (Read or Write)..... 51

iDRAC.ActiveDirectory.CertValidationEnable (Read or Write)..... 51

iDRAC.ActiveDirectory.DCLookupByUserDomain (Read or Write)..... 52

iDRAC.ActiveDirectory.DCLookupDomainName (Read or Write)..... 52

iDRAC.ActiveDirectory.DCLookupEnable (Read or Write)..... 52

iDRAC.ActiveDirectory.DomainController1 (Read or Write)..... 52

iDRAC.ActiveDirectory.DomainController2 (Read or Write)..... 53

iDRAC.ActiveDirectory.DomainController3 (Read or Write)..... 53

iDRAC.ActiveDirectory.Enable (Read or Write)..... 53

iDRAC.ActiveDirectory.GCLookupEnable (Read or Write)..... 53

iDRAC.ActiveDirectory.GCRootDomain (Read or Write)..... 53

iDRAC.ActiveDirectory.GlobalCatalog1 (Read or Write)..... 54

iDRAC.ActiveDirectory.GlobalCatalog2 (Read or Write)..... 54

iDRAC.ActiveDirectory.GlobalCatalog3 (Read or Write)..... 54

iDRAC.ActiveDirectory.RacDomain (Read or Write)..... 54

iDRAC.ActiveDirectory.RacName (Read or Write)..... 54

iDRAC.ActiveDirectory.Schema (Read or Write)..... 55

iDRAC.ActiveDirectory.SSOEnable (Read or Write)..... 55

iDRAC.ADGroup..... 55

iDRAC.ADGroup.Domain (Read or Write)..... 55

iDRAC.ADGroup.Name (Read or Write)..... 55

iDRAC.ADGroup.Privilege (Read or Write)..... 56

iDRAC.ASRConfig..... 56

iDRAC.ASRConfig.Enable (Read or Write)..... 56

iDRAC.Autodiscovery..... 56

iDRAC.Autodiscovery.EnableIPChangeAnnounce (Read or Write)..... 56

iDRAC.Autodiscovery.EnableIPChangeAnnounceFromDHCP (Read or Write)..... 57

iDRAC.Autodiscovery.EnableIPChangeAnnounceFrommDNS (Read or Write)..... 57

iDRAC.Autodiscovery.EnableIPChangeAnnounceFromUnicastDNS (Read or Write)..... 57

iDRAC.Autodiscovery.UnsolicitedIPChangeAnnounceRate (Read or Write)..... 57

iDRAC.AutoOSLockGroup..... 58

iDRAC.AutoOSLockGroup.AutoOSLockState (Read or Write)..... 58

iDRAC.CurrentIPV4..... 58

iDRAC.CurrentIPv4.Address (Read Only)..... 58

iDRAC.CurrentIPv4.DHCPEnable (Read Only)..... 58

iDRAC.CurrentIPv4.DNS1 (Read Only)..... 59

iDRAC.CurrentIPv4.DNS2 (Read Only)..... 59

iDRAC.CurrentIPv4.DNSFromDHCP (Read Only)..... 59

iDRAC.CurrentIPv4.DupAddrDetected (Read Only)..... 59

iDRAC.CurrentIPv4.Enable (Read Only)..... 60

iDRAC.CurrentIPv4.Gateway (Read Only)....60
iDRAC.CurrentIPv4.Netmask (Read Only)....60
iDRAC.CurrentIPV6....60
iDRAC.CurrentIPv6.Address1 (Read Only)....60
iDRAC.CurrentIPv6.Address10 (Read Only)....61
iDRAC.CurrentIPv6.Address11 (Read Only)....61
iDRAC.CurrentIPv6.Address12 (Read Only)....61
iDRAC.CurrentIPv6.Address13 (Read Only)....61
iDRAC.CurrentIPv6.Address14 (Read Only)....61
iDRAC.CurrentIPv6.Address15 (Read Only)....62
iDRAC.CurrentIPv6.Address2 (Read Only)....62
iDRAC.CurrentIPv6.Address3 (Read Only)....62
iDRAC.CurrentIPv6.Address4 (Read Only)....62
iDRAC.CurrentIPv6.Address5 (Read Only)....62
iDRAC.CurrentIPv6.Address6 (Read Only)....63
iDRAC.CurrentIPv6.Address7 (Read Only)....63
iDRAC.CurrentIPv6.Address8 (Read Only)....63
iDRAC.CurrentIPv6.Address9 (Read Only)....63
iDRAC.CurrentIPv6.AutoConfig (Read Only)....64
iDRAC.CurrentIPv6.DNS1 (Read Only)....64
iDRAC.CurrentIPv6.DNS2 (Read Only)....64
iDRAC.CurrentIPv6.DNSFromDHCP6 (Read Only)....64
iDRAC.CurrentIPv6.DUID (Read Only)....64
iDRAC.CurrentIPv6.Enable (Read Only)....65
iDRAC.CurrentIPv6.Gateway (Read Only)....65
iDRAC.CurrentIPv6.IPV6NumOfExtAddress (Read Only)....65
iDRAC.CurrentIPv6.LinkLocalAddress (Read Only)....65
iDRAC.CurrentIPv6.PrefixLength (Read Only)....66
iDRAC.CurrentNIC....66
iDRAC.CurrentNIC.ActiveNIC (Read Only)....66
iDRAC.CurrentNIC.ActiveSharedLOM (Read Only)....66
iDRAC.CurrentNIC.AutoDetect (Read Only)....67
iDRAC.CurrentNIC.Autoneg (Read Only)....67
iDRAC.CurrentNIC.DedicatedNICScanTime (Read Only)....67
iDRAC.CurrentNIC.DNSDomainFromDHCP (Read Only)....68
iDRAC.CurrentNIC.DNSDomainName (Read Only)....68
iDRAC.CurrentNIC.DNSRacName (Read Only)....68
iDRAC.CurrentNIC.DNSRegister (Read Only)....68
iDRAC.CurrentNIC.Duplex (Read Only)....68
iDRAC.CurrentNIC.Enable (Read Only)....69
iDRAC.CurrentNIC.Failover (Read Only)....69
iDRAC.CurrentNIC.LinkStatus (Read Only)....69
iDRAC.CurrentNIC.MACAddress (Read Only)....69
iDRAC.CurrentNIC.MACAddress2 (Read Only)....70
iDRAC.CurrentNIC.MgmtIfaceName (Read Only)....70
iDRAC.CurrentNIC.MTU (Read Only)....70
iDRAC.CurrentNIC.NumberOfLOM (Read Only)....70
iDRAC.CurrentNIC.Selection (Read Only)....71
iDRAC.CurrentNIC.SharedNICScanTime (Read Only)....71
iDRAC.CurrentNIC.Speed (Read Only)....71

iDRAC.CurrentNIC.VLanEnable (Read Only)....71
iDRAC.CurrentNIC.VLanID (Read Only)....72
iDRAC.CurrentNIC.VLanPriority (Read Only)....72
iDRAC.CurrentNIC.VLanSetting (Read Only)....72
iDRAC.DCSCustom....72
iDRAC.DCSCustom.RRCCardPresent (Read or Write)....72
iDRAC.DCSCustom.WANCardPresent (Read or Write)....73
iDRAC.DefaultCredentialMitigationConfigGroup....73
iDRAC.DefaultCredentialMitigationConfigGroup.DefaultCredentialMitigation (Read or Write)....73
iDRAC.EmailAlert....73
iDRAC.EmailAlert.Address (Read or Write)....73
iDRAC.EmailAlert.CustomMsg (Read or Write)....74
iDRAC.EmailAlert.Enable (Read or Write)....74
iDRAC.GroupManager....74
iDRAC.GroupManager.GroupName (Read Only)....74
iDRAC.GroupManager.GroupUUID (Read Only)....74
iDRAC.GroupManager.Status (Read or Write)....75
iDRAC.GUISecurityPolicyMessage....75
iDRAC.GUI.SecurityPolicyMessage (Read or Write)....75
iDRAC.Info....75
iDRAC.Info.Build (Read Only)....75
iDRAC.Info.CPLDVersion (Read Only)....75
iDRAC.Info.Description (Read Only)....76
iDRAC.Info.HWRev (Read Only)....76
iDRAC.Info.IPMIVersion (Read Only)....76
iDRAC.Info.Name (Read Only)....76
iDRAC.Info.Product (Read Only)....77
iDRAC.Info.RollbackBuild (Read Only)....77
iDRAC.Info.RollbackVersion (Read Only)....77
iDRAC.Info.ServerGen (Read Only)....77
iDRAC.Info.Type (Read Only)....77
iDRAC.Info.Version (Read Only)....78
iDRAC.IntegratedDatacenter....78
iDRAC.IntegratedDatacenter.DiscoveryEnable (Read or Write)....78
iDRac.IOIDOpt....78
iDRAC.IOIDOpt.InitiatorPersistencePolicy (Read or Write)....79
iDRAC.IOIDOpt.IOIDOptEnable (Read or Write)....79
iDRAC.IOIDOpt.StorageTargetPersistencePolicy (Read or Write)....79
iDRAC.IOIDOpt.VirtualAddressPersistencePolicyAuxPwrd (Read or Write)....80
iDRAC.IOIDOpt.VirtualAddressPersistencePolicyNonAuxPwrd (Read or Write)....80
iDRAC.IPBlocking....80
iDRAC.IPBlocking.BlockEnable (Read or Write)....80
iDRAC.IPBlocking.FailCount (Read or Write)....81
iDRAC.IPBlocking.FailWindow (Read or Write)....81
iDRAC.IPBlocking.PenaltyTime (Read or Write)....81
iDRAC.IPBlocking.RangeAddr (Read or Write)....81
iDRAC.IPBlocking.RangeEnable (Read or Write)....82
iDRAC.IPBlocking.RangeMask (Read or Write)....82
iDRAC.IPMILan....82
iDRAC.IPMILan.AlertEnable (Read or Write)....82

iDRAC.IPMILan.CommunityName (Read or Write)....82
iDRAC.IPMILan.Enable (Read or Write)....83
iDRAC.IPMILan.EncryptionKey (Read or Write)....83
iDRAC.IPMILan.PrivLimit (Read or Write)....83
iDRAC.IPMISerial....83
iDRAC.IPMISerial.BaudRate (Read or Write)....83
iDRAC.IPMISerial.ChanPrivLimit (Read or Write)....84
iDRAC.IPMISerial.ConnectionMode (Read or Write)....84
iDRAC.IPMISerial.DeleteControl (Read or Write)....84
iDRAC.IPMISerial.EchoControl (Read or Write)....84
iDRAC.IPMISerial.FlowControl (Read or Write)....85
iDRAC.IPMISerial.HandshakeControl (Read or Write)....85
iDRAC.IPMISerial.InputNewLineSeq (Read or Write)....85
iDRAC.IPMISerial.LineEdit (Read or Write)....85
iDRAC.IPMISerial.NewLineSeq (Read or Write)....86
iDRAC.IPMISOL....86
iDRAC.IPMISOL.AccumulateInterval (Read or Write)....86
iDRAC.IPMISOL.BaudRate (Read or Write)....86
iDRAC.IPMISOL.Enable (Read or Write)....86
iDRAC.IPMISOL.MinPrivilege (Read or Write)....87
iDRAC.IPMISOL.SendThreshold (Read or Write)....87
iDRac.IPv4....87
iDRAC.IPv4.Address (Read or Write)....87
iDRAC.IPv4.DHCPEnable (Read or Write)....87
iDRAC.IPv4.DNS1 (Read or Write)....88
iDRAC.IPv4.DNS2 (Read or Write)....88
iDRAC.IPv4.DNSFromDHCP (Read or Write)....88
iDRAC.IPv4.Enable (Read or Write)....88
iDRAC.IPv4.Gateway (Read or Write)....89
iDRAC.IPv4.Netmask (Read or Write)....89
iDRAC.IPV4Static....89
iDRAC.IPv4Static.Address (Read or Write)....89
iDRAC.IPv4Static.DNS1 (Read or Write)....89
iDRAC.IPv4Static.DNS2 (Read or Write)....90
iDRAC.IPv4Static.DNSFromDHCP (Read or Write)....90
iDRAC.IPv4Static.Gateway (Read or Write)....90
iDRAC.IPV6....90
iDRAC.IPv6.Address1 (Read or Write)....90
iDRAC.IPv6.Address10 (Read Only)....91
iDRAC.IPv6.Address11 (Read Only)....91
iDRAC.IPv6.Address12 (Read Only)....91
iDRAC.IPv6.Address13 (Read Only)....91
iDRAC.IPv6.Address14 (Read Only)....91
iDRAC.IPv6.Address15 (Read Only)....92
iDRAC.IPv6.Address2 (Read Only)....92
iDRAC.IPv6.Address3 (Read Only)....92
iDRAC.IPv6.Address4 (Read Only)....92
iDRAC.IPv6.Address5 (Read Only)....92
iDRAC.IPv6.Address6 (Read Only)....93
iDRAC.IPv6.Address7 (Read Only)....93

iDRAC.IPv6.Address8 (Read Only)... 93
iDRAC.IPv6.Address9 (Read Only)... 93
iDRAC.IPv6.AddressState (Read Only)... 94
iDRAC.IPv6.AutoConfig (Read or Write)... 94
iDRAC.IPv6.DNS1 (Read or Write)... 94
iDRAC.IPv6.DNS2 (Read or Write)... 94
iDRAC.IPv6.DNSFromDHCP6 (Read or Write)... 95
iDRAC.IPv6.DUID (Read Only)... 95
iDRAC.IPv6.Enable (Read or Write)... 95
iDRAC.IPv6.Gateway (Read or Write)... 95
iDRAC.IPv6.LinkLocalAddress (Read Only)... 95
iDRAC.IPv6.PrefixLength (Read or Write)... 96
iDRAC.IPv6Static... 96
iDRAC.IPv6Static.Address1 (Read or Write)... 96
iDRAC.IPv6Static.DNS1 (Read or Write)... 96
iDRAC.IPv6Static.DNS2 (Read or Write)... 96
iDRAC.IPv6Static.DNSFromDHCP6 (Read or Write)... 97
iDRAC.IPv6Static.Gateway (Read or Write)... 97
iDRAC.IPv6Static.PrefixLength (Read or Write)... 97
iDRAC.IPv6URL... 97
iDRAC.IPv6URL.URL (Read Only)... 97
iDRAC.LDAP... 98
iDRAC.LDAP.BaseDN (Read or Write)... 98
iDRAC.LDAP.BindDN (Read or Write)... 98
iDRAC.LDAP.BindPassword (Read or Write)... 98
iDRAC.LDAP.CertValidationEnable (Read or Write)... 98
iDRAC.LDAP.Enable (Read or Write)... 99
iDRAC.LDAP.GroupAttribute (Read or Write)... 99
iDRAC.LDAP.GroupAttributeIsDN (Read or Write)... 99
iDRAC.LDAP.Port (Read or Write)... 99
iDRAC.LDAP.SearchFilter (Read or Write)... 99
iDRAC.LDAP.Server (Read or Write)... 100
iDRAC.LDAP.UserAttribute (Read or Write)... 100
iDRAC.LDAPRoleGroup... 100
iDRAC.LDAPRoleGroup.DN (Read or Write)... 100
iDRAC.LDAPRoleGroup.Privilege (Read or Write)... 100
iDRAC.LocalSecurity... 101
iDRAC.LocalSecurity.KCSAccess (Read or Write)... 101
iDRAC.LocalSecurity.LocalConfig (Read or Write)... 101
iDRAC.LocalSecurity.PrebootConfig (Read or Write)... 101
iDRAC.Lockdown... 101
iDRAC.Lockdown.SystemLockdown (Read or Write)... 101
iDRAC.Logging... 102
iDRAC.Logging.SELBufferType (Read or Write)... 102
iDRAC.Logging.SELOEMEventFilterEnable (Read or Write)... 102
iDRAC.MgmtNetworkInterface... 102
iDRAC.MgmtNetworkInterface.NicConfig (Read or Write)... 102
iDRAC.NIC... 103
iDRAC.NIC.AutoConfig (Read or Write)... 103
iDRAC.NIC.AutoConfigIPV6 (Read or Write)... 103

iDRAC.NIC.AutoDetect (Read or Write)....103
iDRAC.NIC.Autoneg (Read or Write)....103
iDRAC.NIC.DedicatedNICScanTime (Read or Write)....104
iDRAC.NIC.DiscoveryLLDP (Read or Write)....104
iDRAC.NIC.DNSDomainFromDHCP (Read or Write)....104
iDRAC.NIC.DNSDomainName (Read or Write)....104
iDRAC.NIC.DNSDomainNameFromDHCP (Read or Write)....105
iDRAC.NIC.DNSRacName (Read or Write)....105
iDRAC.NIC.DNSRegister (Read or Write)....105
iDRAC.NIC.DNSRegisterInterval (Read or Write)....105
iDRAC.NIC.Duplex (Read or Write)....106
iDRAC.NIC.Enable (Read or Write)....106
iDRAC.NIC.Failover (Read or Write)....106
iDRAC.NIC.MACAddress (Read Only)....106
iDRAC.NIC.MTU (Read or Write)....107
iDRAC.NIC.Selection (Read or Write)....107
iDRAC.NIC.SharedNICScanTime (Read or Write)....107
iDRAC.NIC.Speed (Read or Write)....107
iDRAC.NIC.SwitchConnection (Read Only)....108
iDRAC.NIC.SwitchPortConnection (Read Only)....108
iDRAC.NIC.TopologyLldp (Read or Write)....108
iDRAC.NIC.VLanEnable (Read or Write)....108
iDRAC.NIC.VLanID (Read or Write)....109
iDRAC.NIC.VLanPort (Read or Write)....109
iDRAC.NIC.VLanPriority (Read or Write)....109
iDRAC.NICStatic....109
iDRAC.NICStatic.DNSDomainFromDHCP (Read or Write)....109
iDRAC.NICStatic.DNSDomainName (Read or Write)....110
iDRAC.NTPConfigGroup....110
iDRAC.NTPConfigGroup.NTP1 (Read or Write)....110
iDRAC.NTPConfigGroup.NTP2 (Read or Write)....110
iDRAC.NTPConfigGroup.NTP3 (Read or Write)....110
iDRAC.NTPConfigGroup.NTPEnable (Read or Write)....110
iDRAC.NTPConfigGroup.NTPMaxDist (Read or Write)....111
iDRAC.OS-BMC....111
iDRAC.OS-BMC.AdminState (Read or Write)....111
iDRAC.OS-BMC.OsIpAddress (Read or Write)....111
iDRAC.OS-BMC.PTCapability (Read Only)....111
iDRAC.OS-BMC.PTMode (Read or Write)....112
iDRAC.OS-BMC.UsbNicIpAddress (Read or Write)....112
iDRAC.OS-BMC.UsbNicIpV6Address (Read Only)....112
iDRAC.Platformcapability....112
iDRAC.PlatformCapability.FrontPortUSBConfiguration (Read Only)....113
iDRAC.RACADM....113
iDRAC.Racadm.Enable (Read or Write)....113
iDRAC.Racadm.MaxSessions (Read Only)....113
iDRAC.Racadm.Timeout (Read or Write)....113
iDRAC.Redfish....114
iDRAC.Redfish.Enable (Read or Write)....114
iDRAC.RedfishEventing....114

iDRAC.RedfishEventing.DeliveryRetryAttempts (Read or Write)....114
iDRAC.RedfishEventing.DeliveryRetryIntervalInSeconds (Read or Write)....114
iDRAC.RedfishEventing.IgnoreCertificateErrors (Read or Write)....115
iDRAC.RemoteHosts....115
iDRAC.RemoteHosts.SenderEmail (Read or Write)....115
iDRAC.RemoteHosts.SMTPAuthentication (Read or Write)....115
iDRAC.RemoteHosts.SMTPPassword (Read or Write)....115
iDRAC.RemoteHosts.SMTPPort (Read or Write)....116
iDRAC.RemoteHosts.SMTPServerIPAddress (Read or Write)....116
iDRAC.RemoteHosts.SMTPUserName (Read or Write)....116
iDRAC.RFS....116
iDRAC.RFS.AttachMode (Read or Write)....116
iDRAC.RFS.Enable (Read or Write)....117
iDRAC.RFS.IgnoreCertWarning (Read or Write)....117
iDRAC.RFS.Image (Read or Write)....117
iDRAC.RFS.MediaAttachState (Read Only)....117
iDRAC.RFS.Password (Read or Write)....117
iDRAC.RFS.Status (Read or Write)....118
iDRAC.RFS.User (Read or Write)....118
iDRAC.RFS.WriteProtected (Read Only)....118
iDRAC.RSM....118
iDRAC.RSM.RSMCapability (Read Only)....118
iDRAC.RSM.RSMSetting (Read Only)....119
iDRAC.Security....119
iDRAC.Security.CsrCommonName (Read or Write)....119
iDRAC.Security.CsrCountryCode (Read or Write)....119
iDRAC.Security.CsrEmailAddr (Read or Write)....120
iDRAC.Security.CsrKeySize (Read or Write)....120
iDRAC.Security.CsrLocalityName (Read or Write)....120
iDRAC.Security.CsrOrganizationName (Read or Write)....120
iDRAC.Security.CsrOrganizationUnit (Read or Write)....120
iDRAC.Security.CsrStateName (Read or Write)....121
iDRAC.Security.CsrSubjectAltName (Read or Write)....121
iDRAC.Security.FIPSMode (Read or Write)....121
iDRAC.Serial....121
iDRAC.Serial.BaudRate (Read or Write)....121
iDRAC.Serial.Command (Read or Write)....122
iDRAC.Serial.Enable (Read or Write)....122
iDRAC.Serial.HistorySize (Read or Write)....122
iDRAC.Serial.IdleTimeout (Read or Write)....122
iDRAC.Serial.NoAuth (Read or Write)....123
iDRAC.SerialRedirection....123
iDRAC.SerialRedirection.Enable (Read or Write)....123
iDRAC.SerialRedirection.QuitKey (Read or Write)....123
iDRAC.ServerBoot....123
iDRAC.ServerBoot.BootOnce (Read or Write)....123
iDRAC.ServerBoot.FirstBootDevice (Read or Write)....124
iDRAC.ServiceModule....124
iDRAC.ServiceModule.HostSNMPAlert (Read or Write)....124
iDRAC.ServiceModule.HostSNMPGet (Read or Write)....124

iDRAC.ServiceModule.iDRACHardReset (Read or Write)....124
iDRAC.ServiceModule.iDRACSSOLauncher (Read or Write)....125
iDRAC.ServiceModule.LCLReplication (Read or Write)....125
iDRAC.ServiceModule.OMSAPresence (Read Only)....125
iDRAC.ServiceModule.OSInfo (Read or Write)....125
iDRAC.ServiceModule.ServiceModuleEnable (Read or Write)....126
iDRAC.ServiceModule.ServiceModuleState (Read Only)....126
iDRAC.ServiceModule.ServiceModuleVersion (Read Only)....126
iDRAC.ServiceModule.WatchdogRecoveryAction (Read or Write)....127
iDRAC.ServiceModule.WatchdogResetTime (Read or Write)....127
iDRAC.ServiceModule.WatchdogState (Read or Write)....127
iDRAC.ServiceModule.WMIInfo (Read or Write)....127
iDRAC.Smartcard....128
iDRAC.SmartCard.SmartCardCRLEnable (Read or Write)....128
iDRAC.SmartCard.SmartCardLogonEnable (Read or Write)....128
iDRAC.SNMP....128
iDRAC.SNMP.AgentCommunity (Read or Write)....128
iDRAC.SNMP.AgentEnable (Read or Write)....128
iDRAC.SNMP.AlertPort (Read or Write)....129
iDRAC.SNMP.DiscoveryPort (Read or Write)....129
iDRAC.SNMP.EngineID (Read Only)....129
iDRAC.SNMP.SNMPProtocol (Read or Write)....129
iDRAC.SNMP.TrapFormat (Read or Write)....130
iDRAC.SNMP.Alert....130
iDRAC.SNMPAlert.Destination (Read or Write)....130
iDRAC.SNMPAlert.SNMPv3UserID (Read Only)....130
iDRAC.SNMPAlert.SNMPv3Username (Read or Write)....130
iDRAC.SNMPAlert.State (Read or Write)....131
iDRAC.SNMPTRAPIPv4....131
iDRAC.SNMPTrapIPv4.DestinationNum (Read Only)....131
iDRAC.SNMPTrapIPv4.DestIPv4Addr (Read or Write)....131
iDRAC.SNMPTrapIPv4.State (Read or Write)....131
iDRAC.SNMPTRAPIPv6....132
iDRAC.SNMPTrapIPv6.DestinationNum (Read Only)....132
iDRAC.SNMPTrapIPv6.DestIPv6Addr (Read or Write)....132
iDRAC.SNMPTrapIPv6.State (Read or Write)....132
iDRAC.SSH....132
iDRAC.SSH.Enable (Read or Write)....132
iDRAC.SSH.MaxSessions (Read Only)....133
iDRAC.SSH.Port (Read or Write)....133
iDRAC.SSH.Timeout (Read or Write)....133
iDRAC.SupportAssist....133
iDRAC.SupportAssist.DefaultIPAddress (Read or Write)....133
iDRAC.SupportAssist.DefaultPassword (Read or Write)....134
iDRAC.SupportAssist.DefaultProtocol (Read or Write)....134
iDRAC.SupportAssist.DefaultProtocolPort (Read or Write)....134
iDRAC.SupportAssist.DefaultShareName (Read or Write)....134
iDRAC.SupportAssist.DefaultUserName (Read or Write)....135
iDRAC.SupportAssist.DefaultWorkgroupName (Read or Write)....135
iDRAC.SupportAssist.EmailOptIn (Read or Write)....135

iDRAC.SupportAssist.EventBasedAutoCollection (Read or Write)....135
iDRAC.SupportAssist.FilterAutoCollections (Read or Write)....136
iDRAC.SupportAssist.HostOSProxyAddress (Read or Write)....136
iDRAC.SupportAssist.HostOSProxyConfigured (Read or Write)....136
iDRAC.SupportAssist.HostOSProxyPassword (Read or Write)....136
iDRAC.SupportAssist.HostOSProxyPort (Read or Write)....137
iDRAC.SupportAssist.HostOSProxyUserName (Read or Write)....137
iDRAC.SupportAssist.iDRACFirstPowerUpDateTime (Read Only)....137
iDRAC.SupportAssist.NativeOSLogsCollectionSupported (Read Only)....137
iDRAC.SupportAssist.PreferredLanguage (Read or Write)....138
iDRAC.SupportAssist.ProSupportPlusRecommendationsReport (Read or Write)....138
iDRAC.SupportAssist.RegistrationID (Read Only)....138
iDRAC.SupportAssist.RequestTechnicianForPartsDispatch (Read or Write)....138
iDRAC.SupportAssist.SupportAssistEnableState (Read or Write)....139
iDRAC.SwitchConnectionView....139
iDRAC.SwitchConnectionView.Enable (Read or Write)....139
iDRAC.SysInfo....139
iDRAC.SysInfo.LocalConsoleLockOut (Read or Write)....139
iDRAC.SysInfo.SystemRev (Read or Write)....140
iDRAC.Syslog....140
iDRAC.SysLog.Port (Read or Write)....140
iDRAC.SysLog.PowerLogEnable (Read or Write)....140
iDRAC.SysLog.PowerLogInterval (Read or Write)....140
iDRAC.SysLog.Server1 (Read or Write)....141
iDRAC.SysLog.Server2 (Read or Write)....141
iDRAC.SysLog.Server3 (Read or Write)....141
iDRAC.SysLog.SysLogEnable (Read or Write)....141
iDRAC.Telnet....141
iDRAC.Telnet.Enable (Read or Write)....141
iDRAC.Telnet.MaxSessions (Read Only)....142
iDRAC.Telnet.Port (Read or Write)....142
iDRAC.Telnet.Timeout (Read or Write)....142
iDRAC.Time....142
iDRAC.Time.DayLightOffset (Read or Write)....142
iDRAC.Time.Timezone (Read or Write)....143
iDRAC.Time.TimeZoneOffset (Read or Write)....143
iDRAC.Update....143
iDRAC.Update.EnableSharedCompUpdate (Read or Write)....143
iDRAC.Update.FwUpdateIPAddr (Read or Write)....143
iDRAC.Update.FwUpdatePath (Read or Write)....144
iDRAC.Update.FwUpdateTFTPEnable (Read or Write)....144
iDRAC.USB....144
iDRAC.USB.ConfigurationXML (Read or Write)....144
iDRAC.USB.ManagementPortMode (Read Only)....144
iDRAC.USB.PortStatus (Read or Write)....145
iDRAC.USB.ZipPassword (Read or Write)....145
iDRAC.Userdomain....145
iDRAC.UserDomain.Name (Read or Write)....145
iDRAC.Users....145
iDRAC.Users.AuthenticationProtocol (Read or Write)....146

iDRAC.Users.Enable (Read or Write)..... 146
iDRAC.Users.IPMIKey (Read or Write)..... 146
iDRAC.Users.IpmiLanPrivilege (Read or Write)..... 146
iDRAC.Users.IpmiSerialPrivilege (Read or Write)..... 147
iDRAC.Users.MD5v3Key (Read or Write)..... 147
iDRAC.Users.Password (Read or Write)..... 147
iDRAC.Users.PrivacyProtocol (Read or Write)..... 147
iDRAC.Users.Privilege (Read or Write)..... 148
iDRAC.Users.ProtocolEnable (Read or Write)..... 148
iDRAC.Users.SHA1v3Key (Read or Write)..... 148
iDRAC.Users.SHA256Password (Read or Write)..... 148
iDRAC.Users.SHA256PasswordSalt (Read or Write)..... 148
iDRAC.Users.SolEnable (Read or Write)..... 149
iDRAC.Users.UserName (Read or Write)..... 149
iDRAC.vFlashPartition..... 149
iDRAC.vFlashPartition.AccessType (Read or Write)..... 149
iDRAC.vFlashPartition.AttachState (Read or Write)..... 149
iDRAC.vFlashPartition.EmulationType (Read or Write)..... 150
iDRAC.vFlashPartition.FormatType (Read Only)..... 150
iDRAC.vFlashPartition.IsGroupInstanceValid (Read or Write)..... 150
iDRAC.vFlashPartition.Size (Read Only)..... 151
iDRAC.vFlashPartition.VolumeLabel (Read Only)..... 151
iDRAC.vFlashSD..... 151
iDRAC.vFlashSD.AvailableSize (Read Only)..... 151
iDRAC.vFlashSD.Bitmap (Read or Write)..... 151
iDRAC.vFlashSD.Enable (Read or Write)..... 151
iDRAC.vFlashSD.Health (Read Only)..... 152
iDRAC.vFlashSD.Initialized (Read Only)..... 152
iDRAC.vFlashSD.Licensed (Read Only)..... 152
iDRAC.vFlashSD.Presence (Read or Write)..... 152
iDRAC.vFlashSD.Size (Read Only)..... 153
iDRAC.vFlashSD.WriteProtect (Read Only)..... 153
iDRAC.VirtualConsole..... 153
iDRAC.VirtualConsole.AccessPrivilege (Read or Write)..... 153
iDRAC.VirtualConsole.ActiveSessions (Read Only)..... 154
iDRAC.VirtualConsole.AttachState (Read or Write)..... 154
iDRAC.VirtualConsole.Enable (Read or Write)..... 154
iDRAC.VirtualConsole.EncryptEnable (Read or Write)..... 154
iDRAC.VirtualConsole.LocalDisable (Read or Write)..... 155
iDRAC.VirtualConsole.LocalVideo (Read or Write)..... 155
iDRAC.VirtualConsole.MaxSessions (Read or Write)..... 155
iDRAC.VirtualConsole.PluginType (Read or Write)..... 155
iDRAC.VirtualConsole.Port (Read or Write)..... 156
iDRAC.VirtualConsole.Timeout (Read or Write)..... 156
iDRAC.VirtualConsole.TimeoutEnable (Read or Write)..... 156
iDRAC.VirtualMedia..... 156
iDRAC.VirtualMedia.ActiveSessions (Read Only)..... 156
iDRAC.VirtualMedia.Attached (Read or Write)..... 157
iDRAC.VirtualMedia.BootOnce (Read or Write)..... 157
iDRAC.VirtualMedia.Enable (Read or Write)..... 157

iDRAC.VirtualMedia.EncryptEnable (Read or Write)....157
iDRAC.VirtualMedia.FloppyEmulation (Read or Write)....158
iDRAC.VirtualMedia.KeyEnable (Read or Write)....158
iDRAC.VirtualMedia.MaxSessions (Read Only)....158
iDRC.VNCServer....158
iDRAC.VNCServer.ActiveSessions (Read Only)....158
iDRAC.VNCServer.Enable (Read or Write)....159
iDRAC.VNCServer.LowerEncryptionBitLength (Read or Write)....159
iDRAC.VNCServer.MaxSessions (Read or Write)....159
iDRAC.VNCServer.Password (Read or Write)....159
iDRAC.VNCServer.Port (Read or Write)....159
iDRAC.VNCServer.SSLEncryptionBitLength (Read or Write)....160
iDRAC.VNCServer.Timeout (Read or Write)....160
iDRAC.WebServer....160
iDRAC.WebServer.CustomCipherString (Read or Write)....160
iDRAC.WebServer.Enable (Read or Write)....161
iDRAC.WebServer.HttpPort (Read or Write)....161
iDRAC.WebServer.HttpsPort (Read or Write)....161
iDRAC.WebServer.HttpsRedirection (Read or Write)....161
iDRAC.WebServer.LowerEncryptionBitLength (Read or Write)....161
iDRAC.WebServer.MaxNumberOfSessions (Read Only)....162
iDRAC.WebServer.SSLEncryptionBitLength (Read or Write)....162
iDRAC.WebServer.Timeout (Read or Write)....162
iDRAC.WebServer.TitleBarOption (Read or Write)....162
iDRAC.WebServer.TitleBarOptionCustom (Read or Write)....163
iDRAC.WebServer.TLSProtocol (Read or Write)....163

3 Lifecycle Controller Attributes....164
LifecycleController.LCAttributes....164
LifecycleController.LCAttributes.AutoBackup (Read or Write)....164
LifecycleController.LCAttributes.AutoDiscovery (Read Only)....164
LifecycleController.LCAttributes.AutoUpdate (Read or Write)....164
LifecycleController.LCAttributes.BIOSRTDRequested (Read or Write)....165
LifecycleController.LCAttributes.CMCIP (Read Only)....165
LifecycleController.LCAttributes.CollectSystemInventoryOnRestart (Read or Write)....165
LifecycleController.LCAttributes.DiscoveryFactoryDefaults (Read Only)....165
LifecycleController.LCAttributes.IgnoreCertWarning (Read or Write)....166
LifecycleController.LCAttributes.IPAddress (Read or Write)....166
LifecycleController.LCAttributes.IPChangeNotifyPS (Read or Write)....166
LifecycleController.LCAttributes.Licensed (Read Only)....167
LifecycleController.LCAttributes.LifecycleControllerState (Read or Write)....167
LifecycleController.LCAttributes.PartConfigurationUpdate (Read or Write)....167
LifecycleController.LCAttributes.PartFirmwareUpdate (Read or Write)....167
LifecycleController.LCAttributes.ProvisioningServer (Read or Write)....168
LifecycleController.LCAttributes.StorageHealthRollupStatus (Read Only)....168
LifecycleController.LCAttributes.SystemID (Read Only)....168
LifecycleController.LCAttributes.UserProxyPassword (Read or Write)....168
LifecycleController.LCAttributes.UserProxyPort (Read or Write)....169
LifecycleController.LCAttributes.UserProxyServer (Read or Write)....169
LifecycleController.LCAttributes.UserProxyType (Read or Write)....169

LifecycleController.LCAttributes.UserProxyUserName (Read or Write)..... 169
LifecycleController.LCAttributes.VirtualAddressManagement (Read or Write)..... 170
LifecycleController.LCAttributes.VirtualAddressManagementApplication (Read or Write)..... 170

4 System Attributes..... 171
System.AcquisitionInfo..... 171
System.AcquisitionInfo.CostCenter (Read or Write)..... 171
System.AcquisitionInfo.Expensed (Read or Write)..... 172
System.AcquisitionInfo.InstallDate (Read or Write)..... 172
System.AcquisitionInfo.PONumber (Read or Write)..... 172
System.AcquisitionInfo.PurchaseCost (Read or Write)..... 172
System.AcquisitionInfo.PurchaseDate (Read or Write)..... 172
System.AcquisitionInfo.Vendor (Read Only)..... 173
System.AcquisitionInfo.WayBill (Read or Write)..... 173
System.AcquisitionInfo.WhoSigned (Read or Write)..... 173
System.Backplane..... 173
System.Backplane.BackplaneBusMode (Read Only)..... 173
System.Backplane.BackplaneSplitMode (Read or Write)..... 174
System.ChassisControl..... 174
System.ChassisControl.ChassisManagementatServer (Read Only)..... 174
System.ChassisControl.ChassisManagementMonitoring (Read or Write)..... 174
System.ChassisControl.FTREnable (Read or Write)..... 175
System.ChassisInfo 175
System.ChassisInfo.ChassisModel (Read Only)..... 175
System.ChassisInfo.ChassisName (Read Only)..... 175
System.ChassisInfo.ChassisServiceTag (Read Only)..... 175
System.ChassisInfo.ChassisType (Read Only)..... 175
System.ChassisInfo.ConnectionState (Read Only)..... 176
System.ChassisInfo.FirmwareVersion (Read Only)..... 176
System.ChassisInfo.IPV4Address (Read Only)..... 176
System.ChassisInfo.IPV6Address (Read Only)..... 176
System.CustomAsset..... 177
System.CustomAsset.Label (Read or Write)..... 177
System.CustomAsset.Value (Read or Write)..... 177
System.DepreciationInfo..... 177
System.DepreciationInfo.Duration (Read or Write)..... 177
System.DepreciationInfo.DurationUnit (Read or Write)..... 177
System.DepreciationInfo.Method (Read or Write)..... 178
System.DepreciationInfo.Percentage (Read or Write)..... 178
System.Diagnostics..... 178
System.Diagnostics.OSAppCollectionTime (Read Only)..... 178
System.ExtWarrantyInfo..... 178
System.ExtWarrantyInfo.Cost (Read or Write)..... 179
System.ExtWarrantyInfo.EndDate (Read or Write)..... 179
System.ExtWarrantyInfo.Provider (Read or Write)..... 179
System.ExtWarrantyInfo.StartDate (Read or Write)..... 179
System.LCD..... 179
System.LCD.ChassisIdentifyDuration (Read or Write)..... 179
System.LCD.Configuration (Read or Write)..... 180
System.LCD.CurrentDisplay (Read Only)..... 180

System.LCD.ErrorDisplayMode (Read or Write)... 180
System.LCD.FrontPanelLocking (Read or Write)...181
System.LCD.HideErrs (Read or Write)... 181
System.LCD.LicenseMsgEnable (Read or Write)...181
System.LCD.NMIResetOverride (Read or Write)...181
System.LCD.NumberErrsHidden (Read Only)... 182
System.LCD.NumberErrsVisible (Read Only)...182
System.LCD.QualifierTemp (Read or Write)... 182
System.LCD.QualifierWatt (Read or Write)... 182
System.LCD.UserDefinedString (Read or Write)... 183
System.LCD.vConsoleIndication (Read or Write)...183
System.LeaseInfo...183
System.LeaseInfo.Buyout (Read or Write)...183
System.LeaseInfo.EndDate (Read or Write)... 183
System.LeaseInfo.FairValue (Read or Write)... 184
System.LeaseInfo.Lessor (Read or Write)...184
System.LeaseInfo.MultiSched (Read or Write)...184
System.LeaseInfo.RateFactor (Read or Write)...184
System.MaintenanceInfo... 184
System.MaintenanceInfo.EndDate (Read or Write)...185
System.MaintenanceInfo.Provider (Read or Write)... 185
System.MaintenanceInfo.Restrictions (Read or Write)... 185
System.MaintenanceInfo.StartDate (Read or Write)...185
System.OpenIDConnectServer...185
System.OpenIDConnectServer.DiscoveryURL (Read or Write)...185
System.OpenIDConnectServer.Enabled (Read or Write)...186
System.OpenIDConnectServer.HttpsCertificate (Read or Write)... 186
System.OpenIDConnectServer.Name (Read or Write)... 186
System.OpenIDConnectServer.RegistrationDetails (Read or Write)...186
System.OpenIDConnectServer.RegistrationStatus (Read Only)...187
System.OutsourceInfo...187
System.OutsourceInfo.ProbComp (Read or Write)... 187
System.OutsourceInfo.ProviderFee (Read or Write)... 187
System.OutsourceInfo.ServiceFee (Read or Write)...187
System.OutsourceInfo.SignedFor (Read or Write)... 188
System.OutsourceInfo.SLALevel (Read or Write)...188
System.OwnerInfo... 188
System.OwnerInfo.InsComp (Read or Write)... 188
System.OwnerInfo.OwnerName (Read or Write)...188
System.OwnerInfo.Type (Read or Write)... 188
System.PCIeSlotLFM... 189
System.PCIeSlotLFM.3rdPartyCard (Read Only)... 189
System.PCIeSlotLFM.CardType (Read Only)... 189
System.PCIeSlotLFM.CustomLFM (Read or Write)... 189
System.PCIeSlotLFM.LFMMode (Read or Write)...189
System.PCIeSlotLFM.MaxLFM (Read Only)... 190
System.PCIeSlotLFM.PCIeInletTemperature (Read Only)...190
System.PCIeSlotLFM.SlotState (Read Only)...190
System.PCIeSlotLFM.TargetLFM (Read Only)... 190
System.PowerHistorical...191

System.PowerHistorical.IntervalInSeconds (Read or Write)..... 191
System.QuickSync.....191
System.QuickSync.Access (Read or Write).....191
System.QuickSync.InactivityTimeout (Read or Write)..... 191
System.QuickSync.InactivityTimerEnable (Read or Write)..... 192
System.QuickSync.Presence (Read Only).....192
System.QuickSync.ReadAuthentication (Read or Write)..... 192
System.QuickSync.WifiEnable (Read or Write)..... 192
System.SC-BMC.....193
System.SC-BMC.ChassisInfraPower (Read Only)..... 193
System.SC-BMC.ChassisPowerCap (Read Only)..... 193
System.SC-BMC.ChassisServiceTag (Read Only).....193
System.SC-BMC.PowerMonitoring (Read or Write)..... 193
System.ServerInfo..... 193
System.ServerInfo.NodeID (Read Only)..... 194
System.ServerInfo.RChassisServiceTag (Read Only).....194
System.ServerInfo.ServerType (Read Only).....194
System.ServerInfo.ServiceTag (Read Only).....194
System.ServerOS.....194
System.ServerOS.HostName (Read or Write)..... 195
System.ServerOS.OEMOSVersion (Read Only).....195
System.ServerOS.OSName (Read or Write)..... 195
System.ServerOS.OSVersion (Read Only).....195
System.ServerOS.ProductKey (Read Only).....195
System.ServerOS.ServerPoweredOnTime (Read Only)..... 196
System.ServerPwr 196
System.ServerPwr.ActivePolicyName (Read Only)..... 196
System.ServerPwr.ActivePowerCapVal (Read Only).....196
System.ServerPwr.PowerCapMaxThres (Read Only).....196
System.ServerPwr.PowerCapMinThres (Read Only)..... 197
System.ServerPwr.PowerCapSetting (Read or Write).....197
System.ServerPwr.PowerCapValue (Read or Write).....197
System.ServerPwr.PSCalcRedPolicy (Read or Write).....197
System.ServerPwr.PSPFCEnabled (Read or Write)..... 197
System.ServerPwr.PSRapidOn (Read or Write)..... 198
System.ServerPwr.PSRedPolicy (Read or Write)..... 198
System.ServerPwr.RapidOnPrimaryPSU (Read or Write)..... 198
System.ServerPwrMon.....198
System.ServerPwrMon.AccumulativePower (Read Only).....199
System.ServerPwrMon.CumulativePowerStartTime (Read Only)..... 199
System.ServerPwrMon.CumulativePowerStartTimeStr (Read Only)..... 199
System.ServerPwrMon.MinPowerTime (Read Only)..... 199
System.ServerPwrMon.MinPowerTimeStr (Read Only)..... 199
System.ServerPwrMon.MinPowerWatts (Read Only)..... 200
System.ServerPwrMon.PeakCurrentTime (Read Only)..... 200
System.ServerPwrMon.PeakCurrentTimeStr (Read Only).....200
System.ServerPwrMon.PeakPowerStartTime (Read Only)..... 200
System.ServerPwrMon.PeakPowerStartTimeStr (Read Only).....201
System.ServerPwrMon.PeakPowerTime (Read Only)..... 201
System.ServerPwrMon.PeakPowerTimeStr (Read Only).....201

System.ServerPwrMon.PeakPowerWatts (Read Only)..... 201
System.ServerPwrMon.PowerConfigReset (Read or Write)..... 201
System.ServerTopology..... 202
System.ServerTopology.AisleName (Read or Write)..... 202
System.ServerTopology.BladeSlotNumInChassis (Read Only)..... 202
System.ServerTopology.ChassisName (Read Only)..... 202
System.ServerTopology.DataCenterName (Read or Write)..... 203
System.ServerTopology.RackName (Read or Write)..... 203
System.ServerTopology.RackSlot (Read or Write)..... 203
System.ServerTopology.RoomName (Read or Write)..... 203
System.ServerTopology.SizeOfManagedSystemInU (Read Only)..... 203
System.ServiceContract..... 204
System.ServiceContract.Renewed (Read or Write)..... 204
System.ServiceContract.Type (Read or Write)..... 204
System.ServiceContract.Vendor (Read or Write)..... 204
System.Storage..... 204
System.Storage.AvailableSpareAlertThreshold (Read or Write)..... 205
System.Storage.RemainingRatedWriteEnduranceAlertThreshold (Read or Write)..... 205
System.SupportInfo..... 205
System.SupportInfo.AutoFix (Read or Write)..... 205
System.SupportInfo.HelpDesk (Read or Write)..... 205
System.SupportInfo.Outsourced (Read or Write)..... 206
System.SupportInfo.Type (Read or Write)..... 206
System.SystemInfo..... 206
System.SystemInfo.BootTime (Read Only)..... 206
System.SystemInfo.PrimaryTelephone (Read or Write)..... 206
System.SystemInfo.PrimaryUser (Read or Write)..... 207
System.SystemInfo.SysLocation (Read or Write)..... 207
System.SystemInfo.SysTime (Read Only)..... 207
System.ThermalConfig..... 207
System.ThermalConfig.CriticalEventGenerationInterval (Read or Write)..... 207
System.ThermalConfig.EventGenerationInterval (Read or Write)..... 208
System.ThermalConfig.FreshAirCompliantConfiguration (Read Only)..... 208
System.ThermalConfig.MaxCFM (Read Only)..... 208
System.ThermalConfig.ValidFanConfiguration (Read Only)..... 208
System.ThermalHistorical..... 209
System.ThermalHistorical.IntervalInSeconds (Read or Write)..... 209
System.ThermalSettings 209
System.ThermalSettings.AirExhaustTemp (Read or Write)..... 209
System.ThermalSettings.AirExhaustTempSupport (Read Only)..... 209
System.ThermalSettings.AirTemperatureRiseLimit (Read or Write)..... 210
System.ThermalSettings.AirTemperatureRiseLimitSupport (Read Only)..... 210
System.ThermalSettings.CurrentSystemProfileValue (Read Only)..... 210
System.ThermalSettings.FanSpeedHighOffsetVal (Read Only)..... 210
System.ThermalSettings.FanSpeedLowOffsetVal (Read Only)..... 211
System.ThermalSettings.FanSpeedMaxOffsetVal (Read Only)..... 211
System.ThermalSettings.FanSpeedMediumOffsetVal (Read Only)..... 211
System.ThermalSettings.FanSpeedOffset (Read or Write)..... 211
System.ThermalSettings.MaximumPCIeInletTemperatureLimit (Read or Write)..... 212
System.ThermalSettings.MaximumPCIeInletTemperatureLimitSupport (Read Only)..... 212

System.ThermalSettings.MFSMaximumLimit (Read Only)....212
System.ThermalSettings.MFSMinimumLimit (Read Only)....213
System.ThermalSettings.MinimumFanSpeed (Read or Write)....213
System.ThermalSettings.PCIeSlotLFMSupport (Read Only)....213
System.ThermalSettings.SetAirTemperatureRiseLimit (Read or Write)....213
System.ThermalSettings.SetMaximumExhaustTemperatureLimit (Read or Write)....214
System.ThermalSettings.SystemCFMSupport (Read Only)....214
System.ThermalSettings.SystemExhaustTemperature (Read Only)....214
System.ThermalSettings.SystemInletTemperature (Read Only)....214
System.ThermalSettings.SystemInletTemperatureSupportLimitPerConfiguration (Read Only)....215
System.ThermalSettings.TargetExhaustTemperatureLimit (Read Only)....215
System.ThermalSettings.ThermalProfile (Read or Write)....215
System.USBFront....215
System.USBFront.Enable (Read or Write)....215
System.WarrantyInfo....216
System.WarrantyInfo.Cost (Read or Write)....216
System.WarrantyInfo.Duration (Read or Write)....216
System.WarrantyInfo.EndDate (Read or Write)....216
System.WarrantyInfo.UnitType (Read or Write)....216

5 BIOS Attributes....218
BIOS.BiosBootSettings....218
BIOS.BiosBootSettings.BootSeq (Read or Write)....218
BIOS.BiosBootSettings.BootSeqEnDis1 (Read or Write)....219
BIOS.BiosBootSettings.BootSeqEnDis10 (Read or Write)....219
BIOS.BiosBootSettings.BootSeqEnDis11 (Read or Write)....219
BIOS.BiosBootSettings.BootSeqEnDis12 (Read or Write)....219
BIOS.BiosBootSettings.BootSeqEnDis13 (Read or Write)....220
BIOS.BiosBootSettings.BootSeqEnDis14 (Read or Write)....220
BIOS.BiosBootSettings.BootSeqEnDis15 (Read or Write)....220
BIOS.BiosBootSettings.BootSeqEnDis16 (Read or Write)....220
BIOS.BiosBootSettings.BootSeqEnDis17 (Read or Write)....221
BIOS.BiosBootSettings.BootSeqEnDis18 (Read or Write)....221
BIOS.BiosBootSettings.BootSeqEnDis19 (Read or Write)....221
BIOS.BiosBootSettings.BootSeqEnDis2 (Read or Write)....221
BIOS.BiosBootSettings.BootSeqEnDis20 (Read or Write)....222
BIOS.BiosBootSettings.BootSeqEnDis3 (Read or Write)....222
BIOS.BiosBootSettings.BootSeqEnDis4 (Read or Write)....222
BIOS.BiosBootSettings.BootSeqEnDis5 (Read or Write)....222
BIOS.BiosBootSettings.BootSeqEnDis6 (Read or Write)....223
BIOS.BiosBootSettings.BootSeqEnDis7 (Read or Write)....223
BIOS.BiosBootSettings.BootSeqEnDis8 (Read or Write)....223
BIOS.BiosBootSettings.BootSeqEnDis9 (Read or Write)....223
BIOS.BiosBootSettings.BootSeqEnDisRef (Read or Write)....224
BIOS.BiosBootSettings.HddSeq (Read or Write)....224
BIOS.BootSeqEnDis....224
BIOS.BootSeqEnDis.BootSeqEnDis (Read or Write)....224
BIOS.BootSettings....224
BIOS.BootSettings.BiosBootSettingsRef (Read or Write)....224
BIOS.BootSettings.BootMode (Read or Write)....225

BIOS.BootSettings.BootSeqRetry (Read or Write)....225
BIOS.BootSettings.GenericUsbBoot (Read or Write)....225
BIOS.BootSettings.HddFailover (Read or Write)....225
BIOS.BootSettings.HddPlaceholder (Read or Write)....226
BIOS.BootSettings.OneTimeBootRef (Read or Write)....226
BIOS.BootSettings.SetBootOrderDis (Read or Write)....226
BIOS.BootSettings.SetBootOrderEn (Read or Write)....226
BIOS.BootSettings.SetBootOrderFqdd1 (Read or Write)....226
BIOS.BootSettings.SetBootOrderFqdd10 (Read or Write)....227
BIOS.BootSettings.SetBootOrderFqdd11 (Read or Write)....227
BIOS.BootSettings.SetBootOrderFqdd12 (Read or Write)....227
BIOS.BootSettings.SetBootOrderFqdd13 (Read or Write)....227
BIOS.BootSettings.SetBootOrderFqdd14 (Read or Write)....227
BIOS.BootSettings.SetBootOrderFqdd15 (Read or Write)....228
BIOS.BootSettings.SetBootOrderFqdd16 (Read or Write)....228
BIOS.BootSettings.SetBootOrderFqdd2 (Read or Write)....228
BIOS.BootSettings.SetBootOrderFqdd3 (Read or Write)....228
BIOS.BootSettings.SetBootOrderFqdd4 (Read or Write)....229
BIOS.BootSettings.SetBootOrderFqdd5 (Read or Write)....229
BIOS.BootSettings.SetBootOrderFqdd6 (Read or Write)....229
BIOS.BootSettings.SetBootOrderFqdd7 (Read or Write)....229
BIOS.BootSettings.SetBootOrderFqdd8 (Read or Write)....229
BIOS.BootSettings.SetBootOrderFqdd9 (Read or Write)....230
BIOS.BootSettings.SetLegacyHddOrderFqdd1 (Read or Write)....230
BIOS.BootSettings.SetLegacyHddOrderFqdd10 (Read or Write)....230
BIOS.BootSettings.SetLegacyHddOrderFqdd11 (Read or Write)....230
BIOS.BootSettings.SetLegacyHddOrderFqdd12 (Read or Write)....231
BIOS.BootSettings.SetLegacyHddOrderFqdd13 (Read or Write)....231
BIOS.BootSettings.SetLegacyHddOrderFqdd14 (Read or Write)....231
BIOS.BootSettings.SetLegacyHddOrderFqdd15 (Read or Write)....231
BIOS.BootSettings.SetLegacyHddOrderFqdd16 (Read or Write)....232
BIOS.BootSettings.SetLegacyHddOrderFqdd2 (Read or Write)....232
BIOS.BootSettings.SetLegacyHddOrderFqdd3 (Read or Write)....232
BIOS.BootSettings.SetLegacyHddOrderFqdd4 (Read or Write)....232
BIOS.BootSettings.SetLegacyHddOrderFqdd5 (Read or Write)....233
BIOS.BootSettings.SetLegacyHddOrderFqdd6 (Read or Write)....233
BIOS.BootSettings.SetLegacyHddOrderFqdd7 (Read or Write)....233
BIOS.BootSettings.SetLegacyHddOrderFqdd8 (Read or Write)....233
BIOS.BootSettings.SetLegacyHddOrderFqdd9 (Read or Write)....234
BIOS.BootSettings.UefiBootSettingsRef (Read or Write)....234
BIOS.DebugMenulioConfigurationSettings....234
BIOS.DebugMenulioConfigurationSettings.DeviceUnhide (Read or Write)....234
BIOS.DebugMenulioConfigurationSettings.Dfx (Read or Write)....234
BIOS.DebugMenulioConfigurationSettings.DirectMediaInterfaceSpeed (Read or Write)....235
BIOS.DebugMenulioConfigurationSettings.TXEQWA (Read or Write)....235
BIOS.DebugMenulioConfigurationSettings.UnusedPcieClk (Read or Write)....235
BIOS.DebugMenuSetting....235
BIOS.DebugMenuSetting.AttemptFastBoot (Read or Write)....235
BIOS.DebugMenuSetting.AttemptFastBootCold (Read or Write)....236
BIOS.DebugMenuSetting.BiosCpuKnobTuning (Read or Write)....236

BIOS.DebugMenuSetting.BiosCpuKnobTuningRef (Read or Write)....236
BIOS.DebugMenuSetting.BrowserDebugMode (Read or Write)....236
BIOS.DebugMenuSetting.BrowserMode (Read or Write)....237
BIOS.DebugMenuSetting.BrowserOptionsRef (Read or Write)....237
BIOS.DebugMenuSetting.BugChecking (Read or Write)....237
BIOS.DebugMenuSetting.CkeThrottling (Read or Write)....237
BIOS.DebugMenuSetting.ClpOutput (Read or Write)....238
BIOS.DebugMenuSetting.CTOMasking (Read or Write)....238
BIOS.DebugMenuSetting.CurrentLimit (Read or Write)....238
BIOS.DebugMenuSetting.DciTransport (Read or Write)....238
BIOS.DebugMenuSetting.DeadLineLlcAlloc (Read or Write)....238
BIOS.DebugMenuSetting.DebugErrorLevel (Read or Write)....239
BIOS.DebugMenuSetting.DirectoryAtoS (Read or Write)....239
BIOS.DebugMenuSetting.DirectoryMode (Read or Write)....239
BIOS.DebugMenuSetting.EmbSataRSTeDebug (Read or Write)....239
BIOS.DebugMenuSetting.EmbSataTestMode (Read or Write)....240
BIOS.DebugMenuSetting.IdracDebugMode (Read or Write)....240
BIOS.DebugMenuSetting.IgnoreIdracCrReq (Read or Write)....240
BIOS.DebugMenuSetting.IioPcieGlobalSpeed (Read or Write)....240
BIOS.DebugMenuSetting.IntelTestEventIio (Read or Write)....241
BIOS.DebugMenuSetting.InteractivePassword24A (Read or Write)....241
BIOS.DebugMenuSetting.JunoPmEnable (Read or Write)....241
BIOS.DebugMenuSetting.LinkDowntrainReporting (Read or Write)....241
BIOS.DebugMenuSetting.LlcPrefetch (Read or Write)....242
BIOS.DebugMenuSetting.MeFailureRecoveryEnable (Read or Write)....242
BIOS.DebugMenuSetting.MemHotThrottlingMode (Read or Write)....242
BIOS.DebugMenuSetting.MemoryBist (Read or Write)....242
BIOS.DebugMenuSetting.MemoryFastBootCold (Read or Write)....242
BIOS.DebugMenuSetting.MemoryMultiThread (Read or Write)....243
BIOS.DebugMenuSetting.MemoryPerBitMargin (Read or Write)....243
BIOS.DebugMenuSetting.MemoryRmt (Read or Write)....243
BIOS.DebugMenuSetting.MemoryThrottlingMode (Read or Write)....243
BIOS.DebugMenuSetting.MemTestOnFastBoot (Read or Write)....244
BIOS.DebugMenuSetting.MeUmaEnable (Read or Write)....244
BIOS.DebugMenuSetting.MRCSerialDbgOut (Read or Write)....244
BIOS.DebugMenuSetting.MultiThreaded (Read or Write)....244
BIOS.DebugMenuSetting.NdcConfigurationSpeed (Read or Write)....245
BIOS.DebugMenuSetting.PCIeErrorInjection (Read or Write)....245
BIOS.DebugMenuSetting.PCIeLiveErrorRecovery (Read or Write)....245
BIOS.DebugMenuSetting.PostPackageRepair (Read or Write)....245
BIOS.DebugMenuSetting.PPRErrInjectionTest (Read or Write)....246
BIOS.DebugMenuSetting.ProcDpatProDebug (Read or Write)....246
BIOS.DebugMenuSetting.ProcMtrrPatDebug (Read or Write)....246
BIOS.DebugMenuSetting.PSPConsoleOut (Read or Write)....246
BIOS.DebugMenuSetting.RankMargin (Read or Write)....246
BIOS.DebugMenuSetting.RebootTestCount (Read or Write)....247
BIOS.DebugMenuSetting.RebootTestMode (Read or Write)....247
BIOS.DebugMenuSetting.RebootTestPoint (Read or Write)....247
BIOS.DebugMenuSetting.S4Support (Read or Write)....247
BIOS.DebugMenuSetting.SccDebugEnabled (Read or Write)....248

BIOS.DebugMenuSetting.SrefProgramming (Read or Write)....248
BIOS.DebugMenuSetting.TpmBindingReset (Read or Write)....248
BIOS.DebugMenuSetting.TraceHubDebug (Read or Write)....248
BIOS.DebugMenuSetting.VmWareSupport (Read or Write)....249
BIOS.DebugMenuSetting.XptPrefetch (Read or Write)....249
BIOS.EmbServerMgmt....249
BIOS.EmbServerMgmt.EmbServerMgmt (Read or Write)....249
BIOS.EmbServerMgmt.FrontLcd (Read or Write)....249
BIOS.EmbServerMgmt.UserLcdStr (Read or Write)....250
BIOS.HttpDev1Settings....250
BIOS.HttpDev1Settings.HttpDev1DhcpEnDis (Read or Write)....250
BIOS.HttpDev1Settings.HttpDev1Dns1 (Read or Write)....250
BIOS.HttpDev1Settings.HttpDev1Dns2 (Read or Write)....250
BIOS.HttpDev1Settings.HttpDev1DnsDhcpEnDis (Read or Write)....251
BIOS.HttpDev1Settings.HttpDev1Gateway (Read or Write)....251
BIOS.HttpDev1Settings.HttpDev1Interface (Read or Write)....251
BIOS.HttpDev1Settings.HttpDev1Ip (Read or Write)....251
BIOS.HttpDev1Settings.HttpDev1Mask (Read or Write)....251
BIOS.HttpDev1Settings.HttpDev1Protocol (Read or Write)....252
BIOS.HttpDev1Settings.HttpDev1Settings (Read or Write)....252
BIOS.HttpDev1Settings.HttpDev1Uri (Read or Write)....252
BIOS.HttpDev1Settings.HttpDev1VlanEnDis (Read or Write)....252
BIOS.HttpDev1Settings.HttpDev1VlanId (Read or Write)....253
BIOS.HttpDev1Settings.HttpDev1VlanPriority (Read or Write)....253
BIOS.HttpDev2Settings....253
BIOS.HttpDev2Settings.HttpDev2DhcpEnDis (Read or Write)....253
BIOS.HttpDev2Settings.HttpDev2Dns1 (Read or Write)....253
BIOS.HttpDev2Settings.HttpDev2Dns2 (Read or Write)....254
BIOS.HttpDev2Settings.HttpDev2DnsDhcpEnDis (Read or Write)....254
BIOS.HttpDev2Settings.HttpDev2Gateway (Read or Write)....254
BIOS.HttpDev2Settings.HttpDev2Interface (Read or Write)....254
BIOS.HttpDev2Settings.HttpDev2Ip (Read or Write)....254
BIOS.HttpDev2Settings.HttpDev2Mask (Read or Write)....255
BIOS.HttpDev2Settings.HttpDev2Protocol (Read or Write)....255
BIOS.HttpDev2Settings.HttpDev2Settings (Read or Write)....255
BIOS.HttpDev2Settings.HttpDev2Uri (Read or Write)....255
BIOS.HttpDev2Settings.HttpDev2VlanEnDis (Read or Write)....256
BIOS.HttpDev2Settings.HttpDev2VlanId (Read or Write)....256
BIOS.HttpDev2Settings.HttpDev2VlanPriority (Read or Write)....256
BIOS.HttpDev3Settings....256
BIOS.HttpDev3Settings.HttpDev3DhcpEnDis (Read or Write)....256
BIOS.HttpDev3Settings.HttpDev3Dns1 (Read or Write)....257
BIOS.HttpDev3Settings.HttpDev3Dns2 (Read or Write)....257
BIOS.HttpDev3Settings.HttpDev3DnsDhcpEnDis (Read or Write)....257
BIOS.HttpDev3Settings.HttpDev3Gateway (Read or Write)....257
BIOS.HttpDev3Settings.HttpDev3Interface (Read or Write)....258
BIOS.HttpDev3Settings.HttpDev3Ip (Read or Write)....258
BIOS.HttpDev3Settings.HttpDev3Mask (Read or Write)....258
BIOS.HttpDev3Settings.HttpDev3Protocol (Read or Write)....258
BIOS.HttpDev3Settings.HttpDev3Settings (Read or Write)....258

BIOS.HttpDev3Settings.HttpDev3Uri (Read or Write)....259
BIOS.HttpDev3Settings.HttpDev3VlanEnDis (Read or Write)....259
BIOS.HttpDev3Settings.HttpDev3VlanId (Read or Write)....259
BIOS.HttpDev3Settings.HttpDev3VlanPriority (Read or Write)....259
BIOS.HttpDev4Settings....260
BIOS.HttpDev4Settings.HttpDev4DhcpEnDis (Read or Write)....260
BIOS.HttpDev4Settings.HttpDev4Dns1 (Read or Write)....260
BIOS.HttpDev4Settings.HttpDev4Dns2 (Read or Write)....260
BIOS.HttpDev4Settings.HttpDev4DnsDhcpEnDis (Read or Write)....260
BIOS.HttpDev4Settings.HttpDev4Gateway (Read or Write)....261
BIOS.HttpDev4Settings.HttpDev4Interface (Read or Write)....261
BIOS.HttpDev4Settings.HttpDev4Ip (Read or Write)....261
BIOS.HttpDev4Settings.HttpDev4Mask (Read or Write)....261
BIOS.HttpDev4Settings.HttpDev4Protocol (Read or Write)....262
BIOS.HttpDev4Settings.HttpDev4Settings (Read or Write)....262
BIOS.HttpDev4Settings.HttpDev4Uri (Read or Write)....262
BIOS.HttpDev4Settings.HttpDev4VlanEnDis (Read or Write)....262
BIOS.HttpDev4Settings.HttpDev4VlanId (Read or Write)....263
BIOS.HttpDev4Settings.HttpDev4VlanPriority (Read or Write)....263
BIOS.IntegratedDevices....263
BIOS.IntegratedDevices.CurrentEmbVideoState (Read or Write)....263
BIOS.IntegratedDevices.EmbNic1 (Read or Write)....263
BIOS.IntegratedDevices.EmbNic1Nic2 (Read or Write)....264
BIOS.IntegratedDevices.EmbNic2 (Read or Write)....264
BIOS.IntegratedDevices.EmbNic3 (Read or Write)....264
BIOS.IntegratedDevices.EmbNic3Nic4 (Read or Write)....264
BIOS.IntegratedDevices.EmbNic4 (Read or Write)....265
BIOS.IntegratedDevices.EmbNicPort1BootProto (Read or Write)....265
BIOS.IntegratedDevices.EmbNicPort2BootProto (Read or Write)....265
BIOS.IntegratedDevices.EmbNicPort3BootProto (Read or Write)....265
BIOS.IntegratedDevices.EmbNicPort4BootProto (Read or Write)....266
BIOS.IntegratedDevices.EmbVideo (Read or Write)....266
BIOS.IntegratedDevices.GlobalSlotDriverDisable (Read or Write)....266
BIOS.IntegratedDevices.IntegratedDevices (Read or Write)....267
BIOS.IntegratedDevices.IntegratedNetwork1 (Read or Write)....267
BIOS.IntegratedDevices.IntegratedNetwork2 (Read or Write)....267
BIOS.IntegratedDevices.IntegratedRaid (Read or Write)....267
BIOS.IntegratedDevices.IntegratedSas (Read or Write)....268
BIOS.IntegratedDevices.InternalSdCard (Read or Write)....268
BIOS.IntegratedDevices.InternalSdCardPresence (Read or Write)....268
BIOS.IntegratedDevices.InternalSdCardPrimaryCard (Read or Write)....268
BIOS.IntegratedDevices.InternalSdCardRedundancy (Read or Write)....269
BIOS.IntegratedDevices.InternalUsb (Read or Write)....269
BIOS.IntegratedDevices.InternalUsb1 (Read or Write)....269
BIOS.IntegratedDevices.InternalUsb2 (Read or Write)....269
BIOS.IntegratedDevices.IntNic1Port1BootProto (Read or Write)....270
BIOS.IntegratedDevices.IntNic1Port2BootProto (Read or Write)....270
BIOS.IntegratedDevices.IntNic1Port3BootProto (Read or Write)....270
BIOS.IntegratedDevices.IntNic1Port4BootProto (Read or Write)....271
BIOS.IntegratedDevices.IntNic2Port1BootProto (Read or Write)....271

BIOS.IntegratedDevices.IntNic2Port2BootProto (Read or Write)....271
BIOS.IntegratedDevices.IntNic2Port3BootProto (Read or Write)....272
BIOS.IntegratedDevices.IntNic2Port4BootProto (Read or Write)....272
BIOS.IntegratedDevices.IoatEngine (Read or Write)....272
BIOS.IntegratedDevices.IoNonPostedPrefetch (Read or Write)....272
BIOS.IntegratedDevices.MemoryMappedIOH (Read or Write)....273
BIOS.IntegratedDevices.MmioAbove4Gb (Read or Write)....273
BIOS.IntegratedDevices.MmioLimit (Read or Write)....273
BIOS.IntegratedDevices.Ndc1PcieLink1 (Read or Write)....273
BIOS.IntegratedDevices.Ndc1PcieLink2 (Read or Write)....274
BIOS.IntegratedDevices.Ndc1PcieLink3 (Read or Write)....274
BIOS.IntegratedDevices.OsWatchdogTimer (Read or Write)....274
BIOS.IntegratedDevices.PcieBusCustomization (Read or Write)....274
BIOS.IntegratedDevices.RipsPresence (Read or Write)....275
BIOS.IntegratedDevices.SlotDisablementRef (Read or Write)....275
BIOS.IntegratedDevices.SnoopHldOff (Read or Write)....275
BIOS.IntegratedDevices.SriovGlobalEnable (Read or Write)....275
BIOS.IntegratedDevices.Usb3Setting (Read or Write)....276
BIOS.IntegratedDevices.UsbEnableFrontPortsOnly (Read or Write)....276
BIOS.IntegratedDevices.UsbManagedPort (Read or Write)....276
BIOS.IntegratedDevices.UsbPorts (Read or Write)....276
BIOS.IsciDevice1Connection1Settings....277
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Auth (Read or Write)....277
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1ChapName (Read or Write)....277
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1ChapSecret (Read or Write)....277
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1ChapType (Read or Write)....278
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1DhcpEnDis (Read or Write)....278
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Gateway (Read or Write)....278
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Interface (Read or Write)....278
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Ip (Read or Write)....279
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1IsId (Read or Write)....279
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Lun (Read or Write)....279
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Mask (Read or Write)....279
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Port (Read or Write)....280
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Protocol (Read or Write)....280
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Retry (Read or Write)....280
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1RevChapName (Read or Write)....280
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1RevChapSecret (Read or Write)....281
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Settings (Read or Write)....281
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1TargetIp (Read or Write)....281
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1TargetName (Read or Write)....281
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1TgtDhcpEnDis (Read or Write)....282
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Timeout (Read or Write)....282
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1VlanEnDis (Read or Write)....282
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1VlanId (Read or Write)....282
BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1VlanPriority (Read or Write)....283
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Auth (Read or Write)....283
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2ChapName (Read or Write)....283
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2ChapSecret (Read or Write)....283
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2ChapType (Read or Write)....284

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2DhcpEnDis (Read or Write)....284
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Gateway (Read or Write)....284
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Interface (Read or Write)....284
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Ip (Read or Write)....285
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Isid (Read or Write)....285
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Lun (Read or Write)....285
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Mask (Read or Write)....285
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Port (Read or Write)....286
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Protocol (Read or Write)....286
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Retry (Read or Write)....286
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2RevChapName (Read or Write)....286
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2RevChapSecret (Read or Write)....287
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Settings (Read or Write)....287
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2TargetIp (Read or Write)....287
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2TargetName (Read or Write)....287
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2TgtDhcpEnDis (Read or Write)....288
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Timeout (Read or Write)....288
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2VlanEnDis (Read or Write)....288
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2VlanId (Read or Write)....288
BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2VlanPriority (Read or Write)....289
BIOS.IscsiDevice1Settings.IscsiDev1Con1EnDis (Read or Write)....289
BIOS.IscsiDevice1Settings.IscsiDev1Con1SettingsRef (Read or Write)....289
BIOS.IscsiDevice1Settings.IscsiDev1Con2EnDis (Read or Write)....289
BIOS.IscsiDevice1Settings.IscsiDev1Con2SettingsRef (Read or Write)....290
BIOS.IscsiDevice1Settings.IscsiDev1ConOrder (Read or Write)....290
BIOS.IscsiDevice1Settings.IscsiDev1Settings (Read or Write)....290
BIOS.IscsiDevice1Settings....290
BIOS.IscsiDevice1Settings.IscsiDev1Con1EnDis (Read or Write)....290
BIOS.IscsiDevice1Settings.IscsiDev1Con1SettingsRef (Read or Write)....291
BIOS.IscsiDevice1Settings.IscsiDev1Con2EnDis (Read or Write)....291
BIOS.IscsiDevice1Settings.IscsiDev1Con2SettingsRef (Read or Write)....291
BIOS.IscsiDevice1Settings.IscsiDev1ConOrder (Read or Write)....291
BIOS.IscsiDevice1Settings.IscsiDev1Settings (Read or Write)....292
BIOS.MemSettings....292
BIOS.MemSettings.AdddcSetting (Read or Write)....292
BIOS.MemSettings.AddrBasMir (Read or Write)....292
BIOS.MemSettings.AppDirectCapacity (Read or Write)....292
BIOS.MemSettings.AppDirectNamespaceCount0 (Read or Write)....293
BIOS.MemSettings.AppDirectNamespaceCount1 (Read or Write)....293
BIOS.MemSettings.AppDirectNamespaceCount2 (Read or Write)....293
BIOS.MemSettings.AppDirectNamespaceCount3 (Read or Write)....293
BIOS.MemSettings.BatteryStatus (Read or Write)....294
BIOS.MemSettings.Capacity00 (Read or Write)....294
BIOS.MemSettings.Capacity01 (Read or Write)....294
BIOS.MemSettings.Capacity02 (Read or Write)....294
BIOS.MemSettings.Capacity03 (Read or Write)....294
BIOS.MemSettings.Capacity04 (Read or Write)....295
BIOS.MemSettings.Capacity05 (Read or Write)....295
BIOS.MemSettings.Capacity06 (Read or Write)....295
BIOS.MemSettings.Capacity07 (Read or Write)....295

BIOS.MemSettings.Capacity08 (Read or Write)....295
BIOS.MemSettings.Capacity09 (Read or Write)....296
BIOS.MemSettings.Capacity10 (Read or Write)....296
BIOS.MemSettings.Capacity11 (Read or Write)....296
BIOS.MemSettings.Capacity12 (Read or Write)....296
BIOS.MemSettings.Capacity13 (Read or Write)....296
BIOS.MemSettings.Capacity14 (Read or Write)....297
BIOS.MemSettings.Capacity15 (Read or Write)....297
BIOS.MemSettings.Capacity16 (Read or Write)....297
BIOS.MemSettings.Capacity17 (Read or Write)....297
BIOS.MemSettings.Capacity18 (Read or Write)....298
BIOS.MemSettings.Capacity19 (Read or Write)....298
BIOS.MemSettings.Capacity20 (Read or Write)....298
BIOS.MemSettings.Capacity21 (Read or Write)....298
BIOS.MemSettings.Capacity22 (Read or Write)....298
BIOS.MemSettings.Capacity23 (Read or Write)....299
BIOS.MemSettings.ClusterOnDie (Read or Write)....299
BIOS.MemSettings.ConfigureSecurity (Read or Write)....299
BIOS.MemSettings.CorrEccSmi (Read or Write)....299
BIOS.MemSettings.CreateGoalConfig (Read or Write)....299
BIOS.MemSettings.CurrentMemOpModeState (Read or Write)....300
BIOS.MemSettings.DeviceLocator00 (Read or Write)....300
BIOS.MemSettings.DeviceLocator01 (Read or Write)....300
BIOS.MemSettings.DeviceLocator02 (Read or Write)....300
BIOS.MemSettings.DeviceLocator03 (Read or Write)....301
BIOS.MemSettings.DeviceLocator04 (Read or Write)....301
BIOS.MemSettings.DeviceLocator05 (Read or Write)....301
BIOS.MemSettings.DeviceLocator06 (Read or Write)....301
BIOS.MemSettings.DeviceLocator07 (Read or Write)....301
BIOS.MemSettings.DeviceLocator08 (Read or Write)....302
BIOS.MemSettings.DeviceLocator09 (Read or Write)....302
BIOS.MemSettings.DeviceLocator10 (Read or Write)....302
BIOS.MemSettings.DeviceLocator11 (Read or Write)....302
BIOS.MemSettings.DeviceLocator12 (Read or Write)....302
BIOS.MemSettings.DeviceLocator13 (Read or Write)....303
BIOS.MemSettings.DeviceLocator14 (Read or Write)....303
BIOS.MemSettings.DeviceLocator15 (Read or Write)....303
BIOS.MemSettings.DeviceLocator16 (Read or Write)....303
BIOS.MemSettings.DeviceLocator17 (Read or Write)....303
BIOS.MemSettings.DeviceLocator18 (Read or Write)....304
BIOS.MemSettings.DeviceLocator19 (Read or Write)....304
BIOS.MemSettings.DeviceLocator20 (Read or Write)....304
BIOS.MemSettings.DeviceLocator21 (Read or Write)....304
BIOS.MemSettings.DeviceLocator22 (Read or Write)....305
BIOS.MemSettings.DeviceLocator23 (Read or Write)....305
BIOS.MemSettings.DimmID (Read or Write)....305
BIOS.MemSettings.DimmInfo00 (Read or Write)....305
BIOS.MemSettings.DimmInfo01 (Read or Write)....305
BIOS.MemSettings.DimmInfo02 (Read or Write)....306
BIOS.MemSettings.DimmInfo03 (Read or Write)....306

BIOS.MemSettings.DimmInfo04 (Read or Write)....306
BIOS.MemSettings.DimmInfo05 (Read or Write)....306
BIOS.MemSettings.DimmInfo06 (Read or Write)....306
BIOS.MemSettings.DimmInfo07 (Read or Write)....307
BIOS.MemSettings.DimmInfo08 (Read or Write)....307
BIOS.MemSettings.DimmInfo09 (Read or Write)....307
BIOS.MemSettings.DimmInfo10 (Read or Write)....307
BIOS.MemSettings.DimmInfo11 (Read or Write)....307
BIOS.MemSettings.DimmInfo12 (Read or Write)....308
BIOS.MemSettings.DimmInfo13 (Read or Write)....308
BIOS.MemSettings.DimmInfo14 (Read or Write)....308
BIOS.MemSettings.DimmInfo15 (Read or Write)....308
BIOS.MemSettings.DimmInfo16 (Read or Write)....309
BIOS.MemSettings.DimmInfo17 (Read or Write)....309
BIOS.MemSettings.DimmInfo18 (Read or Write)....309
BIOS.MemSettings.DimmInfo19 (Read or Write)....309
BIOS.MemSettings.DimmInfo20 (Read or Write)....309
BIOS.MemSettings.DimmInfo21 (Read or Write)....310
BIOS.MemSettings.DimmInfo22 (Read or Write)....310
BIOS.MemSettings.DimmInfo23 (Read or Write)....310
BIOS.MemSettings.FirmwareVersion00 (Read or Write)....310
BIOS.MemSettings.FirmwareVersion01 (Read or Write)....310
BIOS.MemSettings.FirmwareVersion02 (Read or Write)....311
BIOS.MemSettings.FirmwareVersion03 (Read or Write)....311
BIOS.MemSettings.FirmwareVersion04 (Read or Write)....311
BIOS.MemSettings.FirmwareVersion05 (Read or Write)....311
BIOS.MemSettings.FirmwareVersion06 (Read or Write)....311
BIOS.MemSettings.FirmwareVersion07 (Read or Write)....312
BIOS.MemSettings.FirmwareVersion08 (Read or Write)....312
BIOS.MemSettings.FirmwareVersion09 (Read or Write)....312
BIOS.MemSettings.FirmwareVersion10 (Read or Write)....312
BIOS.MemSettings.FirmwareVersion11 (Read or Write)....313
BIOS.MemSettings.FirmwareVersion12 (Read or Write)....313
BIOS.MemSettings.FirmwareVersion13 (Read or Write)....313
BIOS.MemSettings.FirmwareVersion14 (Read or Write)....313
BIOS.MemSettings.FirmwareVersion15 (Read or Write)....313
BIOS.MemSettings.FirmwareVersion16 (Read or Write)....314
BIOS.MemSettings.FirmwareVersion17 (Read or Write)....314
BIOS.MemSettings.FirmwareVersion18 (Read or Write)....314
BIOS.MemSettings.FirmwareVersion19 (Read or Write)....314
BIOS.MemSettings.FirmwareVersion20 (Read or Write)....314
BIOS.MemSettings.FirmwareVersion21 (Read or Write)....315
BIOS.MemSettings.FirmwareVersion22 (Read or Write)....315
BIOS.MemSettings.FirmwareVersion23 (Read or Write)....315
BIOS.MemSettings.IntelPersistentMemories (Read or Write)....315
BIOS.MemSettings.IntelPersistMemOperationTarget (Read or Write)....316
BIOS.MemSettings.LockState00 (Read or Write)....316
BIOS.MemSettings.LockState01 (Read or Write)....316
BIOS.MemSettings.LockState02 (Read or Write)....316
BIOS.MemSettings.LockState03 (Read or Write)....316

BIOS.MemSettings.LockState04 (Read or Write)....317
BIOS.MemSettings.LockState05 (Read or Write).... 317
BIOS.MemSettings.LockState06 (Read or Write)....317
BIOS.MemSettings.LockState07 (Read or Write)....317
BIOS.MemSettings.LockState08 (Read or Write).... 318
BIOS.MemSettings.LockState09 (Read or Write).... 318
BIOS.MemSettings.LockState10 (Read or Write).... 318
BIOS.MemSettings.LockState11 (Read or Write).... 318
BIOS.MemSettings.LockState12 (Read or Write).... 319
BIOS.MemSettings.LockState13 (Read or Write).... 319
BIOS.MemSettings.LockState14 (Read or Write).... 319
BIOS.MemSettings.LockState15 (Read or Write).... 319
BIOS.MemSettings.LockState16 (Read or Write).... 319
BIOS.MemSettings.LockState17 (Read or Write)....320
BIOS.MemSettings.LockState18 (Read or Write).... 320
BIOS.MemSettings.LockState19 (Read or Write).... 320
BIOS.MemSettings.LockState20 (Read or Write)....320
BIOS.MemSettings.LockState21 (Read or Write).... 321
BIOS.MemSettings.LockState22 (Read or Write)....321
BIOS.MemSettings.LockState23 (Read or Write)....321
BIOS.MemSettings.MemLowPower (Read or Write).... 321
BIOS.MemSettings.MemOpMode (Read or Write)....321
BIOS.MemSettings.MemOptimizer (Read or Write).... 322
BIOS.MemSettings.MemOpVoltage (Read or Write)....322
BIOS.MemSettings.MemoryCapacity (Read or Write).... 322
BIOS.MemSettings.MemoryInterleaving (Read or Write).... 323
BIOS.MemSettings.MemSettings (Read or Write)....323
BIOS.MemSettings.MemTest (Read or Write).... 323
BIOS.MemSettings.MemTestType (Read or Write)....323
BIOS.MemSettings.MemThrottlingMode (Read or Write)....324
BIOS.MemSettings.MltRnkSpr (Read or Write).... 324
BIOS.MemSettings.NodeInterleave (Read or Write)....324
BIOS.MemSettings.NvdimmFactoryDefault (Read or Write).... 324
BIOS.MemSettings.NvdimmFactoryDefault0 (Read or Write)....325
BIOS.MemSettings.NvdimmFactoryDefault1 (Read or Write)....325
BIOS.MemSettings.NvdimmFactoryDefault10 (Read or Write)....325
BIOS.MemSettings.NvdimmFactoryDefault11 (Read or Write).... 325
BIOS.MemSettings.NvdimmFactoryDefault12 (Read or Write)....326
BIOS.MemSettings.NvdimmFactoryDefault13 (Read or Write)....326
BIOS.MemSettings.NvdimmFactoryDefault14 (Read or Write)....326
BIOS.MemSettings.NvdimmFactoryDefault15 (Read or Write)....326
BIOS.MemSettings.NvdimmFactoryDefault16 (Read or Write)....327
BIOS.MemSettings.NvdimmFactoryDefault17 (Read or Write).... 327
BIOS.MemSettings.NvdimmFactoryDefault18 (Read or Write).... 327
BIOS.MemSettings.NvdimmFactoryDefault19 (Read or Write)....327
BIOS.MemSettings.NvdimmFactoryDefault2 (Read or Write).... 328
BIOS.MemSettings.NvdimmFactoryDefault20 (Read or Write)....328
BIOS.MemSettings.NvdimmFactoryDefault21 (Read or Write)....328
BIOS.MemSettings.NvdimmFactoryDefault22 (Read or Write).... 328
BIOS.MemSettings.NvdimmFactoryDefault23 (Read or Write)....329

BIOS.MemSettings.NvdimmFactoryDefault3 (Read or Write)....329
BIOS.MemSettings.NvdimmFactoryDefault4 (Read or Write)....329
BIOS.MemSettings.NvdimmFactoryDefault5 (Read or Write)....329
BIOS.MemSettings.NvdimmFactoryDefault6 (Read or Write)....330
BIOS.MemSettings.NvdimmFactoryDefault7 (Read or Write)....330
BIOS.MemSettings.NvdimmFactoryDefault8 (Read or Write)....330
BIOS.MemSettings.NvdimmFactoryDefault9 (Read or Write)....330
BIOS.MemSettings.NvdimmFirmwareVer0 (Read or Write)....331
BIOS.MemSettings.NvdimmFirmwareVer1 (Read or Write)....331
BIOS.MemSettings.NvdimmFirmwareVer10 (Read or Write)....331
BIOS.MemSettings.NvdimmFirmwareVer11 (Read or Write)....331
BIOS.MemSettings.NvdimmFirmwareVer2 (Read or Write)....331
BIOS.MemSettings.NvdimmFirmwareVer3 (Read or Write)....332
BIOS.MemSettings.NvdimmFirmwareVer4 (Read or Write)....332
BIOS.MemSettings.NvdimmFirmwareVer5 (Read or Write)....332
BIOS.MemSettings.NvdimmFirmwareVer6 (Read or Write)....332
BIOS.MemSettings.NvdimmFirmwareVer7 (Read or Write)....332
BIOS.MemSettings.NvdimmFirmwareVer8 (Read or Write)....333
BIOS.MemSettings.NvdimmFirmwareVer9 (Read or Write)....333
BIOS.MemSettings.NvdimmFreq0 (Read or Write)....333
BIOS.MemSettings.NvdimmFreq1 (Read or Write)....333
BIOS.MemSettings.NvdimmFreq10 (Read or Write)....334
BIOS.MemSettings.NvdimmFreq11 (Read or Write)....334
BIOS.MemSettings.NvdimmFreq2 (Read or Write)....334
BIOS.MemSettings.NvdimmFreq3 (Read or Write)....334
BIOS.MemSettings.NvdimmFreq4 (Read or Write)....334
BIOS.MemSettings.NvdimmFreq5 (Read or Write)....335
BIOS.MemSettings.NvdimmFreq6 (Read or Write)....335
BIOS.MemSettings.NvdimmFreq7 (Read or Write)....335
BIOS.MemSettings.NvdimmFreq8 (Read or Write)....335
BIOS.MemSettings.NvdimmFreq9 (Read or Write)....335
BIOS.MemSettings.NvdimmInterleaveSupport (Read or Write)....336
BIOS.MemSettings.NvdimmLocation0 (Read or Write)....336
BIOS.MemSettings.NvdimmLocation1 (Read or Write)....336
BIOS.MemSettings.NvdimmLocation10 (Read or Write)....336
BIOS.MemSettings.NvdimmLocation11 (Read or Write)....337
BIOS.MemSettings.NvdimmLocation2 (Read or Write)....337
BIOS.MemSettings.NvdimmLocation3 (Read or Write)....337
BIOS.MemSettings.NvdimmLocation4 (Read or Write)....337
BIOS.MemSettings.NvdimmLocation5 (Read or Write)....337
BIOS.MemSettings.NvdimmLocation6 (Read or Write)....338
BIOS.MemSettings.NvdimmLocation7 (Read or Write)....338
BIOS.MemSettings.NvdimmLocation8 (Read or Write)....338
BIOS.MemSettings.NvdimmLocation9 (Read or Write)....338
BIOS.MemSettings.NvdimmReadOnly (Read or Write)....338
BIOS.MemSettings.NvdimmSerialNum0 (Read or Write)....339
BIOS.MemSettings.NvdimmSerialNum1 (Read or Write)....339
BIOS.MemSettings.NvdimmSerialNum10 (Read or Write)....339
BIOS.MemSettings.NvdimmSerialNum11 (Read or Write)....339
BIOS.MemSettings.NvdimmSerialNum2 (Read or Write)....339

BIOS.MemSettings.NvdimmSerialNum3 (Read or Write)..... 340
BIOS.MemSettings.NvdimmSerialNum4 (Read or Write)..... 340
BIOS.MemSettings.NvdimmSerialNum5 (Read or Write)..... 340
BIOS.MemSettings.NvdimmSerialNum6 (Read or Write)..... 340
BIOS.MemSettings.NvdimmSerialNum7 (Read or Write)..... 341
BIOS.MemSettings.NvdimmSerialNum8 (Read or Write)..... 341
BIOS.MemSettings.NvdimmSerialNum9 (Read or Write)..... 341
BIOS.MemSettings.NvdimmSize0 (Read or Write).....341
BIOS.MemSettings.NvdimmSize1 (Read or Write)..... 341
BIOS.MemSettings.NvdimmSize10 (Read or Write)..... 342
BIOS.MemSettings.NvdimmSize11 (Read or Write)..... 342
BIOS.MemSettings.NvdimmSize2 (Read or Write).....342
BIOS.MemSettings.NvdimmSize3 (Read or Write).....342
BIOS.MemSettings.NvdimmSize4 (Read or Write).....342
BIOS.MemSettings.NvdimmSize5 (Read or Write).....343
BIOS.MemSettings.NvdimmSize6 (Read or Write).....343
BIOS.MemSettings.NvdimmSize7 (Read or Write)..... 343
BIOS.MemSettings.NvdimmSize8 (Read or Write).....343
BIOS.MemSettings.NvdimmSize9 (Read or Write).....343
BIOS.MemSettings.OppSrefEn (Read or Write).....344
BIOS.MemSettings.PersistentMemoryMode (Read or Write).....344
BIOS.MemSettings.PersistentMemoryScrubbing (Read or Write)..... 344
BIOS.MemSettings.PersistentMemoryType (Read or Write).....345
BIOS.MemSettings.PersistentMemoryType0 (Read or Write).....345
BIOS.MemSettings.PersistentMemoryType1 (Read or Write).....345
BIOS.MemSettings.PersistentMemoryType2 (Read or Write).....345
BIOS.MemSettings.PersistentMemoryType3 (Read or Write).....346
BIOS.MemSettings.PersistentMemPassphrase (Read or Write)..... 346
BIOS.MemSettings.PmControllerRevisionID00 (Read or Write)..... 346
BIOS.MemSettings.PmControllerRevisionID01 (Read or Write).....346
BIOS.MemSettings.PmControllerRevisionID02 (Read or Write).....347
BIOS.MemSettings.PmControllerRevisionID03 (Read or Write).....347
BIOS.MemSettings.PmControllerRevisionID04 (Read or Write).....347
BIOS.MemSettings.PmControllerRevisionID05 (Read or Write)..... 347
BIOS.MemSettings.PmControllerRevisionID06 (Read or Write)..... 348
BIOS.MemSettings.PmControllerRevisionID07 (Read or Write)..... 348
BIOS.MemSettings.PmControllerRevisionID08 (Read or Write)..... 348
BIOS.MemSettings.PmControllerRevisionID09 (Read or Write)..... 348
BIOS.MemSettings.PmControllerRevisionID10 (Read or Write).....349
BIOS.MemSettings.PmControllerRevisionID11 (Read or Write).....349
BIOS.MemSettings.PmControllerRevisionID13 (Read or Write)..... 349
BIOS.MemSettings.PmControllerRevisionID14 (Read or Write)..... 349
BIOS.MemSettings.PmControllerRevisionID15 (Read or Write).....350
BIOS.MemSettings.PmControllerRevisionID17 (Read or Write)..... 350
BIOS.MemSettings.PmControllerRevisionID18 (Read or Write).....350
BIOS.MemSettings.PmControllerRevisionID19 (Read or Write).....350
BIOS.MemSettings.PmControllerRevisionID20 (Read or Write)..... 351
BIOS.MemSettings.PmControllerRevisionID21 (Read or Write).....351
BIOS.MemSettings.PmControllerRevisionID22 (Read or Write)..... 351
BIOS.MemSettings.PmControllerRevisionID23 (Read or Write)..... 351

BIOS.MemSettings.PmLockState00 (Read or Write)....352
BIOS.MemSettings.PmLockState01 (Read or Write)....352
BIOS.MemSettings.PmLockState02 (Read or Write)....352
BIOS.MemSettings.PmLockState03 (Read or Write)....352
BIOS.MemSettings.PmLockState04 (Read or Write)....352
BIOS.MemSettings.PmLockState05 (Read or Write)....353
BIOS.MemSettings.PmLockState06 (Read or Write)....353
BIOS.MemSettings.PmLockState07 (Read or Write)....353
BIOS.MemSettings.PmLockState08 (Read or Write)....353
BIOS.MemSettings.PmLockState09 (Read or Write)....354
BIOS.MemSettings.PmLockState10 (Read or Write)....354
BIOS.MemSettings.PmLockState11 (Read or Write)....354
BIOS.MemSettings.PmLockState12 (Read or Write)....354
BIOS.MemSettings.PmLockState13 (Read or Write)....354
BIOS.MemSettings.PmLockState14 (Read or Write)....355
BIOS.MemSettings.PmLockState15 (Read or Write)....355
BIOS.MemSettings.PmLockState16 (Read or Write)....355
BIOS.MemSettings.PmLockState17 (Read or Write)....355
BIOS.MemSettings.PmLockState18 (Read or Write)....356
BIOS.MemSettings.PmLockState19 (Read or Write)....356
BIOS.MemSettings.PmLockState20 (Read or Write)....356
BIOS.MemSettings.PmLockState21 (Read or Write)....356
BIOS.MemSettings.PmLockState22 (Read or Write)....356
BIOS.MemSettings.PmLockState23 (Read or Write)....357
BIOS.MemSettings.PmMemoryMode (Read or Write)....357
BIOS.MemSettings.PmPersistentPercentage (Read or Write)....357
BIOS.MemSettings.PmSecureEraseAll (Read or Write)....357
BIOS.MemSettings.PmSocket0 (Read or Write)....358
BIOS.MemSettings.PmSocket1 (Read or Write)....358
BIOS.MemSettings.PmSocket2 (Read or Write)....358
BIOS.MemSettings.PmSocket3 (Read or Write)....358
BIOS.MemSettings.Pool00 (Read or Write)....358
BIOS.MemSettings.Pool01 (Read or Write)....359
BIOS.MemSettings.Pool02 (Read or Write)....359
BIOS.MemSettings.Pool03 (Read or Write)....359
BIOS.MemSettings.Pool04 (Read or Write)....359
BIOS.MemSettings.PoolCapacity0 (Read or Write)....359
BIOS.MemSettings.PoolCapacity1 (Read or Write)....360
BIOS.MemSettings.PoolCapacity2 (Read or Write)....360
BIOS.MemSettings.PoolCapacity3 (Read or Write)....360
BIOS.MemSettings.PoolID (Read or Write)....360
BIOS.MemSettings.PoolID0 (Read or Write)....360
BIOS.MemSettings.PoolID1 (Read or Write)....361
BIOS.MemSettings.PoolID2 (Read or Write)....361
BIOS.MemSettings.PoolID3 (Read or Write)....361
BIOS.MemSettings.Pools (Read or Write)....361
BIOS.MemSettings.ProcEmbMemCacheSize (Read or Write)....362
BIOS.MemSettings.ProcEmbMemMode (Read or Write)....362
BIOS.MemSettings.ProcEmbMemSystemSize (Read or Write)....362
BIOS.MemSettings.ProcEmbMemTotalSize (Read or Write)....362

BIOS.MemSettings.RawCapacity (Read or Write)....363
BIOS.MemSettings.RedundantMem (Read or Write)....363
BIOS.MemSettings.RedundantMemCfgValid (Read or Write)....363
BIOS.MemSettings.RedundantMemInUse (Read or Write)....363
BIOS.MemSettings.RemainingRatedWriteEndurance0 (Read or Write)....364
BIOS.MemSettings.RemainingRatedWriteEndurance1 (Read or Write)....364
BIOS.MemSettings.RemainingRatedWriteEndurance10 (Read or Write)....364
BIOS.MemSettings.RemainingRatedWriteEndurance11 (Read or Write)....364
BIOS.MemSettings.RemainingRatedWriteEndurance12 (Read or Write)....365
BIOS.MemSettings.RemainingRatedWriteEndurance13 (Read or Write)....365
BIOS.MemSettings.RemainingRatedWriteEndurance14 (Read or Write)....365
BIOS.MemSettings.RemainingRatedWriteEndurance15 (Read or Write)....365
BIOS.MemSettings.RemainingRatedWriteEndurance16 (Read or Write)....366
BIOS.MemSettings.RemainingRatedWriteEndurance17 (Read or Write)....366
BIOS.MemSettings.RemainingRatedWriteEndurance18 (Read or Write)....366
BIOS.MemSettings.RemainingRatedWriteEndurance19 (Read or Write)....366
BIOS.MemSettings.RemainingRatedWriteEndurance2 (Read or Write)....367
BIOS.MemSettings.RemainingRatedWriteEndurance20 (Read or Write)....367
BIOS.MemSettings.RemainingRatedWriteEndurance21 (Read or Write)....367
BIOS.MemSettings.RemainingRatedWriteEndurance22 (Read or Write)....367
BIOS.MemSettings.RemainingRatedWriteEndurance23 (Read or Write)....368
BIOS.MemSettings.RemainingRatedWriteEndurance3 (Read or Write)....368
BIOS.MemSettings.RemainingRatedWriteEndurance4 (Read or Write)....368
BIOS.MemSettings.RemainingRatedWriteEndurance5 (Read or Write)....368
BIOS.MemSettings.RemainingRatedWriteEndurance6 (Read or Write)....369
BIOS.MemSettings.RemainingRatedWriteEndurance7 (Read or Write)....369
BIOS.MemSettings.RemainingRatedWriteEndurance8 (Read or Write)....369
BIOS.MemSettings.RemainingRatedWriteEndurance9 (Read or Write)....369
BIOS.MemSettings.SanitizeStatus00 (Read or Write)....370
BIOS.MemSettings.SanitizeStatus01 (Read or Write)....370
BIOS.MemSettings.SanitizeStatus02 (Read or Write)....370
BIOS.MemSettings.SanitizeStatus03 (Read or Write)....370
BIOS.MemSettings.SanitizeStatus04 (Read or Write)....370
BIOS.MemSettings.SanitizeStatus05 (Read or Write)....371
BIOS.MemSettings.SanitizeStatus06 (Read or Write)....371
BIOS.MemSettings.SanitizeStatus07 (Read or Write)....371
BIOS.MemSettings.SanitizeStatus08 (Read or Write)....371
BIOS.MemSettings.SanitizeStatus09 (Read or Write)....371
BIOS.MemSettings.SanitizeStatus10 (Read or Write)....372
BIOS.MemSettings.SanitizeStatus11 (Read or Write)....372
BIOS.MemSettings.SanitizeStatus12 (Read or Write)....372
BIOS.MemSettings.SanitizeStatus13 (Read or Write)....372
BIOS.MemSettings.SanitizeStatus14 (Read or Write)....372
BIOS.MemSettings.SanitizeStatus15 (Read or Write)....373
BIOS.MemSettings.SanitizeStatus16 (Read or Write)....373
BIOS.MemSettings.SanitizeStatus17 (Read or Write)....373
BIOS.MemSettings.SanitizeStatus18 (Read or Write)....373
BIOS.MemSettings.SanitizeStatus19 (Read or Write)....374
BIOS.MemSettings.SanitizeStatus20 (Read or Write)....374
BIOS.MemSettings.SanitizeStatus21 (Read or Write)....374

BIOS.MemSettings.SanitizeStatus22 (Read or Write)....374
BIOS.MemSettings.SanitizeStatus23 (Read or Write)....374
BIOS.MemSettings.SecureErase00 (Read or Write)....375
BIOS.MemSettings.SecureErase01 (Read or Write)....375
BIOS.MemSettings.SecureErase02 (Read or Write)....375
BIOS.MemSettings.SecureErase03 (Read or Write)....375
BIOS.MemSettings.SecureErase04 (Read or Write)....375
BIOS.MemSettings.SecureErase05 (Read or Write)....376
BIOS.MemSettings.SecureErase06 (Read or Write)....376
BIOS.MemSettings.SecureErase07 (Read or Write)....376
BIOS.MemSettings.SecureErase08 (Read or Write)....376
BIOS.MemSettings.SecureErase09 (Read or Write)....376
BIOS.MemSettings.SecureErase10 (Read or Write)....377
BIOS.MemSettings.SecureErase11 (Read or Write)....377
BIOS.MemSettings.SecureErase12 (Read or Write)....377
BIOS.MemSettings.SecureErase13 (Read or Write)....377
BIOS.MemSettings.SecureErase14 (Read or Write)....378
BIOS.MemSettings.SecureErase15 (Read or Write)....378
BIOS.MemSettings.SecureErase16 (Read or Write)....378
BIOS.MemSettings.SecureErase17 (Read or Write)....378
BIOS.MemSettings.SecureErase18 (Read or Write)....378
BIOS.MemSettings.SecureErase19 (Read or Write)....379
BIOS.MemSettings.SecureErase20 (Read or Write)....379
BIOS.MemSettings.SecureErase21 (Read or Write)....379
BIOS.MemSettings.SecureErase22 (Read or Write)....379
BIOS.MemSettings.SecureErase23 (Read or Write)....379
BIOS.MemSettings.SerialNumber00 (Read or Write)....380
BIOS.MemSettings.SerialNumber01 (Read or Write)....380
BIOS.MemSettings.SerialNumber02 (Read or Write)....380
BIOS.MemSettings.SerialNumber03 (Read or Write)....380
BIOS.MemSettings.SerialNumber04 (Read or Write)....380
BIOS.MemSettings.SerialNumber05 (Read or Write)....381
BIOS.MemSettings.SerialNumber06 (Read or Write)....381
BIOS.MemSettings.SerialNumber07 (Read or Write)....381
BIOS.MemSettings.SerialNumber08 (Read or Write)....381
BIOS.MemSettings.SerialNumber09 (Read or Write)....382
BIOS.MemSettings.SerialNumber10 (Read or Write)....382
BIOS.MemSettings.SerialNumber11 (Read or Write)....382
BIOS.MemSettings.SerialNumber12 (Read or Write)....382
BIOS.MemSettings.SerialNumber13 (Read or Write)....382
BIOS.MemSettings.SerialNumber14 (Read or Write)....383
BIOS.MemSettings.SerialNumber15 (Read or Write)....383
BIOS.MemSettings.SerialNumber16 (Read or Write)....383
BIOS.MemSettings.SerialNumber17 (Read or Write)....383
BIOS.MemSettings.SerialNumber18 (Read or Write)....383
BIOS.MemSettings.SerialNumber19 (Read or Write)....384
BIOS.MemSettings.SerialNumber20 (Read or Write)....384
BIOS.MemSettings.SerialNumber21 (Read or Write)....384
BIOS.MemSettings.SerialNumber22 (Read or Write)....384
BIOS.MemSettings.SerialNumber23 (Read or Write)....384

BIOS.MemSettings.SnoopFilter (Read or Write)....385
BIOS.MemSettings.SnoopMode (Read or Write)....385
BIOS.MemSettings.SocketID0 (Read or Write)....385
BIOS.MemSettings.SocketID1 (Read or Write)....385
BIOS.MemSettings.SocketID2 (Read or Write)....386
BIOS.MemSettings.SocketID3 (Read or Write)....386
BIOS.MemSettings.SpeedMHz00 (Read or Write)....386
BIOS.MemSettings.SpeedMHz01 (Read or Write)....386
BIOS.MemSettings.SpeedMHz02 (Read or Write)....386
BIOS.MemSettings.SpeedMHz03 (Read or Write)....387
BIOS.MemSettings.SpeedMHz04 (Read or Write)....387
BIOS.MemSettings.SpeedMHz05 (Read or Write)....387
BIOS.MemSettings.SpeedMHz06 (Read or Write)....387
BIOS.MemSettings.SpeedMHz07 (Read or Write)....388
BIOS.MemSettings.SpeedMHz08 (Read or Write)....388
BIOS.MemSettings.SpeedMHz09 (Read or Write)....388
BIOS.MemSettings.SpeedMHz10 (Read or Write)....388
BIOS.MemSettings.SpeedMHz11 (Read or Write)....388
BIOS.MemSettings.SpeedMHz12 (Read or Write)....389
BIOS.MemSettings.SpeedMHz13 (Read or Write)....389
BIOS.MemSettings.SpeedMHz14 (Read or Write)....389
BIOS.MemSettings.SpeedMHz15 (Read or Write)....389
BIOS.MemSettings.SpeedMHz16 (Read or Write)....389
BIOS.MemSettings.SpeedMHz17 (Read or Write)....390
BIOS.MemSettings.SpeedMHz18 (Read or Write)....390
BIOS.MemSettings.SpeedMHz19 (Read or Write)....390
BIOS.MemSettings.SpeedMHz20 (Read or Write)....390
BIOS.MemSettings.SpeedMHz21 (Read or Write)....390
BIOS.MemSettings.SpeedMHz22 (Read or Write)....391
BIOS.MemSettings.SpeedMHz23 (Read or Write)....391
BIOS.MemSettings.SysMemSize (Read or Write)....391
BIOS.MemSettings.SysMemSpeed (Read or Write)....391
BIOS.MemSettings.SysMemType (Read or Write)....392
BIOS.MemSettings.SysMemVolt (Read or Write)....392
BIOS.MemSettings.SystemMemoryModel (Read or Write)....392
BIOS.MemSettings.UnconfiguredCapacity (Read or Write)....392
BIOS.MemSettings.VideoMem (Read or Write)....392
BIOS.MiscSettings....393
BIOS.MiscSettings.AssetTag (Read or Write)....393
BIOS.MiscSettings.CapsuleFirmwareUpdate (Read or Write)....393
BIOS.MiscSettings.DellWyseP25BIOSAccess (Read or Write)....393
BIOS.MiscSettings.ErrPrompt (Read or Write)....394
BIOS.MiscSettings.ForceInt10 (Read or Write)....394
BIOS.MiscSettings.InSystemCharacterization (Read or Write)....394
BIOS.MiscSettings.MiscSettings (Read or Write)....394
BIOS.MiscSettings.NumLock (Read or Write)....395
BIOS.MiscSettings.PowerCycleRequest (Read or Write)....395
BIOS.MiscSettings.ReportKbdErr (Read or Write)....395
BIOS.MiscSettings.SysMgmtNVByte1 (Read or Write)....395
BIOS.MiscSettings.SysMgmtNVByte2 (Read or Write)....396

BIOS.MiscSettings.SystemUefiShell (Read or Write)....396
BIOS.NetworkSettings....396
BIOS.NetworkSettings.HttpDev1EnDis (Read or Write)....396
BIOS.NetworkSettings.HttpDev1SettingsRef (Read or Write)....396
BIOS.NetworkSettings.HttpDev2EnDis (Read or Write)....396
BIOS.NetworkSettings.HttpDev2SettingsRef (Read or Write)....397
BIOS.NetworkSettings.HttpDev3EnDis (Read or Write)....397
BIOS.NetworkSettings.HttpDev3SettingsRef (Read or Write)....397
BIOS.NetworkSettings.HttpDev4EnDis (Read or Write)....397
BIOS.NetworkSettings.HttpDev4SettingsRef (Read or Write)....398
BIOS.NetworkSettings.IscsiDev1EnDis (Read or Write)....398
BIOS.NetworkSettings.IscsiInitiatorName (Read or Write)....398
BIOS.NetworkSettings.PxeDev1EnDis (Read or Write)....398
BIOS.NetworkSettings.PxeDev2EnDis (Read or Write)....398
BIOS.NetworkSettings.PxeDev3EnDis (Read or Write)....399
BIOS.NetworkSettings.PxeDev4EnDis (Read or Write)....399
BIOS.OneTimeBoot....399
BIOS.OneTimeBoot.OneTimeBiosBootSeq (Read or Write)....399
BIOS.OneTimeBoot.OneTimeBoot (Read or Write)....399
BIOS.OneTimeBoot.OneTimeBootMode (Read or Write)....400
BIOS.OneTimeBoot.OneTimeBootModeSeq (Read or Write)....400
BIOS.OneTimeBoot.OneTimeBootSeqDev (Read or Write)....400
BIOS.OneTimeBoot.OneTimeCustomBootStr (Read or Write)....400
BIOS.OneTimeBoot.OneTimeHddSeq (Read or Write)....401
BIOS.OneTimeBoot.OneTimeHddSeqDev (Read or Write)....401
BIOS.OneTimeBoot.OneTimeUefiBootPath (Read or Write)....401
BIOS.OneTimeBoot.OneTimeUefiBootSeq (Read or Write)....401
BIOS.OneTimeBoot.OneTimeUefiBootSeqDev (Read or Write)....402
BIOS.PowerMgmtSettings....402
BIOS.PowerMgmtSettings.FanPwrPerf (Read or Write)....402
BIOS.PowerMgmtSettings.MemDynamicPwr (Read or Write)....402
BIOS.PowerMgmtSettings.MemPwrPerf (Read or Write)....402
BIOS.PowerMgmtSettings.PowerMgmt (Read or Write)....403
BIOS.PowerMgmtSettings.PowerMgmtSettings (Read or Write)....403
BIOS.ProcSettings....403
BIOS.ProcSettings.ControlledTurbo (Read or Write)....403
BIOS.ProcSettings.ControlledTurboExtended (Read or Write)....403
BIOS.ProcSettings.ControlledTurboMinusBin (Read or Write)....404
BIOS.ProcSettings.CorePerfBoost (Read or Write)....404
BIOS.ProcSettings.CpuInterconnectBusSpeed (Read or Write)....404
BIOS.ProcSettings.CpuMinSevAsid (Read or Write)....404
BIOS.ProcSettings.DataReuse (Read or Write)....405
BIOS.ProcSettings.DcuIpPrefetcher (Read or Write)....405
BIOS.ProcSettings.DcuStreamerPrefetcher (Read or Write)....405
BIOS.ProcSettings.DmaVirtualization (Read or Write)....405
BIOS.ProcSettings.DynamicCoreAllocation (Read or Write)....406
BIOS.ProcSettings.L1Prefetcher (Read or Write)....406
BIOS.ProcSettings.L2Prefetcher (Read or Write)....406
BIOS.ProcSettings.LogicalProc (Read or Write)....406
BIOS.ProcSettings.MadtCoreEnumeration (Read or Write)....407

BIOS.ProcSettings.NumaDistanceEnum (Read or Write)..... 407
BIOS.ProcSettings.PerfMonitorDevices (Read or Write)..... 407
BIOS.ProcSettings.Proc1Brand (Read or Write)..... 407
BIOS.ProcSettings.Proc1ControlledTurbo (Read or Write)..... 408
BIOS.ProcSettings.Proc1ControlledTurboMinusBin (Read or Write)..... 408
BIOS.ProcSettings.Proc1Cores (Read or Write)..... 408
BIOS.ProcSettings.Proc1Id (Read or Write)..... 408
BIOS.ProcSettings.Proc1L2Cache (Read or Write)..... 409
BIOS.ProcSettings.Proc1L3Cache (Read or Write)..... 409
BIOS.ProcSettings.Proc1MaxMemoryCapacity (Read or Write)..... 409
BIOS.ProcSettings.Proc1Microcode (Read or Write)..... 409
BIOS.ProcSettings.Proc1NumCores (Read or Write)..... 409
BIOS.ProcSettings.Proc2Brand (Read or Write)..... 410
BIOS.ProcSettings.Proc2ControlledTurbo (Read or Write)..... 410
BIOS.ProcSettings.Proc2ControlledTurboMinusBin (Read or Write)..... 410
BIOS.ProcSettings.Proc2Cores (Read or Write)..... 410
BIOS.ProcSettings.Proc2Id (Read or Write)..... 411
BIOS.ProcSettings.Proc2L2Cache (Read or Write)..... 411
BIOS.ProcSettings.Proc2L3Cache (Read or Write)..... 411
BIOS.ProcSettings.Proc2MaxMemoryCapacity (Read or Write)..... 411
BIOS.ProcSettings.Proc2Microcode (Read or Write)..... 411
BIOS.ProcSettings.Proc2NumCores (Read or Write)..... 412
BIOS.ProcSettings.Proc3Brand (Read or Write)..... 412
BIOS.ProcSettings.Proc3ControlledTurbo (Read or Write)..... 412
BIOS.ProcSettings.Proc3ControlledTurboMinusBin (Read or Write)..... 412
BIOS.ProcSettings.Proc3Cores (Read or Write)..... 413
BIOS.ProcSettings.Proc3Id (Read or Write)..... 413
BIOS.ProcSettings.Proc3L2Cache (Read or Write)..... 413
BIOS.ProcSettings.Proc3L3Cache (Read or Write)..... 413
BIOS.ProcSettings.Proc3MaxMemoryCapacity (Read or Write)..... 413
BIOS.ProcSettings.Proc3Microcode (Read or Write)..... 414
BIOS.ProcSettings.Proc3NumCores (Read or Write)..... 414
BIOS.ProcSettings.Proc4Brand (Read or Write)..... 414
BIOS.ProcSettings.Proc4ControlledTurbo (Read or Write)..... 414
BIOS.ProcSettings.Proc4ControlledTurboMinusBin (Read or Write)..... 415
BIOS.ProcSettings.Proc4Cores (Read or Write)..... 415
BIOS.ProcSettings.Proc4Id (Read or Write)..... 415
BIOS.ProcSettings.Proc4L2Cache (Read or Write)..... 415
BIOS.ProcSettings.Proc4L3Cache (Read or Write)..... 415
BIOS.ProcSettings.Proc4MaxMemoryCapacity (Read or Write)..... 416
BIOS.ProcSettings.Proc4Microcode (Read or Write)..... 416
BIOS.ProcSettings.Proc4NumCores (Read or Write)..... 416
BIOS.ProcSettings.Proc64bit (Read or Write)..... 416
BIOS.ProcSettings.ProcAdjCacheLine (Read or Write)..... 417
BIOS.ProcSettings.ProcAts (Read or Write)..... 417
BIOS.ProcSettings.ProcBusSpeed (Read or Write)..... 417
BIOS.ProcSettings.ProcConfigTdp (Read or Write)..... 417
BIOS.ProcSettings.ProcCores (Read or Write)..... 417
BIOS.ProcSettings.ProcCoreSpeed (Read or Write)..... 418
BIOS.ProcSettings.ProcCoresPerDie (Read or Write)..... 418

BIOS.ProcSettings.ProcDramPrefetcher (Read or Write)....418
BIOS.ProcSettings.ProcExecuteDisable (Read or Write)....418
BIOS.ProcSettings.ProcHpcMode (Read or Write)....419
BIOS.ProcSettings.ProcHtAssist (Read or Write)....419
BIOS.ProcSettings.ProcHwPrefetcher (Read or Write)....419
BIOS.ProcSettings.ProcHyperTransport (Read or Write)....419
BIOS.ProcSettings.ProcSettings (Read or Write)....420
BIOS.ProcSettings.ProcSoftwarePrefetcher (Read or Write)....420
BIOS.ProcSettings.ProcSwPrefetcher (Read or Write)....420
BIOS.ProcSettings.ProcVirtualization (Read or Write)....420
BIOS.ProcSettings.ProcX2Apic (Read or Write)....421
BIOS.ProcSettings.QpiBandwidthPriority (Read or Write)....421
BIOS.ProcSettings.QpiSpeed (Read or Write)....421
BIOS.ProcSettings.RtidSetting (Read or Write)....421
BIOS.ProcSettings.SubNumaCluster (Read or Write)....422
BIOS.ProcSettings.UpiPrefetch (Read or Write)....422
BIOS.PxeDev1Settings....422
BIOS.PxeDev1Settings.PxeDev1Interface (Read or Write)....422
BIOS.PxeDev1Settings.PxeDev1Protocol (Read or Write)....422
BIOS.PxeDev1Settings.PxeDev1VlanEnDis (Read or Write)....423
BIOS.PxeDev1Settings.PxeDev1VlanId (Read or Write)....423
BIOS.PxeDev1Settings.PxeDev1VlanPriority (Read or Write)....423
BIOS.PxeDev2Settings....423
BIOS.PxeDev2Settings.PxeDev2Interface (Read or Write)....423
BIOS.PxeDev2Settings.PxeDev2Protocol (Read or Write)....424
BIOS.PxeDev2Settings.PxeDev2VlanEnDis (Read or Write)....424
BIOS.PxeDev2Settings.PxeDev2VlanId (Read or Write)....424
BIOS.PxeDev2Settings.PxeDev2VlanPriority (Read or Write)....424
BIOS.PxeDev3Settings....424
BIOS.PxeDev3Settings.PxeDev3Interface (Read or Write)....424
BIOS.PxeDev3Settings.PxeDev3Protocol (Read or Write)....425
BIOS.PxeDev3Settings.PxeDev3VlanEnDis (Read or Write)....425
BIOS.PxeDev3Settings.PxeDev3VlanId (Read or Write)....425
BIOS.PxeDev3Settings.PxeDev3VlanPriority (Read or Write)....425
BIOS.PxeDev4Settings....426
BIOS.PxeDev4Settings.PxeDev4Interface (Read or Write)....426
BIOS.PxeDev4Settings.PxeDev4Protocol (Read or Write)....426
BIOS.PxeDev4Settings.PxeDev4VlanEnDis (Read or Write)....426
BIOS.PxeDev4Settings.PxeDev4VlanId (Read or Write)....426
BIOS.PxeDev4Settings.PxeDev4VlanPriority (Read or Write)....427
BIOS.RedundantOsControl....427
BIOS.RedundantOsControl.RedundantOsBoot (Read or Write)....427
BIOS.RedundantOsControl.RedundantOsLocation (Read or Write)....427
BIOS.RedundantOsControl.RedundantOsState (Read or Write)....427
BIOS.SataSettings....428
BIOS.SataSettings.EmbSata (Read or Write)....428
BIOS.SataSettings.EmbSataShadow (Read or Write)....428
BIOS.SataSettings.eSataPort1 (Read or Write)....428
BIOS.SataSettings.eSataPort1Capacity (Read or Write)....428
BIOS.SataSettings.eSataPort1DriveType (Read or Write)....429

BIOS.SataSettings.eSataPort1Model (Read or Write)....429
BIOS.SataSettings.SataPortA (Read or Write)....429
BIOS.SataSettings.SataPortACapacity (Read or Write)....429
BIOS.SataSettings.SataPortADriveType (Read or Write)....430
BIOS.SataSettings.SataPortAModel (Read or Write)....430
BIOS.SataSettings.SataPortB (Read or Write)....430
BIOS.SataSettings.SataPortBCapacity (Read or Write)....430
BIOS.SataSettings.SataPortBDriveType (Read or Write)....430
BIOS.SataSettings.SataPortBModel (Read or Write)....431
BIOS.SataSettings.SataPortC (Read or Write)....431
BIOS.SataSettings.SataPortCCapacity (Read or Write)....431
BIOS.SataSettings.SataPortCDriveType (Read or Write)....431
BIOS.SataSettings.SataPortCModel (Read or Write)....432
BIOS.SataSettings.SataPortD (Read or Write)....432
BIOS.SataSettings.SataPortDCapacity (Read or Write)....432
BIOS.SataSettings.SataPortDDriveType (Read or Write)....432
BIOS.SataSettings.SataPortDModel (Read or Write)....432
BIOS.SataSettings.SataPortE (Read or Write)....433
BIOS.SataSettings.SataPortECapacity (Read or Write)....433
BIOS.SataSettings.SataPortEDriveType (Read or Write)....433
BIOS.SataSettings.SataPortEModel (Read or Write)....433
BIOS.SataSettings.SataPortF (Read or Write)....434
BIOS.SataSettings.SataPortFCapacity (Read or Write)....434
BIOS.SataSettings.SataPortFDriveType (Read or Write)....434
BIOS.SataSettings.SataPortFModel (Read or Write)....434
BIOS.SataSettings.SataPortG (Read or Write)....434
BIOS.SataSettings.SataPortGCapacity (Read or Write)....435
BIOS.SataSettings.SataPortGDriveType (Read or Write)....435
BIOS.SataSettings.SataPortGModel (Read or Write)....435
BIOS.SataSettings.SataPortH (Read or Write)....435
BIOS.SataSettings.SataPortHCapacity (Read or Write)....436
BIOS.SataSettings.SataPortHDriveType (Read or Write)....436
BIOS.SataSettings.SataPortHModel (Read or Write)....436
BIOS.SataSettings.SataPortI (Read or Write)....436
BIOS.SataSettings.SataPortICapacity (Read or Write)....436
BIOS.SataSettings.SataPortIDriveType (Read or Write)....437
BIOS.SataSettings.SataPortIModel (Read or Write)....437
BIOS.SataSettings.SataPortJ (Read or Write)....437
BIOS.SataSettings.SataPortJCapacity (Read or Write)....437
BIOS.SataSettings.SataPortJDriveType (Read or Write)....438
BIOS.SataSettings.SataPortJModel (Read or Write)....438
BIOS.SataSettings.SataPortK (Read or Write)....438
BIOS.SataSettings.SataPortKCapacity (Read or Write)....438
BIOS.SataSettings.SataPortKDriveType (Read or Write)....438
BIOS.SataSettings.SataPortKModel (Read or Write)....439
BIOS.SataSettings.SataPortL (Read or Write)....439
BIOS.SataSettings.SataPortLCapacity (Read or Write)....439
BIOS.SataSettings.SataPortLDriveType (Read or Write)....439
BIOS.SataSettings.SataPortLModel (Read or Write)....440
BIOS.SataSettings.SataPortM (Read or Write)....440

BIOS.SataSettings.SataPortMCapacity (Read or Write)....440
BIOS.SataSettings.SataPortMDriveType (Read or Write)....440
BIOS.SataSettings.SataPortMModel (Read or Write)....440
BIOS.SataSettings.SataPortN (Read or Write)....441
BIOS.SataSettings.SataPortNCapacity (Read or Write)....441
BIOS.SataSettings.SataPortNDriveType (Read or Write)....441
BIOS.SataSettings.SataPortNModel (Read or Write)....441
BIOS.SataSettings.SataSettings (Read or Write)....442
BIOS.SataSettings.SecurityFreezeLock (Read or Write)....442
BIOS.SataSettings.WriteCache (Read or Write)....442
BIOS.SerialCommSettings....442
BIOS.SerialCommSettings.ConTermType (Read or Write)....442
BIOS.SerialCommSettings.ExtSerialConnector (Read or Write)....443
BIOS.SerialCommSettings.FailSafeBaud (Read or Write)....443
BIOS.SerialCommSettings.RedirAfterBoot (Read or Write)....443
BIOS.SerialCommSettings.SerialComm (Read or Write)....443
BIOS.SerialCommSettings.SerialCommSettings (Read or Write)....443
BIOS.SerialCommSettings.SerialPortAddress (Read or Write)....444
BIOS.SlotBifurcation....444
BIOS.SlotBifurcation.DellAutoDiscovery (Read or Write)....444
BIOS.SlotBifurcation.Slot10Bif (Read or Write)....444
BIOS.SlotBifurcation.Slot11Bif (Read or Write)....445
BIOS.SlotBifurcation.Slot12Bif (Read or Write)....445
BIOS.SlotBifurcation.Slot13Bif (Read or Write)....445
BIOS.SlotBifurcation.Slot14Bif (Read or Write)....445
BIOS.SlotBifurcation.Slot1Bif (Read or Write)....446
BIOS.SlotBifurcation.Slot2Bif (Read or Write)....446
BIOS.SlotBifurcation.Slot3Bif (Read or Write)....446
BIOS.SlotBifurcation.Slot4Bif (Read or Write)....447
BIOS.SlotBifurcation.Slot5Bif (Read or Write)....447
BIOS.SlotBifurcation.Slot6Bif (Read or Write)....447
BIOS.SlotBifurcation.Slot7Bif (Read or Write)....447
BIOS.SlotBifurcation.Slot8Bif (Read or Write)....448
BIOS.SlotBifurcation.Slot9Bif (Read or Write)....448
BIOS.SlotBifurcation.SlotBifurcation (Read or Write)....448
BIOS.SlotDisablement....449
BIOS.SlotDisablement.Slot1 (Read or Write)....449
BIOS.SlotDisablement.Slot10 (Read or Write)....449
BIOS.SlotDisablement.Slot11 (Read or Write)....449
BIOS.SlotDisablement.Slot12 (Read or Write)....450
BIOS.SlotDisablement.Slot13 (Read or Write)....450
BIOS.SlotDisablement.Slot2 (Read or Write)....450
BIOS.SlotDisablement.Slot3 (Read or Write)....451
BIOS.SlotDisablement.Slot4 (Read or Write)....451
BIOS.SlotDisablement.Slot5 (Read or Write)....452
BIOS.SlotDisablement.Slot6 (Read or Write)....452
BIOS.SlotDisablement.Slot7 (Read or Write)....452
BIOS.SlotDisablement.Slot8 (Read or Write)....453
BIOS.SlotDisablement.Slot9 (Read or Write)....453
BIOS.SlotDisablement.SlotDisablement (Read or Write)....453

BIOS.SysInformation....454
BIOS.SysInformation.SysInformation (Read or Write)....454
BIOS.SysInformation.SysMfrContactInfo (Read or Write)....454
BIOS.SysInformation.SystemBiosVersion (Read or Write)....454
BIOS.SysInformation.SystemCpldVersion (Read or Write)....454
BIOS.SysInformation.SystemManufacturer (Read or Write)....455
BIOS.SysInformation.SystemMeVersion (Read or Write)....455
BIOS.SysInformation.SystemModelName (Read or Write)....455
BIOS.SysInformation.SystemServiceTag (Read or Write)....455
BIOS.SysInformation.UefiComplianceVersion (Read or Write)....455
BIOS.SysProfileSettings....456
BIOS.SysProfileSettings.CollaborativeCpuPerfCtrl (Read or Write)....456
BIOS.SysProfileSettings.CpuInterconnectBusLinkPower (Read or Write)....456
BIOS.SysProfileSettings.DeterminismSlider (Read or Write)....456
BIOS.SysProfileSettings.EnergyEfficientTurbo (Read or Write)....457
BIOS.SysProfileSettings.EnergyPerformanceBias (Read or Write)....457
BIOS.SysProfileSettings.MemFrequency (Read or Write)....457
BIOS.SysProfileSettings.MemPatrolScrub (Read or Write)....457
BIOS.SysProfileSettings.MemPwrMgmt (Read or Write)....458
BIOS.SysProfileSettings.MemRefreshRate (Read or Write)....458
BIOS.SysProfileSettings.MemVolt (Read or Write)....458
BIOS.SysProfileSettings.MonitorMwait (Read or Write)....458
BIOS.SysProfileSettings.PcieAspmL1 (Read or Write)....459
BIOS.SysProfileSettings.PowerDelivery (Read or Write)....459
BIOS.SysProfileSettings.PowerSaver (Read or Write)....459
BIOS.SysProfileSettings.Proc1TurboCoreNum (Read or Write)....459
BIOS.SysProfileSettings.Proc2TurboCoreNum (Read or Write)....460
BIOS.SysProfileSettings.Proc3TurboCoreNum (Read or Write)....460
BIOS.SysProfileSettings.Proc4TurboCoreNum (Read or Write)....460
BIOS.SysProfileSettings.ProcC1E (Read or Write)....460
BIOS.SysProfileSettings.ProcCStates (Read or Write)....461
BIOS.SysProfileSettings.ProcPwrPerf (Read or Write)....461
BIOS.SysProfileSettings.ProcTurboMode (Read or Write)....461
BIOS.SysProfileSettings.SysProfile (Read or Write)....462
BIOS.SysProfileSettings.SysProfileSettings (Read or Write)....462
BIOS.SysProfileSettings.UncoreFrequency (Read or Write)....462
BIOS.SysProfileSettings.WorkloadProfile (Read or Write)....463
BIOS.SysProfileSettings.WriteDataCrc (Read or Write)....463
BIOS.SysSecurity....463
BIOS.SysSecurity.AcPwrRcvry (Read or Write)....463
BIOS.SysSecurity.AcPwrRcvryDelay (Read or Write)....463
BIOS.SysSecurity.AcPwrRcvryUserDelay (Read or Write)....464
BIOS.SysSecurity.AesNi (Read or Write)....464
BIOS.SysSecurity.AuthorizeDeviceFirmware (Read or Write)....464
BIOS.SysSecurity.BiosUpdateControl (Read or Write)....464
BIOS.SysSecurity.BootmanagerPassword (Read or Write)....465
BIOS.SysSecurity.InBandManageabilityInterface (Read or Write)....465
BIOS.SysSecurity.IntelSgx (Read or Write)....465
BIOS.SysSecurity.IntelTxt (Read or Write)....465
BIOS.SysSecurity.NewSetupPassword (Read or Write)....466

BIOS.SysSecurity.NewSysPassword (Read or Write)..... 466
BIOS.SysSecurity.NmiButton (Read or Write)..... 466
BIOS.SysSecurity.OldSetupPassword (Read or Write)..... 466
BIOS.SysSecurity.OldSysPassword (Read or Write)..... 467
BIOS.SysSecurity.PasswordStatus (Read or Write)..... 467
BIOS.SysSecurity.PwrButton (Read or Write)..... 467
BIOS.SysSecurity.SecureBoot (Read or Write)..... 467
BIOS.SysSecurity.SecureBootMode (Read or Write)..... 468
BIOS.SysSecurity.SecureBootPolicy (Read or Write)..... 468
BIOS.SysSecurity.SetupPassword (Read or Write)..... 468
BIOS.SysSecurity.SHA256SetupPassword (Read or Write)..... 468
BIOS.SysSecurity.SHA256SetupPasswordSalt (Read or Write)..... 469
BIOS.SysSecurity.SHA256SystemPassword (Read or Write)..... 469
BIOS.SysSecurity.SHA256SystemPasswordSalt (Read or Write)..... 469
BIOS.SysSecurity.SignedFirmwareUpdate (Read or Write)..... 469
BIOS.SysSecurity.SysPassword (Read or Write)..... 470
BIOS.SysSecurity.SysSecurity (Read or Write)..... 470
BIOS.SysSecurity.TcmActivation (Read or Write)..... 470
BIOS.SysSecurity.TcmClear (Read or Write)..... 470
BIOS.SysSecurity.TcmSecurity (Read or Write)..... 471
BIOS.SysSecurity.Tpm2Hierarchy (Read or Write)..... 471
BIOS.SysSecurity.TpmActivation (Read or Write)..... 471
BIOS.SysSecurity.TpmClear (Read or Write)..... 471
BIOS.SysSecurity.TpmCommand (Read or Write)..... 472
BIOS.SysSecurity.TpmFirmware (Read or Write)..... 472
BIOS.SysSecurity.TpmInfo (Read or Write)..... 472
BIOS.SysSecurity.TpmSecurity (Read or Write)..... 472
BIOS.SysSecurity.TpmStatus (Read or Write)..... 473
BIOS.SysSecurity.UefiVariableAccess (Read or Write)..... 473
BIOS.TpmAdvancedSettings..... 473
BIOS.TpmAdvancedSettings.TpmPpiBypassClear (Read or Write)..... 473
BIOS.TpmAdvancedSettings.Tpm2Algorithm (Read or Write)..... 473
BIOS.TpmAdvancedSettings.TpmPpiBypassProvision (Read or Write)..... 474
BIOS.UefiBootSeqEnDis..... 474
BIOS.UefiBootSeqEnDis.UefiBootSeqEnDis (Read or Write)..... 474
BIOS.UefiBootSettings..... 474
BIOS.UefiBootSettings.UefiBootSeq (Read or Write)..... 474
BIOS.UefiBootSettings.UefiBootSeqEnDis1 (Read or Write)..... 475
BIOS.UefiBootSettings.UefiBootSeqEnDis10 (Read or Write)..... 475
BIOS.UefiBootSettings.UefiBootSeqEnDis11 (Read or Write)..... 475
BIOS.UefiBootSettings.UefiBootSeqEnDis12 (Read or Write)..... 475
BIOS.UefiBootSettings.UefiBootSeqEnDis13 (Read or Write)..... 476
BIOS.UefiBootSettings.UefiBootSeqEnDis14 (Read or Write)..... 476
BIOS.UefiBootSettings.UefiBootSeqEnDis15 (Read or Write)..... 476
BIOS.UefiBootSettings.UefiBootSeqEnDis16 (Read or Write)..... 477
BIOS.UefiBootSettings.UefiBootSeqEnDis17 (Read or Write)..... 477
BIOS.UefiBootSettings.UefiBootSeqEnDis18 (Read or Write)..... 477
BIOS.UefiBootSettings.UefiBootSeqEnDis19 (Read or Write)..... 477
BIOS.UefiBootSettings.UefiBootSeqEnDis2 (Read or Write)..... 478
BIOS.UefiBootSettings.UefiBootSeqEnDis20 (Read or Write)..... 478

BIOS.UefiBootSettings.UefiBootSeqEnDis3 (Read or Write)..... 478
BIOS.UefiBootSettings.UefiBootSeqEnDis4 (Read or Write)..... 479
BIOS.UefiBootSettings.UefiBootSeqEnDis5 (Read or Write)..... 479
BIOS.UefiBootSettings.UefiBootSeqEnDis6 (Read or Write)..... 479
BIOS.UefiBootSettings.UefiBootSeqEnDis7 (Read or Write)..... 479
BIOS.UefiBootSettings.UefiBootSeqEnDis8 (Read or Write)..... 480
BIOS.UefiBootSettings.UefiBootSeqEnDis9 (Read or Write)..... 480
BIOS.UefiBootSettings.UefiBootSeqEnDisRef (Read or Write)..... 480
BIOS.UefiBootSettings.UefiBootSettings (Read or Write)..... 480
BIOS.UefiBootSettings.UefiPxeIpVersion (Read or Write)..... 481

6 NIC Attributes..... 482
NIC.ConfigureFormn..... 482
NIC.ConfigureFormn.FCoEOffloadMode (Read or Write)..... 482
NIC.ConfigureFormn.FIPMacAddr (Read Only)..... 482
NIC.ConfigureFormn.InstanceNumber (Read Only)..... 483
NIC.ConfigureFormn.IscsiFIPMacAddr (Read Only)..... 483
NIC.ConfigureFormn.IscsiMacAddr (Read Only)..... 483
NIC.ConfigureFormn.iScsiOffloadMode (Read or Write)..... 483
NIC.ConfigureFormn.L2FIPMacAddr (Read Only)..... 484
NIC.ConfigureFormn.L2IscsiFIPMacAddr (Read Only)..... 484
NIC.ConfigureFormn.L2IscsiMacAddr (Read Only)..... 484
NIC.ConfigureFormn.MacAddr (Read Only)..... 484
NIC.ConfigureFormn.NicMode (Read or Write)..... 485
NIC.ConfigureFormn.NumberVFAdvertised (Read or Write)..... 485
NIC.ConfigureFormn.NumberVFSupported (Read Only)..... 485
NIC.ConfigureFormn.PCIDeviceID (Read Only)..... 485
NIC.ConfigureFormn.PortNumber (Read Only)..... 486
NIC.ConfigureFormn.SVID (Read or Write)..... 486
NIC.ConfigureFormn.VirtFIPMacAddr (Read or Write)..... 486
NIC.ConfigureFormn.VirtIscsiFIPMacAddr (Read or Write)..... 486
NIC.ConfigureFormn.VirtIscsiMacAddr (Read or Write)..... 487
NIC.ConfigureFormn.VirtL2FIPMacAddr (Read or Write)..... 487
NIC.ConfigureFormn.VirtL2IscsiFIPMacAddr (Read or Write)..... 487
NIC.ConfigureFormn.VirtL2IscsiMacAddr (Read or Write)..... 488
NIC.ConfigureFormn.VirtMacAddr (Read or Write)..... 488
NIC.ConfigureFormn.VirtWWN (Read or Write)..... 488
NIC.ConfigureFormn.VirtWWPN (Read or Write)..... 488
NIC.ConfigureFormn.WWN (Read Only)..... 489
NIC.ConfigureFormn.WWPN (Read Only)..... 489
NIC.DCBSettings..... 489
NIC.DCBSettings.CongestionNotification (Read Only)..... 489
NIC.DCBSettings.EnhancedTransmissionSelection (Read Only)..... 489
NIC.DCBSettings.LocalDCBXWillingMode (Read or Write)..... 490
NIC.DCBSettings.PriorityFlowControl (Read Only)..... 490
NIC.DCBSettings.PriorityGroup0BandwidthAllocation (Read or Write)..... 490
NIC.DCBSettings.PriorityGroup0ProtocolAssignment (Read or Write)..... 490
NIC.DCBSettings.PriorityGroup15BandwidthAllocation (Read or Write)..... 491
NIC.DCBSettings.PriorityGroup15ProtocolAssignment (Read or Write)..... 491
NIC.DCBSettings.PriorityGroup1BandwidthAllocation (Read or Write)..... 491

NIC.DCBSettings.PriorityGroup1ProtocolAssignment (Read or Write)....492
NIC.DCBSettings.PriorityGroup2BandwidthAllocation (Read or Write)....492
NIC.DCBSettings.PriorityGroup2ProtocolAssignment (Read or Write)....492
NIC.DCBSettings.PriorityGroup3BandwidthAllocation (Read or Write)....492
NIC.DCBSettings.PriorityGroup3ProtocolAssignment (Read or Write)....493
NIC.DCBSettings.PriorityGroup4BandwidthAllocation (Read or Write)....493
NIC.DCBSettings.PriorityGroup5BandwidthAllocation (Read or Write)....493
NIC.DCBSettings.PriorityGroup5ProtocolAssignment (Read or Write)....494
NIC.DCBSettings.PriorityGroup6BandwidthAllocation (Read or Write)....494
NIC.DCBSettings.PriorityGroup6ProtocolAssignment (Read or Write)....494
NIC.DCBSettings.PriorityGroup7BandwidthAllocation (Read or Write)....494
NIC.DCBSettings.PriorityGroup7ProtocolAssignment (Read or Write)....495
NIC.DCBSettings.PriorityGroupBandwidthAllocation (Read or Write)....495
NIC.DCBSettings.PriorityGroup4ProtocolAssignment (Read or Write)....495
NIC.DeviceLevelConfig....496
NIC.DeviceLevelConfig.ConfigureLogicalPortsSupport (Read Only)....496
NIC.DeviceLevelConfig.EVBModesSupport (Read Only)....496
NIC.DeviceLevelConfig.MaxNumberVFSupportedByDevice (Read Only)....496
NIC.DeviceLevelConfig.NetworkPartitioningMode (Read or Write)....497
NIC.DeviceLevelConfig.NICPartitioningConfig (Read Only)....497
NIC.DeviceLevelConfig.NParEP (Read or Write)....497
NIC.DeviceLevelConfig.NPCP (Read or Write)....497
NIC.DeviceLevelConfig.NumberPCIFunctionsSupported (Read Only)....498
NIC.DeviceLevelConfig.NumberVFSupported (Read Only)....498
NIC.DeviceLevelConfig.PartitionStateInterpretation (Read Only)....498
NIC.DeviceLevelConfig.RDMAApplicationProfile (Read or Write)....498
NIC.DeviceLevelConfig.RDMAProtocolSupport (Read Only)....499
NIC.DeviceLevelConfig.RDMASupport (Read Only)....499
NIC.DeviceLevelConfig.SRIOVSupport (Read Only)....499
NIC.DeviceLevelConfig.TotalNumberLogicalPorts (Read or Write)....500
NIC.DeviceLevelConfig.VFAllocBasis (Read Only)....500
NIC.DeviceLevelConfig.VFAllocMult (Read Only)....500
NIC.DeviceLevelConfig.VirtualizationMode (Read or Write)....500
NIC.FCOECapabilities....501
NIC.FCOECapabilities.AddressingMode (Read Only)....501
NIC.FCOECapabilities.MaxFrameSize (Read Only)....501
NIC.FCOECapabilities.MaxIOsPerSession (Read Only)....501
NIC.FCOECapabilities.MaxNPIVPerPort (Read Only)....501
NIC.FCOECapabilities.MaxNumberExchanges (Read Only)....502
NIC.FCOECapabilities.MaxNumberLogins (Read Only)....502
NIC.FCOECapabilities.MaxNumberOfFCTargets (Read Only)....502
NIC.FCOECapabilities.MaxNumberOutStandingCommands (Read Only)....502
NIC.FCOECapabilities.MTUReconfigurationSupport (Read Only)....503
NIC.FCOEConfiguration....503
NIC.FCoEConfiguration.BootOrderFirstFCoETarget (Read or Write)....503
NIC.FCoEConfiguration.BootOrderFourthFCoETarget (Read or Write)....503
NIC.FCoEConfiguration.BootOrderSecondFCoETarget (Read or Write)....504
NIC.FCoEConfiguration.BootOrderThirdFCoETarget (Read or Write)....504
NIC.FCoEConfiguration.ConnectFirstFCoETarget (Read or Write)....504
NIC.FCoEConfiguration.FCoEGenParams (Read Only)....504

NIC.FCoEConfiguration.FCoEGenParamsRef (Read Only)..... 505
NIC.FCoEConfiguration.FirstFCoEBootTargetLUN (Read or Write).....505
NIC.FCoEConfiguration.FirstFCoEFCFVLANID (Read or Write)..... 505
NIC.FCoEConfiguration.FirstFCoEWWPNTarget (Read or Write).....505
NIC.FCoEConfiguration.MTUParams (Read or Write)..... 506
NIC.FCOEGenParams..... 506
NIC.FCoEGenParams.FCoEBootScanSelection (Read or Write).....506
NIC.FCoEGenParams.FCoEFabricDiscoveryRetryCnt (Read or Write).....506
NIC.FCoEGenParams.FCoEFirstHddTarget (Read or Write).....507
NIC.FCoEGenParams.FCoELnkUpDelayTime (Read or Write).....507
NIC.FCoEGenParams.FCoELunBusyRetryCnt (Read or Write)..... 507
NIC.FCoEGenParams.FCoETgtBoot (Read or Write).....507
NIC.FrmimgMenu.....508
NIC.FrmwImgMenu.ControllerBIOSVersion (Read Only)..... 508
NIC.FrmwImgMenu.EFIVersion (Read Only).....508
NIC.FrmwImgMenu.FamilyVersion (Read Only)..... 508
NIC.GlobalBandwidthAllocation.....508
NIC.GlobalBandwidthAllocation.MaxBandwidth (Read or Write).....508
NIC.GlobalBandwidthAllocation.MinBandwidth (Read or Write).....509
NIC.iSCSIConfig..... 509
NIC.iSCSIConfig.IscsiFirstTgtParams (Read Only).....509
NIC.iSCSIConfig.IscsiFirstTgtParamsRef (Read Only)..... 509
NIC.iSCSIConfig.IscsiGenParams (Read Only)..... 509
NIC.iSCSIConfig.IscsiGenParamsRef (Read Only).....510
NIC.iSCSIConfig.IscsiInitiatorParams (Read Only)..... 510
NIC.iSCSIConfig.IscsiInitiatorParamsRef (Read Only).....510
NIC.iSCSIConfig.IscsiSecondaryDeviceParams (Read Only).....510
NIC.iSCSIConfig.IscsiSecondaryDeviceParamsRef (Read Only).....511
NIC.iSCSIConfig.IscsiSecondTgtParams (Read Only).....511
NIC.iSCSIConfig.IscsiSecondTgtParamsRef (Read Only).....511
NIC.IscsiFirstTgtParams..... 511
NIC.IscsiFirstTgtParams.ConnectFirstTgt (Read or Write).....511
NIC.IscsiFirstTgtParams.FirstTgtBootLun (Read or Write)..... 512
NIC.IscsiFirstTgtParams.FirstTgtChapId (Read or Write).....512
NIC.IscsiFirstTgtParams.FirstTgtChapPwd (Read or Write)..... 512
NIC.IscsiFirstTgtParams.FirstTgtIpAddress (Read or Write).....512
NIC.IscsiFirstTgtParams.FirstTgtIpVer (Read or Write).....513
NIC.IscsiFirstTgtParams.FirstTgtIscsiName (Read or Write)..... 513
NIC.IscsiFirstTgtParams.FirstTgtTcpPort (Read or Write).....513
NIC.IscsiGenParams..... 513
NIC.IscsiGenParams.ChapAuthEnable (Read or Write).....513
NIC.IscsiGenParams.ChapMutualAuth (Read or Write)..... 514
NIC.IscsiGenParams.DhcpVendId (Read or Write)..... 514
NIC.IscsiGenParams.FirstHddTarget (Read or Write)..... 514
NIC.IscsiGenParams.IpAutoConfig (Read or Write).....514
NIC.IscsiGenParams.IpVer (Read or Write).....514
NIC.IscsiGenParams.IscsiTgtBoot (Read or Write).....515
NIC.IscsiGenParams.IscsiViaDHCP (Read or Write).....515
NIC.IscsiGenParams.IscsiVLanId (Read or Write)..... 515
NIC.IscsiGenParams.IscsiVLanMode (Read or Write)..... 515

NIC.IscsiGenParams.LnkUpDelayTime (Read or Write)..... 516
NIC.IscsiGenParams.LunBusyRetryCnt (Read or Write)..... 516
NIC.IscsiGenParams.TcpIpViaDHCP (Read or Write)..... 516
NIC.IscsiGenParams.TcpTimestmp (Read or Write)..... 516
NIC.IscsiGenParams.WinHbaBootMode (Read or Write)..... 517
NIC.IscsiInitiatorParams..... 517
NIC.IscsiInitiatorParams.IscsiInitiatorChapId (Read or Write)..... 517
NIC.IscsiInitiatorParams.IscsiInitiatorChapPwd (Read or Write)..... 517
NIC.IscsiInitiatorParams.IscsiInitiatorGateway (Read or Write)..... 517
NIC.IscsiInitiatorParams.IscsiInitiatorIpAddr (Read or Write)..... 518
NIC.IscsiInitiatorParams.IscsiInitiatorIpv4Addr (Read or Write)..... 518
NIC.IscsiInitiatorParams.IscsiInitiatorIpv4Gateway (Read or Write)..... 518
NIC.IscsiInitiatorParams.IscsiInitiatorIpv4PrimDns (Read or Write)..... 518
NIC.IscsiInitiatorParams.IscsiInitiatorIpv4SecDns (Read or Write)..... 519
NIC.IscsiInitiatorParams.IscsiInitiatorIpv6Addr (Read or Write)..... 519
NIC.IscsiInitiatorParams.IscsiInitiatorIpv6Gateway (Read or Write)..... 519
NIC.IscsiInitiatorParams.IscsiInitiatorIpv6PrimDns (Read or Write)..... 519
NIC.IscsiInitiatorParams.IscsiInitiatorIpv6SecDns (Read or Write)..... 520
NIC.IscsiInitiatorParams.IscsiInitiatorName (Read or Write)..... 520
NIC.IscsiInitiatorParams.IscsiInitiatorPrimDns (Read or Write)..... 520
NIC.IscsiInitiatorParams.IscsiInitiatorSecDns (Read or Write)..... 520
NIC.IscsiInitiatorParams.IscsiInitiatorSubnet (Read or Write)..... 521
NIC.IscsiInitiatorParams.IscsiInitiatorSubnetPrefix (Read or Write)..... 521
NIC.IscsiSecondaryDeviceParams..... 521
NIC.IscsiSecondaryDeviceParams.SecondaryDeviceMacAddr (Read or Write)..... 521
NIC.IscsiSecondaryDeviceParams.UseIndTgtName (Read or Write)..... 521
NIC.IscsiSecondaryDeviceParams.UseIndTgtPortal (Read or Write)..... 522
NIC.IscsiSecondTgtParams..... 522
NIC.IscsiSecondTgtParams.ConnectSecondTgt (Read or Write)..... 522
NIC.IscsiSecondTgtParams.SecondTgtBootLun (Read or Write)..... 522
NIC.IscsiSecondTgtParams.SecondTgtChapId (Read or Write)..... 523
NIC.IscsiSecondTgtParams.SecondTgtChapPwd (Read or Write)..... 523
NIC.IscsiSecondTgtParams.SecondTgtIpAddress (Read or Write)..... 523
NIC.IscsiSecondTgtParams.SecondTgtIpVer (Read or Write)..... 523
NIC.IscsiSecondTgtParams.SecondTgtIscsiName (Read or Write)..... 524
NIC.IscsiSecondTgtParams.SecondTgtTcpPort (Read or Write)..... 524
NIC.NICConfig..... 524
NIC.NICConfig.BannerMessageTimeout (Read or Write)..... 524
NIC.NICConfig.BootOptionROM (Read or Write)..... 524
NIC.NICConfig.BootRetryCnt (Read or Write)..... 525
NIC.NICConfig.BootStrapType (Read or Write)..... 525
NIC.NICConfig.FWBootProtocol (Read or Write)..... 525
NIC.NICConfig.HideSetupPrompt (Read or Write)..... 526
NIC.NICConfig.LegacyBootProto (Read or Write)..... 526
NIC.NICConfig.LnkSpeed (Read or Write)..... 526
NIC.NICConfig.NumberVFAdvertised (Read or Write)..... 527
NIC.NICConfig.VLanId (Read or Write)..... 527
NIC.NICConfig.VLanMode (Read or Write)..... 527
NIC.NICConfig.WakeOnLan (Read or Write)..... 527
NIC.NICConfig.WakeOnLanLnkSpeed (Read or Write)..... 527

NIC.NICPartitioningConfig....528
NIC.NICPartitioningConfig.ConfigureFormn (Read Only)....528
NIC.NICPartitioningConfig.ConfigureFormRef (Read Only)....528
NIC.NICPartitioningConfig.FlowControlSetting (Read or Write)....528
NIC.NICPartitioningConfig.GlobalBandwidthAllocation (Read Only)....529
NIC.NICPartitioningConfig.GlobalBandwidthAllocationRef (Read Only)....529
NIC.NICPartitioningConfig.MgmtSVID (Read Only)....529
NIC.NICPartitioningConfig.NicPartitioning (Read or Write)....530
NIC.NICPartitioningConfig.NumberPCIFunctionsEnabled (Read Only)....530
NIC.NICPartitioningConfig.NumberPCIFunctionsSupported (Read Only)....530
NIC.NICPartitioningConfig.PartitionState (Read Only)....530
NIC.NICPartitioningConfig.RDMANICModeOnPartition (Read or Write)....531
NIC.PortLevelConfig....531
NIC.PortLevelConfig.VFDistribution (Read or Write)....531
NIC.VndrConfigGroup....531
NIC.VndrConfigPage.BlnkLeds (Read or Write)....531
NIC.VndrConfigPage.BusDeviceFunction (Read Only)....532
NIC.VndrConfigPage.ChipMdl (Read Only)....532
NIC.VndrConfigPage.DCBSettings (Read Only)....532
NIC.VndrConfigPage.DCBSettingsRef (Read Only)....532
NIC.VndrConfigPage.DCBXSupport (Read Only)....532
NIC.VndrConfigPage.DeviceLevelConfig (Read Only)....533
NIC.VndrConfigPage.DeviceLevelConfigurationRef (Read Only)....533
NIC.VndrConfigPage.DeviceName (Read Only)....533
NIC.VndrConfigPage.EEEControl (Read or Write)....533
NIC.VndrConfigPage.EnergyEfficientEthernet (Read Only)....534
NIC.VndrConfigPage.FCoEBootSupport (Read Only)....534
NIC.VndrConfigPage.FCOECapabilities (Read Only)....534
NIC.VndrConfigPage.FCoECapabilitiesRef (Read Only)....534
NIC.VndrConfigPage.FCoEConfigRef (Read Only)....535
NIC.VndrConfigPage.FCoEConfiguration (Read Only)....535
NIC.VndrConfigPage.FCoEOffloadMode (Read or Write)....535
NIC.VndrConfigPage.FCoEOffloadSupport (Read Only)....535
NIC.VndrConfigPage.FeatureLicensingSupport (Read Only)....535
NIC.VndrConfigPage.FIPMacAddr (Read Only)....536
NIC.VndrConfigPage.FlexAddressing (Read Only)....536
NIC.VndrConfigPage.FrmwImgMenu (Read Only)....536
NIC.VndrConfigPage.FrmwImgMenuRef (Read Only)....536
NIC.VndrConfigPage.HairpinMode (Read or Write)....537
NIC.VndrConfigPage.InfiniBand (Read Only)....537
NIC.VndrConfigPage.iSCSIBootSupport (Read Only)....537
NIC.VndrConfigPage.iSCSIConfig (Read Only)....537
NIC.VndrConfigPage.iSCSIConfigRef (Read Only)....538
NIC.VndrConfigPage.iSCSIDualIPVersionSupport (Read Only)....538
NIC.VndrConfigPage.IscsiMacAddr (Read Only)....538
NIC.VndrConfigPage.iScsiOffloadMode (Read or Write)....538
NIC.VndrConfigPage.iSCSIOffloadSupport (Read Only)....539
NIC.VndrConfigPage.LinkStatus (Read Only)....539
NIC.VndrConfigPage.LogicalPortEnable (Read or Write)....539
NIC.VndrConfigPage.MacAddr (Read Only)....539

NIC.VndrConfigPage.NetworkLinkType (Read or Write)....539
NIC.VndrConfigPage.NICConfig (Read Only)....540
NIC.VndrConfigPage.NICConfigRef (Read Only)....540
NIC.VndrConfigPage.NicMode (Read or Write)....540
NIC.VndrConfigPage.NICPartitioningConfigRef (Read Only)....540
NIC.VndrConfigPage.NicPartitioningSupport (Read Only)....541
NIC.VndrConfigPage.NodeGUID (Read Only)....541
NIC.VndrConfigPage.NWManagementPassThrough (Read Only)....541
NIC.VndrConfigPage.OmniPath (Read Only)....541
NIC.VndrConfigPage.OnChipThermalSensor (Read Only)....542
NIC.VndrConfigPage.OSBMCManagementPassThrough (Read Only)....542
NIC.VndrConfigPage.PCIDeviceID (Read Only)....542
NIC.VndrConfigPage.PKey (Read or Write)....542
NIC.VndrConfigPage.PortGUID (Read Only)....542
NIC.VndrConfigPage.PXEBootSupport (Read Only)....543
NIC.VndrConfigPage.RDMANICModeOnPort (Read or Write)....543
NIC.VndrConfigPage.RemotePHY (Read Only)....543
NIC.VndrConfigPage.RXFlowControl (Read Only)....543
NIC.VndrConfigPage.SNAPI (Read Only)....544
NIC.VndrConfigPage.SNAPIState (Read Only)....544
NIC.VndrConfigPage.SwitchDepPartitioningSupport (Read Only)....544
NIC.VndrConfigPage.TOESupport (Read Only)....544
NIC.VndrConfigPage.TXBandwidthControlMaximum (Read Only)....545
NIC.VndrConfigPage.TXBandwidthControlMinimum (Read Only)....545
NIC.VndrConfigPage.TXFlowControl (Read Only)....545
NIC.VndrConfigPage.VirtFIPMacAddr (Read or Write)....546
NIC.VndrConfigPage.VirtIscsiMacAddr (Read or Write)....546
NIC.VndrConfigPage.VirtMacAddr (Read or Write)....546
NIC.VndrConfigPage.VirtPortGUID (Read or Write)....546
NIC.VndrConfigPage.VirtWWN (Read or Write)....547
NIC.VndrConfigPage.VirtWWPN (Read or Write)....547
NIC.VndrConfigPage.VndrConfigPage (Read Only)....547
NIC.VndrConfigPage.VndrFormSet (Read Only)....547
NIC.VndrConfigPage.VPI (Read Only)....548
NIC.VndrConfigPage.WWN (Read Only)....548
NIC.VndrConfigPage.WWPN (Read Only)....548

7 Storage Attributes....549
Storage.Controller....549
Storage.Controller.Background Initialization Rate (Read or Write)....549
Storage.Controller.Battery Learn Mode (Read or Write)....549
Storage.Controller.Check Consistency Mode (Read or Write)....549
Storage.Controller.Check Consistency Rate (Read or Write)....550
Storage.Controller.Controller Boot Mode (Read or Write)....550
Storage.Controller.Controller Encryption Mode (Read Only)....550
Storage.Controller.Controller Rekey (Read or Write)....551
Storage.Controller.Controller Reset Configuration (Read or Write)....551
Storage.Controller.Copyback Mode (Read or Write)....551
Storage.Controller.Current Controller Mode (Read Only)....551
Storage.Controller.Enhanced Import Foreign Configuration (Read or Write)....552

Storage.Controller.Foreign Configuration (Read or Write)..... 552
Storage.Controller.Key identifier (Read Only).....552
Storage.Controller.Load Balanced Mode (Read or Write).....552
Storage.Controller.Maximum Capable Speed (Read Only)..... 553
Storage.Controller.Maximum Physical Disks in Span (Read Only)..... 553
Storage.Controller.Maximum Spans in Virtual Disk (Read Only)..... 553
Storage.Controller.Maximum Supported Virtual Disks (Read Only).....553
Storage.Controller.New Controller Key (Read or Write)..... 554
Storage.Controller.Old Controller Key (Read or Write)..... 554
Storage.Controller.Patrol Read Iterations (Read Only).....554
Storage.Controller.Patrol Read Mode (Read or Write).....554
Storage.Controller.Patrol Read on Unconfigured area (Read or Write).....555
Storage.Controller.Patrol Read Rate (Read Only).....555
Storage.Controller.Rebuild Rate (Read or Write)..... 555
Storage.Controller.Reconstruction Rate (Read or Write)..... 555
Storage.Controller.Remove Controller key (Read or Write)..... 555
Storage.Controller.Requested Controller Mode (Read or Write).....556
Storage.Controller.Spin Down Idle Time (Read Only)..... 556
Storage.Controller.Supported Disk Protocols (Read Only)..... 556
Storage.Controller.Supported Encryption types (Read Only).....557
Storage.Controller.Supported Initialization types (Read Only)..... 557
Storage.Controller.Supported RAID Levels (Read Only)..... 557
Storage.Enclosure.....557
Storage.Enclosure.Asset Tag (Read Only)..... 557
Storage.Enclosure.Backplane Type (Read Only)..... 558
Storage.Enclosure.Block Size In Bytes (Read Only).....558
Storage.Enclosure.Effective SAS Address (Read Only)..... 558
Storage.Enclosure.Enclosure Current Configuration Mode (Read Only)..... 558
Storage.Enclosure.Enclousre Requested Configuration Mode (Read or Write).....559
Storage.PhysicalDisk..... 559
Storage.PhysicalDisk.Bus Protocol (Read Only).....559
Storage.PhysicalDisk.Full Initiallzation (Read or Write).....559
Storage.PhysicalDisk.Hotspare Status (Read Only).....559
Storage.PhysicalDisk.Media Type (Read Only).....560
Storage.PhysicalDisk.Negotiated Speed (Read Only).....560
Storage.PhysicalDisk.Nominal Medium Rotation Rate (Read Only).....560
Storage.PhysicalDisk.Physical Disk State (Read Only)..... 560
Storage.PhysicalDisk.Software RAID Mode (Read or Write).....561
Storage.PhysicalDisk.T10PI capable (Read Only)..... 561
Storage.VirtualDisk..... 561
Storage.VirtualDisk.Action (Read or Write).....561
Storage.VirtualDisk.Cachecade State (Read Only)..... 562
Storage.VirtualDisk.Dedicated Spare (Read or Write)..... 562
Storage.VirtualDisk.Disk Cache Policy (Read or Write)..... 562
Storage.VirtualDisk.Initialization Operation (Read or Write).....562
Storage.VirtualDisk.Lock Status (Read Only).....563
Storage.VirtualDisk.Name (Read Only)..... 563
Storage.VirtualDisk.Physical Disk ID (Read or Write).....563
Storage.VirtualDisk.RAID Level (Read Only)..... 563
Storage.VirtualDisk.Read Policy (Read or Write).....564

Storage.VirtualDisk.Size (Read Only)....564
Storage.VirtualDisk.Span Depth (Read Only)....564
Storage.VirtualDisk.Span Length (Read Only)....564
Storage.VirtualDisk.Stripe Size (Read Only)....565
Storage.VirtualDisk.T10PIStatus (Read or Write)....565
Storage.VirtualDisk.Write Policy (Read or Write)....565

1

iDRAC Property Database Group and Object Descriptions

The iDRAC property database contains the configuration information for iDRAC. Associated object is organizing data, and object group is organizing object. The IDs for the groups and objects that the property database supports are listed in this guide. To configure iDRAC, use the group and object IDs.

All string values are limited to displayable ASCII characters, except where otherwise noted.

NOTE: You can configure a setting that does not have a hash symbol (#) as the prefix in its output name. To modify a configurable object, use the `-o` option.

2

iDRAC Attributes

Topics:

- iDRAC.ActiveDirectory
- iDRAC.ADGroup
- iDRAC.ASRConfig
- iDRAC.Autodiscovery
- iDRAC.AutoOSLockGroup
- iDRAC.CurrentIPV4
- iDRAC.CurrentIPV6
- iDRAC.CurrentNIC
- iDRAC.DCSCustom
- iDRAC.DefaultCredentialMitigationConfigGroup
- iDRAC.EmailAlert
- iDRAC.GroupManager
- iDRAC.GUISecurityPolicyMessage
- iDRAC.Info
- iDRAC.IntegratedDatacenter
- iDRac.IOIDOpt
- iDRAC.IPBlocking
- iDRAC.IPMILan
- iDRAC.IPMISerial
- iDRAC.IPMISOL
- iDRac.IPv4
- iDRAC.IPV4Static
- iDRAC.IPV6
- iDRAC.IPv6Static
- iDRAC.IPv6URL
- iDRAC.LDAP
- iDRAC.LDAPRoleGroup
- iDRAC.LocalSecurity
- iDRAC.Lockdown
- iDRAC.Logging
- iDRAC.MgmtNetworkInterface
- iDRAC.NIC
- iDRAC.NICStatic
- iDRAC.NTPConfigGroup
- iDRAC.OS-BMC
- iDRAC.Platformcapability
- iDRAC.RACADM
- iDRAC.Redfish
- iDRAC.RedfishEventing
- iDRAC.RemoteHosts
- iDRAC.RFS
- iDRAC.RSM
- iDRAC.Security
- iDRAC.Serial
- iDRAC.SerialRedirection
- iDRAC.ServerBoot
- iDRAC.ServiceModule
- iDRAC.Smartcard

- iDRAC.SNMP
- iDRAC.SNMP.Alert
- iDRAC.SNMPTRAPIPv4
- iDRAC.SNMPTRAPIPv6
- iDRAC.SSH
- iDRAC.SupportAssist
- iDRAC.SwitchConnectionView
- iDRAC.SysInfo
- iDRAC.Syslog
- iDRAC.Telnet
- iDRAC.Time
- iDRAC.Update
- iDRAC.USB
- iDRAC.Userdomain
- iDRAC.Users
- iDRAC.vFlashPartition
- iDRAC.vFlashSD
- iDRAC.VirtualConsole
- iDRAC.VirtualMedia
- iDRC.VNCServer
- iDRAC.WebServer

iDRAC.ActiveDirectory

This group contains the attributes that provides details about ActiveDirectory.

iDRAC.ActiveDirectory.AuthTimeout (Read or Write)

Description	Specifies the number of seconds to wait for Active Directory authentication requests to complete before timing out.
Legal Values	None
Default Value	• 120
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.CertValidationEnable (Read or Write)

Description	Enables or disables Active Directory certificate validation as a part of the Active Directory configuration process.
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.DCLookupByUserDomain (Read or Write)

Description	Chooses the way the user domain is looked up for Active Directory.
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	Cannot be Disabled unless DC Lookup Domain Name is set

iDRAC.ActiveDirectory.DCLookupDomainName (Read or Write)

Description	This is the configured search domain to use when DCLookupByUserDomain is disabled
Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.DCLookupEnable (Read or Write)

Description	Configures iDRAC to use pre-configured domain controllers or to use DNS to find the domain controller.
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.DomainController1 (Read or Write)

Description	Specifies the LDAP server from which you want the iDRAC to obtain user names
Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.DomainController2 (Read or Write)

Description	Specifies the LDAP server from which you want the iDRAC to obtain user names
Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.DomainController3 (Read or Write)

Description	Specifies the LDAP server from which you want the iDRAC to obtain user names
Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.Enable (Read or Write)

Description	Enables or disables Active Directory user authentication on iDRAC
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.GCLookupEnable (Read or Write)

Description	Determines how the global catalog server is looked up.
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.GCRootDomain (Read or Write)

Description	The name of the Active Directory root domain used for DNS look up, to locate Global Catalog servers.
Legal Values	None
Default Value	None

Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.GlobalCatalog1 (Read or Write)

Description	Specifies the Global Catalog server from which you want the iDRAC to obtain user names.
Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.GlobalCatalog2 (Read or Write)

Description	Specifies the Global Catalog server from which you want the iDRAC to obtain user names.
Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.GlobalCatalog3 (Read or Write)

Description	Specifies the Global Catalog server from which you want the iDRAC to obtain user names.
Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.RacDomain (Read or Write)

Description	Active Directory Domain in which iDRAC resides.
Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.RacName (Read or Write)

Description	Name of iDRAC as recorded in the Active Directory forest.

Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.Schema (Read or Write)

Description	Determines the schema type to use with Active Directory.
Legal Values	• 1-Extended Schema • 2-Standard Schema
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ActiveDirectory.SSOEnable (Read or Write)

Description	Enables or disables Active Directory single sign-on authentication on iDRAC.
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	Cannot be Enabled unless SmartCard Logon Enable is Disabled

iDRAC.ADGroup

This group contains the attributes that provides details about ADGroup.

iDRAC.ADGroup.Domain (Read or Write)

Description	Active Directory Domain in which the Role Group resides.
Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ADGroup.Name (Read or Write)

Description	Name of the Role Group as recorded in the Active Directory forest.
Legal Values	None

Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ADGroup.Privilege (Read or Write)

Description	Role-based authority privileges for a Role Group
Legal Values	None
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.ASRConfig

This group contains the attributes that provides details about ASR configuration.

iDRAC.ASRConfig.Enable (Read or Write)

Description	Status of ASR Config
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Autodiscovery

This group contains the attributes that provides details about `iDRAC.Autodiscovery`.

iDRAC.Autodiscovery.EnableIPChangeAnnounce (Read or Write)

Description	Enable Auto Discovery to allow 1:many consoles to discover iDRAC
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Autodiscovery.EnableIPChangeAnnounceFromDHCP (Read or Write)

Description	Enable iDRAC to obtain list of consoles through DHCP.
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Autodiscovery.EnableIPChangeAnnounceFrommDNS (Read or Write)

Description	Enable iDRAC to obtain list of consoles through mDNS
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Autodiscovery.EnableIPChangeAnnounceFromUnicastDNS (Read or Write)

Description	Enable iDRAC to obtain list of consoles through unicast DNS.
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.Autodiscovery.UnsolicitedIPChangeAnnounceRate (Read or Write)

Description	Rate of periodic refresh of IP address to consoles
Legal Values	• 0-Disabled • 1-1 hour • 2-6 hours • 3-12 hours

- 4-1 day
- 5-3 days
- 6-1 week
- 7-2 weeks
- 8-4 weeks
- 9-6 weeks

Default Value	• 4
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.AutoOSLockGroup

This group contains the attributes that provides details about Auto OS lock group.

iDRAC.AutoOSLockGroup.AutoOSLockState (Read or Write)

Description	Enable Auto OS Lock State
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPV4

This group contains the attributes that provides details about `iDRAC.CurrentIPV4`.

iDRAC.CurrentIPv4.Address (Read Only)

Description	The current IPv4 address assigned to the iDRAC
Legal Values	None
Default Value	• 0.0.0.0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv4.DHCPEnable (Read Only)

Description	Specifies if DHCP is used to assign the iDRAC IPv4 address
Legal Values	• 0-Disabled • 1-Enabled

Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv4.DNS1 (Read Only)

Description	IPv4 address for DNS server 1
Legal Values	None
Default Value	• 0.0.0.0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv4.DNS2 (Read Only)

Description	IPv4 address for DNS Server 2
Legal Values	None
Default Value	• 0.0.0.0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv4.DNSFromDHCP (Read Only)

Description	Specifies if the DNS server IPv4 addresses should be assigned from the DHCP server on the network.
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv4.DupAddrDetected (Read Only)

Description	The current IPv4 address assigned to the iDRAC
Legal Values	None
Default Value	• 0.0.0.0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv4.Enable (Read Only)

Description	Enables or Disables the iDRAC IPv4 stack
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv4.Gateway (Read Only)

Description	The gateway for the iDRAC IPv4 address
Legal Values	None
Default Value	• 0.0.0.0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv4.Netmask (Read Only)

Description	The subnet mask used for the iDRAC IPv4 address
Legal Values	None
Default Value	• 0.0.0.0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPV6

This group contains the attributes that provides details about current IPv6 settings.

iDRAC.CurrentIPv6.Address1 (Read Only)

Description	iDRAC IPv6 Address
Legal Values	None
Default Value	• ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Address10 (Read Only)

Description	iDRAC IPv6 tenth address
Legal Values	None
Default Value	. ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Address11 (Read Only)

Description	iDRAC IPv6 eleventh address
Legal Values	None
Default Value	. ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Address12 (Read Only)

Description	iDRAC IPv6 twelfth address
Legal Values	None
Default Value	. ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Address13 (Read Only)

Description	iDRAC IPv6 thirteenth address
Legal Values	None
Default Value	. ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Address14 (Read Only)

Description	iDRAC IPv6 fourteenth address
Legal Values	None
Default Value	. ::
Write Privilege	Configure iDRAC

License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Address15 (Read Only)

Description	iDRAC IPv6 fifteenth address
Legal Values	None
Default Value	. ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Address2 (Read Only)

Description	iDRAC IPv6 second address
Legal Values	None
Default Value	. ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Address3 (Read Only)

Description	iDRAC IPv6 third address
Legal Values	None
Default Value	. ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Address4 (Read Only)

Description	iDRAC IPv6 fourth address
Legal Values	None
Default Value	. ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Address5 (Read Only)

Description	iDRAC IPv6 fifth address

Legal Values	None
Default Value	. ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Address6 (Read Only)

Description	iDRAC IPv6 sixth address
Legal Values	None
Default Value	. ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Address7 (Read Only)

Description	iDRAC IPv6 seventh address
Legal Values	None
Default Value	. ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Address8 (Read Only)

Description	iDRAC IPv6 eighth address
Legal Values	None
Default Value	. ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Address9 (Read Only)

Description	iDRAC IPv6 ninth address
Legal Values	None
Default Value	. ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.AutoConfig (Read Only)

Description	Enables or Disables the iDRAC IPv6 auto configuration option
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.DNS1 (Read Only)

Description	IPv6 DNS Server 1 Address
Legal Values	None
Default Value	• ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.DNS2 (Read Only)

Description	IPv6 DNS Server 2 Address
Legal Values	None
Default Value	• ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.DNSFromDHCP6 (Read Only)

Description	Specifies if the DNS Server addresses are obtained from DHCP or not
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.DUID (Read Only)

Description	DHCP Unique Identifier
Legal Values	None

Default Value	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Enable (Read Only)

Description	Enables or Disables iDRAC IPv6 stack
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.Gateway (Read Only)

Description	iDRAC IPv6 Gateway
Legal Values	None
Default Value	• ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.IPV6NumOfExtAddress (Read Only)

Description	Total number of extended IP
Legal Values	None
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.LinkLocalAddress (Read Only)

Description	iDRAC IPv6 Link Local Address
Legal Values	None
Default Value	• ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentIPv6.PrefixLength (Read Only)

Description	Prefix length for the iDRAC IPv6 Address
Legal Values	None
Default Value	• 64
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC

This group contains the attributes that provide details about current NIC.

iDRAC.CurrentNIC.ActiveNIC (Read Only)

Description	Currently Active iDRAC network interface
Legal Values	• 0-None • 1-Dedicated • 2-LOM1 • 3-LOM2 • 4-LOM3 • 5-LOM4 • 6-LOM5 • 7-LOM6 • 8-LOM7 • 9-LOM8 • 10-LOM9 • 11-LOM10 • 12-LOM11 • 13-LOM12 • 14-LOM13 • 15-LOM14 • 16-LOM15 • 17-LOM16
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.ActiveSharedLOM (Read Only)

Description	Currently Active iDRAC shared network interface
Legal Values	• 0-None • 1-LOM1 • 2-LOM2 • 3-LOM3 • 4-LOM4 • 5-LOM5

- 6-LOM6
- 7-LOM7
- 8-LOM8
- 9-LOM9
- 10-LOM10
- 11-LOM11
- 12-LOM12
- 13-LOM13
- 14-LOM14
- 15-LOM15
- 16-LOM16

Default Value
- 0

Write Privilege Configure iDRAC

License Required Not Applicable

Dependency None

iDRAC.CurrentNIC.AutoDetect (Read Only)

Description Enable or disable auto detection feature of iDRAC

Legal Values
- 0-Disabled
- 1-Enabled

Default Value
- 0

Write Privilege Configure iDRAC

License Required Not Applicable

Dependency None

iDRAC.CurrentNIC.Autoneg (Read Only)

Description Enables autonegotiation of physical link speed and duplex

Legal Values
- 0-Disabled
- 1-Enabled

Default Value
- 1

Write Privilege Configure iDRAC

License Required Not Applicable

Dependency None

iDRAC.CurrentNIC.DedicatedNICScanTime (Read Only)

Description Shared to Dedicated Failover Timeout

Legal Values None

Default Value
- 5

Write Privilege Configure iDRAC

License Required Not Applicable

Dependency None

iDRAC.CurrentNIC.DNSDomainFromDHCP (Read Only)

Description	Specifies that the iDRAC DNS Domain Name should be assigned from the network DHCP server.
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.DNSDomainName (Read Only)

Description	The DNS Domain Name
Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.DNSRacName (Read Only)

Description	The iDRAC name, which is iDRAC-<SVCTAG> by default
Legal Values	None
Default Value	• idrac-SVCTAG
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.DNSRegister (Read Only)

Description	Registers the iDRAC name with the DNS server.
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.Duplex (Read Only)

Description	Specifies the duplex setting for the iDRAC NIC
Legal Values	• 0-Half

- 1-full

Default Value
- 1

Write Privilege Configure iDRAC

License Required Not Applicable

Dependency None

iDRAC.CurrentNIC.Enable (Read Only)

Description Enables or Disables the iDRAC network interface controller.

Legal Values
- 0-Disabled
- 1-Enabled

Default Value
- 1

Write Privilege Configure iDRAC

License Required Not Applicable

Dependency None

iDRAC.CurrentNIC.Failover (Read Only)

Description Specifies the NIC Failover LOM

Legal Values
- 0-None
- 1-LOM1
- 2-LOM2
- 3-LOM3
- 4-LOM4
- 5-ALL

Default Value
- 0

Write Privilege Configure iDRAC

License Required Not Applicable

Dependency None

iDRAC.CurrentNIC.LinkStatus (Read Only)

Description iDRAC Link Status.

Legal Values
- 0-No
- 1-Yes

Default Value
- 1

Write Privilege Configure iDRAC

License Required Not Applicable

Dependency None

iDRAC.CurrentNIC.MACAddress (Read Only)

Description The MAC Address of the iDRAC

Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.MACAddress2 (Read Only)

Description	The MAC Address 2 of the iDRAC
Legal Values	None
Default Value	• 00:00:00:00:00:02
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.MgmtIfaceName (Read Only)

Description	The name of the Management Network Interface
Legal Values	None
Default Value	• bond0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.MTU (Read Only)

Description	The size in bytes of the maximum transmission unit used by the iDRAC NIC
Legal Values	None
Default Value	• 1500
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.NumberOfLOM (Read Only)

Description	Number of shared LOM available for iDRAC network interface
Legal Values	None
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.Selection (Read Only)

Description	Specifies the current mode of operation for the iDRAC network interface controller
Legal Values	• 1-Dedicated • 2-LOM1 • 3-LOM2 • 4-LOM3 • 5-LOM4
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.SharedNICScanTime (Read Only)

Description	Dedicated to Shared Failover Timeout
Legal Values	None
Default Value	• 30
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.Speed (Read Only)

Description	Specifies the speed for the iDRAC NIC
Legal Values	• 0-10 • 1-100 • 2-1000 • 3-2500 • 4-10000 • 5-20000 • 6-25000 • 7-40000 • 8-50000 • 9-100000
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.VLanEnable (Read Only)

Description	Enables or Disables the VLAN capabilities of the iDRAC
Legal Values	• 0-Disabled • 1-Enabled

Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.VLanID (Read Only)

Description	Specifies the VLAN ID for the network VLAN configuration
Legal Values	None
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.VLanPriority (Read Only)

Description	Specifies the VLAN priority for the network VLAN configuration
Legal Values	None
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.CurrentNIC.VLanSetting (Read Only)

Description	Auto VLAN Setting
Legal Values	• 0-Both Enable • 1-Disabled on Dedicated • 2-Disabled on share
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.DCSCustom

This group contains the attributes that provides DCS custom details.

iDRAC.DCSCustom.RRCCardPresent (Read or Write)

Description	Indicates the presence or absence of RRC card or any other fabric
Legal Values	• 0-NotApplicable

- 1-Unknown
- 2-Present
- 3-Absent

Default Value
- 0

Write Privilege Configure iDRAC

License Required Not Applicable

Dependency None

iDRAC.DCSCustom.WANCardPresent (Read or Write)

Description Indicates the presence or absence of WAN Card

Legal Values
- 0-Unknown
- 1-Present
- 2-Absent
- 3-NotApplicable

Default Value
- 3

Write Privilege Configure iDRAC

License Required Not Applicable

Dependency None

iDRAC.DefaultCredentialMitigationConfigGroup

This group contains the attributes that provide details about iDRAC Default Credential Mitigation Configuration Group.

iDRAC.DefaultCredentialMitigationConfigGroup.DefaultCredentialMitigation (Read or Write)

Description Enable Default Credential Mitigation

Legal Values
- 0-Disabled
- 1-Enabled

Default Value
- 1

Write Privilege Configure User

License Required Not Applicable

Dependency None

iDRAC.EmailAlert

This group contains the attributes that provide details about email alerts.

iDRAC.EmailAlert.Address (Read or Write)

Description Specifies the destination email address for email alerts

Legal Values None

Default Value None

Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.EmailAlert.CustomMsg (Read or Write)

Description	Specifies the custom message that forms the subject of the alert
Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.EmailAlert.Enable (Read or Write)

Description	Enables or Disables the destination to receive alerts
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.GroupManager

This group contains the attributes that provides details about GroupManager.

iDRAC.GroupManager.GroupName (Read Only)

Description	GroupName is the user specified name of the iDRAC Group Manager local group.
Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.GroupManager.GroupUUID (Read Only)

Description	GroupUUID is a universally unique identifier that is automatically generated when the iDRAC Group Manager local group is created. This is used to track a group and remains constant for the life of the group.
Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise

Dependency	None

iDRAC.GroupManager.Status (Read or Write)

Description	Enables or disables Group Management. iDRAC Group Manager feature offers simplified basic management of iDRACs on the same local network using the iDRAC GUI. When enabled a link local IPv6 address is used to discover and communicate with other iDRACs.
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.GUISecurityPolicyMessage

This group contains the attributes that provides details about GUI security policy message.

iDRAC.GUI.SecurityPolicyMessage (Read or Write)

Description	Security Policy Message Displayed on the GUI login screen
Legal Values	None
Default Value	• By accessing this computer, you confirm that such access complies with your organization's security policy.
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Info

This group contains the attributes that provides details about iDRAC info.

iDRAC.Info.Build (Read Only)

Description	String containing the current product build version
Legal Values	None
Default Value	• 25
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Info.CPLDVersion (Read Only)

Description	Specifies the CPLD firmware version of the server.
Legal Values	None

Default Value	• 0.0.0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

iDRAC.Info.Description (Read Only)

Description	Text description of the iDRAC
Legal Values	None
Default Value	• This system component provides a complete set of remote management functions for Dell PowerEdge Server.
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Info.HWRev (Read Only)

Description	Specifies the iDRAC hardware revision.
Legal Values	None
Default Value	• .0.1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Info.IPMIVersion (Read Only)

Description	Current IPMI Version supported on iDRAC
Legal Values	None
Default Value	• 2.0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

iDRAC.Info.Name (Read Only)

Description	User assigned name identifying this controller
Legal Values	None
Default Value	• iDRAC
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Info.Product (Read Only)

Description	String identifying the Product
Legal Values	None
Default Value	• Integrated Dell Remote Access Controller
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Info.RollbackBuild (Read Only)

Description	Specifies the iDRAC rollback build number.
Legal Values	None
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Info.RollbackVersion (Read Only)

Description	Specifies the iDRAC rollback version.
Legal Values	None
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Info.ServerGen (Read Only)

Description	String containing the current server generation
Legal Values	• 1-12G • 2-13G • 3-14G
Default Value	• 3
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Info.Type (Read Only)

Description	Identifies the remote access controller type as iDRAC
Legal Values	• 0-12G/13G/14G

- 1-Other
- 2-Unknown
- 16-12G Monolithic
- 17-12G Modular
- 32-13G Monolithic
- 33-13G Modular
- 21-12G DCS
- 34-13G DCS
- 48-14G Monolithic
- 49-14G Modular
- 50-14G DCS

Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Info.Version (Read Only)

Description	String containing the current product firmware version
Legal Values	None
Default Value	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IntegratedDatacenter

This group contains the attributes that provides details about Integrated datacenter.

iDRAC.IntegratedDatacenter.DiscoveryEnable (Read or Write)

Description	Enable Autodiscovery
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRac.IOIDOpt

This group contains the attributes that provides details about iDRAC IOIDOpt.

iDRAC.IOIDOpt.InitiatorPersistencePolicy (Read or Write)

Description	Initiator Persistence Policy
Legal Values	• 0-None • 1-WarmReset • 2-ColdReset • 3-WarmReset, ColdReset • 4-ACPowerLoss • 5-WarmReset, ACPowerLoss • 6-ColdReset, ACPowerLoss • 7-WarmReset, ColdReset, ACPowerLoss
Default Value	• 7
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IOIDOpt.IOIDOptEnable (Read or Write)

Description	Enable IO Identity Optimization
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IOIDOpt.StorageTargetPersistencePolicy (Read or Write)

Description	Storage Target Persistence Policy
Legal Values	• 0-None • 1-WarmReset • 2-ColdReset • 3-WarmReset, ColdReset • 4-ACPowerLoss • 5-WarmReset, ACPowerLoss • 6-ColdReset, ACPowerLoss • 7-WarmReset, ColdReset, ACPowerLoss
Default Value	• 7
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IOIDOpt.VirtualAddressPersistencePolicyAuxPwrd (Read or Write)

Description	Virtual Address Persistence Policy Auxiliary Powered
Legal Values	• 0-None • 1-WarmReset • 2-ColdReset • 3-WarmReset, ColdReset • 4-ACPowerLoss • 5-WarmReset, ACPowerLoss • 6-ColdReset, ACPowerLoss • 7-WarmReset, ColdReset, ACPowerLoss
Default Value	• 3
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IOIDOpt.VirtualAddressPersistencePolicyNonAuxPwrd (Read or Write)

Description	Virtual Address Persistence Policy Non Auxiliary Powered
Legal Values	• 0-None • 1-WarmReset • 2-ColdReset • 3-WarmReset, ColdReset • 4-ACPowerLoss • 5-WarmReset, ACPowerLoss • 6-ColdReset, ACPowerLoss • 7-WarmReset, ColdReset, ACPowerLoss
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPBlocking

This group contains the attributes that provides details about IP Blocking.

iDRAC.IPBlocking.BlockEnable (Read or Write)

Description	Enables or disables the IPv4 address blocking feature of iDRAC
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 1
Write Privilege	Configure iDRAC

License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPBlocking.FailCount (Read or Write)

Description	The maximum number of login failures to occur within the window before login attempts from the IP address are rejected.
Legal Values	None
Default Value	• 3
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPBlocking.FailWindow (Read or Write)

Description	Defines the time span in seconds that the failed attempts are counted.
Legal Values	None
Default Value	• 60
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPBlocking.PenaltyTime (Read or Write)

Description	Defines the time span in seconds that session requests from an IP address with excessive failures are rejected.
Legal Values	None
Default Value	• 60
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPBlocking.RangeAddr (Read or Write)

Description	Specifies the acceptable IPv4 address bit pattern in positions determined by the "1"s in the range mask
Legal Values	None
Default Value	• 192.168.1.1
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPBlocking.RangeEnable (Read or Write)

Description	Enables or disables the IPv4 Address Range validation feature of iDRAC
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPBlocking.RangeMask (Read or Write)

Description	Standard IP mask values with left-justified bits.
Legal Values	None
Default Value	• 255.255.255.0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.IPMILan

This group contains the attributes that provides details about iDRAC IPMI Lan.

iDRAC.IPMILan.AlertEnable (Read or Write)

Description	Enables or Disables global email alerting
Legal Values	• 1-Disabled • 0-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	
Dependency	None

iDRAC.IPMILan.CommunityName (Read or Write)

Description	Specifies the SNMP community name for traps
Legal Values	None
Default Value	• public
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMILan.Enable (Read or Write)

Description	Enables or Disables the IPMI over LAN interface
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMILan.EncryptionKey (Read or Write)

Description	Specifies the IPMI Encryption key
Legal Values	None
Default Value	• 00000000000000000000000000000000000000000000
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMILan.PrivLimit (Read or Write)

Description	Specifies the maximum privilege level for IPMI over LAN access
Legal Values	• 2-User • 3-Operator • 4-Administrator
Default Value	• 4
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMISerial

This group contains the attributes that provides details about iDRAC IPMI Serial.

iDRAC.IPMISerial.BaudRate (Read or Write)

Description	Specifies the baud rate for serial connection over IPMI
Legal Values	• 9600-9600 • 19200-19200 • 57600-57600 • 115200-115200
Default Value	• 57600
Write Privilege	Configure iDRAC

License Required	Not Applicable
Dependency	None

iDRAC.IPMISerial.ChanPrivLimit (Read or Write)

Description	Specifies the maximum privilege limit allowed on the IPMI serial channel
Legal Values	• 2-User • 3-Operator • 4-Administrator
Default Value	• 4
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMISerial.ConnectionMode (Read or Write)

Description	Determines the IPMI defined mode of the serial port
Legal Values	• 0-Terminal • 1-Basic
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMISerial.DeleteControl (Read or Write)

Description	Enables or Disables delete control on the IPMI serial interface
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMISerial.EchoControl (Read or Write)

Description	Enables or Disables echo control on the IPMI serial interface
Legal Values	• 0-Disabled • 1-Enabled
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable

Dependency	None

iDRAC.IPMISerial.FlowControl (Read or Write)

Description	Specifies the Flow Control setting for IPMI serial port
Legal Values	• 0-None • 1-RTS/CTS
Default Value	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMISerial.HandshakeControl (Read or Write)

Description	Enables or Disables the IPMI terminal mode handshake control
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMISerial.InputNewLineSeq (Read or Write)

Description	Specifies the input new line sequence for the IPMI serial interface
Legal Values	• 1-Enter • 2-Null
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMISerial.LineEdit (Read or Write)

Description	Enables or Disables line editing on the IPMI serial interface
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMISerial.NewLineSeq (Read or Write)

Description	Specifies the new line sequence for the IPMI serial interface
Legal Values	• 0-None • 1-CR-LF • 2-NULL • 3-CR • 4-LF-CR • 5-LF
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMISOL

This group contains the attributes that provides details about iDRAC IPMI SOL.

iDRAC.IPMISOL.AccumulateInterval (Read or Write)

Description	Specifies the typical amount of time that iDRAC waits before transmitting a partial SOL character data packet
Legal Values	None
Default Values	• 10
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMISOL.BaudRate (Read or Write)

Description	Specifies the Baud rate for serial communication over LAN
Legal Values	• 9600-9600 • 19200-19200 • 57600-57600 • 115200-115200
Default Values	• 115200
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMISOL.Enable (Read or Write)

Description	Enables or disables Serial Over LAN (SOL)
Legal Values	• 0-Disabled • 1-Enabled

Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMISOL.MinPrivilege (Read or Write)

Description	Specifies the minimum privilege level required for serial access
Legal Values	• 2-User • 3-Operator • 4-Administrator
Default Values	• 4
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPMISOL.SendThreshold (Read or Write)

Description	Specifies the SOL threshold limit value and the maximum number of bytes to buffer before sending an SOL data packet
Legal Values	None
Default Values	• 255
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRac.IPv4

This group contains the attributes that provides details about iDRAC IPv4 settings.

iDRAC.IPv4.Address (Read or Write)

Description	The current IPv4 address assigned to the iDRAC
Legal Values	None
Default Values	• 192.168.0.120
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv4.DHCPEnable (Read or Write)

Description	Specifies if DHCP is used to assign the iDRAC IPv4 address
Legal Values	• 0-Disabled

- 1-Enabled

Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv4.DNS1 (Read or Write)

Description	IPv4 address for DNS server 1
Legal Values	None
Default Values	• 0.0.0.0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv4.DNS2 (Read or Write)

Description	IPv4 address for DNS Server 2
Legal Values	None
Default Values	• 0.0.0.0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv4.DNSFromDHCP (Read or Write)

Description	Specifies if the DNS server IPv4 addresses should be assigned from the DHCP server on the network.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv4.Enable (Read or Write)

Description	Enables or Disables the iDRAC IPv4 stack
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC

License Required	Not Applicable
Dependency	None

iDRAC.IPv4.Gateway (Read or Write)

Description	The gateway for the iDRAC IPv4 address
Legal Values	None
Default Values	• 192.168.0.1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv4.Netmask (Read or Write)

Description	The subnet mask used for the iDRAC IPv4 address
Legal Values	None
Default Values	• 255.255.255.0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPV4Static

This group contains the attributes that provides details about `iDRAC.IPV4Static`.

iDRAC.IPv4Static.Address (Read or Write)

Description	iDRAC static IPv4 address (can be configured even when DHCP is enabled)
Legal Values	None
Default Values	• 192.168.0.120
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv4Static.DNS1 (Read or Write)

Description	Statically configurable DNS Server 1
Legal Values	None
Default Values	• 0.0.0.0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv4Static.DNS2 (Read or Write)

Description	Statically configurable DNS Server 2
Legal Values	None
Default Values	• 0.0.0.0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv4Static.DNSFromDHCP (Read or Write)

Description	Specifies if the DNS server IPv4 addresses should be assigned from the DHCP server on the network.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv4Static.Gateway (Read or Write)

Description	iDRAC static IPv4 gateway (can be configured even when DHCP is enabled)
Legal Values	None
Default Values	• 192.168.0.1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPV6

This group contains the attributes that provides details about iDRAC IPv6 settings

iDRAC.IPv6.Address1 (Read or Write)

Description	iDRAC IPv6 Address
Legal Values	None
Default Values	• ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address10 (Read Only)

Description	iDRAC IPv6 tenth address
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address11 (Read Only)

Description	iDRAC IPv6 eleventh address
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address12 (Read Only)

Description	iDRAC IPv6 twelfth address
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address13 (Read Only)

Description	iDRAC IPv6 thirteenth address
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address14 (Read Only)

Description	iDRAC IPv6 fourteenth address
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC

License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address15 (Read Only)

Description	iDRAC IPv6 fifteenth address
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address2 (Read Only)

Description	iDRAC IPv6 second address
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address3 (Read Only)

Description	iDRAC IPv6 third address
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address4 (Read Only)

Description	iDRAC IPv6 fourth address
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address5 (Read Only)

Description	iDRAC IPv6 fifth address

Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address6 (Read Only)

Description	iDRAC IPv6 sixth address
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address7 (Read Only)

Description	iDRAC IPv6 seventh address
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address8 (Read Only)

Description	iDRAC IPv6 eighth address
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.Address9 (Read Only)

Description	iDRAC IPv6 ninth address
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.AddressState (Read Only)

Description	IPV6 Address State
Legal Values	• 0-Active • 1-Disabled • 2-Pending • 3-Failed • 4-Deprecated • 5-Invalid
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv6.AutoConfig (Read or Write)

Description	Enables or Disables the iDRAC IPv6 auto configuration option
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.DNS1 (Read or Write)

Description	IPv6 DNS Server 1 Address
Legal Values	None
Default Values	• ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.DNS2 (Read or Write)

Description	IPv6 DNS Server 2 Address
Legal Values	None
Default Values	• ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.DNSFromDHCP6 (Read or Write)

Description	Specifies if the DNS Server addresses are obtained from DHCP or not
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.DUID (Read Only)

Description	DHCP Unique Identifier
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv6.Enable (Read or Write)

Description	Enables or Disables iDRAC IPv6 stack
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv6.Gateway (Read or Write)

Description	iDRAC IPv6 Gateway
Legal Values	None
Default Values	• ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.LinkLocalAddress (Read Only)

Description	iDRAC IPv6 Link Local Address
Legal Values	None

Default Values	. ::
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6.PrefixLength (Read or Write)

Description	Prefix length for the iDRAC IPv6 Address
Legal Values	None
Default Values	. 64
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.IPv6Static

This group contains the attributes that provides details about iDRAC IPv6 Static.

iDRAC.IPv6Static.Address1 (Read or Write)

Description	iDRAC static IPv6 address
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv6Static.DNS1 (Read or Write)

Description	Statically configurable DNS Server 1
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv6Static.DNS2 (Read or Write)

Description	Statically configurable DNS Server 1
Legal Values	None
Default Values	. ::
Write Privilege	Configure iDRAC

License Required	Not Applicable
Dependency	None

iDRAC.IPv6Static.DNSFromDHCP6 (Read or Write)

Description	Specifies if the DNS server IPv6 addresses should be assigned from the DHCP server on the network.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv6Static.Gateway (Read or Write)

Description	iDRAC static IPv6 gateway
Legal Values	None
Default Values	• ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv6Static.PrefixLength (Read or Write)

Description	Prefix length for the iDRAC IPv6 Address
Legal Values	None
Default Values	• 64
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.IPv6URL

This group contains the attributes that provides details about iDRAC IPv6 URL.

iDRAC.IPv6URL.URL (Read Only)

Description	Provides the IPv6 URL for the iDRAC.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.LDAP

This group contains the attributes that provides details about iDRAC LDAP.

iDRAC.LDAP.BaseDN (Read or Write)

Description	The Domain Name of the branch of the directory where all searches should start from.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.BindDN (Read or Write)

Description	The distinguished name of a user used to bind to the server when searching for the login user's DN.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.BindPassword (Read or Write)

Description	A bind password to use in conjunction with the bindDN.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.CertValidationEnable (Read or Write)

Description	Controls certificate validation during SSL handshake.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.Enable (Read or Write)

Description	Turns LDAP service on or off.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.GroupAttribute (Read or Write)

Description	Specifies which LDAP attribute is used to check for group membership.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.GroupAttributeIsDN (Read or Write)

Description	Specifies whether the user domain name should be used from the LDAP server or from what was provided by user at login
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.Port (Read or Write)

Description	Port of LDAP over SSL.
Legal Values	None
Default Values	• 636
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.SearchFilter (Read or Write)

Description	A valid LDAP search filter to be used if the user attribute cannot uniquely identify the login user within the chosen baseDN.

Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.Server (Read or Write)

Description	Configures the address of the LDAP Server
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAP.UserAttribute (Read or Write)

Description	Specifies the user attribute to search for.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAPRoleGroup

This group contains the attributes that provides details about iDRAC LDAP Role Grouping.

iDRAC.LDAPRoleGroup.DN (Read or Write)

Description	This is the Domain Name of the group.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.LDAPRoleGroup.Privilege (Read or Write)

Description	A bit-mask defining the privileges associated with this particular group.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC

License Required	iDRAC Enterprise
Dependency	None

iDRAC.LocalSecurity

This group contains the attributes that provides details about iDRAC local security.

iDRAC.LocalSecurity.KCSAccess (Read or Write)

Description	Disable KCS access from host
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.LocalSecurity.LocalConfig (Read or Write)

Description	Enable local security
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.LocalSecurity.PrebootConfig (Read or Write)

Description	Enables or disables the ability of the local user to configure iDRAC from the BIOS POST option-ROM.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Lockdown

This group contains the attributes that provides details about iDRAC lockdown.

iDRAC.Lockdown.SystemLockdown (Read or Write)

Description	Specifies if the System Lockdown is enabled or disabled

Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.Logging

This group contains the attributes that provides details about iDRAC logging.

iDRAC.Logging.SELBufferType (Read or Write)

Description	Configurable attribute to modify the SEL behavior to make it linear instead of default circular.
Legal Values	• 0-Circular • 1-Linear
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Logging.SELOEMEventFilterEnable (Read or Write)

Description	Enable SEL OEM Event Filter
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.MgmtNetworkInterface

This group contains the attributes that provides details about iDRAC mgmt network interface.

iDRAC.MgmtNetworkInterface.NicConfig (Read or Write)

Description	NIC Configuration
Legal Values	• 0-Disabled • 1-CableDetect
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable

Dependency	Requires LOM1 NIC selection.

iDRAC.NIC

This group contains the attributes that provides details about iDRAC NIC.

iDRAC.NIC.AutoConfig (Read or Write)

Description	Enable Auto Configuration
Legal Values	• 0-Disabled • 1-Enable Once • 2-Enable Once After Reset
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.NIC.AutoConfigIPV6 (Read or Write)

Description	IPV6 Enable Auto Configuration
Legal Values	• 0-Disabled • 1-Enable Once • 2-Enable Once After Reset
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.AutoDetect (Read or Write)

Description	Enable or disable auto detection feature of iDRAC
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.NIC.Autoneg (Read or Write)

Description	Enables autonegotiation of physical link speed and duplex
Legal Values	• 0-Disabled • 1-Enabled

Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.DedicatedNICScanTime (Read or Write)

Description	Wait time for the iDRAC to switch from dedicated mode to shared mode.
Legal Values	None
Default Values	• 5
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.NIC.DiscoveryLLDP (Read or Write)

Description	Enables LLDP over active NIC Interface.
Legal Values	• 0-Disabled • 1-Dedicated • 2-SharedLOM • 3-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.DNSDomainFromDHCP (Read or Write)

Description	Specifies that the iDRAC DNS Domain Name should be assigned from the network DHCP server.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.NIC.DNSDomainName (Read or Write)

Description	The DNS Domain Name
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC

License Required	Not Applicable
Dependency	None

iDRAC.NIC.DNSDomainNameFromDHCP (Read or Write)

Description	Specifies that the iDRAC DNS Domain Name should be assigned from the network DHCP server.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.NIC.DNSRacName (Read or Write)

Description	The iDRAC name, which is iDRAC-<SVCTAG> by default
Legal Values	None
Default Values	• idrac-SVCTAG
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.NIC.DNSRegister (Read or Write)

Description	Registers the iDRAC name with the DNS server.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.NIC.DNSRegisterInterval (Read or Write)

Description	Set DNS Interval as required
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.Duplex (Read or Write)

Description	Specifies the duplex setting for the iDRAC NIC
Legal Values	• 0-Half • 1-Full
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.Enable (Read or Write)

Description	Enables or Disables the iDRAC network interface controller.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.Failover (Read or Write)

Description	Specifies the NIC Failover LOM.
Legal Values	• 0-None • 1-LOM1 • 2-LOM2 • 3-LOM3 • 4-LOM4 • 5-ALL
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.MACAddress (Read Only)

Description	The MAC Address of the iDRAC
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.MTU (Read or Write)

Description	The size in bytes of the maximum transmission unit used by the iDRAC NIC
Legal Values	None
Default Values	• 1500
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.Selection (Read or Write)

Description	Specifies the current mode of operation for the iDRAC network interface controller
Legal Values	• 1-Dedicated • 2-LOM1 • 3-LOM2 • 4-LOM3 • 5-LOM4
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.SharedNICScanTime (Read or Write)

Description	Wait time for the iDRAC to switch from shared mode to dedicated mode.
Legal Values	None
Default Values	• 30
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.NIC.Speed (Read or Write)

Description	Specifies the speed for the iDRAC NIC
Legal Values	• 0-10 • 1-100 • 2-1000 • 3-2500 • 4-10000 • 5-20000 • 6-25000 • 7-40000 • 8-50000 • 9-100000
Default Values	• 1

Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.SwitchConnection (Read Only)

Description	Specifies the Chassis ID extracted from LLDP packet
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.SwitchPortConnection (Read Only)

Description	Specifies the Port ID extracted from LLDP packet.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.TopologyLldp (Read or Write)

Description	Enable/Disable LLDP topology information
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.VLanEnable (Read or Write)

Description	Enables or Disables the VLAN capabilities of the iDRAC
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.VLanID (Read or Write)

Description	Specifies the VLAN ID for the network VLAN configuration
Legal Values	None
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.VLanPort (Read or Write)

Description	VLAN Port
Legal Values	• 0-Both • 1-Dedicated port only • 2-LOM ports only
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NIC.VLanPriority (Read or Write)

Description	Specifies the VLAN priority for the network VLAN configuration
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NICStatic

This group contains the attributes that provides details about iDRAC NIC Static.

iDRAC.NICStatic.DNSDomainFromDHCP (Read or Write)

Description	Specifies that the iDRAC DNS Domain Name should be assigned from the network DHCP server.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NICStatic.DNSDomainName (Read or Write)

Description	The DNS Domain Name
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.NTPConfigGroup

This group contains the attributes that provides details about iDRAC NTP Config group.

iDRAC.NTPConfigGroup.NTP1 (Read or Write)

Description	Name of NTP Server 1
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NTPConfigGroup.NTP2 (Read or Write)

Description	Name of NTP Server 2
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NTPConfigGroup.NTP3 (Read or Write)

Description	Name of NTP Server 3
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NTPConfigGroup.NTPEnable (Read or Write)

Description	Enable Network Time Protocol
Legal Values	• 0-Disabled

	• 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.NTPConfigGroup.NTPMaxDist (Read or Write)

Description	NTP Maximum Distance
Legal Values	None
Default Values	• 16
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.OS-BMC

This group contains the attributes that provides details about iDRAC OS BMC.

iDRAC.OS-BMC.AdminState (Read or Write)

Description	Manages the administrative state of the IMC.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.OS-BMC.OsIpAddress (Read or Write)

Description	OS-BMC Passthrough Host IP Address. Enter a valid IPv4 address.
Legal Values	None
Default Values	• 0.0.0.0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.OS-BMC.PTCapability (Read Only)

Description	OS-BMC Pass Through Capability
Legal Values	• 0-Not Capable

- 1-Capable
- 2-Unavailable

Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.OS-BMC.PTMode (Read or Write)

Description	Specify the OS-BMC Passthrough Mode
Legal Values	• 0-lom-p2p • 1-usb-p2p
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	OS-BMC.PTCompatibility must be set to Capable.

iDRAC.OS-BMC.UsbNicIpAddress (Read or Write)

Description	Specifies the USB NIC IP Address. Enter a valid IPv4 address.
Legal Values	None
Default Values	• 169.254.1.1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.OS-BMC.UsbNicIpV6Address (Read Only)

Description	USB NIC IPv6 Address
Legal Values	None
Default Values	• ::
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Platformcapability

This group contains the attributes that provides details about iDRAC Platform capability.

iDRAC.PlatformCapability.FrontPortUSBConfiguration (Read Only)

Description	When BIOS is configured as "All Ports Off (Dynamic)" the above capability attribute will be set to true, otherwise false.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.RACADM

This group contains the attributes that provides details about iDRAC RACADM.

iDRAC.Racadm.Enable (Read or Write)

Description	Enables or disables the Remote Racadm interface.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Racadm.MaxSessions (Read Only)

Description	Specifies the maximum number of active Remote Racadm sessions allowed.
Legal Values	None
Default Values	• 2
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Racadm.Timeout (Read or Write)

Description	Defines the idle timeout in seconds of the Remote Racadm interface.
Legal Values	None
Default Values	• 60
Write Privilege	Configure iDRAC
License Required	Not Applicable

Dependency	None

iDRAC.Redfish

This group contains the attributes that provides details about iDRAC Redfish.

iDRAC.Redfish.Enable (Read or Write)

Description	Redfish Enable
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.RedfishEventing

This group contains the attributes that provides details about iDRAC Redfish Eventing.

iDRAC.RedfishEventing.DeliveryRetryAttempts (Read or Write)

Description	This is the number of attempts an event posting is retried before the subscription is terminated.
Legal Values	• 0-0-5 •
Default Values	• 3
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.RedfishEventing.DeliveryRetryIntervalInSeconds (Read or Write)

Description	This represents the number of seconds between retry attempts for sending any given Event.
Legal Values	• 5-60-5-60
Default Values	• 5
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.RedfishEventing.IgnoreCertificateErrors (Read or Write)

Description	To ignore any SSL certificate warnings that may arise during SSL handshake with Event Listener.
Legal Values	• 0-No • 1-Yes
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.RemoteHosts

This group contains the attributes that provides details about iDRAC remote hosts.

iDRAC.RemoteHosts.SenderEmail (Read or Write)

Description	Specifies the address of emails sent by iDRAC
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.RemoteHosts.SMTPAuthentication (Read or Write)

Description	Enable SMTP Authentication
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.RemoteHosts.SMTPPassword (Read or Write)

Description	SMTP Password
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.RemoteHosts.SMTPPort (Read or Write)

Description	Specifies the SMTP Port
Legal Values	None
Default Values	• 25
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.RemoteHosts.SMTPServerIPAddress (Read or Write)

Description	Address of the network SMTP server
Legal Values	None
Default Values	• 0.0.0.0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.RemoteHosts.SMTPUserName (Read or Write)

Description	SMTP User Name
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.RFS

This group contains the attributes that provides details about iDRAC RFS

iDRAC.RFS.AttachMode (Read or Write)

Description	RFS Media attach mode
Legal Values	• 0-Auto Attach • 1-Attach
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.RFS.Enable (Read or Write)

Description	RFS Enable State
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.RFS.IgnoreCertWarning (Read or Write)

Description	Ignore certificate warning message
Legal Values	• 0-No • 1-Yes
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.RFS.Image (Read or Write)

Description	RFS Image path
Legal Values	None
Default Values	None
Write Privilege	Server Configuration
License Required	iDRAC Enterprise
Dependency	None

iDRAC.RFS.MediaAttachState (Read Only)

Description	RFS Media attach state
Legal Values	• 0-Detached • 1-Attached
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.RFS.Password (Read or Write)

Description	Specifies the remote file share password.

Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.RFS.Status (Read or Write)

Description	RFS connection status
Legal Values	• 0-Done • 1-Pending • 2-Error
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.RFS.User (Read or Write)

Description	Specifies the remote file share user.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.RFS.WriteProtected (Read Only)

Description	RFS Write Protection
Legal Values	• 0-Read Only • 1-Read Write
Default Values	• 0
Write Privilege	Server Configuration
License Required	iDRAC Enterprise
Dependency	None

iDRAC.RSM

This group contains the attributes that provides details about iDRAC RSM.

iDRAC.RSM.RSMCapability (Read Only)

Description	Indicates if system is Server Based Management Capable or not

Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

iDRAC.RSM.RSMSetting (Read Only)

Description	Indicates the current Server Based Management setting.
Legal Values	• 0-None • 1-Monitor • 2-Manage and Monitor
Default Values	• 1
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

iDRAC.Security

This group contains the attributes that provides details about iDRAC security.

iDRAC.Security.CsrCommonName (Read or Write)

Description	Specifies the CSR Common Name (CN) being certified (usually the web server's Fully Qualified Domain Name (FQDN).
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Security.CsrCountryCode (Read or Write)

Description	Specifies the CSR Country Code (CC).
Legal Values	None
Default Values	• US
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Security.CsrEmailAddr (Read or Write)

Description	Specifies the CSR email address.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Security.CsrKeySize (Read or Write)

Description	Specifies the SSL asymmetric key size for the CSRs.
Legal Values	• 2048-2048 • 4096-4096
Default Values	• 2048
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Security.CsrLocalityName (Read or Write)

Description	Specifies the CSR Locality (L).
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Security.CsrOrganizationName (Read or Write)

Description	Specifies the CSR Organization Name (O)
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Security.CsrOrganizationUnit (Read or Write)

Description	Specifies the CSR Organization Unit (OU)
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC

License Required	Not Applicable
Dependency	None

iDRAC.Security.CsrStateName (Read or Write)

Description	Specifies the CSR State Name (S).
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Security.CsrSubjectAltName (Read or Write)

Description	Specifies the CSR Subject Alternative Name
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Security.FIPSMode (Read or Write)

Description	Enables or Disables the FIPS mode compliance. Enabling FIPS mode resets iDRAC configuration to factory defaults.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Serial

This group contains the attributes that provides details about iDRAC Serial.

iDRAC.Serial.BaudRate (Read or Write)

Description	Sets the Baud rate on the iDRAC serial port
Legal Values	• 9600-9600 • 19200-19200 • 38400-38400 • 57600-57600 • 115200-115200

Default Values	• 57600
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Serial.Command (Read or Write)

Description	Specifies a serial command that is executed after the user logs into the serial console interface
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Serial.Enable (Read or Write)

Description	Enables or Disables the iDRAC serial console interface
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Serial.HistorySize (Read or Write)

Description	Specifies the maximum size of the serial history buffer
Legal Values	None
Default Values	• 8192
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Serial.IdleTimeout (Read or Write)

Description	The maximum number of seconds to wait before an idle serial console session is disconnected. The special value 0 disables the timeout.
Legal Values	None
Default Values	• 300
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Serial.NoAuth (Read or Write)

Description	Enables or Disables iDRAC serial console login authentication
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.SerialRedirection

This group contains the attributes that provides details about iDRAC Serial Redirection.

iDRAC.SerialRedirection.Enable (Read or Write)

Description	Enables or Disables the console for COM2 port redirection
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.SerialRedirection.QuitKey (Read or Write)

Description	This key or key combination terminates the Virtual Console when using the console COM2 command. The valid quitkey should start with ^ and has to end with any of the following characters: 'a-zA-Z[]^_' (i.e. letter or one of 5 special characters).
Legal Values	None
Default Values	• ^
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.ServerBoot

This group contains the attributes that provides details about iDRAC server boot.

iDRAC.ServerBoot.BootOnce (Read or Write)

Description	Enable Boot Once
Legal Values	• 0-Disabled • 1-Enabled

Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.ServerBoot.FirstBootDevice (Read or Write)

Description	Specify the First Boot Device.
Legal Values	None
Default Values	• Normal
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.ServiceModule

This group contains the attributes that provides details about iDRAC Service module.

iDRAC.ServiceModule.HostSNMPAlert (Read or Write)

Description	Host SNMP Alert
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.ServiceModule.HostSNMPGet (Read or Write)

Description	Host SNMP Get
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.ServiceModule.iDRACHardReset (Read or Write)

Description	ServiceModule Attribute for iDRAC reset
Legal Values	• 0-Disabled

- 1-Enabled

Default Values
- 1

Write Privilege Configure iDRAC

License Required Not Applicable

Dependency iDRAC.ServiceModule.ServiceModuleEnable should be Enabled

iDRAC.ServiceModule.iDRACSSOLauncher (Read or Write)

Description iDRAC SSO login via Host OS

Legal Values
- 0-Disabled
- 1-Enabled

Default Values
- 1

Write Privilege Configure iDRAC

License Required Not Applicable

Dependency None

iDRAC.ServiceModule.LCLReplication (Read or Write)

Description Enable Lifecycle Log Replication

Legal Values
- 0-Disabled
- 1-Enabled

Default Values
- 0

Write Privilege Configure iDRAC

License Required Not Applicable

Dependency With OMSA presence automatically set to 'Disabled'.

iDRAC.ServiceModule.OMSAPresence (Read Only)

Description Indicates if OMSA is present on the host or not.

Legal Values
- 0-Not Present
- 1-Present
- 2-NA

Default Values
- 2

Write Privilege Configure iDRAC

License Required Not Applicable

Dependency None

iDRAC.ServiceModule.OSInfo (Read or Write)

Description Enable Sharing OS Information via service module

Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	Provide OS information via iDRAC Service Module

iDRAC.ServiceModule.ServiceModuleEnable (Read or Write)

Description	Enable Service Module
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.ServiceModule.ServiceModuleState (Read Only)

Description	Specifies the state of the service module on the system
Legal Values	• 0-Not Running • 1-Running • 2-Not running (TLS error)
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.ServiceModule.ServiceModuleVersion (Read Only)

Description	Provides the installed version of iDRAC Service Module (iSM).
Legal Values	None
Default Values	• NA
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.ServiceModule.WatchdogRecoveryAction (Read or Write)

Description	Specifies the recovery action on watchdog alert
Legal Values	• 0-None • 1-Reboot • 2-Poweroff • 3-Powercycle
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	The value cannot be set if WatchdogState is 'Disabled'.

iDRAC.ServiceModule.WatchdogResetTime (Read or Write)

Description	Specifies the System reset time on watchdog alert
Legal Values	None
Default Values	• 480
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	The value cannot be set if WatchdogState is 'Disabled'.

iDRAC.ServiceModule.WatchdogState (Read or Write)

Description	Enable watchdog timer via service module
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	The value will be disabled if OMSA is detected or OS Watchdog is enabled.

iDRAC.ServiceModule.WMIInfo (Read or Write)

Description	Populate WMI information via ServiceModule
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable

Dependency	None

iDRAC.Smartcard

This group contains the attributes that provides details about iDRAC Smartcard.

iDRAC.SmartCard.SmartCardCRLEnable (Read or Write)

Description	Enables or disables the Certificate Revocation List (CRL).
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.SmartCard.SmartCardLogonEnable (Read or Write)

Description	Enables, disables, or enables with Remote RACADM support for access to iDRAC using a smart card
Legal Values	• 0-Disabled • 1-Enabled • 2-Enabled With Racadm
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.SNMP

This group contains the attributes that provides details about iDRAC SNMP.

iDRAC.SNMP.AgentCommunity (Read or Write)

Description	Specifies the SNMP community name to be used for SNMP Agents
Legal Values	None
Default Values	• public
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.SNMP.AgentEnable (Read or Write)

Description	Enables or Disables the SNMP Agent on the iDRAC

Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.SNMP.AlertPort (Read or Write)

Description	Specifies the SNMP Alert Port
Legal Values	None
Default Values	• 162
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.SNMP.DiscoveryPort (Read or Write)

Description	Specifies the SNMP Discovery Port
Legal Values	None
Default Values	• 161
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	The port number to be set can not be the same as any other service's port number.

iDRAC.SNMP.EngineID (Read Only)

Description	Specifies SNMP V3 Engine ID to be used to receive the SNMP v3 Trap
Legal Values	None
Default Values	• 0x800002A2040102030405060708090
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.SNMP.SNMPProtocol (Read or Write)

Description	SNMP Protocol
Legal Values	• 0-All • 1-SNMPv3
Default Values	• 0
Write Privilege	Configure iDRAC

License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.SNMP.TrapFormat (Read or Write)

Description	SNMP Trap Format
Legal Values	• 0-SNMPv1 • 1-SNMPv2 • 2-SNMPv3
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.SNMP.Alert

This group contains the attributes that provides details about iDRAC SNMP Alert.

iDRAC.SNMPAlert.Destination (Read or Write)

Description	Specifies the IPv4, IPv6, FQDN address, or hostname of the target destination to receive alerts. Must be valid IPv4, IPv6, FQDN address, or hostname.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.SNMPAlert.SNMPv3UserID (Read Only)

Description	Indicates the index of the iDRAC user that this SNMP alert destination has been configured to use when sending SNMP v3 traps.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.SNMPAlert.SNMPv3Username (Read or Write)

Description	Specifies the name of the iDRAC user that this SNMP alert destination is configured to use when sending SNMP v3 traps.
Legal Values	None
Default Values	None

Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	Value to be set must be an existing iDRAC user name, and that iDRAC user must be enabled with SNMPv3 support also enabled for that user.

iDRAC.SNMPAlert.State (Read or Write)

Description	Enable SNMP Alert State
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.SNMPTRAPIPv4

This group contains the attributes that provides details about iDRAC SNMP TRAP IPv4.

iDRAC.SNMPTrapIPv4.DestinationNum (Read Only)

Description	Identifier number for the trap destination.
Legal Values	None
Default Values	• 1
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

iDRAC.SNMPTrapIPv4.DestIPv4Addr (Read or Write)

Description	See SNMPAlert.1-4.Destination
Legal Values	None
Default Values	• 0.0.0.0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

iDRAC.SNMPTrapIPv4.State (Read or Write)

Description	See SNMPAlert.1-4.Enable
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0

Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

iDRAC.SNMPTRAPIPv6

This group contains the attributes that provides details about iDRAC SNMP TRAP IPv6.

iDRAC.SNMPTrapIPv6.DestinationNum (Read Only)

Description	Identifier number for the trap destination.
Legal Values	None
Default Values	• 1
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.SNMPTrapIPv6.DestIPv6Addr (Read or Write)

Description	See SNMPAlert.5-8.Destination
Legal Values	None
Default Values	• ::
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.SNMPTrapIPv6.State (Read or Write)

Description	See SNMPAlert.5-8.Enable
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.SSH

This group contains the attributes that provides details about iDRAC SSH.

iDRAC.SSH.Enable (Read or Write)

Description	Enables or Disables SSH

Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.SSH.MaxSessions (Read Only)

Description	Maximum number of SSH sessions allowed
Legal Values	None
Default Values	• 4
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.SSH.Port (Read or Write)

Description	Specifies the port number for the iDRAC SSH interface
Legal Values	None
Default Values	• 22
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	The port number to be set can not be the same as any other service's port number.

iDRAC.SSH.Timeout (Read or Write)

Description	Defines the secure shell idle timeout. The special value 0 disables the timeout.
Legal Values	None
Default Values	• 1800
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.SupportAssist

This group contains the attributes that provides details about iDRAC SupportAssist.

iDRAC.SupportAssist.DefaultIPAddress (Read or Write)

Description	Default IP address for saving SupportAssist collections to network share.
Legal Values	None
Default Values	None

Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.SupportAssist.DefaultPassword (Read or Write)

Description	Default password for saving SupportAssist collections to network share.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.SupportAssist.DefaultProtocol (Read or Write)

Description	Default protocol (NFS/CIFS Only) for saving SupportAssist collections.
Legal Values	• 1-NFS • 2-CIFS • 3-HTTP • 4-HTTPS • 5-TFTP • 6-FTP
Default Values	• 2
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.SupportAssist.DefaultProtocolPort (Read or Write)

Description	Default Protocol Port value
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.SupportAssist.DefaultShareName (Read or Write)

Description	Default share name for saving SupportAssist collections to network share.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable

Dependency	None

iDRAC.SupportAssist.DefaultUserName (Read or Write)

Description	Default user name for saving SupportAssist collections to network share.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.SupportAssist.DefaultWorkgroupName (Read or Write)

Description	Default workgroup name for saving SupportAssist collections to network share.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.SupportAssist.EmailOptIn (Read or Write)

Description	Option to receive E-mails from Dell on case creation and collection upload.
Legal Values	• 0-No • 1-Yes
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	Registration ID needs to be obtained before Email option configuration

iDRAC.SupportAssist.EventBasedAutoCollection (Read or Write)

Description	Indicates whether SupportAssist event based auto collection features is enabled on this system.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	Can be enabled only when SupportAssistEnableState is configured to 1-Enabled

iDRAC.SupportAssist.FilterAutoCollections (Read or Write)

Description	Indicates whether auto collections need to be filtered for identification information.
Legal Values	• 0-No • 1-Yes
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.SupportAssist.HostOSProxyAddress (Read or Write)

Description	Host OS proxy address
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	HostOSProxyConfigured should be Yes-1

iDRAC.SupportAssist.HostOSProxyConfigured (Read or Write)

Description	Indicates whether Host OS uses proxy configuration to connect to Internet.
Legal Values	• 0-No • 1-Yes
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.SupportAssist.HostOSProxyPassword (Read or Write)

Description	Host OS proxy password
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	HostOSProxyConfigured should be Yes-1

iDRAC.SupportAssist.HostOSProxyPort (Read or Write)

Description	Host OS proxy port
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	HostOSProxyConfigured should be Yes-1

iDRAC.SupportAssist.HostOSProxyUserName (Read or Write)

Description	Host OS proxy username
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	HostOSProxyConfigured should be Yes-1

iDRAC.SupportAssist.iDRACFirstPowerUpDateTime (Read Only)

Description	iDRAC's First Power Up Date / Time
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.SupportAssist.NativeOSLogsCollectionSupported (Read Only)

Description	Indicates whether Host OS supports native OS logs collection.
Legal Values	• 0-None • 1-FullReport • 2-FilteredReport • 3-Both
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.SupportAssist.PreferredLanguage (Read or Write)

Description	Preferred Language for E-mail communication from Dell
Legal Values	• 0-English • 1-German • 2-French • 3-Japanese • 4-Spanish • 5-Simplified Chinese
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	Registration ID needs to be obtained before changing language settings.

iDRAC.SupportAssist.ProSupportPlusRecommendationsReport (Read or Write)

Description	Indicates whether this server will be included for recommendations in ProSupport Plus Recommendations Report
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	ScheduleBasedAutoCollection is Enabled and set to Weekly or Monthly Schedule

iDRAC.SupportAssist.RegistrationID (Read Only)

Description	Specifies the SupportAssist Registration ID if the system was registered with Dell.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.SupportAssist.RequestTechnicianForPartsDispatch (Read or Write)

Description	Indicates whether onsite technician is required to replace the part that is being dispatched for the alert that is being monitored.
Legal Values	• 0-No • 1-Yes
Default Values	• 0
Write Privilege	Configure iDRAC

License Required	Not Applicable
Dependency	None

iDRAC.SupportAssist.SupportAssistEnableState (Read or Write)

Description	Indicates whether SupportAssist auto collection features are enabled on this system.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	Registration ID needs to be obtained before SupportAssistEnabledState can be toggled.

iDRAC.SwitchConnectionView

This group contains the attributes that provides details about iDRAC Switch connection view.

iDRAC.SwitchConnectionView.Enable (Read or Write)

Description	This Attribute is for Enabling/Disabling the Switch Connection View.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.SysInfo

This group contains the attributes that provides details about iDRAC Sysinfo.

iDRAC.SysInfo.LocalConsoleLockOut (Read or Write)

Description	Specifies the local console lockout state.
Legal Values	None
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.SysInfo.SystemRev (Read or Write)

Description	Provides the system revision.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Syslog

This group contains the attributes that provides details about iDRAC Syslog.

iDRAC.SysLog.Port (Read or Write)

Description	Remote syslog port number
Legal Values	None
Default Values	• 514
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.SysLog.PowerLogEnable (Read or Write)

Description	Enable Power Logs
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.SysLog.PowerLogInterval (Read or Write)

Description	Set Power Log Interval
Legal Values	None
Default Values	• 5
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.SysLog.Server1 (Read or Write)

Description	Name of remote syslog server
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.SysLog.Server2 (Read or Write)

Description	Name of remote syslog server
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.SysLog.Server3 (Read or Write)

Description	Name of remote syslog server
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.SysLog.SysLogEnable (Read or Write)

Description	Enables or disables remote syslog
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.Telnet

This group contains the attributes that provides details about iDRAC telnet.

iDRAC.Telnet.Enable (Read or Write)

Description	Enables or Disables Telnet

Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.Telnet.MaxSessions (Read Only)

Description	Maximum numbers of telnet sessions allowed
Legal Values	None
Default Values	• 2
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.Telnet.Port (Read or Write)

Description	Specifies the port number for the iDRAC Telnet interface
Legal Values	None
Default Values	• 23
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	The port number to be set can not be the same as any other service's port number.

iDRAC.Telnet.Timeout (Read or Write)

Description	Defines the Telnet idle timeout. The special value 0 disables the timeout.
Legal Values	None
Default Values	• 1800
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.Time

This group contains the attributes that provides details about iDRAC time.

iDRAC.Time.DayLightOffset (Read or Write)

Description	Specifies the daylight savings offset (in minutes) to use for the iDRAC Time.
Legal Values	None

Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Time.Timezone (Read or Write)

Description	Time Zone String
Legal Values	None
Default Values	• CST6CDT
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Time.TimeZoneOffset (Read or Write)

Description	Specifies the time zone offset (in minutes) from Greenwich Mean Time (GMT)/Coordinated Universal Time (UTC) to use for the iDRAC Time
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Update

This group contains the attributes that provides details about iDRAC update.

iDRAC.Update.EnableSharedCompUpdate (Read or Write)

Description	Enables or disables shared component update.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	RSM Capability should be enabled

iDRAC.Update.FwUpdateIPAddr (Read or Write)

Description	Specifies the TFTP server address to be used for iDRAC firmware update operations
Legal Values	None
Default Values	• 0.0.0.0

Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Update.FwUpdatePath (Read or Write)

Description	Specifies TFTP path where iDRAC firmware image resides on TFTP server
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Update.FwUpdateTFTPEnable (Read or Write)

Description	Enables or Disables iDRAC firmware updates from a TFTP server
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.USB

This group contains the attributes that provides details about iDRAC USB.

iDRAC.USB.ConfigurationXML (Read or Write)

Description	Specifies whether configuration can be performed using USB management port.
Legal Values	• 0-Disabled • 1-Enabled while server has default credential settings only • 2-Enabled • 3-Enabled only for compressed configuration files
Default Values	• 1
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

iDRAC.USB.ManagementPortMode (Read Only)

Description	Provides how USB Management Port is used.
Legal Values	• 0-iDRAC Direct Only

Default Values	• 0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

iDRAC.USB.PortStatus (Read or Write)

Description	Enables or disables the iDRAC front USB port.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.USB.ZipPassword (Read or Write)

Description	Specifies password that is used to unlock zip file containing Server Configuration Profile on USB drive.
Legal Values	None
Default Values	None
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

iDRAC.Userdomain

This group contains the attributes that provides details about iDRAC userdomain.

iDRAC.UserDomain.Name (Read or Write)

Description	Specifies the Active Directory user domain name. Must be fully qualified domain name or IP address of the domain controller.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.Users

This group contains the attributes that provides details about iDRAC users.

iDRAC.Users.AuthenticationProtocol (Read or Write)

Description	The Authentication Protocol for SNMP v3
Legal Values	• 0-None • 1-MD5 • 2-SHA
Default Values	• 2
Write Privilege	Configure User
License Required	Not Applicable
Dependency	Need valid username and password to set the attribute. The value could not be set to none if privacy protocol is not none.

iDRAC.Users.Enable (Read or Write)

Description	Enables or Disables an individual user
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure User
License Required	Not Applicable
Dependency	Both UserName and Password must be configured prior to enabling user

iDRAC.Users.IPMIKey (Read or Write)

Description	IPMI key is used for IPMI authentication
Legal Values	None
Default Values	None
Write Privilege	Configure User
License Required	Not Applicable
Dependency	Need valid username to set the attribute.

iDRAC.Users.IpmiLanPrivilege (Read or Write)

Description	Specifies the maximum privilege on the IPMI LAN channel
Legal Values	• 2-User • 3-Operator • 4-Administrator • 15-No Access
Default Values	• 15
Write Privilege	Configure User
License Required	Not Applicable
Dependency	Both UserName and Password must be configured prior to sets

iDRAC.Users.IpmiSerialPrivilege (Read or Write)

Description	Specifies the maximum IPMI Serial privilege
Legal Values	• 2-User • 3-Operator • 4-Administrator • 15-No Access
Default Values	• 15
Write Privilege	Configure User
License Required	Not Applicable
Dependency	Both UserName and Password must be configured prior to sets

iDRAC.Users.MD5v3Key (Read or Write)

Description	Specifies the MD5 hash of the SNMPv3 key
Legal Values	None
Default Values	None
Write Privilege	Configure User
License Required	Not Applicable
Dependency	Cannot be set without User Name being set first

iDRAC.Users.Password (Read or Write)

Description	iDRAC User Password
Legal Values	None
Default Values	None
Write Privilege	Configure User
License Required	Not Applicable
Dependency	Cannot be set without User Name being set first

iDRAC.Users.PrivacyProtocol (Read or Write)

Description	The Privacy Protocol for SNMP v3
Legal Values	• 0-None • 1-DES • 2-AES
Default Values	• 2
Write Privilege	Configure User
License Required	Not Applicable
Dependency	Need valid username and password to set the attribute. The value could not be set to AES or DES if authentication protocol is none.

iDRAC.Users.Privilege (Read or Write)

Description	Specifies the role based authority privileges allowed for the user. Below list shows the decimal values for each individual privilege.To create a custom privilege, add up below privilege decimal values and pass the value to the attribute. Login 1 Configure 2 Configure Users 4 Logs 8 System Control 16 Access Virtual Console 32 Access Virtual Media 64 System Operations 128 Debug 256
Legal Values	None
Default Values	• 0
Write Privilege	Configure User
License Required	Not Applicable
Dependency	Both UserName and Password must be configured prior to sets

iDRAC.Users.ProtocolEnable (Read or Write)

Description	Enable SNMP v3 Protocol
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure User
License Required	Not Applicable
Dependency	None

iDRAC.Users.SHA1v3Key (Read or Write)

Description	Specifies the SHA1 hash of the SNMPv3 key
Legal Values	None
Default Values	None
Write Privilege	Configure User
License Required	Not Applicable
Dependency	Cannot be set without User Name being set first

iDRAC.Users.SHA256Password (Read or Write)

Description	Specifies the SHA256 hash of the password
Legal Values	None
Default Values	None
Write Privilege	Configure User
License Required	Not Applicable
Dependency	Cannot be set without User Name being set first

iDRAC.Users.SHA256PasswordSalt (Read or Write)

Description	Specifies the Salt String appended to the password prior to hash
Legal Values	None

Default Values	None
Write Privilege	Configure User
License Required	Not Applicable
Dependency	Both User Name and SHA256 User password must be configured prior to sets

iDRAC.Users.SolEnable (Read or Write)

Description	Enables or Disables SOL for the user
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure User
License Required	Not Applicable
Dependency	Both UserName and Password must be configured prior to enabling user

iDRAC.Users.UserName (Read or Write)

Description	iDRAC User Name
Legal Values	None
Default Values	None
Write Privilege	Configure User
License Required	Not Applicable
Dependency	No duplicate User Names are allowed

iDRAC.vFlashPartition

This group contains the attributes that provides details about iDRAC vFlash partition.

iDRAC.vFlashPartition.AccessType (Read or Write)

Description	vFlash Partition Access Type
Legal Values	• 0-Read Write • 1-Read Only
Default Values	• 1
Write Privilege	Virtual Media
License Required	iDRAC Enterprise
Dependency	vFlash SD card has to be enabled. Partition at the specified index has to be created. AttachState should be Detached.

iDRAC.vFlashPartition.AttachState (Read or Write)

Description	vFlash Partition Attach State
Legal Values	• 0-Detached

	• 1-Attached
Default Values	• 0
Write Privilege	Virtual Media
License Required	iDRAC Enterprise
Dependency	vFlash SD card has to be enabled. Partition at the specified index has to be created

iDRAC.vFlashPartition.EmulationType (Read or Write)

Description	vFlash Partition Emulation Type
Legal Values	• 0-CD-DVD • 1-HDD • 2-Floppy
Default Values	• 0
Write Privilege	Virtual Media
License Required	iDRAC Enterprise
Dependency	vFlash SD card has to be enabled. Partition at the specified index has to be created. AttachState should be Detached.

iDRAC.vFlashPartition.FormatType (Read Only)

Description	vFlash Partition Format Type
Legal Values	• 0-RAW • 1-EXT2 • 2-EXT3 • 3-FAT16 • 4-FAT32
Default Values	• 0
Write Privilege	Virtual Media
License Required	iDRAC Enterprise
Dependency	vFlash SD card has to be enabled. Partition at the specified index has to be created

iDRAC.vFlashPartition.IsGroupInstanceValid (Read or Write)

Description	vFlash Partition Valid Group
Legal Values	• 0-Invalid • 1-Valid
Default Values	• 0
Write Privilege	Server Configuration
License Required	iDRAC Enterprise
Dependency	None

iDRAC.vFlashPartition.Size (Read Only)

Description	vFlash Partition Size
Legal Values	None
Default Values	• 0
Write Privilege	Virtual Media
License Required	iDRAC Enterprise
Dependency	vFlash SD card has to be enabled. Partition at the specified index has to be created

iDRAC.vFlashPartition.VolumeLabel (Read Only)

Description	vFlash Partition Volume Label
Legal Values	None
Default Values	• 0
Write Privilege	Virtual Media
License Required	iDRAC Enterprise
Dependency	vFlash SD card has to be enabled. Partition at the specified index has to be created

iDRAC.vFlashSD

This group contains the attributes that provides details about iDRAC vFlash SD.

iDRAC.vFlashSD.AvailableSize (Read Only)

Description	vFlash SD Available Size
Legal Values	None
Default Values	None
Write Privilege	Virtual Media
License Required	iDRAC Enterprise
Dependency	vFlashSD has to be enabled

iDRAC.vFlashSD.Bitmap (Read or Write)

Description	Bitmap
Legal Values	None
Default Values	• 0x0000000000000000
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.vFlashSD.Enable (Read or Write)

Description	Enable vFlash SD

Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Virtual Media
License Required	iDRAC Enterprise
Dependency	None

iDRAC.vFlashSD.Health (Read Only)

Description	vFlash SD Health
Legal Values	• 0-OK • 1-Critical • 2-Warning • 3-Unknown
Default Values	• 0
Write Privilege	Virtual Media
License Required	iDRAC Enterprise
Dependency	vFlashSD has to be enabled

iDRAC.vFlashSD.Initialized (Read Only)

Description	Specifies if vFlash SD is initialized
Legal Values	• 0-Not Initialized • 1-Initialized
Default Values	• 0
Write Privilege	Virtual Media
License Required	iDRAC Enterprise
Dependency	vFlashSD has to be enabled

iDRAC.vFlashSD.Licensed (Read Only)

Description	Specifies if the vFlash SD is licensed
Legal Values	• 0-Not Licensed • 1-Licensed
Default Values	• 0
Write Privilege	Virtual Media
License Required	iDRAC Enterprise
Dependency	vFlashSD has to be enabled

iDRAC.vFlashSD.Presence (Read or Write)

Description	vFlash SD card presence

Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

iDRAC.vFlashSD.Size (Read Only)

Description	vFlash SD Size
Legal Values	None
Default Values	None
Write Privilege	Virtual Media
License Required	iDRAC Enterprise
Dependency	vFlashSD has to be enabled

iDRAC.vFlashSD.WriteProtect (Read Only)

Description	Enable vFlash SD Write Protect
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Virtual Media
License Required	iDRAC Enterprise
Dependency	vFlashSD has to be enabled

iDRAC.VirtualConsole

This group contains the attributes that provides details about iDRAC virtual console.

iDRAC.VirtualConsole.AccessPrivilege (Read or Write)

Description	Specifies the default action upon session sharing request timeout
Legal Values	• 0-Full Access • 1-Read Only Access • 2-Deny Access
Default Values	• 2
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.ActiveSessions (Read Only)

Description	Specifies current active number of Virtual Console sessions.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.AttachState (Read or Write)

Description	Specifies the attach state for the Virtual Console.
Legal Values	• 0-Detached • 1-Attached • 2-Auto-attach
Default Values	• 2
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.Enable (Read or Write)

Description	Enables or disables the Virtual Console.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.EncryptEnable (Read or Write)

Description	Encrypts the video in a Virtual Console session.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.LocalDisable (Read or Write)

Description	Enables/disables the video signal on the local video port of the server.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.LocalVideo (Read or Write)

Description	Enables or disables the local server video.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.MaxSessions (Read or Write)

Description	Specifies maximum number of Virtual Console sessions.
Legal Values	None
Default Values	• 6
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.PluginType (Read or Write)

Description	Specifies the plugin type to use when running Virtual Console from a browser.
Legal Values	• 0-ActiveX • 1-Java • 2-HTML5
Default Values	• 2
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.Port (Read or Write)

Description	Specifies the virtual KVM port.
Legal Values	None
Default Values	• 5900
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	The port number to be set can not be the same as any other service's port number.

iDRAC.VirtualConsole.Timeout (Read or Write)

Description	Specifies the idle timeout in seconds for the Virtual Console.
Legal Values	None
Default Values	• 1800
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualConsole.TimeoutEnable (Read or Write)

Description	Specifies if timeout is enabled for the Virtual Console
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualMedia

This group contains the attributes that provides details about iDRAC virtual media.

iDRAC.VirtualMedia.ActiveSessions (Read Only)

Description	Provides the number of Virtual Media sessions that are currently active.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualMedia.Attached (Read or Write)

Description	Used to attach virtual devices to the system via the USB bus
Legal Values	• 0-Detached • 1-Attached • 2-AutoAttach
Default Values	• 2
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualMedia.BootOnce (Read or Write)

Description	Enables or Disables the virtual media boot once feature of the iDRAC
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualMedia.Enable (Read or Write)

Description	Enables or disables the Virtual Media.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualMedia.EncryptEnable (Read or Write)

Description	Encrypts the video in a Virtual Media session
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualMedia.FloppyEmulation (Read or Write)

Description	When Disabled, the virtual floppy disk is recognized as a removable disk by Windows OS
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualMedia.KeyEnable (Read or Write)

Description	Enables or Disables the virtual media key feature of the iDRAC
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRAC.VirtualMedia.MaxSessions (Read Only)

Description	Provides the maximum number of the Virtual Media sessions allowed.
Legal Values	None
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

iDRC.VNCServer

This group contains the attributes that provides details about iDRAC VNC server.

iDRAC.VNCServer.ActiveSessions (Read Only)

Description	VNC Server Current Active VNC Sessions
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.VNCServer.Enable (Read or Write)

Description	Enable VNC Server
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.VNCServer.LowerEncryptionBitLength (Read or Write)

Description	Enable VNC Lower Encryption Bit Length
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.VNCServer.MaxSessions (Read or Write)

Description	VNC Server Maximum Session Allowed
Legal Values	None
Default Values	• 2
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.VNCServer.Password (Read or Write)

Description	VNC Server Password
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.VNCServer.Port (Read or Write)

Description	VNC Server Port

Legal Values	None
Default Values	• 5901
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.VNCServer.SSLEncryptionBitLength (Read or Write)

Description	VNC SSL Encryption Bit Length
Legal Values	• 0-Disabled • 1-Auto Negotiate • 2-128-Bit or higher • 3-168-Bit or higher • 4-256-Bit or higher
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.VNCServer.Timeout (Read or Write)

Description	VNC Server Timeout
Legal Values	None
Default Values	• 300
Write Privilege	Configure iDRAC
License Required	iDRAC Enterprise
Dependency	None

iDRAC.WebServer

This group contains the attributes that provides details about iDRAC web server

iDRAC.WebServer.CustomCipherString (Read or Write)

Description	Specifies the custom cipher string to filter the available in-use TLS cipher suite (e.g. DEFAULT:CAMELLIA - Note: These strings are case sensitive).
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.WebServer.Enable (Read or Write)

Description	Enables or Disables iDRAC WebServer
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.WebServer.HttpPort (Read or Write)

Description	Specifies the port number for HTTP communication with the iDRAC
Legal Values	None
Default Values	• 80
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.WebServer.HttpsPort (Read or Write)

Description	Specifies the port number for HTTPS communication with the iDRAC
Legal Values	None
Default Values	• 443
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.WebServer.HttpsRedirection (Read or Write)

Description	Enable HTTPS redirection
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.WebServer.LowerEncryptionBitLength (Read or Write)

Description	Lower Encryption Bit Length

Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.WebServer.MaxNumberOfSessions (Read Only)

Description	Max session allowed
Legal Values	None
Default Values	• 8
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.WebServer.SSLEncryptionBitLength (Read or Write)

Description	Specifies the SSL encryption bit length.
Legal Values	• 0-Auto-Negotiate • 1-128-Bit or higher • 2-168-Bit or higher • 3-256-Bit or higher
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.WebServer.Timeout (Read or Write)

Description	Specifies the web server idle timeout.
Legal Values	None
Default Values	• 1800
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.WebServer.TitleBarOption (Read or Write)

Description	Specifies what to display in the title bar.

Legal Values	• 1-Auto • 2-DNS RAC Name • 3-IP Address • 4-Service Tag • 5-System Host Name • 6-Custom
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.WebServer.TitleBarOptionCustom (Read or Write)

Description	Specifies the custom title when the title bar option is Custom.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

iDRAC.WebServer.TLSProtocol (Read or Write)

Description	Specifies the TLS protocol version support.
Legal Values	• 0-TLS 1.0 and Higher • 1-TLS 1.1 and Higher • 2-TLS 1.2 Only
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

3

Lifecycle Controller Attributes

Topics:

- LifecycleController.LCAttributes

LifecycleController.LCAttributes

This group contains the Lifecycle controller LC attributes details.

LifecycleController.LCAttributes.AutoBackup (Read or Write)

Description	Enables or disables the automatic backup scheduler.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.AutoDiscovery (Read Only)

Description	Indicates if Auto Discovery feature is turned off or on.
Legal Values	• 0-Off • 1-On
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.AutoUpdate (Read or Write)

Description	Enables or disables the automatic update scheduler.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0

Write Privilege	Server Configuration
License Required	iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.BIOSRTDRequested (Read or Write)

Description	Allows to reset all the BIOS attributes to the default state. After this property is enabled, restart iDRAC to view the default values of BIOS.
Legal Values	• 0-False • 1-True • 2-OEMIDDefaults
Default Values	• 0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

LifecycleController.LCAttributes.CMCIP (Read Only)

Description	CMC IP address
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

LifecycleController.LCAttributes.CollectSystemInventoryOnRestart (Read or Write)

Description	Enables or disables collection of system inventory on host reboot.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.DiscoveryFactoryDefaults (Read Only)

Description	Off- Do not reset to factory defaults when performing auto discovery. On-Reset to defaults when performing auto discovery.

Legal Values	• 0-Off • 1-On
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.IgnoreCertWarning (Read or Write)

Description	Ignore Certificate warning default when not provided.
Legal Values	• 0-Off • 1-On
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

LifecycleController.LCAttributes.IPAddress (Read or Write)

Description	IP Address of the network share
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

LifecycleController.LCAttributes.IPChangeNotifyPS (Read or Write)

Description	On- Notify provisioning server of an IP change. Off- Do not notify provisioning server of an IP change.
Legal Values	• 0-Off • 1-On
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

LifecycleController.LCAttributes.Licensed (Read Only)

Description	Indicates if the Part Replacement feature is licensed or not
Legal Values	• 0-No • 1-Yes
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

LifecycleController.LCAttributes.LifecycleControllerState (Read or Write)

Description	Enables or disables Lifecycle Controller.
Legal Values	• 0-Disabled • 1-Enabled • 2-Recovery
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.PartConfigurationUpdate (Read or Write)

Description	Apply hardware configuration to the replaced part on part replacement.
Legal Values	• 0-Disabled • 1-Apply Always • 2-Apply only if Firmware Match
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.PartFirmwareUpdate (Read or Write)

Description	Apply firmware changes to the replaced part on part replacement.
Legal Values	• 0-Disable • 1-Allow version upgrade only • 2-Match firmware of replaced part

Default Values	. 2
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.ProvisioningServer (Read or Write)

Description	Provisioning server address and port.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.StorageHealthRollupStatus (Read Only)

Description	[To be filled]
Legal Values	None
Default Values	. 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

LifecycleController.LCAttributes.SystemID (Read Only)

Description	Dell System ID
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

LifecycleController.LCAttributes.UserProxyPassword (Read or Write)

Description	Proxy Password default if not provided
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC

License Required	Not Applicable
Dependency	None

LifecycleController.LCAttributes.UserProxyPort (Read or Write)

Description	Proxy Port default if not provided. Proxy Port is limited to values in the range of 0 - 65535.
Legal Values	None
Default Values	• 80
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

LifecycleController.LCAttributes.UserProxyServer (Read or Write)

Description	Proxy Server default if not provided.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

LifecycleController.LCAttributes.UserProxyType (Read or Write)

Description	Proxy Type default if not provided
Legal Values	• 0-HTTP • 1-SOCKS
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

LifecycleController.LCAttributes.UserProxyUserName (Read or Write)

Description	Proxy User name default if not provided.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC

License Required	Not Applicable
Dependency	None

LifecycleController.LCAttributes.VirtualAddressManagement (Read or Write)

Description	Specify the Virtual Address Management setting
Legal Values	• 0-Console • 1-FlexAddress
Default Values	• 1
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

LifecycleController.LCAttributes.VirtualAddressManagementApplication (Read or Write)

Description	The console name of the Virtual Address Management Application,VirtualAddressManagement attribute is set to CurrentValue equals "Console".
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

4

System Attributes

Topics:

- System.AcquisitionInfo
- System.Backplane
- System.ChassisControl
- System.ChassisInfo
- System.CustomAsset
- System.DepreciationInfo
- System.Diagnostics
- System.ExtWarrantyInfo
- System.LCD
- System.LeaseInfo
- System.MaintenanceInfo
- System.OpenIDConnectServer
- System.OutsourceInfo
- System.OwnerInfo
- System.PCIeSlotLFM
- System.PowerHistorical
- System.QuickSync
- System.SC-BMC
- System.ServerInfo
- System.ServerOS
- System.ServerPwr
- System.ServerPwrMon
- System.ServerTopology
- System.ServiceContract
- System.Storage
- System.SupportInfo
- System.SystemInfo
- System.ThermalConfig
- System.ThermalHistorical
- System.ThermalSettings
- System.USBFront
- System.WarrantyInfo

System.AcquisitionInfo

This group contains the attributes that provides details about `System.AcquisitionInfo`.

System.AcquisitionInfo.CostCenter (Read or Write)

Description	Identifying information for the accounting unit within the purchasing company that authorized the purchase.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	RACADM

Dependency	None

System.AcquisitionInfo.Expensed (Read or Write)

Description	Determines whether the cost of the system was subtracted from the budget of a particular person or department in the purchasing company.
Legal Values	• 0-Yes • 1-No
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.AcquisitionInfo.InstallDate (Read or Write)

Description	Date the system was put into service by the purchasing company.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.AcquisitionInfo.PONumber (Read or Write)

Description	Number of the purchase order that authorized buying the system.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.AcquisitionInfo.PurchaseCost (Read or Write)

Description	Value expressed in currency unit that was paid for the system, for example, 25000.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.AcquisitionInfo.PurchaseDate (Read or Write)

Description	Date the transaction for acquiring the system was completed.

Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.AcquisitionInfo.Vendor (Read Only)

Description	Company who sold the system to the purchaser.
Legal Values	None
Default Values	• Dell
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.AcquisitionInfo.WayBill (Read or Write)

Description	Identifying information for the waybill or delivery slip, such as a waybill number.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.AcquisitionInfo.WhoSigned (Read or Write)

Description	Person who accepted delivery of the system.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.Backplane

This group contains the attributes that provides details about System backplane.

System.Backplane.BackplaneBusMode (Read Only)

Description	Enclosure serial interface type, either SGPIO or I2C
Legal Values	• 0-Unknown • 1-I2C • 2-SGPIO

Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.Backplane.BackplaneSplitMode (Read or Write)

Description	Enclosure split mode setting
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ChassisControl

This group contains the attributes that provides details about System Chassis Control.

System.ChassisControl.ChassisManagementatServer (Read Only)

Description	Specifies the Chassis Management at Server (CMAS) setting for the CMC.
Legal Values	• 0-None • 1-Monitor • 2-Manage and Monitor
Default Values	• 0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

System.ChassisControl.ChassisManagementMonitoring (Read or Write)

Description	Specifies the Chassis Management at Server (CMAS) setting for the iDRAC.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

System.ChassisControl.FTREnable (Read or Write)

Description	Enable/Disable Fault Tolerant Redundancy
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ChassisInfo

This group contains the attributes that provides details about sytem chassis info.

System.ChassisInfo.ChassisModel (Read Only)

Description	Specifies the chassis model.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ChassisInfo.ChassisName (Read Only)

Description	Specifies the chassis name.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ChassisInfo.ChassisServiceTag (Read Only)

Description	Specifies the chassis service tag.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ChassisInfo.ChassisType (Read Only)

Description	Specifies the chassis type.

Legal Values	• 0-Data Not Available • 9-M1000e • 10-VRTX • 11-FX2 PSB • 12-FX2 FOB • 16-MX7000
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ChassisInfo.ConnectionState (Read Only)

Description	Chassis connection state
Legal Values	• 0-Unknown • 1-Disconnected/Offline • 2-Connected/Ready
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ChassisInfo.FirmwareVersion (Read Only)

Description	Chassis firmware version
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ChassisInfo.IPV4Address (Read Only)

Description	Chassis IPV4 address
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ChassisInfo.IPV6Address (Read Only)

Description	Chassis IPV6 address
Legal Values	None

Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.CustomAsset

This group contains the attributes that provides details about System.CustomAsset.

System.CustomAsset.Label (Read or Write)

Description	Custom Asset label.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.CustomAsset.Value (Read or Write)

Description	Custom Asset value
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.DepreciationInfo

This group contains the attributes that provides details about System.DepreciationInfo.

System.DepreciationInfo.Duration (Read or Write)

Description	Displays the duration for which the depreciation value is being calculated.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.DepreciationInfo.DurationUnit (Read or Write)

Description	Indicates the duration in months or years.
Legal Values	• 0-Months

- 1-Years

Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.DepreciationInfo.Method (Read or Write)

Description	Displays the steps and assumptions used to compute the system's depreciation.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.DepreciationInfo.Percentage (Read or Write)

Description	Indicates the portion of 100 that an asset is devalued or depreciated. If the duration of depreciation is 5 years, and the method is straight line, then the percentage is 20 percent.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.Diagnostics

This group contains the attributes that provides details about system diagnostics.

System.Diagnostics.OSAppCollectionTime (Read Only)

Description	Displays the last OS and Application Data collection time
Legal Values	None
Default Values	None
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

System.ExtWarrantyInfo

This group contains the attributes that provides details about System.ExtWarrantyInfo

System.ExtWarrantyInfo.Cost (Read or Write)

Description	Displays the total cost of the warranty service on a system.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ExtWarrantyInfo.EndDate (Read or Write)

Description	Displays the date that extended warranty service ends.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ExtWarrantyInfo.Provider (Read or Write)

Description	Displays the name of the business that is providing warranty service to the system owner.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ExtWarrantyInfo.StartDate (Read or Write)

Description	Displays the date that extended warranty service begins. This date usually follows the standard warranty service.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.LCD

This group contains the attributes that provide details about System.LCD.

System.LCD.ChassisIdentifyDuration (Read or Write)

Description	Enable/Disable chassis Identify. A value of -1 = force on indefinitely; 0 = 0ff; > 0 number of seconds chassis identify is on

Legal Values	None
Default Values	• 0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

System.LCD.Configuration (Read or Write)

Description	Current LCD configuration. If this is set to User Defined, the User defined string will be displayed on the LCD.
Legal Values	• 0-User Defined • 1-Model Name • 2-None • 4-iDRAC IPv4 Address • 8-iDRAC MAC Address • 16-OS System Name • 32-Service Tag • 64-IPv6 Address • 128-Ambient Temperature • 129-Airflow • 256-System Watts • 512-Asset Tag • 1024-Post • 2048-ADStat • 2049-ADTime • 2050-ADComp • 2051-ADErr
Default Values	• 32
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.LCD.CurrentDisplay (Read Only)

Description	The string currently displayed on the LCD
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.LCD.ErrorDisplayMode (Read or Write)

Description	LCD error message format selection SEL or simple where simple format include the message ID.
Legal Values	• 1-SEL • 2-simple
Default Values	• 1

Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

System.LCD.FrontPanelLocking (Read or Write)

Description	Sets LCD button interface to Full-Access;View-Only; or No access (Locked)
Legal Values	• 0-Full-Access • 1-View-Only • 2-Locked
Default Values	• 0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

System.LCD.HideErrs (Read or Write)

Description	Hide or unhide errors displayed on LCD screen.
Legal Values	• 0-hide • 1-unhide
Default Values	• 1
Write Privilege	
License Required	Not Applicable
Dependency	None

System.LCD.LicenseMsgEnable (Read or Write)

Description	Enable/disable display of no license available for certain licensable features.
Legal Values	• 0-No-License-Msg • 1-Display-Licens-Msg
Default Values	• 0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

System.LCD.NMIResetOverride (Read or Write)

Description	Enable/disables iDRAC reset capability via the Chassis ID button
Legal Values	• 0-DIsabled • 1-IDButtonResets • 2-IDButtonDoesNotReset
Default Values	• 0

Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

System.LCD.NumberErrsHidden (Read Only)

Description	The number of hidden LCD active errors
Legal Values	None
Default Values	• 0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

System.LCD.NumberErrsVisible (Read Only)

Description	The number of visible LCD active errors
Legal Values	None
Default Values	• 0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

System.LCD.QualifierTemp (Read or Write)

Description	Specifies Ambient Temperature Qualifier
Legal Values	• 0-C • 1-F
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.LCD.QualifierWatt (Read or Write)

Description	Specifies System Watt Qualifier
Legal Values	• 0-Watts • 1-BTU/hr
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.LCD.UserDefinedString (Read or Write)

Description	User defined custom string for display on LCD
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	System.LCD.Configuration has to be set to 'User Defined' mode

System.LCD.vConsoleIndication (Read or Write)

Description	Virtual Console Indication
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.LeaseInfo

This group contains the attributes that provides details about System.LeaseInfo.

System.LeaseInfo.Buyout (Read or Write)

Description	Indicates the amount of money you would have to pay to own a system you are leasing.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.LeaseInfo.EndDate (Read or Write)

Description	Displays the agreed upon day, month, and year that the lease is no longer in force.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.LeaseInfo.FairValue (Read or Write)

Description	Refers to an arrangement that allows a customer to purchase systems at the end of the lease for its then current fair market value.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.LeaseInfo.Lessor (Read or Write)

Description	Displays the name of the business entity that is leasing the system to the user.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.LeaseInfo.MultiSched (Read or Write)

Description	Indicates whether the cost of leasing the system is computed by more than one rate schedule.
Legal Values	• 0-Yes • 1-No
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.LeaseInfo.RateFactor (Read or Write)

Description	Displays the factor used to calculate the lease payment.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.MaintenanceInfo

This group contains the attributes that provides details about System.MaintenanceInfo.

System.MaintenanceInfo.EndDate (Read or Write)

Description	The date that maintenance ends.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.MaintenanceInfo.Provider (Read or Write)

Description	The business entity that provides maintenance on a system.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.MaintenanceInfo.Restrictions (Read or Write)

Description	Any exclusions that apply to the maintenance agreement for the system.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.MaintenanceInfo.StartDate (Read or Write)

Description	The date that maintenance begins.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.OpenIDConnectServer

This group contains the attributes that provide details about System.OpenIDConnnectServer.

System.OpenIDConnectServer.DiscoveryURL (Read or Write)

Description	Discovery URL

Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.OpenIDConnectServer.Enabled (Read or Write)

Description	Server state
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.OpenIDConnectServer.HttpsCertificate (Read or Write)

Description	HTTPS public certificate
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.OpenIDConnectServer.Name (Read or Write)

Description	Server name
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.OpenIDConnectServer.RegistrationDetails (Read or Write)

Description	Registration details
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC

License Required	Not Applicable
Dependency	None

System.OpenIDConnectServer.RegistrationStatus (Read Only)

Description	Registration status
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.OutsourceInfo

This group contains the attributes that provides details about System.OutsourceInfo.

System.OutsourceInfo.ProbComp (Read or Write)

Description	Component of the system that requires corrective action such as repair or replacement.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.OutsourceInfo.ProviderFee (Read or Write)

Description	Defines any additional fee invoiced by the outsource service provider.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.OutsourceInfo.ServiceFee (Read or Write)

Description	Amount of money paid for either the service contract or for corrective action on a specific problem component.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.OutsourceInfo.SignedFor (Read or Write)

Description	Person who authorized the repair of the component.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.OutsourceInfo.SLALevel (Read or Write)

Description	Service Level Agreement (SLA) between the service provider and the system owner spells out when service is available (for example, how many hours and days per week) and what components are excluded. Levels of service to which the system owner is entitled.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.OwnerInfo

This group contains the attributes that provides details about System.OwnerInfo.

System.OwnerInfo.InsComp (Read or Write)

Description	The company that insures the system against theft or other loss.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.OwnerInfo.OwnerName (Read or Write)

Description	The individual or business entity that holds legal title to the system.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.OwnerInfo.Type (Read or Write)

Description	Whether the system is owned or leased.

Legal Values	• 0-Owned • 1-Leased
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.PCIeSlotLFM

This group contains the attributes that provides details about System PCIeSlot LFM.

System.PCIeSlotLFM.3rdPartyCard (Read Only)

Description	3rd Party PCIe Card may benefit from additional settings
Legal Values	• 0-No • 1-Yes • 2-N/A
Default Values	• 2
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.PCIeSlotLFM.CardType (Read Only)

Description	Type of PCIe card installed
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.PCIeSlotLFM.CustomLFM (Read or Write)

Description	Minimum airflow to be delivered the installed PCIe card
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	CustomLFM is read/write when LFMMode is set to custom

System.PCIeSlotLFM.LFMMode (Read or Write)

Description	Cooling Response Mode

Legal Values	• 0-Automatic • 1-Disabled • 2-Custom
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	LFMMode is read/write when 3rdPartyCard is set to Yes

System.PCIeSlotLFM.MaxLFM (Read Only)

Description	Estimated airflow delivered to the slot at full fan speed
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.PCIeSlotLFM.PCIeInletTemperature (Read Only)

Description	Indicates the current PCIe Inlet Temperature for the PCIe Slot.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.PCIeSlotLFM.SlotState (Read Only)

Description	PCIe slot physically exists
Legal Values	• 0-Not-Defined • 1-Defined
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.PCIeSlotLFM.TargetLFM (Read Only)

Description	Minimum airflow provisioned for the installed PCIe card
Legal Values	None
Default Values	• -
Write Privilege	Configure iDRAC

License Required	Not Applicable
Dependency	None

System.PowerHistorical

This group contains the attributes that provide details about System.PowerHistorical.

System.PowerHistorical.IntervalInSeconds (Read or Write)

Description	Time interval between two power reading in the graph.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.QuickSync

This group contains the attributes that provides details about System quicksync.

System.QuickSync.Access (Read or Write)

Description	Sets QuickSync access permission
Legal Values	• 0-Disabled • 1-Read-only • 2-Read-write
Default Values	• 2
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	System.QuickSync.Presence has to be Absent or Present

System.QuickSync.InactivityTimeout (Read or Write)

Description	Quick Sync Inactivity Timeout value specified in seconds with max value of 3600 seconds
Legal Values	None
Default Values	• 120
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	Cannot be set unless InactivityTimerEnable is Enabled

System.QuickSync.InactivityTimerEnable (Read or Write)

Description	Enables or disables the QuickSync inactivity timer
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	System.QuickSync.Presence has to be Absent or Present

System.QuickSync.Presence (Read Only)

Description	Indicates the presence or absence of the QuickSync hardware
Legal Values	• 0-Not Supported • 1-Absent • 2-Present
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	System.QuickSync.Presence has to be Absent or Present

System.QuickSync.ReadAuthentication (Read or Write)

Description	Enables or disables QuickSync read authentication to the server
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	System.QuickSync.Presence has to be Absent or Present

System.QuickSync.WifiEnable (Read or Write)

Description	Enables or disables QuickSync WiFi access
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	System.QuickSync.Presence has to be Absent or Present

System.SC-BMC

This group contains the attributes that provide details about System.SC-BMC.

System.SC-BMC.ChassisInfraPower (Read Only)

Description	Chassis Infrastructure Power
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.SC-BMC.ChassisPowerCap (Read Only)

Description	Chassis Power Cap
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.SC-BMC.ChassisServiceTag (Read Only)

Description	Chassis Service tag
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.SC-BMC.PowerMonitoring (Read or Write)

Description	Power monitoring
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerInfo

This group contains the attributes that provides details about system server info.

System.ServerInfo.NodeID (Read Only)

Description	Specifies the system node ID.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerInfo.RChassisServiceTag (Read Only)

Description	Provides the system chassis-related service tag.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerInfo.ServerType (Read Only)

Description	The type of physical form factor of the Server
Legal Values	• 0-Rack • 1-Blade • 2-Tower • 3-Sled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerInfo.ServiceTag (Read Only)

Description	Specifies the system service tag.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerOS

This group contains the attributes that provides details about system server OS.

System.ServerOS.HostName (Read or Write)

Description	Server Host Name
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerOS.OEMOSVersion (Read Only)

Description	Server OEM OS Version
Legal Values	None
Default Values	None
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

System.ServerOS.OSName (Read or Write)

Description	Server Operating System
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerOS.OSVersion (Read Only)

Description	Server OS Version
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerOS.ProductKey (Read Only)

Description	Windows OS Product Key associated with the server
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable

Dependency	None

System.ServerOS.ServerPoweredOnTime (Read Only)

Description	Indicates the time since the Host OS has been powered on (seconds).
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerPwr

This group contains the attributes that provides details about system server power.

System.ServerPwr.ActivePolicyName (Read Only)

Description	The active power cap policy name
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ServerPwr.ActivePowerCapVal (Read Only)

Description	Set the Active Power Cap value
Legal Values	None
Default Values	. 32767
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ServerPwr.PowerCapMaxThres (Read Only)

Description	Maximum threshold for Power Cap
Legal Values	None
Default Values	. 32767
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ServerPwr.PowerCapMinThres (Read Only)

Description	Minimum threshold for Power Cap
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ServerPwr.PowerCapSetting (Read or Write)

Description	Enables or Disables setting the power cap value
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ServerPwr.PowerCapValue (Read or Write)

Description	Indicates maximum power consumption limit in Watts
Legal Values	None
Default Values	• 32767
Write Privilege	Configure iDRAC
License Required	iDRAC Express or iDRAC Enterprise
Dependency	None

System.ServerPwr.PSCalcRedPolicy (Read or Write)

Description	Specify the Power Supply redundancy policy
Legal Values	• 0-Not Redundant • 1-PSU Redundant • 2-A/B Grid Redundant
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

System.ServerPwr.PSPFCEnabled (Read or Write)

Description	Enable the Power Supply Power Factor Correction

Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

System.ServerPwr.PSRapidOn (Read or Write)

Description	Enable the Power Supply Rapid On. Rapid On is exactly same as Hotspare as listed in idrac GUI.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

System.ServerPwr.PSRedPolicy (Read or Write)

Description	Specify the Power Supply redundancy policy
Legal Values	• 0-Not Redundant • 1-A/B Grid Redundant
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

System.ServerPwr.RapidOnPrimaryPSU (Read or Write)

Description	The Rapid On Primary PSU
Legal Values	• 1-PSU1 • 2-PSU2
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

System.ServerPwrMon

This group contains the attributes that provide details about system server power monitor.

System.ServerPwrMon.AccumulativePower (Read Only)

Description	Total power in energy consumed by server from start time.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerPwrMon.CumulativePowerStartTime (Read Only)

Description	Start of time period from which cumulative power is calculated.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerPwrMon.CumulativePowerStartTimeStr (Read Only)

Description	The start time when cumulative power is recorded.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerPwrMon.MinPowerTime (Read Only)

Description	The time when minimum power is recorded.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerPwrMon.MinPowerTimeStr (Read Only)

Description	The time when minimum power is recorded.

Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerPwrMon.MinPowerWatts (Read Only)

Description	Minimum Power Historical
Legal Values	None
Default Values	. 65553
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerPwrMon.PeakCurrentTime (Read Only)

Description	Time at which the server observed the maximum current from start time.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerPwrMon.PeakCurrentTimeStr (Read Only)

Description	The time when peak current is recorded.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerPwrMon.PeakPowerStartTime (Read Only)

Description	Start of time period for which peak power is recorded.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerPwrMon.PeakPowerStartTimeStr (Read Only)

Description	The start time when peak power is recorded.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerPwrMon.PeakPowerTime (Read Only)

Description	Time at which the server consumed the maximum power from start time.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerPwrMon.PeakPowerTimeStr (Read Only)

Description	The time when peak power is recorded.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerPwrMon.PeakPowerWatts (Read Only)

Description	Maximum power consumed by server from the start time.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerPwrMon.PowerConfigReset (Read or Write)

Description	Resets the power statistics starting time. (Write only).

Legal Values	• 0-None • 1-ClrCumulaPowerAndTime • 2-ClrPeaKValueAndTIme • 3-ClrAll • 4-ClrPeakAndCumulaValue
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerTopology

This group contains the attributes that provides details about System server topology.

System.ServerTopology.AisleName (Read or Write)

Description	The aisle the system is located in.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerTopology.BladeSlotNumInChassis (Read Only)

Description	Slot number within chassis.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerTopology.ChassisName (Read Only)

Description	Chassis in which this system is located
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerTopology.DataCenterName (Read or Write)

Description	The data center the system is located in.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerTopology.RackName (Read or Write)

Description	Name of the rack on which the system is located.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerTopology.RackSlot (Read or Write)

Description	Slot in the rack where the system is located.
Legal Values	None
Default Values	. 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerTopology.RoomName (Read or Write)

Description	Room Name
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServerTopology.SizeOfManagedSystemInU (Read Only)

Description	Measure of thickness of the system in U
Legal Values	None
Default Values	. 1

Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServiceContract

This group contains the attributes that provides details about System.ServiceContract.

System.ServiceContract.Renewed (Read or Write)

Description	Whether the service contract was renewed or not (Yes or No).
Legal Values	• 0-Yes • 1-No
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServiceContract.Type (Read or Write)

Description	Type refers to the name or feature of the system covered by the service contract. For example, Installation Service, Maintenance Service, Return Service, Gold Service, Premier Service.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ServiceContract.Vendor (Read or Write)

Description	The business entity contracting to service the system.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.Storage

This group contains the attributes that provides details about system storage.

System.Storage.AvailableSpareAlertThreshold (Read or Write)

Description	Displays the system level user configured threshold value for available spare value of the SSD devices connected to system.
Legal Values	• 1-99-1-99
Default Values	• 10
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.Storage.RemainingRatedWriteEnduranceAlertThreshold (Read or Write)

Description	Displays the system level user configured threshold value for write endurance value of the SSD devices connected to system.
Legal Values	• 1-99-1-99
Default Values	• 10
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.SupportInfo

This group contains the attributes that provides details about System.SupportInfo.

System.SupportInfo.AutoFix (Read or Write)

Description	Method used to fix the problem
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.SupportInfo.HelpDesk (Read or Write)

Description	Name of the help desk that provides technical support for your system; information provided by the help desk.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable

Dependency	None

System.SupportInfo.Outsourced (Read or Write)

Description	Indicates whether you have contracted with an outside business entity to provide technical support for your system.
Legal Values	• 0-Yes • 1-No
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.SupportInfo.Type (Read or Write)

Description	Indicates whether a support request is for a problem with your system's network connectivity or with a particular system component.
Legal Values	• 0-Network • 1-Storage
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.SystemInfo

This group contains the attributes that provides details about System.SystemInfo.

System.SystemInfo.BootTime (Read Only)

Description	Time of the last system boot.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.SystemInfo.PrimaryTelephone (Read or Write)

Description	Telephone number for the person responsible for managing the system.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable

Dependency	None

System.SystemInfo.PrimaryUser (Read or Write)

Description	Text that provides the name for the person responsible for managing the system.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.SystemInfo.SysLocation (Read or Write)

Description	Alphanumeric text that specifies where the system is, such as building and room.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.SystemInfo.SysTime (Read Only)

Description	Current time configured on the system clock.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalConfig

This group contains the attributes that provide details about System.ThermalConfig.

System.ThermalConfig.CriticalEventGenerationInterval (Read or Write)

Description	Indicates time interval in days for critical events to be generated
Legal Values	None
Default Values	• 30
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalConfig.EventGenerationInterval (Read or Write)

Description	Indicates time interval in days for warning events to be generated
Legal Values	None
Default Values	• 30
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalConfig.FreshAirCompliantConfiguration (Read Only)

Description	Indicates if the system is a Fresh Air compliant configuration
Legal Values	• 0-Not Applicable • 1-Yes • 2-No
Default Values	• 1
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalConfig.MaxCFM (Read Only)

Description	[To be filled]
Legal Values	None
Default Values	• 0
Write Privilege	Not Applicable
License Required	Not Applicable
Dependency	Not shown if system.embedded.1#thermalsettings.1#systemCFMsupport is not supported.

System.ThermalConfig.ValidFanConfiguration (Read Only)

Description	Valid Fan Configuration
Legal Values	• 0-No • 1-Yes • 2-NotApplicable
Default Values	• 2
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

System.ThermalHistorical

This group contains the attributes that provide details about System.ThermalHistorical.

System.ThermalHistorical.IntervalInSeconds (Read or Write)

Description	Specifies the time resolution
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings

This group contains the attributes that provides details about system thermal settings.

System.ThermalSettings.AirExhaustTemp (Read or Write)

Description	Specifies the Average Air Exhaust Temperature
Legal Values	• 0-40 • 1-45 • 2-50 • 3-55 • 4-60 • 5-65 • 255-70
Default Values	• 255
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	Feature must be supported to set the value.

System.ThermalSettings.AirExhaustTempSupport (Read Only)

Description	Specifies if the Average Air Exhaust Temperature is supported
Legal Values	• 0-Not Supported • 1-Supported
Default Values	• 0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

System.ThermalSettings.AirTemperatureRiseLimit (Read or Write)

Description	Defines the Air Temperature Rise Limit
Legal Values	• 0-15 • 1-20 • 2-25 • 3-30 • 4-35 • 5-40 • 6-45 • 255-NO LIMIT
Default Values	• 255
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	Feature must be supported to set the value.

System.ThermalSettings.AirTemperatureRiseLimitSupport (Read Only)

Description	Defines if the Air Temperature Rise Limit configuration is supported
Legal Values	• 0-Not Supported • 1-Supported
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings.CurrentSystemProfileValue (Read Only)

Description	Displays current system profile value
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings.FanSpeedHighOffsetVal (Read Only)

Description	Specifies the Fan Speed High Offset Value

Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings.FanSpeedLowOffsetVal (Read Only)

Description	Specifies the Fan Speed Low Offset Value
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings.FanSpeedMaxOffsetVal (Read Only)

Description	Specifies the Fan Speed Max Offset Value
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings.FanSpeedMediumOffsetVal (Read Only)

Description	Specifies the Fan Speed Medium Offset Value
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings.FanSpeedOffset (Read or Write)

Description	Specifies the Fan Speed Offset
Legal Values	• 0-Low

- 1-High
- 2-Medium
- 3-Max
- 255-Off

Default Values	• 255
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings.MaximumPCIeInletTemperatureLimit (Read or Write)

Description	Defines the Maximum PCIe Inlet Temperature Limit.
Legal Values	• 0-55 • 1-45
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	Feature must be supported to set the value.

System.ThermalSettings.MaximumPCIeInletTemperatureLimitSupport (Read Only)

Description	Defines if the Maximum PCIe Inlet Temperature Limit configuration is supported.
Legal Values	• 0-Not Supported • 1-Supported
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings.MFSMaximumLimit (Read Only)

Description	Specifies the MFS Maximum Limit
Legal Values	None
Default Values	• 100
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings.MFSMinimumLimit (Read Only)

Description	Specifies the MFS Minimum Limit
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings.MinimumFanSpeed (Read or Write)

Description	Minimum Fan Speed
Legal Values	None
Default Values	• 255
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings.PCIeSlotLFMSupport (Read Only)

Description	Specifies if the PCIe LFM feature is supported
Legal Values	• 0-Not Supported • 1-Supported
Default Values	• 0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

System.ThermalSettings.SetAirTemperatureRiseLimit (Read or Write)

Description	Defines if the Air Temperature Rise Limit configuration is enabled/disabled.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	Feature must be supported to set the value.

System.ThermalSettings.SetMaximumExhaustTemperatureLimit (Read or Write)

Description	Defines if the Exhaust Temperature Limit configuration is disabled or enabled.
Legal Values	• 0-Disabled • 1-Enabled
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	Feature must be supported to set the value.

System.ThermalSettings.SystemCFMSupport (Read Only)

Description	Specifies if the System CFM is supported
Legal Values	• 0-Not Supported • 1-Supported
Default Values	• 0
Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	None

System.ThermalSettings.SystemExhaustTemperature (Read Only)

Description	Indicates the current system exhaust temperature.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings.SystemInletTemperature (Read Only)

Description	Indicates the current system inlet (ambient) temperature.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings.SystemInletTemperatureSupportLimitPerConfiguration (Read Only)

Description	Indicates the system inlet temperature limit supported for system configuration.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings.TargetExhaustTemperatureLimit (Read Only)

Description	Indicates the current effective target exhaust temperature limit.
Legal Values	None
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.ThermalSettings.ThermalProfile (Read or Write)

Description	Specifies the Thermal Profile
Legal Values	• 0-Default Thermal Profile Settings • 1-Maximum Performance • 2-Minimum Power • 3-Sound Cap
Default Values	• 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.USBFront

This group contains the attributes that provides details about system USB front.

System.USBFront.Enable (Read or Write)

Description	Enables or disables the host front USB port. This setting can be overwritten by BIOS Menu setting.
Legal Values	• 2-Enabled • 1-Disabled • 0-Not Applicable
Default Values	• 0

Write Privilege	Server Configuration
License Required	Not Applicable
Dependency	System.USBFront.Enable can only be set to Enable/Disable if iDRAC.PlatformCapability.FrontPortUSBConfiguration is Enabled. System. USBFront.Enable can only be set to NotApplicable if iDRAC.PlatformCapability.FrontPortUSBConfiguration is Disabled.

System.WarrantyInfo

This group contains the attributes that provides details about System.WarrantyInfo.

System.WarrantyInfo.Cost (Read or Write)

Description	The total cost of the warranty service on a system.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.WarrantyInfo.Duration (Read or Write)

Description	The number of days or months that the warranty is to be in force.
Legal Values	None
Default Values	. 0
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.WarrantyInfo.EndDate (Read or Write)

Description	The date that extended warranty service ends.
Legal Values	None
Default Values	None
Write Privilege	Configure iDRAC
License Required	Not Applicable
Dependency	None

System.WarrantyInfo.UnitType (Read or Write)

Description	Indicates whether the length of the warranty is measured in days or months.
Legal Values	. 0-Days . 1-Months
Default Values	. 0
Write Privilege	Configure iDRAC

License Required	Not Applicable
Dependency	None

5

BIOS Attributes

Topics:

- BIOS.BiosBootSettings
- BIOS.BootSeqEnDis
- BIOS.BootSettings
- BIOS.DebugMenulioConfigurationSettings
- BIOS.DebugMenuSetting
- BIOS.EmbServerMgmt
- BIOS.HttpDev1Settings
- BIOS.HttpDev2Settings
- BIOS.HttpDev3Settings
- BIOS.HttpDev4Settings
- BIOS.IntegratedDevices
- BIOS.IsciDevice1Connection1Settings
- BIOS.IscsiDevice1Settings
- BIOS.MemSettings
- BIOS.MiscSettings
- BIOS.NetworkSettings
- BIOS.OneTimeBoot
- BIOS.PowerMgmtSettings
- BIOS.ProcSettings
- BIOS.PxeDev1Settings
- BIOS.PxeDev2Settings
- BIOS.PxeDev3Settings
- BIOS.PxeDev4Settings
- BIOS.RedundantOsControl
- BIOS.SataSettings
- BIOS.SerialCommSettings
- BIOS.SlotBifurcation
- BIOS.SlotDisablement
- BIOS.SysInformation
- BIOS.SysProfileSettings
- BIOS.SysSecurity
- BIOS.TpmAdvancedSettings
- BIOS.UefiBootSeqEnDis
- BIOS.UefiBootSettings

BIOS.BiosBootSettings

You can manage the BIOS start settings using the objects in this group.

BIOS.BiosBootSettings.BootSeq (Read or Write)

Description	This field tells the system where to find the operating system files needed for system startup. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis1 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis10 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis11 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis12 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis13 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis14 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis15 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis16 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis17 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis18 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis19 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis2 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis20 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis3 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis4 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis5 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis6 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis7 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis8 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDis9 (Read or Write)

Description	This field enables or disables this boot option in the Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.BootSeqEnDisRef (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BiosBootSettings.HddSeq (Read or Write)

Description	This field specifies the order in which hard-disk drives will be configured in the system. The first hard drive in the system will be the bootable C: drive in DOS/DOS-like operating systems. This field applies only when Boot Mode is 'BIOS'; it has no effect when Boot Mode is 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSeqEnDis

This group contains the attributes that provides details about `BIOS.BootSeqEnDis`.

BIOS.BootSeqEnDis.BootSeqEnDis (Read or Write)

Description	This field allows a boot option to be enabled or disabled. When disabled, the device will be skipped in the boot sequence when booting to the OS.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings

This group contains the attributes that provides details about `BIOS.BootSettings`.

BIOS.BootSettings.BiosBootSettingsRef (Read or Write)

Description	This field controls system boot settings when Boot Mode is set to 'BIOS'. This field has no effect when Boot Mode is set to 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.BootSettings.BootMode (Read or Write)

Description	Determines whether the BIOS attempts to boot the OS via the method defined by the Unified Extensible Firmware Interface (UEFI) specification or via the legacy (BIOS) method. Selecting BIOS ensures compatibility with older operating systems that do not support the UEFI method. Many newer operating systems are UEFI-aware, and some of them may also support legacy boot methods.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.BootSeqRetry (Read or Write)

Description	This field enables/disables the Boot Sequence Retry feature. When set to Enabled, the system will re-attempt the Boot Sequence after a 30-second timeout if the last boot attempt has failed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.GenericUsbBoot (Read or Write)

Description	When set to Enabled, a Generic USB Boot placeholder will be placed in the UEFI Boot Sequence, which will map to the first bootable USB device in the boot sequence. This allows the entry to remain present even if the USB device is not present. This is only available in UEFI Boot Mode.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.HddFailover (Read or Write)

Description	When Boot Mode is BIOS, this field specifies the devices in the Hard-Disk Drive Sequence menu the BIOS will attempt to boot. This field has no effect when Boot Mode is UEFI. When set to Disabled, the BIOS will only attempt to boot the first Hard-Disk device in the list. When set to Enabled, the BIOS will attempt to boot each Hard-Disk device in order until it is successful or the entire Hard-Disk Drive Sequence has been attempted.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.HddPlaceholder (Read or Write)

Description	When set to Enabled, a Generic RAID HDD placeholder will be placed into the UEFI Boot Sequence. The entry will remain present until an operating system or boot file is installed on the RAID disk. This setting is only available in UEFI Boot Mode.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.OneTimeBootRef (Read or Write)

Description	This field supports a one-time boot to a specified device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderDis (Read or Write)

Description	"The SetBootOrderDis fields specify a list of Fqdds representing the boot Option Disabled to be applied on the next boot."
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderEn (Read or Write)

Description	"The SetBootOrderEnDis fields specify a list of Fqdds representing the boot " "Option Enable to be applied on the next boot."
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd1 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd10 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd11 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd12 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd13 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd14 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd15 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd16 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd2 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd3 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd4 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd5 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd6 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd7 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd8 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.BootSettings.SetBootOrderFqdd9 (Read or Write)

Description	The SetBootOrderFqdd fields specify a list of Fqdds representing the boot list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd1 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd10 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd11 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd12 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd13 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd14 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd15 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd16 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd2 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd3 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd4 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd5 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd6 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd7 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd8 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.SetLegacyHddOrderFqdd9 (Read or Write)

Description	The SetLegacyHddOrderFqdd fields specify a list of Fqdds representing the Legacy HDD list to be applied on the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.BootSettings.UefiBootSettingsRef (Read or Write)

Description	This field controls system boot settings when Boot Mode is set to 'UEFI'. This field has no effect when Boot Mode is set to 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenulioConfigurationSettings

This group contains the attributes that provides details about `BIOS.DebugMenulioConfigurationSettings`.

BIOS.DebugMenulioConfigurationSettings.DeviceUnhide (Read or Write)

Description	This field enables/disables IIO Misc Device unhiding. This field also controls powering down unused ports.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenulioConfigurationSettings.Dfx (Read or Write)

Description	This field enables/disables DFX for margining. When Enabled, TXT and VT are disabled.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.DebugMenulioConfigurationSettings.DirectMediaInterfaceSpeed (Read or Write)

Description	Changing this field will change the speed for the Direct Media Interface.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenulioConfigurationSettings.TXEQWA (Read or Write)

Description	Enable/Disable PCIe TXEQ Workaround.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenulioConfigurationSettings.UnusedPcieClk (Read or Write)

Description	This field enables unused PCIe clocks for Mfg Test. When Enabled, no attempt is made to disable PCIe clocks.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting

This group contains the attributes that provides details about `BIOS.DebugMenuSetting`.

BIOS.DebugMenuSetting.AttemptFastBoot (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.AttemptFastBootCold (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.BiosCpuKnobTuning (Read or Write)

Description	BIOS CPU Knob Tuning
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.BiosCpuKnobTuningRef (Read or Write)

Description	BIOS CPU Knob Tuning
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.BrowserDebugMode (Read or Write)

Description	When enabled, the HII browser will turn on debug related features.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.BrowserMode (Read or Write)

Description	Changes display mode of HII browser. The setting will take effect after save and exit from the system setup. The setting will not apply to the next boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.BrowserOptionsRef (Read or Write)

Description	HII forms browser options
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.BugChecking (Read or Write)

Description	This field enables/disables features of the BIOS designed to catch serious software bugs. These features include the memory checker, NULL pointer checking, and sanity checks within the BIOS core. Disabling these features maximize compatibility. Developers and Testers should enable this feature to detect serious software issues.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.CkeThrottling (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.ClpOutput (Read or Write)

Description	This field enables or disables CLP strings output during POST for debug purpose.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.CTOMasking (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.CurrentLimit (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.DciTransport (Read or Write)

Description	Enabling this field will turn on the Intel PCH Direct Connect Interface.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.DeadLineLlcAlloc (Read or Write)

Description	"Enabled - opportunistically fill dead lines in LLC. " "Disabled - never fill dead lines in LLC."
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.DebugErrorLevel (Read or Write)

Description	This field controls serial DEBUG output level for certain drivers. The value overrides the platform PcdDebugPrintErrorLevel PCD value. The value is a 32-bit bit mask of the following values: DEBUG_INIT 0x00000001 DEBUG_WARN 0x00000002 DEBUG_LOAD 0x00000004 DEBUG_FS 0x00000008 DEBUG_POOL 0x00000010 DEBUG_PAGE 0x00000020 DEBUG_INFO 0x00000040 DEBUG_DISPATCH 0x00000080 DEBUG_VARIABLE 0x00000100 DEBUG_BM 0x00000400 DEBUG_BLKIO 0x00001000 DEBUG_NET 0x00004000 DEBUG_UNDI 0x00010000 DEBUG_LOADFILE 0x00020000 DEBUG_EVENT 0x00080000 DEBUG_GCD 0x00100000 DEBUG_CACHE 0x00200000 DEBUG_VERBOSE 0x00400000 DEBUG_ERROR 0x80000000 If the Field is clear, the platform PcdDebugPrintErrorLevel PCD value is used.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.DirectoryAtoS (Read or Write)

Description	"AtoS optimization reduces remote read latencies for repeat read accesses without intervening writes."
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.DirectoryMode (Read or Write)

Description	Enable or disable directory mode. Useful for Cscript error injection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.EmbSataRSTeDebug (Read or Write)

Description	Enable Hot Plug for SATA ports of the embedded SATA controllers.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.EmbSataTestMode (Read or Write)

Description	Enable Test Mode for SATA ports of the embedded SATA controllers.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.IdracDebugMode (Read or Write)

Description	This field enables or disables the IDRAC IPMI KCS and SMA debug interface.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.IgnoreIdracCrReq (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.IioPcieGlobalSpeed (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.DebugMenuSetting.IntelTestEventIio (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.InteractivePassword24A (Read or Write)

Description	Enables or disables the new flow of interactive password defined since UEFI 2.4A (1085 and 1174 errata). When set to Disabled, the HII browser will apply the old flow defined in UEFI 2.3.1.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.JunoPmEnable (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.LinkDowntrainReporting (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.LlcPrefetch (Read or Write)

Description	"Enable/Disable LLC Prefetch on all threads."
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.MeFailureRecoveryEnable (Read or Write)

Description	Determines whether BIOS will attempt to recover ME when it is in a failed state
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.MemHotThrottlingMode (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.MemoryBist (Read or Write)

Description	This field enables/disables Memory BIST.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.MemoryFastBootCold (Read or Write)

Description	Enable/Disable Memory RMT.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.MemoryMultiThread (Read or Write)

Description	Enable/Disable Memory RMT.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.MemoryPerBitMargin (Read or Write)

Description	Enable/Disable Memory RMT.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.MemoryRmt (Read or Write)

Description	Enable/Disable Memory RMT.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.MemoryThrottlingMode (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.MemTestOnFastBoot (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.MeUmaEnable (Read or Write)

Description	Changing this field will enable/disable the ME UMA feature
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.MRCSerialDbgOut (Read or Write)

Description	This field enables/disables the RC/MRC Serial debug output.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.MultiThreaded (Read or Write)

Description	Enable to execute the Memory Reference Code multi-threaded.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.NdcConfigurationSpeed (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.PCIeErrorInjection (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.PCIeLiveErrorRecovery (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.PostPackageRepair (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.PPRErrInjectionTest (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.ProcDpatProDebug (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.ProcMtrrPatDebug (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.PSPConsoleOut (Read or Write)

Description	This field enables/disables PSP Console Output (serial debug).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.RankMargin (Read or Write)

Description	Enable/Disable Memory RMT.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.RebootTestCount (Read or Write)

Description	This field selects Reboot count between 1 - 65535.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.RebootTestMode (Read or Write)

Description	This field selects Reboot Type.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.RebootTestPoint (Read or Write)

Description	This field selects Reboot Location.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.S4Support (Read or Write)

Description	Enable, Disable, or allow normal platform control (Auto) of S4 Sleep State Support.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.SccDebugEnabled (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.SrefProgramming (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.TpmBindingReset (Read or Write)

Description	Clears the TPM, resets the binding and turns off TPM Security. To apply this, TPM Security should also be set to On when setting TPM Binding Reset to On.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.TraceHubDebug (Read or Write)

Description	This setting enables/disables the Intel North Peak Trace Hub feature.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.VmWareSupport (Read or Write)

Description	This field is for enable different _DSM of NvDimm deivce for MicroSoft or VMWARE (for development purpose)
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.DebugMenuSetting.XptPrefetch (Read or Write)

Description	"XPT Prefetch is a mechanism that enables a read request that is being sent to the LLC to speculatively issue a copy of that read to the memory controller."
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.EmbServerMgmt

This group contains the attributes that provides details about `BIOS.EmbServerMgmt`.

BIOS.EmbServerMgmt.EmbServerMgmt (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.EmbServerMgmt.FrontLcd (Read or Write)

Description	This field allows you to select whether to display the Default (Model name and number) or a user-defined string in the front-panel LCD display. To modify the advanced features of the front-panel LCD, press F2 during boot to enter System Setup and then select iDRAC Settings.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.EmbServerMgmt.UserLcdStr (Read or Write)

Description	This field allows you to view/enter the User-Defined String to be displayed on the LCD. The string can be 62 characters long.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev1Settings

This group contains the attributes that provides details about `BIOS.HttpDev1Settings`.

BIOS.HttpDev1Settings.HttpDev1DhcpEnDis (Read or Write)

Description	DHCP Enable/Disable for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev1Settings.HttpDev1Dns1 (Read or Write)

Description	Primary DNS server IP address for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev1Settings.HttpDev1Dns2 (Read or Write)

Description	Secondary DNS server IP address for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev1Settings.HttpDev1DnsDhcpEnDis (Read or Write)

Description	DNS information from DHCP Enable/Disable for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev1Settings.HttpDev1Gateway (Read or Write)

Description	Gateway for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev1Settings.HttpDev1Interface (Read or Write)

Description	NIC interface used for this HTTP device
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev1Settings.HttpDev1Ip (Read or Write)

Description	IP address for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev1Settings.HttpDev1Mask (Read or Write)

Description	Subnet mask for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev1Settings.HttpDev1Protocol (Read or Write)

Description	Determines whether Internet Protocol version 4 (the most common, older version) or Internet Protocol version 6 (the newest version) is used for this device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev1Settings.HttpDev1Settings (Read or Write)

Description	This field controls the configuration for this HTTP device
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev1Settings.HttpDev1Uri (Read or Write)

Description	Contains the Uniform Resource Identifier (URI) that the BIOS should boot. If this field is blank, the BIOS will attempt to contact the network's DHCP server and ask it for the boot file name.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev1Settings.HttpDev1VlanEnDis (Read or Write)

Description	Set this field to Enabled if your DNS or HTTP servers reside on a Virtual LAN (VLAN).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev1Settings.HttpDev1VlanId (Read or Write)

Description	When VLAN is enabled, identifies which of the 4094 possible VLANs contains the desired DNS or HTTP servers. This value can be from 1 to 4094 inclusive.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev1Settings.HttpDev1VlanPriority (Read or Write)

Description	When VLAN is enabled, identifies which of 8 possible priorities are assigned to the VLAN having the given ID. This value can be from 0 to 7 inclusive.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev2Settings

This group contains the attributes that provides details about `BIOS.HttpDev2Settings`.

BIOS.HttpDev2Settings.HttpDev2DhcpEnDis (Read or Write)

Description	DHCP Enable/Disable for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev2Settings.HttpDev2Dns1 (Read or Write)

Description	Primary DNS server IP address for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev2Settings.HttpDev2Dns2 (Read or Write)

Description	Secondary DNS server IP address for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev2Settings.HttpDev2DnsDhcpEnDis (Read or Write)

Description	DNS information from DHCP Enable/Disable for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev2Settings.HttpDev2Gateway (Read or Write)

Description	Gateway for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev2Settings.HttpDev2Interface (Read or Write)

Description	NIC interface for this HTTP device
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev2Settings.HttpDev2Ip (Read or Write)

Description	IP address for this HTTP Device.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev2Settings.HttpDev2Mask (Read or Write)

Description	Subnet mask for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev2Settings.HttpDev2Protocol (Read or Write)

Description	Determines whether Internet Protocol version 4 (the most common, older version) or Internet Protocol version 6 (the newest version) is used for this device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev2Settings.HttpDev2Settings (Read or Write)

Description	This field controls the configuration for this HTTP device
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev2Settings.HttpDev2Uri (Read or Write)

Description	Contains the Uniform Resource Identifier (URI) that the BIOS should boot. If this field is blank, the BIOS will attempt to contact the network's DHCP server and ask it for the boot file name.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev2Settings.HttpDev2VlanEnDis (Read or Write)

Description	Set this field to Enabled if your DNS or HTTP servers reside on a Virtual LAN (VLAN).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev2Settings.HttpDev2VlanId (Read or Write)

Description	When VLAN is enabled, identifies which of the 4094 possible VLANs contains the desired DNS or HTTP servers. This value can be from 1 to 4094 inclusive.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev2Settings.HttpDev2VlanPriority (Read or Write)

Description	When VLAN is enabled, identifies which of 8 possible priorities are assigned to the VLAN having the given ID. This value can be from 0 to 7 inclusive.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev3Settings

This group contains the attributes that provides details about `BIOS.HttpDev3Settings`.

BIOS.HttpDev3Settings.HttpDev3DhcpEnDis (Read or Write)

Description	DHCP Enable/Disable for this HTTP Device.
Legal Values	Not Applicable

Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev3Settings.HttpDev3Dns1 (Read or Write)

Description	Primary DNS server IP address for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev3Settings.HttpDev3Dns2 (Read or Write)

Description	Secondary DNS server IP address for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev3Settings.HttpDev3DnsDhcpEnDis (Read or Write)

Description	DNS information from DHCP Enable/Disable for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev3Settings.HttpDev3Gateway (Read or Write)

Description	Gateway for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev3Settings.HttpDev3Interface (Read or Write)

Description	NIC interface for this HTTP device
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev3Settings.HttpDev3Ip (Read or Write)

Description	IP address for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev3Settings.HttpDev3Mask (Read or Write)

Description	Subnet mask for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev3Settings.HttpDev3Protocol (Read or Write)

Description	Determines whether Internet Protocol version 4 (the most common, older version) or Internet Protocol version 6 (the newest version) is used for this device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev3Settings.HttpDev3Settings (Read or Write)

Description	This field controls the configuration for this HTTP device

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev3Settings.HttpDev3Uri (Read or Write)

Description	Contains the Uniform Resource Identifier (URI) that the BIOS should boot. If this field is blank, the BIOS will attempt to contact the network's DHCP server and ask it for the boot file name.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev3Settings.HttpDev3VlanEnDis (Read or Write)

Description	Set this field to Enabled if your DNS or HTTP servers reside on a Virtual LAN (VLAN).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev3Settings.HttpDev3VlanId (Read or Write)

Description	When VLAN is enabled, identifies which of the 4094 possible VLANs contains the desired DNS or HTTP servers. This value can be from 1 to 4094 inclusive.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev3Settings.HttpDev3VlanPriority (Read or Write)

Description	When VLAN is enabled, identifies which of 8 possible priorities are assigned to the VLAN having the given ID. This value can be from 0 to 7 inclusive.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev4Settings

This group contains the attributes that provides details about `BIOS.HttpDev4Settings`.

BIOS.HttpDev4Settings.HttpDev4DhcpEnDis (Read or Write)

Description	DHCP Enable/Disable for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev4Settings.HttpDev4Dns1 (Read or Write)

Description	Primary DNS server IP address for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev4Settings.HttpDev4Dns2 (Read or Write)

Description	Secondary DNS server IP address for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev4Settings.HttpDev4DnsDhcpEnDis (Read or Write)

Description	DNS information from DHCP Enable/Disable for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev4Settings.HttpDev4Gateway (Read or Write)

Description	Gateway for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev4Settings.HttpDev4Interface (Read or Write)

Description	NIC interface for this HTTP device
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev4Settings.HttpDev4Ip (Read or Write)

Description	IP address for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev4Settings.HttpDev4Mask (Read or Write)

Description	Subnet mask for this HTTP Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev4Settings.HttpDev4Protocol (Read or Write)

Description	Determines whether Internet Protocol version 4 (the most common, older version) or Internet Protocol version 6 (the newest version) is used for this device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev4Settings.HttpDev4Settings (Read or Write)

Description	This field controls the configuration for this HTTP device
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev4Settings.HttpDev4Uri (Read or Write)

Description	Contains the Uniform Resource Identifier (URI) that the BIOS should boot. If this field is blank, the BIOS will attempt to contact the network's DHCP server and ask it for the boot file name.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev4Settings.HttpDev4VlanEnDis (Read or Write)

Description	Set this field to Enabled if your DNS or HTTP servers reside on a Virtual LAN (VLAN).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev4Settings.HttpDev4VlanId (Read or Write)

Description	When VLAN is enabled, identifies which of the 4094 possible VLANs contains the desired DNS or HTTP servers. This value can be from 1 to 4094 inclusive.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.HttpDev4Settings.HttpDev4VlanPriority (Read or Write)

Description	When VLAN is enabled, identifies which of 8 possible priorities are assigned to the VLAN having the given ID. This value can be from 0 to 7 inclusive.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices

This group contains the attributes that provides details about `BIOS.IntegratedDevices`.

BIOS.IntegratedDevices.CurrentEmbVideoState (Read or Write)

Description	Read-only. Indicates the current state of the Embedded Video Controller. If the Embedded Video Controller is the only display capability in the system (that is, no add-in graphics card is installed), then the Embedded Video Controller is automatically used as the primary display even if the Embedded Video Controller setting is Disabled.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.EmbNic1 (Read or Write)

Description	Enables or disables the embedded NIC. NOTE: If set to Disabled (OS), the embedded NIC may still be available for shared network access by the embedded management controller. This function must be configured via the NIC management utilities provided with your system. There is only one onboard RJ45 port shared between BIOS and iDRAC. So it can only be enabled when iDRAC NIC selection is set to Shared. If the iDRAC setting is Dedicated, it will be grayed out and forced to Disabled.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.EmbNic1Nic2 (Read or Write)

Description	Enables or disables the OS interface of the embedded NIC1 and NIC2 controller. NOTE: If set to Disabled (OS), the embedded NICs may still be available for shared network access by the embedded management controller. This function must be configured via the NIC management utilities provided with your system.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.EmbNic2 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.EmbNic3 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.EmbNic3Nic4 (Read or Write)

Description	Enables or disables the OS interface of the embedded NIC3 and NIC4 controller. NOTE: If set to Disabled (OS), the embedded NICs may still be available for shared network access by the embedded management controller. This function must be configured via the NIC management utilities provided with your system.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.EmbNic4 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.EmbNicPort1BootProto (Read or Write)

Description	This is a Write-Only attribute to control the Legacy Boot Protocol of the LOM Port specified by the Embedded NIC port number. This attribute is for system management software use, and does not appear in System BIOS Setup. This attribute always returns Unknown when read. There is no change to the LOM Port Legacy Boot Protocol setting when Unknown is written. An error is returned if written with a setting (None, PXE, or iSCSI) that is not supported by the LOM Port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.EmbNicPort2BootProto (Read or Write)

Description	This is a Write-Only attribute to control the Legacy Boot Protocol of the LOM Port specified by the Embedded NIC port number. This attribute is for system management software use, and does not appear in System BIOS Setup. This attribute always returns Unknown when read. There is no change to the LOM Port Legacy Boot Protocol setting when Unknown is written. An error is returned if written with a setting (None, PXE, or iSCSI) that is not supported by the LOM Port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.EmbNicPort3BootProto (Read or Write)

Description	This is a Write-Only attribute to control the Legacy Boot Protocol of the LOM Port specified by the Embedded NIC port number. This attribute is for system management software use, and does not appear in System BIOS Setup. This attribute always returns Unknown when read. There is no change to the LOM Port Legacy Boot Protocol setting when Unknown is written. An error is returned if written with a setting (None, PXE, or iSCSI) that is not supported by the LOM Port.
Legal Values	Not Applicable

Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.EmbNicPort4BootProto (Read or Write)

Description	This is a Write-Only attribute to control the Legacy Boot Protocol of the LOM Port specified by the Embedded NIC port number. This attribute is for system management software use, and does not appear in System BIOS Setup. This attribute always returns Unknown when read. There is no change to the LOM Port Legacy Boot Protocol setting when Unknown is written. An error is returned if written with a setting (None, PXE, or iSCSI) that is not supported by the LOM Port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.EmbVideo (Read or Write)

Description	Enables or disables the use of the Embedded Video Controller as the primary display. When set to Enabled, the Embedded Video Controller will be the primary display even if add-in graphics cards are installed. When set to Disabled, an add-in graphics card will be used as the primary display. BIOS will output displays to both the primary add-in video and the embedded video during POST and pre-boot environment. The embedded video will then be disabled right before the operating system boots. Note: When there are multiple add-in graphics cards installed in the system, the first card discovered during PCI enumeration is selected as the primary video. You may have to re-arrange the cards in the slots in order to control which card is the primary video controller.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.GlobalSlotDriverDisable (Read or Write)

Description	If you set this field to Enabled, the BIOS will not load any legacy option ROMs (when Boot Mode is BIOS) or UEFI drivers (when Boot Mode is UEFI) for any cards in the system slots. If the boot support for some card is provided by the option ROM, then the system will not be able to boot from the card, nor will its pre-boot services be available. However, the card will be available for operating system use. If you do not want this behavior or you would like to limit which slots have this behavior, set this field to Disabled. Use the Slot Disablement setting to limit the slots having this behavior. This option does not apply to any slot containing a Dell RAID card.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.IntegratedDevices.IntegratedDevices (Read or Write)

Description	Configuration menu for devices integrated on the system board.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.IntegratedNetwork1 (Read or Write)

Description	Enables or disables the integrated network card (NDC). When set to Disabled, the NDC is not available to the operating system (OS). NOTE: If set to Disabled (OS), the Integrated NICs may still be available for shared network access by iDRAC.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.IntegratedNetwork2 (Read or Write)

Description	Enables or disables the second integrated network card (NDC). When set to Disabled, the NDC is not available to the operating system (OS). NOTE: If set to Disabled (OS), the Integrated NICs may still be available for shared network access by iDRAC.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.IntegratedRaid (Read or Write)

Description	Enables or disables the integrated RAID controller. When set to Disabled, the device is not visible to the operating system (OS).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.IntegratedDevices.IntegratedSas (Read or Write)

Description	Enables or disables the integrated SAS controller. When set to Disabled, the device is not visisble to the operating system (OS).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.InternalSdCard (Read or Write)

Description	Enables or disables the internal SD Card port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.InternalSdCardPresence (Read or Write)

Description	Indicate the presence state of the Internal Dual SD module (IDSDM).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.InternalSdCardPrimaryCard (Read or Write)

Description	When Redundancy is set to Disabled, either one of the SD card can be selected to present itself as mass storage device by setting it to be primary card. By default primary SD card is selected to be SD Card 1. If SD Card 1 is not present, then controller will select SD Card 2 to be primary SD card.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.InternalSdCardRedundancy (Read or Write)

Description	Configures the redundancy mode of the Internal Dual SD module (IDSDM). When set to Mirror Mode, data is written to both SD cards. After failure of either card and replacement of the failed card, the data of the active card is copied to the offline card during the system boot. When Redundancy is set to disabled, only the primary SD Card is visible to the OS.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.InternalUsb (Read or Write)

Description	Enables or disables the internal USB port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.InternalUsb1 (Read or Write)

Description	Enables or disables the internal USB port 1.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.InternalUsb2 (Read or Write)

Description	Enables or disables the internal USB port 2.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.IntNic1Port1BootProto (Read or Write)

Description	This is a Write-Only attribute to control the Legacy Boot Protocol of the LOM Port specified by the Integrated Network Card number and port number. This attribute is for system management software use, and does not appear in System BIOS Setup. This attribute always returns Unknown when read. There is no change to the LOM Port Legacy Boot Protocol setting when Unknown is written. An error is returned if written with a setting (None, PXE, or iSCSI) that is not supported by the LOM Port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.IntNic1Port2BootProto (Read or Write)

Description	This is a Write-Only attribute to control the Legacy Boot Protocol of the LOM Port specified by the Integrated Network Card number and port number. This attribute is for system management software use, and does not appear in System BIOS Setup. This attribute always returns Unknown when read. There is no change to the LOM Port Legacy Boot Protocol setting when Unknown is written. An error is returned if written with a setting (None, PXE, or iSCSI) that is not supported by the LOM Port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.IntNic1Port3BootProto (Read or Write)

Description	This is a Write-Only attribute to control the Legacy Boot Protocol of the LOM Port specified by the Integrated Network Card number and port number. This attribute is for system management software use, and does not appear in System BIOS Setup. This attribute always returns Unknown when read. There is no change to the LOM Port Legacy Boot Protocol setting when Unknown is written. An error is returned if written with a setting (None, PXE, or iSCSI) that is not supported by the LOM Port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.IntNic1Port4BootProto (Read or Write)

Description	This is a Write-Only attribute to control the Legacy Boot Protocol of the LOM Port specified by the Integrated Network Card number and port number. This attribute is for system management software use, and does not appear in System BIOS Setup. This attribute always returns Unknown when read. There is no change to the LOM Port Legacy Boot Protocol setting when Unknown is written. An error is returned if written with a setting (None, PXE, or iSCSI) that is not supported by the LOM Port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.IntNic2Port1BootProto (Read or Write)

Description	This is a Write-Only attribute to control the Legacy Boot Protocol of the LOM Port specified by the Integrated Network Card number and port number. This attribute is for system management software use, and does not appear in System BIOS Setup. This attribute always returns Unknown when read. There is no change to the LOM Port Legacy Boot Protocol setting when Unknown is written. An error is returned if written with a setting (None, PXE, or iSCSI) that is not supported by the LOM Port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.IntNic2Port2BootProto (Read or Write)

Description	This is a Write-Only attribute to control the Legacy Boot Protocol of the LOM Port specified by the Integrated Network Card number and port number. This attribute is for system management software use, and does not appear in System BIOS Setup. This attribute always returns Unknown when read. There is no change to the LOM Port Legacy Boot Protocol setting when Unknown is written. An error is returned if written with a setting (None, PXE, or iSCSI) that is not supported by the LOM Port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.IntNic2Port3BootProto (Read or Write)

Description	This is a Write-Only attribute to control the Legacy Boot Protocol of the LOM Port specified by the Integrated Network Card number and port number. This attribute is for system management software use, and does not appear in System BIOS Setup. This attribute always returns Unknown when read. There is no change to the LOM Port Legacy Boot Protocol setting when Unknown is written. An error is returned if written with a setting (None, PXE, or iSCSI) that is not supported by the LOM Port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.IntNic2Port4BootProto (Read or Write)

Description	This is a Write-Only attribute to control the Legacy Boot Protocol of the LOM Port specified by the Integrated Network Card number and port number. This attribute is for system management software use, and does not appear in System BIOS Setup. This attribute always returns Unknown when read. There is no change to the LOM Port Legacy Boot Protocol setting when Unknown is written. An error is returned if written with a setting (None, PXE, or iSCSI) that is not supported by the LOM Port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.IoatEngine (Read or Write)

Description	Enables or disables the I/O Acceleration Technology (I/OAT). I/OAT is a set of DMA features designed to accelerate network traffic and lower CPU utilization. This feature should be enabled only if the hardware and software support I/OAT.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.IoNonPostedPrefetch (Read or Write)

Description	Controls the PCIe throughput by enabling or disabling the PCI IO non-posted prefetch mode. When set to Enabled, memory reads from PCI devices are optimized. However, performance may be reduced for writes from PCI devices.
Legal Values	Not Applicable

Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.MemoryMappedIOH (Read or Write)

Description	MMIO base default is 56TB. User should not change the default value unless addressing a known issue. When set to 12TB, the system will map MMIO base to 12TB. Enable this feature for an OS that requires 44bit PCIe addressing. When set to 512GB, the system will map MMIO base to 512GB, and reduce the maximum support for memory to less than 512GB. Enable this option only for the 4 GPU DGMA issue.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.MmioAbove4Gb (Read or Write)

Description	Enables support for PCIe devices that require large amount of MMIO resources. Enable this option only for 64-bit operating systems.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.MmioLimit (Read or Write)

Description	When set to 1TB, the system will restrict maximum MMIO space to 1TB. Enable this feature for devices not support above 1TB addressing.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.Ndc1PcieLink1 (Read or Write)

Description	Enables or disables the integrated network card (NDC) PCIe link. When set to Disabled, the NDC link is not available to the operating system (OS). NOTE: If set to Disabled (OS), the Integrated NIC may still be available for shared network access by iDRAC.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.Ndc1PcieLink2 (Read or Write)

Description	Enables or disables the integrated network card (NDC) PCIe link. When set to Disabled, the NDC link is not available to the operating system (OS). NOTE: If set to Disabled (OS), the Integrated NIC may still be available for shared network access by iDRAC.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.Ndc1PcieLink3 (Read or Write)

Description	Enables or disables the integrated network card (NDC) PCIe link. When set to Disabled, the NDC link is not available to the operating system (OS). NOTE: If set to Disabled (OS), the Integrated NIC may still be available for shared network access by iDRAC.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.OsWatchdogTimer (Read or Write)

Description	If the system stops responding, this watchdog timer helps in the recovery of your operating system (OS). When set to Enabled, the OS is allowed to initialize the timer. When it is set to Disabled, the timer will have no effect on the system.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.PcieBusCustomization (Read or Write)

Description	"Provide options for customizing the allocation of PCIe bus ranges to " "PCIe slots. This can be useful when connecting complex device sets " "to a slot.n" "n" "PCIe Bus System Allocation uses the normal rules of the system to " "allocate bus ranges.n" "n" "PCIe Bus Custom Allocation Option 1 increases the bus ranges allocated " "to the wider slots.n" "n" "PCIe Bus Custom Allocation Option 2 increases the bus range allocated " "to one of the wide slots more than with option 1.n" "n" "PCIe Bus Custom Allocation Option 3 allocates the largest bus

	range " "practical to one of the wide slots.n" "n" "Note that use of this option may cause insufficient resources to be " "available for remaining slots and prevent the system from functioning.n" "n"
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.RipsPresence (Read or Write)

Description	Indicate the presence state of the RIPS (Redundant Internal Persistent Storage).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.SlotDisablementRef (Read or Write)

Description	Controls the configuration of PCIe cards installed in the specified slot. Only slots that are present on the system will be available for control.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.SnoopHldOff (Read or Write)

Description	Selects the number of cycles PCI I/O can withhold snoop requests, from the CPU, to allow time to complete its own write to LLC. This setting can help improve performance on workloads where throughput and latency are critical.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.SriovGlobalEnable (Read or Write)

Description	Enables or disables the BIOS configuration of Single Root I/O Virtualization (SR-IOV) devices. Enable this feature if booting to a virtualization operating system that recognize SR-IOV devices.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.Usb3Setting (Read or Write)

Description	Controls USB 3.0 support. When set to Disabled, BIOS disables USB 3.0 mode for all the USB3.0 ports. The USB devices operate at USB2.0 mode. When set to Enabled, BIOS operates all USB3.0 ports at USB2.0 mode during POST, and switches them to USB3.0 mode right after the operating system (OS) boots. You must select this option only if the operating system (such as. Windows Server 2012) has a native USB 3.0 driver. Otherwise none of the USB devices will work after boot. The Auto option is available only on workstation servers. If this option is selected, the BIOS leaves all USB 3.0 ports at USB 2.0 mode, and a special OS switching driver is required to set the USB3.0 port to USB3.0 mode. Microsoft Windows 7 has switching driver capability.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.UsbEnableFrontPortsOnly (Read or Write)

Description	This field enables/disables the front USB ports during the OS runtime when User Accessible USB Ports is set as All Ports Off (Dynamic).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.UsbManagedPort (Read or Write)

Description	The iDRAC Direct USB port is managed by iDRAC exclusively with no host visibility. When set to OFF, iDRAC would not detect any USB devices installed in this managed port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IntegratedDevices.UsbPorts (Read or Write)

Description	Configure the User Accessible USB Ports. Selecting Only Back Ports On disables the front USB ports; Selecting All Ports Off disables all front and back USB ports. The USB keyboard and mouse will still function in certain USB

	ports during the boot process, depending on the selection. After the boot process is complete, the USB ports will be enabled or disabled as per the setting. Note: Selecting Only Back Ports On and All Ports Off will disable the USB management port and restrict access to the iDRAC USB management port features.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IsciDevice1Connection1Settings

This group contains the attributes that provides details about `BIOS.IsciDevice1Connection1Settings`.

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Auth (Read or Write)

Description	Authentication type for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1ChapName (Read or Write)

Description	CHAP name for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1ChapSecret (Read or Write)

Description	CHAP secret for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1ChapType (Read or Write)

Description	CHAP type for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1DhcpEnDis (Read or Write)

Description	DHCP Enable/Disable for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Gateway (Read or Write)

Description	Initiator Gateway for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Interface (Read or Write)

Description	NIC interface used for this iSCSI connection
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Ip (Read or Write)

Description	Initiator IP Address for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Isid (Read or Write)

Description	ISID for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Lun (Read or Write)

Description	Target LUN for this iSCSI connection. The value format is a string containing a hexadecimal-encoded representation of the 64-bit SCSI Logical Unit Number in the format described in the T10 SCSI Architecture Model specification. This format consists of four 2-byte fields separated by dashes. In most cases, the human-oriented logical unit number will be in the high-order two bytes and the low-order six bytes will be zero. Examples are: 4752-3A4F-6b7e-2F99, 6734-9-156f-127, 4186-9 or 0.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Mask (Read or Write)

Description	Initiator Subnet Mask for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Port (Read or Write)

Description	Target Port for this iSCSI connection. The standard port number for iSCSI connections is 3260.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Protocol (Read or Write)

Description	This field controls the Internet Protocol used for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Retry (Read or Write)

Description	Retry Count for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1RevChapName (Read or Write)

Description	Reverse CHAP name for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1RevChapSecret (Read or Write)

Description	Reverse CHAP secret for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Settings (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1TargetIp (Read or Write)

Description	Target IP Address for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1TargetName (Read or Write)

Description	Target name for this iSCSI connection in IQN format.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1TgtDhcpEnDis (Read or Write)

Description	Target DHCP Enable/Disable for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1Timeout (Read or Write)

Description	Timeout for this iSCSI connection in milliseconds.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1VlanEnDis (Read or Write)

Description	VLAN Enable/Disable for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1VlanId (Read or Write)

Description	VLAN ID for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection1Settings.IscsiDev1Con1VlanPriority (Read or Write)

Description	VLAN priority for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Auth (Read or Write)

Description	Authentication type for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2ChapName (Read or Write)

Description	CHAP name for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2ChapSecret (Read or Write)

Description	CHAP secret for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2ChapType (Read or Write)

Description	CHAP type for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2DhcpEnDis (Read or Write)

Description	DHCP Enable/Disable for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Gateway (Read or Write)

Description	Initiator Gateway for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Interface (Read or Write)

Description	NIC interface used for this iSCSI connection
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Ip (Read or Write)

Description	Initiator IP Address for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Isld (Read or Write)

Description	ISID for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Lun (Read or Write)

Description	Target Lun for this iSCSI connection.The value format is a string containing a hexadecimal-encoded representation of the 64-bit SCSI Logical Unit Number in the format described in the T10 SCSI Architecture Model specification. This format consists of four 2-byte fields separated by dashes. In most cases, the human-oriented logical unit number will be in the high-order two bytes and the low-order six bytes will be zero. Examples are: 4752-3A4F-6b7e-2F99, 6734-9-156f-127, 4186-9 or 0.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Mask (Read or Write)

Description	Initiator Subnet Mask for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Port (Read or Write)

Description	Target Port for this iSCSI connection. The standard port number for iSCSI connections is 3260.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Protocol (Read or Write)

Description	This field controls the Internet Protocol used for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Retry (Read or Write)

Description	Retry Count for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2RevChapName (Read or Write)

Description	Reverse CHAP name for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2RevChapSecret (Read or Write)

Description	Reverse CHAP secret for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Settings (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2TargetIp (Read or Write)

Description	Target IP Address for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2TargetName (Read or Write)

Description	Target name for this iSCSI connection in IQN format.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2TgtDhcpEnDis (Read or Write)

Description	Target DHCP Enable/Disable for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2Timeout (Read or Write)

Description	Timeout for this iSCSI connection in milliseconds.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2VlanEnDis (Read or Write)

Description	VLAN Enable/Disable for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2VlanId (Read or Write)

Description	VLAN ID for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Connection2Settings.IscsiDev1Con2VlanPriority (Read or Write)

Description	VLAN priority for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Settings.IscsiDev1Con1EnDis (Read or Write)

Description	This field controls the configuration for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Settings.IscsiDev1Con1SettingsRef (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Settings.IscsiDev1Con2EnDis (Read or Write)

Description	This field controls the configuration for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Settings.IscsiDev1Con2SettingsRef (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Settings.IscsiDev1ConOrder (Read or Write)

Description	This field controls the order for which the iSCSI connections will be attempted.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Settings.IscsiDev1Settings (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Settings

This group contains the attributes that provides details about `BIOS.IscsiDevice1Settings`.

BIOS.IscsiDevice1Settings.IscsiDev1Con1EnDis (Read or Write)

Description	This field controls the configuration for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.IscsiDevice1Settings.IscsiDev1Con1SettingsRef (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Settings.IscsiDev1Con2EnDis (Read or Write)

Description	This field controls the configuration for this iSCSI connection.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Settings.IscsiDev1Con2SettingsRef (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Settings.IscsiDev1ConOrder (Read or Write)

Description	This field controls the order for which the iSCSI connections will be attempted.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.IscsiDevice1Settings.IscsiDev1Settings (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings

To manage memory-related configuration settings, use the objects in this group.

BIOS.MemSettings.AdddcSetting (Read or Write)

Description	This feature is applicable for x4 DIMMs only. When Adaptive Double DRAM Correction (ADDDC) is enabled, failing DRAM's are dynamically mapped out. When ADDDC is disabled, system performance may be higher.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.AddrBasMir (Read or Write)

Description	If the system is configured for Dell Fault Resilient Mode (FRM), controls the amount of memory for FRM per processor. The FRM memory is located on a single memory riser per processor. Only half of the FRM memory will be visible to the OS.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.AppDirectCapacity (Read or Write)

Description	Total NVDIMM size configured as AppDirect mode in the system.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.AppDirectNamespaceCount0 (Read or Write)

Description	App Direct namespace count
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.AppDirectNamespaceCount1 (Read or Write)

Description	App Direct namespace count
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.AppDirectNamespaceCount2 (Read or Write)

Description	App Direct namespace count
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.AppDirectNamespaceCount3 (Read or Write)

Description	App Direct namespace count
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.BatteryStatus (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity00 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity01 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity02 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity03 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.Capacity04 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity05 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity06 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity07 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity08 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity09 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity10 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity11 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity12 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity13 (Read or Write)

Description	The size of this NVDIMM.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity14 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity15 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity16 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity17 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity18 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity19 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity20 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity21 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Capacity22 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.Capacity23 (Read or Write)

Description	The size of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.ClusterOnDie (Read or Write)

Description	Enables or disables the Cluster on Die feature.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.ConfigureSecurity (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.CorrEccSmi (Read or Write)

Description	Allows the system to log ECC corrected DRAM errors into the SEL log. Logging these rare errors can help identify marginal components; however the system will pause for a few milliseconds after an error while the log entry is created. Latency conscious customers may wish to disable the feature. Spare Mode, and Mirror mode require this feature to be enabled.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.CreateGoalConfig (Read or Write)

Description	Create goal configuration of Intel Persistent Memory pools.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.CurrentMemOpModeState (Read or Write)

Description	Read-only. Indicates the current state of the memory operating mode.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator00 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator01 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator02 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator03 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator04 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator05 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator06 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator07 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.DeviceLocator08 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator09 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator10 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator11 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator12 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator13 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator14 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator15 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator16 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator17 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator18 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator19 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator20 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator21 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator22 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DeviceLocator23 (Read or Write)

Description	The DIMM slot that this NVDIMM is being populated.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmID (Read or Write)

Description	View Intel Persistent Memory details.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo00 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo01 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.DimmInfo02 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo03 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo04 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo05 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo06 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo07 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo08 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo09 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo10 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo11 (Read or Write)

Description	

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo12 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo13 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo14 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo15 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo16 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo17 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo18 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo19 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo20 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.DimmInfo21 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo22 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.DimmInfo23 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion00 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion01 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion02 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion03 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion04 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion05 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion06 (Read or Write)

Description	The firmware revision of this NVDIMM.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion07 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion08 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion09 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion10 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion11 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion12 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion13 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion14 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion15 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion16 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion17 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion18 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion19 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion20 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion21 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion22 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.FirmwareVersion23 (Read or Write)

Description	The firmware revision of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.IntelPersistentMemories (Read or Write)

Description	View and configure installed Intel Persistent Memories.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.IntelPersistMemOperationTarget (Read or Write)

Description	NVDIMM region creation target in per Platform or per Socket.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState00 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState01 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState02 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState03 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState04 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState05 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState06 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState07 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.LockState08 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState09 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState10 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState11 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState12 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState13 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState14 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState15 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState16 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable

Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState17 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState18 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState19 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState20 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState21 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState22 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.LockState23 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.MemLowPower (Read or Write)

Description	Enables or disables the low-power mode of memory. When set to Disabled, the memory will run at full speed. When set to Enabled, the memory will run at a reduced speed to conserve power. Default: Disabled
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.MemOpMode (Read or Write)

Description	Allows the selection of the memory operating mode. Certain options are active only if a valid memory configuration is detected. When the Optimizer Mode is enabled, the DRAM controllers operate independently in 64-bit mode and provide optimized memory performance. When Advanced ECC Mode is enabled, the two DRAM controllers are combined in 128-bit mode and provide optimized reliability. Memory that cannot be teamed by the

	controllers is not reported to the Operating System. When Mirror Mode is enabled, the system maintains two identical copies of data in the memory. This feature provides maximum reliability and enables the system to continue running even during a high severity memory failure. NOTE: In Mirror Mode, only half of the installed system memory is reported to the operating system. When Spare Mode is enabled, the BIOS reserves a rank of memory as a spare. At runtime, the memory controller can move a rank that exhibits a large number of correctable errors to the spare rank. NOTE: In Spare Mode, the system memory size reported to the Operating System does not include the spare portion. Spare with Advanced ECC Mode operates similarly to the Spare Mode. When this mode is enabled, the system runs under Advanced ECC mode with a spare rank reserved in each channel. NOTE: In Spare with Advanced ECC Mode, the system memory size reported to the Operating System does not include the spare portion. When Dell Fault Resilient Mode is enabled, the BIOS establishes an area of memory that is fault resilient. This mode can be used by an Operating System that supports the feature to load critical applications or enables the Operating System kernel to maximize system availability. Default: Optimizer Mode
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.MemOptimizer (Read or Write)

Description	When set to Disabled, the two DRAM controllers are combined in 128-bit mode and provide optimized reliability with Advanced ECC Mode. When set to Enabled, the two DRAM controllers operate independently in 64-bit mode and provide optimized performance without Advanced ECC Mode. Default: Disabled
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.MemOpVoltage (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.MemoryCapacity (Read or Write)

Description	Total NVDIMM size configured as memory mode in the system.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.MemoryInterleaving (Read or Write)

Description	When set to Enabled, memory interleaving is supported if a symmetric memory configuration is installed. When set to Disabled, the system " supports Non-Uniform Memory Access (NUMA) (asymmetric) memory configurations. Operating Systems that are NUMA-aware understand the distribution of memory in a particular system and can intelligently allocate memory in an optimal manner. Operating Systems that are not NUMA aware could allocate memory to a processor that is not local resulting in a loss of performance. Die and Socket Interleaving should only be enabled for Operating Systems that are not NUMA aware.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.MemSettings (Read or Write)

Description	This page controls the system memory settings.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.MemTest (Read or Write)

Description	Indicates whether or not the BIOS system memory tests are conducted during POST. When set to Enabled, memory tests are performed. NOTE: Enabling this feature will result in longer boot time. The extent of increased time depends on the size of the system memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.MemTestType (Read or Write)

Description	Indicates type of BIOS-based system memory test to perform during POST. When set to Hardware, the memory tests are performed via hardware. When set to Software, the memory tests are performed via software . Note: POST time will increase when memory test are enabled, with Software test taking longer than Hardware test.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.MemThrottlingMode (Read or Write)

Description	Displays MCDRAM thermal management/throttling modes of processor(s).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.MltRnkSpr (Read or Write)

Description	If the system is configured for Spare Mode or Spare With Advanced ECC Mode, this field controls the number of spare ranks per DDR channel. The default is one spare rank per DDR channel.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NodeInterleave (Read or Write)

Description	When set to Enabled, memory interleaving is supported if a symmetric memory configuration is installed. When set to Disabled, the system supports Non-Uniform Memory Access (NUMA) (asymmetric) memory configurations. Operating Systems that are NUMA-aware understand the distribution of memory in a particular system and can intelligently allocate memory in an optimal manner. Operating Systems that are not NUMA aware could allocate memory to a processor that is not local resulting in a loss of performance. Node Interleaving should only be enabled for Operating Systems that are not NUMA aware.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault (Read or Write)

Description	Reset all NVDIMM-Ns to their Factory Default state, and erase all NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault0 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault1 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault10 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault11 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault12 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault13 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault14 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault15 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault16 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault17 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault18 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault19 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault2 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault20 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault21 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault22 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault23 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault3 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault4 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault5 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault6 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault7 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault8 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFactoryDefault9 (Read or Write)

Description	Reset an NVDIMM-N to its Factory Default state, and erase the NVDIMM-N data. WARNING: All contents in NVDIMM-N will be lost if changes are saved when exiting BIOS!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFirmwareVer0 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFirmwareVer1 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFirmwareVer10 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFirmwareVer11 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFirmwareVer2 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFirmwareVer3 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFirmwareVer4 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFirmwareVer5 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFirmwareVer6 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFirmwareVer7 (Read or Write)

Description

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFirmwareVer8 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFirmwareVer9 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFreq0 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFreq1 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFreq10 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFreq11 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFreq2 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFreq3 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFreq4 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.NvdimmFreq5 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFreq6 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFreq7 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFreq8 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmFreq9 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmInterleaveSupport (Read or Write)

Description	Enabling this setting interleaves NVDIMMs on a per-processor basis. When interleaving is enabled, Memory performance increases. However, if one NVDIMM fails, the data in all interleaved NVDIMMs is lost. When interleaving is disabled, if one NVDIMM fails, the data in other NVDIMMs remains intact."
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmLocation0 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmLocation1 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmLocation10 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmLocation11 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmLocation2 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmLocation3 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmLocation4 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmLocation5 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.NvdimmLocation6 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmLocation7 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmLocation8 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmLocation9 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmReadOnly (Read or Write)

Description	When set to enabled, NVDIMM-N is in write-protect mode.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSerialNum0 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSerialNum1 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSerialNum10 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSerialNum11 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSerialNum2 (Read or Write)

Description

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSerialNum3 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSerialNum4 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSerialNum5 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSerialNum6 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSerialNum7 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSerialNum8 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSerialNum9 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSize0 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSize1 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.NvdimmSize10 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSize11 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSize2 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSize3 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSize4 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSize5 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSize6 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSize7 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSize8 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.NvdimmSize9 (Read or Write)

Description	

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.OppSrefEn (Read or Write)

Description	This field enables/disables opportunistic self-refresh feature.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PersistentMemoryMode (Read or Write)

Description	When Select NVDIMM-N will enable NVDIMM-N Support. When select Off, all persistent memory access in OS will be disabled.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PersistentMemoryScrubbing (Read or Write)

Description	Set Persistent Memory Scrubbing mode. Auto: System automatically scrubs persistent memory during POST when multibit errors have been detected. One Shot: System will scrub persistent memory during POST on the entire persistent memory range once. Upon next boot, Fystem will go back to "Auto" persistent memory srcub mode. Enable: System will scrub persistent memory during POST on the entire persistent memory range on everyboot. Note: Scrubbing persistent memory on the entire persistent memory range could take more than 60 minutes during system POST depending on system memory population.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PersistentMemoryType (Read or Write)

Description	Select the type of the persistent memory capacity to create.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PersistentMemoryType0 (Read or Write)

Description	Persistent memory type
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PersistentMemoryType1 (Read or Write)

Description	Persistent memory type
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PersistentMemoryType2 (Read or Write)

Description	Persistent memory type
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PersistentMemoryType3 (Read or Write)

Description	Persistent memory type
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PersistentMemPassphrase (Read or Write)

Description	The Persistent Memory Passphrase unlocks secured Persistent Memory DIMMs. All Persistent Memory DIMMs are affected if the passphrase is modified. WARNING: Entering and confirming a blank passphrase disables passphrase security in all Persistent Memory DIMMs.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID00 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID01 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID02 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID03 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID04 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID05 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID06 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID07 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID08 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID09 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID10 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID11 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID13 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID14 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID15 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID17 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID18 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID19 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID20 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID21 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID22 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmControllerRevisionID23 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState00 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState01 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState02 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState03 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState04 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable

Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState05 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState06 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState07 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState08 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState09 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState10 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState11 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState12 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState13 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable

Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState14 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState15 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState16 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState17 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState18 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState19 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState20 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState21 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState22 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable

Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmLockState23 (Read or Write)

Description	The security state of this NVDIMM as unknown, disabled, unlocked, locked, frozen, max password, and not supported.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmMemoryMode (Read or Write)

Description	Set the percentage of the total capacity to use in Memory Mode(0-100). Due to platform memory alignment requirements, the capacity will be aligned automatically.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmPersistentPercentage (Read or Write)

Description	Reserve a percentage (0-100) of the requested AEP DIMM capacity that will be mapped into the system physical address space as Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmSecureEraseAll (Read or Write)

Description	Secure Erase Intel Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmSocket0 (Read or Write)

Description	NVDIMM pool creation for socket00
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmSocket1 (Read or Write)

Description	NVDIMM region creation for socket01
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmSocket2 (Read or Write)

Description	NVDIMM pool creation for socket02
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PmSocket3 (Read or Write)

Description	NVDIMM pool creation for socket03
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Pool00 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.Pool01 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Pool02 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Pool03 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Pool04 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PoolCapacity0 (Read or Write)

Description	Pool Capacity
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PoolCapacity1 (Read or Write)

Description	Pool Capacity
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PoolCapacity2 (Read or Write)

Description	Pool Capacity
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PoolCapacity3 (Read or Write)

Description	Pool Capacity
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PoolID (Read or Write)

Description	View pool details.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PoolID0 (Read or Write)

Description	Pool ID

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PoolID1 (Read or Write)

Description	Pool ID
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PoolID2 (Read or Write)

Description	Pool ID
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.PoolID3 (Read or Write)

Description	Pool ID
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.Pools (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.ProcEmbMemCacheSize (Read or Write)

Description	Displays cache size of the MCDRAM
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.ProcEmbMemMode (Read or Write)

Description	Displays 2LM memory modes of the processor(s). When configured as Cache mode, all the MCDRAM memory is used as memory side cache (MSC). When configured as Flat mode, all the MCDRAM memory is directly mapped to system address space. When configured as Hybrid mode, part of MCDRAM memory is mapped to system address space and the rest is used as MSC.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.ProcEmbMemSystemSize (Read or Write)

Description	Displays flat size of the MCDRAM
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.ProcEmbMemTotalSize (Read or Write)

Description	Displays total size of the MCDRAM
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RawCapacity (Read or Write)

Description	Total NVDIMM raw size in the system.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RedundantMem (Read or Write)

Description	Enables or disables the redundant memory feature. This feature can be enabled only if a valid redundant memory configuration is detected. When Mirror Mode is enabled, the server maintains two identical copies of data in memory. This feature allows the system to continue running even during a catastrophic memory failure. NOTE: In Mirror Mode, only half of the memory size is reported to the OS. When Spare Mode is enabled, certain sets of DIMMs or a portion of these DIMMs called a Rank will be set aside as the spare memory. When a preset threshold of correctable errors has been reached on an active DIMM rank, the contents of that rank will be copied to the spare memory to prevent catastrophic memory failure. Note that in Spare Mode, the memory size reported to the OS does not include the spare portion. Default: Disabled
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RedundantMemCfgValid (Read or Write)

Description	Indicates whether the Redundant Memory Configuration is valid.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RedundantMemInUse (Read or Write)

Description	Indicates that the Redundant Memory Configuration feature is in use.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance0 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance1 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance10 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance11 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance12 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance13 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance14 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance15 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance16 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance17 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance18 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance19 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance2 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance20 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance21 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance22 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance23 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance3 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance4 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance5 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance6 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance7 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance8 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.RemainingRatedWriteEndurance9 (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus00 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus01 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus02 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus03 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus04 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus05 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus06 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus07 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus08 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus09 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus10 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus11 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus12 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus13 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus14 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus15 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus16 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus17 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus18 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus19 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus20 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus21 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus22 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SanitizeStatus23 (Read or Write)

Description	The sanitize status of this NVDIMM as unknown, not started, in progress, and completed.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.SecureErase00 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase01 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase02 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase03 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase04 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase05 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase06 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase07 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase08 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase09 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase10 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase11 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase12 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase13 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase14 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase15 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase16 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase17 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase18 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.SecureErase19 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase20 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase21 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase22 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SecureErase23 (Read or Write)

Description	Enable or Disable Secure Erase Persistent Memory.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber00 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber01 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber02 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber03 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber04 (Read or Write)

Description	The serial number of this NVDIMM.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber05 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber06 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber07 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber08 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber09 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber10 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber11 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber12 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber13 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.SerialNumber14 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber15 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber16 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber17 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber18 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber19 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber20 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber21 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber22 (Read or Write)

Description	The serial number of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SerialNumber23 (Read or Write)

Description	The serial number of this NVDIMM.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SnoopFilter (Read or Write)

Description	Enables or disables the snoop filter option.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SnoopMode (Read or Write)

Description	Allows tuning of memory performances under different memory bandwidths. The optimal Snoop Mode setting is highly dependent on workload type. Early Snoop is best used for latency sensitive workloads. This setting offers the best balance between workload effects. Home Snoop is best used for NUMA workloads that need maximum local and remote memory bandwidth. Cluster on Die is best used for highly NUMA optimized workloads. This setting offers the best case local memory latency, but worst case remote latency. Cluster On Die is only available when Node Interleaving is Disabled. Opportunistic Snoop Broadcast, available on select processor models, works well for workloads of mixed NUMA optimization. It offers a good balance of latency and bandwidth.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SocketID0 (Read or Write)

Description	Socket ID
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SocketID1 (Read or Write)

Description	Socket ID
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SocketID2 (Read or Write)

Description	Socket ID
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SocketID3 (Read or Write)

Description	Socket ID
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz00 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz01 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz02 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable

Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz03 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz04 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz05 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz06 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz07 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz08 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz09 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz10 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz11 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MemSettings.SpeedMHz12 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz13 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz14 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz15 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz16 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz17 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz18 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz19 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz20 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz21 (Read or Write)

Description	The speed of this NVDIMM.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz22 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SpeedMHz23 (Read or Write)

Description	The speed of this NVDIMM.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SysMemSize (Read or Write)

Description	Indicates the amount of main memory in the system.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SysMemSpeed (Read or Write)

Description	Indicates the clock frequency of the main memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SysMemType (Read or Write)

Description	Indicates the type of main memory installed in the system.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SysMemVolt (Read or Write)

Description	Indicates the current operating voltage of main memory.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.SystemMemoryModel (Read or Write)

Description	Displays the memory model of the processor(s) When configured as All2All, all the cores will be serviced by all CHAs (caching/home agent - Caching architecture). When configured as SNC-2, all the CHAs, EDCs, MCs and DRAM/memory are equally split and assigned to each cluster. When configured as SNC-4, only the EDCs and DRAM memory are equally split and assigned to 4 clusters When configured as Hemisphere, all the CHAs, EDCs, MCs are equally split and assigned to each cluster (system address space is interleaved instead of split). When configured as Quadrant, all the CHAs, EDCs, MCs are equally split and assigned to 4 clusters (system address space is interleaved instead of split).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.UnconfiguredCapacity (Read or Write)

Description	Total NVDIMM size that is unconfigured in the system.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MemSettings.VideoMem (Read or Write)

Description	Indicates the total amount of video memory available to the embedded video controller.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MiscSettings

To manage the miscellaneous objects settings, use the object in this group.

BIOS.MiscSettings.AssetTag (Read or Write)

Description	This field displays the Asset Tag and allows you to modify it. The Asset Tag is a string assigned to a system, usually by an administrator, for security or tracking purposes. The Asset Tag can be up to 63 printable US-ASCII characters.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MiscSettings.CapsuleFirmwareUpdate (Read or Write)

Description	This field enables or disables BIOS update using a UEFI capsule update package. NOTE: If this option is disabled, you will not be able to update the BIOS using services such as Windows Update. This setting has effect only when Boot Mode is set to 'UEFI'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MiscSettings.DellWyseP25BIOSAccess (Read or Write)

Description	Controls remote user access to BIOS Setup via Dell Wyse P25/P45 Portal. When set to Disabled, pre-OS keyboard and mouse access is prevented, including to Diagnostics and Boot Options. It cannot be set back to Enabled from the P25/P45.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MiscSettings.ErrPrompt (Read or Write)

Description	This field determines whether the BIOS stops and displays a prompt when certain types of errors occur during POST. The BIOS will display the prompt when this setting is Enabled; otherwise, the BIOS will continue through POST and attempt to boot an operating system.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MiscSettings.ForceInt10 (Read or Write)

Description	In UEFI Boot Mode, this field determines whether the system BIOS will load the legacy video (INT 10h) option ROM from the video controller. Normally there would be no reason to do so. However, you might need to do this in order to install certain older operating systems. During installation of these older operating systems, you may be presented with a blank screen (no visible screen output). Setting this field to Enabled may fix this OS installation issue. This field has no effect when Boot Mode is set to BIOS. This field cannot be set to Enabled when Boot Mode is UEFI and Secure Boot is enabled.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MiscSettings.InSystemCharacterization (Read or Write)

Description	When enabled, In-System Characterization (ISC) executes during POST upon detecting relevant change(s) in system configuration to optimize system power and performance. ISC takes about 20 seconds to execute, and system reset is required for ISC results to be applied. The Enabled - No Reboot option executes ISC and continues without applying ISC results until the next time system reset occurs. The Enabled option executes ISC and forces an immediate system reset so that ISC results can be applied right away. It takes the system longer to be ready due to the forced system reset. When disabled, ISC will not execute.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MiscSettings.MiscSettings (Read or Write)

Description	This field controls some miscellaneous system settings.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.MiscSettings.NumLock (Read or Write)

Description	This field determines whether the system boots with Num Lock enabled or disabled. This does not apply to 84-key keyboards. When Num Lock is On, the rightmost keys on the keyboard function like those on a numeric calculator. With Num Lock Off, they function as cursor-control keys.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MiscSettings.PowerCycleRequest (Read or Write)

Description	This feature allows you to mimic a one-time AC power cycle. You will rarely need to use this feature. You may be directed to use it by Dell support. This feature is usually set to None. When you change it to Virtual AC, the system will do its best to mimic a temporary removal of AC power from the system (the AC Power Recovery feature will not be triggered by this action). The effect of this action is that some of the hardware components of the system that are always powered on when AC is present (even when the system appears to be off) will be reset. Using this feature is much more convenient than having to physically remove and reinsert the AC power cord, which would then trigger the AC Power Recovery feature when the cord was reinserted.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MiscSettings.ReportKbdErr (Read or Write)

Description	This field sets whether keyboard-related error messages are reported at system startup.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MiscSettings.SysMgmtNVByte1 (Read or Write)

Description	System Management NVRAM Byte that can be used as a state flag.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MiscSettings.SysMgmtNVByte2 (Read or Write)

Description	System Management NVRAM Byte that can be used as a state flag.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.MiscSettings.SystemUefiShell (Read or Write)

Description	This field enables or disables the System UEFI Shell as a UEFI boot option choice.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.NetworkSettings

This group contains the attributes that provides details about `BIOS.NetworkSettings`.

BIOS.NetworkSettings.HttpDev1EnDis (Read or Write)

Description	When this setting is Enabled, the BIOS will create a UEFI boot option for the HTTP device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.NetworkSettings.HttpDev1SettingsRef (Read or Write)

Description	View and/or modify this device's boot configuration.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.NetworkSettings.HttpDev2EnDis (Read or Write)

Description	When this setting is Enabled, the BIOS will create a UEFI boot option for the HTTP device.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.NetworkSettings.HttpDev2SettingsRef (Read or Write)

Description	View and/or modify this device's boot configuration.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.NetworkSettings.HttpDev3EnDis (Read or Write)

Description	When this setting is Enabled, the BIOS will create a UEFI boot option for the HTTP device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.NetworkSettings.HttpDev3SettingsRef (Read or Write)

Description	View and/or modify this device's boot configuration.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.NetworkSettings.HttpDev4EnDis (Read or Write)

Description	When this setting is Enabled, the BIOS will create a UEFI boot option for the HTTP device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.NetworkSettings.HttpDev4SettingsRef (Read or Write)

Description	View and/or modify this device's boot configuration.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.NetworkSettings.IscsiDev1EnDis (Read or Write)

Description	This field controls the configuration for this iSCSI device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.NetworkSettings.IscsiInitiatorName (Read or Write)

Description	This field specifies the name of the iSCSI Initiator in IQN format.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.NetworkSettings.PxeDev1EnDis (Read or Write)

Description	PXE device Enable/Disable. When enabled, a UEFI boot option will be created for the PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.NetworkSettings.PxeDev2EnDis (Read or Write)

Description	PXE device Enable/Disable. When enabled, a UEFI boot option will be created for the PXE device.
Legal Values	Not Applicable

Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.NetworkSettings.PxeDev3EnDis (Read or Write)

Description	PXE device Enable/Disable. When enabled, a UEFI boot option will be created for the PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.NetworkSettings.PxeDev4EnDis (Read or Write)

Description	PXE device Enable/Disable. When enabled, a UEFI boot option will be created for the PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.OneTimeBoot

You can manage the one time boot settings using the objects in this group.

BIOS.OneTimeBoot.OneTimeBiosBootSeq (Read or Write)

Description	This field determines the one-time boot device when the One-Time Boot Device List is set to BIOS Boot Sequence Device. If Boot Mode is set to UEFI, the system temporarily switches the Boot Mode to BIOS when attempting a one-time boot to the device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.OneTimeBoot.OneTimeBoot (Read or Write)

Description	This field supports a one-time boot to a specified device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.OneTimeBoot.OneTimeBootMode (Read or Write)

Description	This field enables the boot device list from which a boot device can be selected. After selecting the One-Time Boot Device List, the desired boot device must be selected from the corresponding Sequence Device field. The system will attempt to boot once to the selected device on next startup.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.OneTimeBoot.OneTimeBootModeSeq (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.OneTimeBoot.OneTimeBootSeqDev (Read or Write)

Description	This field determines the one-time boot device when the One-Time Boot Device List is set to BIOS Boot Sequence Device. If Boot Mode is set to UEFI, the system temporarily switches the Boot Mode to BIOS when attempting a one-time boot to the device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.OneTimeBoot.OneTimeCustomBootStr (Read or Write)

Description	This field determines the one-time boot device when the One-Time Boot Device List is set to one of the Custom String options. The system may temporarily switch to the correct boot mode based on the One-Time Boot Device List setting.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.OneTimeBoot.OneTimeHddSeq (Read or Write)

Description	This field determines the one-time boot hard disk when the One-Time Boot Device List is set to BIOS Hard-Disk Drive Sequence Device. If Boot Mode is set to UEFI, the system temporarily switches the Boot Mode to BIOS when attempting a one-time boot to the device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.OneTimeBoot.OneTimeHddSeqDev (Read or Write)

Description	This field determines the one-time boot hard disk when the One-Time Boot Device List is set to BIOS Hard-Disk Drive Sequence Device. If Boot Mode is set to UEFI, the system temporarily switches the Boot Mode to BIOS when attempting a one-time boot to the device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.OneTimeBoot.OneTimeUefiBootPath (Read or Write)

Description	Allows a one-time UEFI boot to the provided UEFI device path.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.OneTimeBoot.OneTimeUefiBootSeq (Read or Write)

Description	This field determines the one-time boot device when the One-Time Boot Device List is set to UEFI Boot Sequence Device. If Boot Mode is set to BIOS, the system temporarily switches the Boot Mode to UEFI when attempting a one-time boot to the device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.OneTimeBoot.OneTimeUefiBootSeqDev (Read or Write)

Description	This field determines the one-time boot device when the One-Time Boot Device List is set to UEFI Boot Sequence Device. If Boot Mode is set to BIOS, the system temporarily switches the Boot Mode to UEFI when attempting a one-time boot to the device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PowerMgmtSettings

This group contains the attributes that provides details about `BIOS.PowerMgmtSettings`.

BIOS.PowerMgmtSettings.FanPwrPerf (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PowerMgmtSettings.MemDynamicPwr (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PowerMgmtSettings.MemPwrPerf (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PowerMgmtSettings.PowerMgmt (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PowerMgmtSettings.PowerMgmtSettings (Read or Write)

Description	This field controls the power management settings.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings

To configure the processor settings, use the objects in this group.

BIOS.ProcSettings.ControlledTurbo (Read or Write)

Description	Helps to control the turbo engagement feature. It is active when System Profile is set to Performance, or when System Profile is set to Custom, CPU Power Management is set to Maximum Performance, and Turbo Boost enabled.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ControlledTurboExtended (Read or Write)

Description	Enables control of the turbo limit engagement. Effective only when the Dell Controlled Turbo feature is enabled.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ControlledTurboMinusBin (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.CorePerfBoost (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.CpuInterconnectBusSpeed (Read or Write)

Description	This setting governs the frequency of the communication links among the CPUs in the system. Note that standard and basic bin processors support lower link frequencies than the advanced parts do. Maximum Data Rate indicates that the BIOS will run the communication links at the maximum frequency supported by the processors. You can also select specific frequencies that the processors support, which can vary. For best performance, you should choose the Maximum Data setting. Any reduction in the communication link frequency will affect the performance of non-local memory accesses and cache coherency traffic. In addition, it can slow access to non-local I/O devices from a particular CPU. However, if power saving considerations outweigh performance, you may want to reduce the frequency of the CPU communication links. If you do this, you should localize memory and I/O accesses to the nearest NUMA node to minimize the impact to system performance.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.CpuMinSevAsid (Read or Write)

Description	This option determines the number of Secure Encrypted Virtualization ES and non-ES available Address Space IDs. It is a slider where the number is the dividing line between non-ES and ES ASIDs. ES - Encrypted State - the register save state area is also encrypted along with the entire guest memory area A value of 1 means there are only non-ES ASIDs available A value of 16 means there are only ES ASIDs available. A value in-between, like 8 means the ASIDs are split into 7 ES and 8 non-ES ASIDs.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.DataReuse (Read or Write)

Description	When set to Enabled, allows the processor to retain frequently used lines in all levels of cache at the expense of some control signals between the processor and cache.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.DcuIpPrefetcher (Read or Write)

Description	Enables or disables Data Cache Unit (DCU) IP Prefetcher. This setting can affect performance, depending on the application running on the server. Recommended for High Performance Computing applications.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.DcuStreamerPrefetcher (Read or Write)

Description	Enables or disables Data Cache Unit (DCU) Streamer Prefetcher. This setting can affect performance, depending on the application running on the server. Recommended for High Performance Computing applications.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.DmaVirtualization (Read or Write)

Description	When enabled, additional hardware capabilities for DMA Remapping and Virtualization are available.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.DynamicCoreAllocation (Read or Write)

Description	Logical Processor Idling (LPI) is a collaborative interface between platform and Operating System that helps to improve the energy efficiency of a system. This feature is required in those cases where customer has a need to go for power budgeting. It uses Operating Systems core parking algorithm and parks some of the logical processors in the system which in turn lets the corresponding processor cores transition into a lower power idle state. If LPI is getting used instead of throttling, better performances can be achieved when power budgeting is used. Setting to Disabled limits the OS capability to put the logical processors in idling state. Note: This feature is not supported if CPU Power Management is set to Maximum Performance.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.L1Prefetcher (Read or Write)

Description	Enables or disables the L1 Prefetcher. This setting can affect performance, depending on the application running on the server. Recommended for High Performance Computing applications.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.L2Prefetcher (Read or Write)

Description	Enables or disables the L2 Prefetcher. This setting can affect performance, depending on the application runningon the server. Recommended for High Performance Computing applications.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.LogicalProc (Read or Write)

Description	Each processor core supports up to two logical processors. When set to Enabled, the BIOS reports all logical processors. When set to Disabled, the BIOS only reports one logical processor per core. Generally, higher processor count results in increased performance for most multi-threaded workloads and the recommendation is to keep this enabled. However, there are some floating point/scientific workloads, including HPC workloads, where disabling this feature may result in higher performance.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.ProcSettings.MadtCoreEnumeration (Read or Write)

Description	This field determines how BIOS enumerates processor cores in the ACPI MADT table. When set to Round Robin, Processor cores are enumerated in a Round Robin order to evenly distribute interrupt controllers for the OS across all Sockets and Dies. When set to Linear, Processor cores are enumerated across all Dies within a Socket before enumerating additional Sockets for a linear distribition of interrupt conotrollers for the OS.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.NumaDistanceEnum (Read or Write)

Description	This field determines how BIOS enumerate NUMA nodes distance in ACPI SLIT tables. When set to physical, NUMA node distance will enumerated by physical architecture. When set to logical, the level of NUMA node distance will simplified by logical distance for better OS capability.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.PerfMonitorDevices (Read or Write)

Description	When set to Enabled, Performance Monitor Devices are visible to the OS.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc1Brand (Read or Write)

Description	This field displays the brand text provided by the processor manufacturer.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc1ControlledTurbo (Read or Write)

Description	Helps control the turbo engagement for processor 1. This option is active when System Profile is set to Performance, or when System Profile is set to Custom, CPU Power Management is set to Maximum Performance, and Turbo Boost enabled. A DPAT Pro license is needed to enable this feature.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc1ControlledTurboMinusBin (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc1Cores (Read or Write)

Description	Controls the number of enabled cores in the processor. Under certain circumstances, you may see limited performance improvements to Intel Turbo Boost Technology and benefit from potentially larger shared caches if you reduce the number of enabled cores. Most computing environments tend to benefit more from larger number of processing cores, so you must carefully weigh the disabling of cores to gain nominal performance enhancements.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc1Id (Read or Write)

Description	Displays the processor's family, model, and stepping values.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc1L2Cache (Read or Write)

Description	Displays the amount of memory in the corresponding processor cache.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc1L3Cache (Read or Write)

Description	Displays the amount of memory in the corresponding processor cache.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc1MaxMemoryCapacity (Read or Write)

Description	Displays the maximum amount of system memory supported by this processor.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc1Microcode (Read or Write)

Description	Indicates the microcode update signature.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc1NumCores (Read or Write)

Description	Displays the number of cores in the processor package.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc2Brand (Read or Write)

Description	Displays the brand text provided by the processor manufacturer.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc2ControlledTurbo (Read or Write)

Description	Helps control the turbo engagement for processor 2. This option is active when System Profile is set to Performance, or when System Profile is set to Custom, CPU Power Management is set to Maximum Performance, and Turbo Boost enabled. A DPAT Pro license is needed to enable this feature.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc2ControlledTurboMinusBin (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc2Cores (Read or Write)

Description	Controls the number of enabled cores in the processor. Under certain circumstances, you may see limited performance improvements to Intel Turbo Boost Technology and benefit from potentially larger shared caches if you reduce the number of enabled cores. Most computing environments tend to benefit more from larger number of processing cores, so you must carefully weigh the disabling of cores to gain nominal performance enhancements.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc2Id (Read or Write)

Description	Displays the processor's family, model, and stepping values.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc2L2Cache (Read or Write)

Description	Displays the amount of memory in the corresponding processor cache.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc2L3Cache (Read or Write)

Description	Displays the amount of memory in the corresponding processor cache.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc2MaxMemoryCapacity (Read or Write)

Description	Displays the maximum amount of system memory supported by this processor.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc2Microcode (Read or Write)

Description	Indicates the microcode update signature.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc2NumCores (Read or Write)

Description	Displays the number of cores in the processor package.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc3Brand (Read or Write)

Description	Displays the brand text provided by the processor manufacturer.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc3ControlledTurbo (Read or Write)

Description	Helps control the turbo engagement for processor 3. This option is active when System Profile is set to Performance, or when System Profile is set to Custom, CPU Power Management is set to Maximum Performance, and Turbo Boost enabled. A DPAT Pro license is needed to enable this feature.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc3ControlledTurboMinusBin (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc3Cores (Read or Write)

Description	Controls the number of enabled cores in the processor. Under certain circumstances, you may see limited performance improvements to Intel Turbo Boost Technology and benefit from potentially larger shared caches if you reduce the number of enabled cores. Most computing environments tend to benefit more from larger number of processing cores, so you must carefully weigh the disabling of cores to gain nominal performance enhancements.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc3Id (Read or Write)

Description	Displays the processor's family, model, and stepping values.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc3L2Cache (Read or Write)

Description	Displays the amount of memory in the corresponding processor cache.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc3L3Cache (Read or Write)

Description	Displays the amount of memory in the corresponding processor cache.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc3MaxMemoryCapacity (Read or Write)

Description	Displays the maximum amount of system memory supported by this processor.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc3Microcode (Read or Write)

Description	Indicates the microcode update signature.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc3NumCores (Read or Write)

Description	Displays the number of cores in the processor package.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc4Brand (Read or Write)

Description	Displays the brand text provided by the processor manufacturer.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc4ControlledTurbo (Read or Write)

Description	Helps to control the turbo engagement for processor 4. This option is active when System Profile is set to Performance, or when System Profile is set to Custom, CPU Power Management is set to Maximum Performance, and Turbo Boost enabled. A DPAT Pro license is needed to enable this feature.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc4ControlledTurboMinusBin (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc4Cores (Read or Write)

Description	Controls the number of enabled cores in the processor. Under certain circumstances, you may see limited performance improvements to Intel Turbo Boost Technology and benefit from potentially larger shared caches if you reduce the number of enabled cores. Most computing environments tend to benefit more from larger number of processing cores, so you must carefully weigh the disabling of cores to gain nominal performance enhancements.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc4Id (Read or Write)

Description	Displays the processor's family, model, and stepping values.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc4L2Cache (Read or Write)

Description	This field displays the amount of memory in the corresponding processor cache.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc4L3Cache (Read or Write)

Description	This field displays the amount of memory in the corresponding processor cache.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc4MaxMemoryCapacity (Read or Write)

Description	Displays the maximum amount of system memory supported by this processor.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc4Microcode (Read or Write)

Description	Indicates the microcode update signature.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc4NumCores (Read or Write)

Description	This field displays the number of cores in the processor package.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.Proc64bit (Read or Write)

Description	Indicates whether or not the installed processor(s) support 64-bit extensions.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcAdjCacheLine (Read or Write)

Description	When set to Enabled, the system is optimized for applications that require high utilization of sequential memory access. Disable this option for applications that require high utilization of random memory access.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcAts (Read or Write)

Description	Defines the Address Translation Cache (ATC) behavior for devices to cache DMA translations. This field provides an interface to a chipset's Address Translation and Protection Table to translate DMA addresses to host addresses.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcBusSpeed (Read or Write)

Description	Displays the bus speed of the processor(s).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcConfigTdp (Read or Write)

Description	Allows the reconfiguration of the processor Thermal Design Power (TDP) levels based on the power and thermal delivery capabilities of the system. TDP refers to the maximum amount of power the cooling system is required to dissipate. NOTE: This option is only available on certain SKUs of the processors, and the number of alternative levels varies as well.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcCores (Read or Write)

Description	Controls the number of cores presented to the Operating System (OS) from each populated processor socket. In general, it is uncommon to artificially reduce the core count for a given system, but under some circumstances,

	limited performance improvements to Intel Turbo Boost Technology and potentially larger shared caches may benefit some customers. Most computing environments tend to benefit more from larger numbers of processing cores, so you must carefully weigh disabling cores to gain nominal performance enhancements.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcCoreSpeed (Read or Write)

Description	Displays the rated clock speed of the processor(s).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcCoresPerDie (Read or Write)

Description	Controls the number of enabled cores in the processor. Under certain circumstances, you may see limited performance improvements to Boost Technology and benefit from potentially larger shared caches if you reduce the number of enabled cores. Most computing environments tend to benefit more from larger number of processing cores, so you must carefully weigh the disabling of cores to gain nominal performance enhancements.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcDramPrefetcher (Read or Write)

Description	When set to Enabled, turns on the DRAM prefetch unit in the Northbridge. When set to Disabled, prevents DRAM references from triggering DRAM prefetch requests. Default: Enabled
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcExecuteDisable (Read or Write)

Description	A security feature designed to prevent certain types of buffer overflow attacks by enforcing specific areas of memory that applications can execute code. In general, it is best pratice to leave this option set to Enabled for the security benefits, as no real performance advantage has been detected by disabling this feature in BIOS.
Legal Values	Not Applicable

Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcHpcMode (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcHtAssist (Read or Write)

Description	When enabled, it provides filtering of broadcast probes to improve HyperTransport I/O Link bandwidth and performance on multi-node systems. When set to Enabled, the probe filter is enabled if two or more processors are installed and all processors support the probe filter. If only one processor is installed, both nodes must have memory (at least 1067 MHz) attached. The default is Disabled for single-processor systems and Enabled for multi-processor systems.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcHwPrefetcher (Read or Write)

Description	When set to Enabled, the processor is able to prefetch extra cache lines for every memory request. This setting can affect performance, depending on the application running on the server and memory bandwidth utilization.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcHyperTransport (Read or Write)

Description	Specifies the supported HyperTransport I/O Link Specification. If the system board and all installed processors support HT 3, this field is settable to HT 3 or HT 1, else this field will become Read-Only and set to HT 1.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.ProcSettings.ProcSettings (Read or Write)

Description	Enables you to control the processor(s) settings.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcSoftwarePrefetcher (Read or Write)

Description	When set to Enabled, the hardware prefetcher considers software prefetches when detecting strides for prefetch requests. When set to Disabled, prevents the hardware prefetcher from considering software prefetches when detecting strides for prefetch requests. Default: Enabled
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcSwPrefetcher (Read or Write)

Description	When set to Enabled, the processor is able to prefetch extra cache lines for every memory request. This setting can affect performance, depending on the application running on the server and memory bandwidth utilization.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcVirtualization (Read or Write)

Description	When set to Enabled, the BIOS will enable processor Virtualization features and provide the virtualization support to the Operating System (OS) through the DMAR table. In general, only virtualized environments such as VMware(r) ESX(tm), Microsoft Hyper-V(r), Red Hat(r) KVM, and other virtualized operating systems will take advantage of these features. Disabling this feature is not known to significantly alter the performance or power characteristics of the system, so leaving this option Enabled is advised for most cases.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.ProcX2Apic (Read or Write)

Description	Enable or Disable x2APIC mode. Compared to the traditional xAPIC architecture, x2APIC extends processor addressability and enhances interrupt delivery performance. Virtualization Technology must be enabled to allow enabling and disabling of x2APIC mode. The x2APIC mode is forced to Disabled when Virtualization Technology is disabled.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.QpiBandwidthPriority (Read or Write)

Description	Determines the number and priority of requests on the QuickPath Interconnect (QPI) bus. The QPI connects the processor sockets. The Compute setting favors computational traffic while the I/O setting is optimized for IO intensive workloads.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.QpiSpeed (Read or Write)

Description	The Intel QuickPath Interconnect (QPI) Speed option in the Processor section governs the frequency of the QPI links between the populated processors. The user should be aware that standard and basic bin Intel processors of this architecture support slower QPI link speeds than the advanced parts provide. Maximum Data Rate indicates that the BIOS will run the QPI links at the maximum frequency supported by the processor. Specific frequencies supported by the processor, which can vary, can also be selected. For best performance, the QPI link speed should be left at the maximized setting, for any reduction in QPI speed will affect the performance of non-local memory accesses and cache coherency traffic. In addition, access to non-local I/O devices from a particular core can be slowed by the reduction of QPI link speed. However, in some cases it may be advisable to reduce QPI speed where power considerations outweigh the performance cost. For users considering reducing the QPI link speeds, memory and I/O accesses should be localized to the nearest NUMA node to minimize the performance impact.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.RtidSetting (Read or Write)

Description	Manipulates Requestor Transaction IDs, which are QuickPath Interconnect (QPI) resources. Generally should be left at Disabled, as no workloads have been identified as benefitting from the manipulation of this feature. NOTE: Enabling this option almost always results in negative impacts to overall system performance.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.SubNumaCluster (Read or Write)

Description	Sub NUMA Clustering (SNC) is a feature for breaking up the LLC into disjoint clusters based on address range, with each cluster bound to a subset of the memory controllers in the system. It improves average latency to the LLC.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.ProcSettings.UpiPrefetch (Read or Write)

Description	UPI Prefetch is a mechanism too get the memory read started early on DDR bus, the UPI Rx path will spawn a MemSpecRd to iMC directly.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev1Settings

This group contains the attributes that provides details about `BIOS.PxeDev1Settings`.

BIOS.PxeDev1Settings.PxeDev1Interface (Read or Write)

Description	NIC Interface used for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev1Settings.PxeDev1Protocol (Read or Write)

Description	This field controls the PXE protocol used for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.PxeDev1Settings.PxeDev1VlanEnDis (Read or Write)

Description	VLAN Enable/Disable for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev1Settings.PxeDev1VlanId (Read or Write)

Description	VLAN ID for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev1Settings.PxeDev1VlanPriority (Read or Write)

Description	VLAN priority for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev2Settings

This group contains the attributes that provides details about `BIOS.PxeDev2SettingsBIOS.PowerManagement`.

BIOS.PxeDev2Settings.PxeDev2Interface (Read or Write)

Description	NIC Interface used for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev2Settings.PxeDev2Protocol (Read or Write)

Description	This field controls the PXE protocol used for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev2Settings.PxeDev2VlanEnDis (Read or Write)

Description	VLAN Enable/Disable for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev2Settings.PxeDev2VlanId (Read or Write)

Description	VLAN ID for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev2Settings.PxeDev2VlanPriority (Read or Write)

Description	VLAN priority for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev3Settings

This group contains the attributes that provides details about `BIOS.PxeDev3Settings`.

BIOS.PxeDev3Settings.PxeDev3Interface (Read or Write)

Description	NIC Interface used for this PXE device.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev3Settings.PxeDev3Protocol (Read or Write)

Description	This field controls the PXE protocol used for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev3Settings.PxeDev3VlanEnDis (Read or Write)

Description	VLAN Enable/Disable for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev3Settings.PxeDev3VlanId (Read or Write)

Description	VLAN ID for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev3Settings.PxeDev3VlanPriority (Read or Write)

Description	VLAN priority for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev4Settings

This group contains the attributes that provides details about `BIOS.PxeDev4Settings`.

BIOS.PxeDev4Settings.PxeDev4Interface (Read or Write)

Description	NIC Interface used for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev4Settings.PxeDev4Protocol (Read or Write)

Description	This field controls the PXE protocol used for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev4Settings.PxeDev4VlanEnDis (Read or Write)

Description	VLAN Enable/Disable for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev4Settings.PxeDev4VlanId (Read or Write)

Description	VLAN ID for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.PxeDev4Settings.PxeDev4VlanPriority (Read or Write)

Description	VLAN priority for this PXE device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.RedundantOsControl

This group contains the attributes that provides details about `BIOS.RedundantOsControl`.

BIOS.RedundantOsControl.RedundantOsBoot (Read or Write)

Description	When set to Enabled, the BIOS will boot to the device specified by Redundant OS Location.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.RedundantOsControl.RedundantOsLocation (Read or Write)

Description	Specifies the backup device for the Redundant OS Control feature. When Redundant OS Boot is set to Enabled, the BIOS will boot to this device. Note: 1) SD Card Port, Internal USB Port, M.2 cards - If a device is set as the Redundant OS Location, then the corresponding device setting will be set based on Redundant OS state and not be available to be changed in Integrated Devices. 2) Embedded SATA - must be set to anything other than Off for SATA ports to show up as optional backup devices
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.RedundantOsControl.RedundantOsState (Read or Write)

Description	When set to Hidden, the device specified by Redundant OS Location will be hidden. It will not be visible in the Operating System or the BIOS boot sequence.
Legal Values	Not Applicable

Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings

Use the objects in this group to configure the BIOS SATA settings.

BIOS.SataSettings.EmbSata (Read or Write)

Description	Configures the embedded SATA to be set to Off, ATA, AHCI, or RAID Mode.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.EmbSataShadow (Read or Write)

Description	For internal use.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.eSataPort1 (Read or Write)

Description	Sets the drive type of the selected device. When the Embedded SATA setting is ATA Mode, set this field to Auto to enable BIOS support for the device. Select Off to turn off BIOS support for the device. When the Embedded SATA setting is AHCI Mode or RAID Mode, BIOS always enables support for the device and this field is read-only.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.eSataPort1Capacity (Read or Write)

Description	Indicates the total capacity of a hard-disk drive. This field is undefined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.eSataPort1DriveType (Read or Write)

Description	Indicates type of device attached to this SATA port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.eSataPort1Model (Read or Write)

Description	Indicates the drive model of the selected device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortA (Read or Write)

Description	Sets the drive type of the selected device. When the Embedded SATA setting is ATA Mode, set this field to Auto to enable BIOS support for the device. Select Off to turn off BIOS support for the device. When the Embedded SATA setting is AHCI Mode or RAID Mode, BIOS always enables support for the device and this field is read-only.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortACapacity (Read or Write)

Description	Indicates the total capacity of a hard-disk drive. This field is undefined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortADriveType (Read or Write)

Description	Indicates type of device attached to this SATA port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortAModel (Read or Write)

Description	Indicates the drive model of the selected device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortB (Read or Write)

Description	Sets the drive type of the selected device. When the Embedded SATA setting is ATA Mode, set this field to Auto to enable BIOS support for the device. Select Off to turn off BIOS support for the device. When the Embedded SATA setting is AHCI Mode or RAID Mode, BIOS always enables support for the device and this field is read-only.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortBCapacity (Read or Write)

Description	Indicates the total capacity of a hard-disk drive. This field is undefined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortBDriveType (Read or Write)

Description	Indicates type of device attached to this SATA port.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortBModel (Read or Write)

Description	Indicates the drive model of the selected device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortC (Read or Write)

Description	Sets the drive type of the selected device. When the Embedded SATA setting is ATA Mode, set this field to Auto to enable BIOS support for the device. Select Off to turn off BIOS support for the device. When the Embedded SATA setting is AHCI Mode or RAID Mode, BIOS always enables support for the device and this field is read-only.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortCCapacity (Read or Write)

Description	Indicates the total capacity of a hard-disk drive. This field is undefined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortCDriveType (Read or Write)

Description	Indicates type of device attached to this SATA port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortCModel (Read or Write)

Description	Indicates the drive model of the selected device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortD (Read or Write)

Description	Sets the drive type of the selected device. When the Embedded SATA setting is ATA Mode, set this field to Auto to enable BIOS support for the device. Select Off to turn off BIOS support for the device. When the Embedded SATA setting is AHCI Mode or RAID Mode, BIOS always enables support for the device and this field is read-only.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortDCapacity (Read or Write)

Description	Indicates the total capacity of a hard-disk drive. This field is undefined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortDDriveType (Read or Write)

Description	Indicates type of device attached to this SATA port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortDModel (Read or Write)

Description	Indicates the drive model of the selected device.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortE (Read or Write)

Description	Sets the drive type of the selected device. When the Embedded SATA setting is ATA Mode, set this field to Auto to enable BIOS support for the device. Select Off to turn off BIOS support for the device. When the Embedded SATA setting is AHCI Mode or RAID Mode, BIOS always enables support for the device and this field is read-only.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortECapacity (Read or Write)

Description	Indicates the total capacity of a hard-disk drive. This field is undefined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortEDriveType (Read or Write)

Description	Indicates type of device attached to this SATA port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortEModel (Read or Write)

Description	Indicates the drive model of the selected device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortF (Read or Write)

Description	Sets the drive type of the selected device. When the Embedded SATA setting is ATA Mode, set this field to Auto to enable BIOS support for the device. Select Off to turn off BIOS support for the device. When the Embedded SATA setting is AHCI Mode or RAID Mode, BIOS always enables support for the device and this field is read-only.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortFCapacity (Read or Write)

Description	Indicates the total capacity of a hard-disk drive. This field is undefined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortFDriveType (Read or Write)

Description	Indicates type of device attached to this SATA port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortFModel (Read or Write)

Description	Indicates the drive model of the selected device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortG (Read or Write)

Description	Sets the drive type of the selected device. When the Embedded SATA setting is ATA Mode, set this field to Auto to enable BIOS support for the device. Select Off to turn off BIOS support for the device. When the Embedded SATA setting is AHCI Mode or RAID Mode, BIOS always enables support for the device and this field is read-only.
Legal Values	Not Applicable

Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortGCapacity (Read or Write)

Description	Indicates the total capacity of a hard-disk drive. This field is undefined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortGDriveType (Read or Write)

Description	Indicates type of device attached to this SATA port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortGModel (Read or Write)

Description	Indicates the drive model of the selected device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortH (Read or Write)

Description	Sets the drive type of the selected device. When the Embedded SATA setting is ATA Mode, set this field to Auto to enable BIOS support for the device. Select Off to turn off BIOS support for the device. When the Embedded SATA setting is AHCI Mode or RAID Mode, BIOS always enables support for the device and this field is read-only.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortHCapacity (Read or Write)

Description	Indicates the total capacity of a hard-disk drive. This field is undefined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortHDriveType (Read or Write)

Description	Indicates type of device attached to this SATA port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortHModel (Read or Write)

Description	Indicates the drive model of the selected device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortI (Read or Write)

Description	Sets the drive type of the selected device. When the Embedded SATA setting is ATA Mode, set this field to Auto to enable BIOS support for the device. Select Off to turn off BIOS support for the device. When the Embedded SATA setting is AHCI Mode or RAID Mode, BIOS always enables support for the device and this field is read-only.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortICapacity (Read or Write)

Description	Indicates the total capacity of a hard-disk drive. This field is undefined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortIDriveType (Read or Write)

Description	This field indicates type of device attached to this SATA port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortIModel (Read or Write)

Description	Indicates the drive model of the selected device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortJ (Read or Write)

Description	Sets the drive type of the selected device. When the Embedded SATA setting is ATA Mode, set this field to Auto to enable BIOS support for the device. Select Off to turn off BIOS support for the device. When the Embedded SATA setting is AHCI Mode or RAID Mode, BIOS always enables support for the device and this field is read-only.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortJCapacity (Read or Write)

Description	Indicates the total capacity of a hard-disk drive. This field is undefined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortJDriveType (Read or Write)

Description	Indicates type of device attached to this SATA port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortJModel (Read or Write)

Description	Indicates the drive model of the selected device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortK (Read or Write)

Description	Sets the drive type of the selected device. When the Embedded SATA setting is ATA Mode, set this field to Auto to enable BIOS support for the device. Select Off to turn off BIOS support for the device. When the Embedded SATA setting is AHCI Mode or RAID Mode, BIOS always enables support for the device and this field is read-only.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortKCapacity (Read or Write)

Description	Indicates the total capacity of a hard-disk drive. This field is undefined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortKDriveType (Read or Write)

Description	Indicates type of device attached to this SATA port.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortKModel (Read or Write)

Description	Indicates the drive model of the selected device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortL (Read or Write)

Description	Sets the drive type of the selected device. When the Embedded SATA setting is ATA Mode, set this field to Auto to enable BIOS support for the device. Select Off to turn off BIOS support for the device. When the Embedded SATA setting is AHCI Mode or RAID Mode, BIOS always enables support for the device and this field is read-only.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortLCapacity (Read or Write)

Description	Indicates the total capacity of a hard-disk drive. This field is undefined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortLDriveType (Read or Write)

Description	Indicates type of device attached to this SATA port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortLModel (Read or Write)

Description	Indicates the drive model of the selected device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortM (Read or Write)

Description	Sets the drive type of the selected device. When the Embedded SATA setting is ATA Mode, set this field to Auto to enable BIOS support for the device. Select Off to turn off BIOS support for the device. When the Embedded SATA setting is AHCI Mode or RAID Mode, BIOS always enables support for the device and this field is read-only.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortMCapacity (Read or Write)

Description	Indicates the total capacity of a hard-disk drive. This field is undefined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortMDriveType (Read or Write)

Description	Indicates type of device attached to this SATA port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortMModel (Read or Write)

Description	Indicates the drive model of the selected device.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortN (Read or Write)

Description	Sets the drive type of the selected device. When the Embedded SATA setting is ATA Mode, set this field to Auto to enable BIOS support for the device. Select Off to turn off BIOS support for the device. When the Embedded SATA setting is AHCI Mode or RAID Mode, BIOS always enables support for the device and this field is read-only.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortNCapacity (Read or Write)

Description	Indicates the total capacity of a hard-disk drive. This field is undefined for removable-media devices such as optical drives.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortNDriveType (Read or Write)

Description	Indicates type of device attached to this SATA port.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataPortNModel (Read or Write)

Description	Indicates the drive model of the selected device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SataSettings (Read or Write)

Description	Controls embedded SATA settings.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.SecurityFreezeLock (Read or Write)

Description	When set to Enabled, the Security Freeze Lock command is sent to the Embedded SATA drives during POST. This option is only applicable to ATA, AHCI mode, and is not applicable to RAID mode.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SataSettings.WriteCache (Read or Write)

Description	Sends Enable or Disable Write Cache command to the Embedded SATA drives during POST. This option is only applicable to ATA, AHCI mode, and is not applicable to RAID mode.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SerialCommSettings

To manage the serial port settings, use the objects in the group.

BIOS.SerialCommSettings.ConTermType (Read or Write)

Description	This field sets your remote console's terminal type. The <Ctrl><Alt><Del> key sequence is mapped to <ESC><R><ESC><r><ESC><R> on the Terminal. The <Ctrl><H>, <Ctrl><I>, <Ctrl><J>, <Ctrl><M> key sequences are mapped to <ESC><Ctrl><H>, <ESC><Ctrl><I>, <ESC><Ctrl><J>, <ESC><Ctrl><M> on the Terminal. <Alt><x> key sequences are mapped to <ESC><X><X> on the Terminal, where x is any letter key, and X is the upper case of that key.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SerialCommSettings.ExtSerialConnector (Read or Write)

Description	Use this field to associate the External Serial Connector to Serial Device 1, Serial Device 2, or the Remote Access Device. Note: Only Serial Device 2 can be used for Serial Over LAN. Configuring the External Serial Connector to Serial Device 1 allows independent use of Serial Device 1 while Serial Device 2 can be used for Serial Over LAN. Please see the User's Guide for the various operating modes available.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SerialCommSettings.FailSafeBaud (Read or Write)

Description	If the BIOS fails to determine the baud rate automatically, then it will use the baud rate specified by this field.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SerialCommSettings.RedirAfterBoot (Read or Write)

Description	Determines whether console redirection is enabled when the operating system is loaded.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SerialCommSettings.SerialComm (Read or Write)

Description	This field controls the Serial Communication options.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SerialCommSettings.SerialCommSettings (Read or Write)

Description	This field controls the Serial Communication options.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SerialCommSettings.SerialPortAddress (Read or Write)

Description	This field sets port address for the Serial Devices. (COM1=0x3F8, COM2=0x2F8) Note: Only Serial Device 2 can be used for Serial Over LAN (SOL). To get Console Redirection via SOL, configure the same port address for Console Redirection and Serial Device.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation

This group contains the attributes that provides details about `BIOS.SlotBifurcation`.

BIOS.SlotBifurcation.DellAutoDiscovery (Read or Write)

Description	Allow BIOS to dynamically scan for PCIe devices rather than relying strictly on system slot definitions. The Platform Default setting will strictly follow the system slot definitions when configuring each PCIe slot. The Auto Discovery setting will analyze the installed PCIe cards and determine the correct configuration for each slot. This may include bifurcation of the slot for multiple devices. Manual Control allows the user to override bifurcation settings for each slot. CAUTION: Improper configuration of PCIe slots can prevent the system from functioning properly!
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation.Slot10Bif (Read or Write)

Description	Controls the bifurcation of PCIe cards installed in the specified slot. When set to default, the slot will operate at the default bifurcation for that slot. When set to x4 All Bifurcation, the slot will bifurcate to either two or four x4 links depending on the slot capability. When set to x8 All Bifurcation the slot will bifurcate to two x8 links. When set to x16 All Bifurcation the slot will bifurcate to x16 links. When set to x4 x4 x8 Bifurcation the slot will bifurcate to two 4 links plus a x8 link When set to x8 x4 x4 Bifurcation the slot will bifurcate x8 link plus two x4 links NOTE: Only bifurcation options that the slot can support will be shown.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation.Slot11Bif (Read or Write)

Description	Controls the bifurcation of PCIe cards installed in the specified slot. When set to default, the slot will operate at the default bifurcation for that slot. When set to x4 All Bifurcation, the slot will bifurcate to either two or four x4 links depending on the slot capability. When set to x8 All Bifurcation the slot will bifurcate to two x8 links. When set to x16 All Bifurcation the slot will bifurcate to x16 links. When set to x4 x4 x8 Bifurcation the slot will bifurcate to two 4 links plus a x8 link When set to x8 x4 x4 Bifurcation the slot will bifurcate x8 link plus two x4 links NOTE: Only bifurcation options that the slot can support will be shown.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation.Slot12Bif (Read or Write)

Description	Controls the bifurcation of PCIe cards installed in the specified slot. When set to default, the slot will operate at the default bifurcation for that slot. When set to x4 All Bifurcation, the slot will bifurcate to either two or four x4 links depending on the slot capability. When set to x8 All Bifurcation the slot will bifurcate to two x8 links. When set to x16 All Bifurcation the slot will bifurcate to x16 links. When set to x4 x4 x8 Bifurcation the slot will bifurcate to two 4 links plus a x8 link When set to x8 x4 x4 Bifurcation the slot will bifurcate x8 link plus two x4 links NOTE: Only bifurcation options that the slot can support will be shown.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation.Slot13Bif (Read or Write)

Description	Controls the bifurcation of PCIe cards installed in the specified slot. When set to default, the slot will operate at the default bifurcation for that slot. When set to x4 All Bifurcation, the slot will bifurcate to either two or four x4 links depending on the slot capability. When set to x8 All Bifurcation the slot will bifurcate to two x8 links. When set to x16 All Bifurcation the slot will bifurcate to x16 links. When set to x4 x4 x8 Bifurcation the slot will bifurcate to two 4 links plus a x8 link When set to x8 x4 x4 Bifurcation the slot will bifurcate x8 link plus two x4 links NOTE: Only bifurcation options that the slot can support will be shown.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation.Slot14Bif (Read or Write)

Description	Controls the bifurcation of PCIe cards installed in the specified slot. When set to default, the slot will operate at the default bifurcation for that slot. When set to x4 All Bifurcation, the slot will bifurcate to either two or four x4

	links depending on the slot capability. When set to x8 All Bifurcation the slot will bifurcate to two x8 links. When set to x16 All Bifurcation the slot will bifurcate to x16 links. When set to x4 x4 x8 Bifurcation the slot will bifurcate to two 4 links plus a x8 link When set to x8 x4 x4 Bifurcation the slot will bifurcate x8 link plus two x4 links NOTE: Only bifurcation options that the slot can support will be shown.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation.Slot1Bif (Read or Write)

Description	Controls the bifurcation of PCIe cards installed in the specified slot. When set to default, the slot will operate at the default bifurcation for that slot. When set to x4 All Bifurcation, the slot will bifurcate to either two or four x4 links depending on the slot capability. When set to x8 All Bifurcation the slot will bifurcate to two x8 links. When set to x16 All Bifurcation the slot will bifurcate to x16 links. When set to x4 x4 x8 Bifurcation the slot will bifurcate to two 4 links plus a x8 link When set to x8 x4 x4 Bifurcation the slot will bifurcate x8 link plus two x4 links NOTE: Only bifurcation options that the slot can support will be shown.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation.Slot2Bif (Read or Write)

Description	Controls the bifurcation of PCIe cards installed in the specified slot. When set to default, the slot will operate at the default bifurcation for that slot. When set to x4 All Bifurcation, the slot will bifurcate to either two or four x4 links depending on the slot capability. When set to x8 All Bifurcation the slot will bifurcate to two x8 links. When set to x16 All Bifurcation the slot will bifurcate to x16 links. When set to x4 x4 x8 Bifurcation the slot will bifurcate to two 4 links plus a x8 link When set to x8 x4 x4 Bifurcation the slot will bifurcate x8 link plus two x4 links NOTE: Only bifurcation options that the slot can support will be shown.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation.Slot3Bif (Read or Write)

Description	Controls the bifurcation of PCIe cards installed in the specified slot. When set to default, the slot will operate at the default bifurcation for that slot. When set to x4 All Bifurcation, the slot will bifurcate to either two or four x4 links depending on the slot capability. When set to x8 All Bifurcation the slot will bifurcate to two x8 links. When set to x16 All Bifurcation the slot will bifurcate to x16 links. When set to x4 x4 x8 Bifurcation the slot will bifurcate to two 4 links plus a x8 link When set to x8 x4 x4 Bifurcation the slot will bifurcate x8 link plus two x4 links NOTE: Only bifurcation options that the slot can support will be shown.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation.Slot4Bif (Read or Write)

Description	Controls the bifurcation of PCIe cards installed in the specified slot. When set to default, the slot will operate at the default bifurcation for that slot. When set to x4 All Bifurcation, the slot will bifurcate to either two or four x4 links depending on the slot capability. When set to x8 All Bifurcation the slot will bifurcate to two x8 links. When set to x16 All Bifurcation the slot will bifurcate to x16 links. When set to x4 x4 x8 Bifurcation the slot will bifurcate to two 4 links plus a x8 link When set to x8 x4 x4 Bifurcation the slot will bifurcate x8 link plus two x4 links NOTE: Only bifurcation options that the slot can support will be shown.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation.Slot5Bif (Read or Write)

Description	Controls the bifurcation of PCIe cards installed in the specified slot. When set to default, the slot will operate at the default bifurcation for that slot. When set to x4 All Bifurcation, the slot will bifurcate to either two or four x4 links depending on the slot capability. When set to x8 All Bifurcation the slot will bifurcate to two x8 links. When set to x16 All Bifurcation the slot will bifurcate to x16 links. When set to x4 x4 x8 Bifurcation the slot will bifurcate to two 4 links plus a x8 link When set to x8 x4 x4 Bifurcation the slot will bifurcate x8 link plus two x4 links NOTE: Only bifurcation options that the slot can support will be shown.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation.Slot6Bif (Read or Write)

Description	Controls the bifurcation of PCIe cards installed in the specified slot. When set to default, the slot will operate at the default bifurcation for that slot. When set to x4 All Bifurcation, the slot will bifurcate to either two or four x4 links depending on the slot capability. When set to x8 All Bifurcation the slot will bifurcate to two x8 links. When set to x16 All Bifurcation the slot will bifurcate to x16 links. When set to x4 x4 x8 Bifurcation the slot will bifurcate to two 4 links plus a x8 link When set to x8 x4 x4 Bifurcation the slot will bifurcate x8 link plus two x4 links NOTE: Only bifurcation options that the slot can support will be shown.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation.Slot7Bif (Read or Write)

Description	Controls the bifurcation of PCIe cards installed in the specified slot. When set to default, the slot will operate at the default bifurcation for that slot. When set to x4 All Bifurcation, the slot will bifurcate to either two or four x4

	links depending on the slot capability. When set to x8 All Bifurcation the slot will bifurcate to two x8 links. When set to x16 All Bifurcation the slot will bifurcate to x16 links. When set to x4 x4 x8 Bifurcation the slot will bifurcate to two 4 links plus a x8 link When set to x8 x4 x4 Bifurcation the slot will bifurcate x8 link plus two x4 links NOTE: Only bifurcation options that the slot can support will be shown.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation.Slot8Bif (Read or Write)

Description	Controls the bifurcation of PCIe cards installed in the specified slot. When set to default, the slot will operate at the default bifurcation for that slot. When set to x4 All Bifurcation, the slot will bifurcate to either two or four x4 links depending on the slot capability. When set to x8 All Bifurcation the slot will bifurcate to two x8 links. When set to x16 All Bifurcation the slot will bifurcate to x16 links. When set to x4 x4 x8 Bifurcation the slot will bifurcate to two 4 links plus a x8 link When set to x8 x4 x4 Bifurcation the slot will bifurcate x8 link plus two x4 links NOTE: Only bifurcation options that the slot can support will be shown.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation.Slot9Bif (Read or Write)

Description	Controls the bifurcation of PCIe cards installed in the specified slot. When set to default, the slot will operate at the default bifurcation for that slot. When set to x4 All Bifurcation, the slot will bifurcate to either two or four x4 links depending on the slot capability. When set to x8 All Bifurcation the slot will bifurcate to two x8 links. When set to x16 All Bifurcation the slot will bifurcate to x16 links. When set to x4 x4 x8 Bifurcation the slot will bifurcate to two 4 links plus a x8 link When set to x8 x4 x4 Bifurcation the slot will bifurcate x8 link plus two x4 links NOTE: Only bifurcation options that the slot can support will be shown.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotBifurcation.SlotBifurcation (Read or Write)

Description	Controls the bifurcation of the specified slot. Only slots that are present on the system will be available for control.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotDisablement

To manage the slot disablement settings, use the objects in this group.

BIOS.SlotDisablement.Slot1 (Read or Write)

Description	Controls the configuration of PCIe cards installed in the specified slot. Slot disablement must be used only when the installed peripheral card is preventing booting into the operating system or causing delays or lockups in system startup. When set to Disabled, both the Option ROM and UEFI driver are disabled, the card is not enumerated on the PCI bus, and will not be available to the operating system. When set to Boot Driver Disabled, the Option ROM and UEFI driver from that slot will not run during POST. As a result, the system will not boot from the card, and its pre-boot services will not be available. However, the card is available to the operating system. Note: This option is not available if the slot contains a Dell PowerEdge RAID card (PERC). This option is not available if the slot contains the primary video display adapter. Note: Some PCIe device manufacturers implement a master boot driver that can initialize and manage all the similar devices in the system. In this case, to make sure that the Option ROM and UEFI driver do not run, you must select Boot Driver Disabled for all the cards from the same manufacturer (including its integrated device versions such as NDCs).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotDisablement.Slot10 (Read or Write)

Description	Controls the configuration of PCIe cards installed in the specified slot. Slot disablement must be used only when the installed peripheral card is preventing booting into the operating system or causing delays or lockups in system startup. When set to Disabled, both the Option ROM and UEFI driver are disabled, the card is not enumerated on the PCI bus, and will not be available to the operating system. When set to Boot Driver Disabled, the Option ROM and UEFI driver from that slot will not run during POST. As a result, the system will not boot from the card, and its pre-boot services will not be available. However, the card is available to the operating system. Note: This option is not available if the slot contains a Dell PowerEdge RAID card (PERC). This option is not available if the slot contains the primary video display adapter. Note: Some PCIe device manufacturers implement a master boot driver that can initialize and manage all the similar devices in the system. In this case, to make sure that the Option ROM and UEFI driver do not run, you must select Boot Driver Disabled for all the cards from the same manufacturer (including its integrated device versions such as NDCs).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotDisablement.Slot11 (Read or Write)

Description	Controls the configuration of PCIe cards installed in the specified slot. Slot disablement must be used only when the installed peripheral card is preventing booting into the operating system or causing delays or lockups in system startup. When set to Disabled, both the Option ROM and UEFI driver are disabled, the card is not enumerated on the PCI bus, and will not be available to the operating system. When set to Boot Driver Disabled, the Option ROM and UEFI driver from that slot will not run during POST. As a result,the system will not boot from the card, and its pre-boot services will not be available. However, the card is available to the operating system. Note: This option is not available if the slot contains a Dell PowerEdge RAID card (PERC). This option is not available if the slot contains the primary video display adapter. Note: Some PCIe device manufacturers implement a master boot driver that can initialize and manage all the similar devices in the system. In this case, to make sure that the Option

ROM and UEFI driver do not run, you must select Boot Driver Disabled for all the cards from the same manufacturer (including its integrated device versions such as NDCs).

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotDisablement.Slot12 (Read or Write)

Description	Controls the configuration of PCIe cards installed in the specified slot. Slot disablement must be used only when the installed peripheral card is preventing booting into the operating system or causing delays or lockups in system startup. When set to Disabled, both the Option ROM and UEFI driver are disabled, the card is not enumerated on the PCI bus, and will not be available to the operating system. When set to Boot Driver Disabled, the Option ROM and UEFI driver from that slot will not run during POST. As a result,the system will not boot from the card, and its pre-boot services will not be available. However, the card is available to the operating system. Note: This option is not available if the slot contains a Dell PowerEdge RAID card (PERC). This option is not available if the slot contains the primary video display adapter. Note: Some PCIe device manufacturers implement a master boot driver that can initialize and manage all the similar devices in the system. In this case, to make sure that the Option ROM and UEFI driver do not run, you must select Boot Driver Disabled for all the cards from the same manufacturer (including its integrated device versions such as NDCs).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotDisablement.Slot13 (Read or Write)

Description	Controls the configuration of PCIe cards installed in the specified slot. Slot disablement must be used only when the installed peripheral card is preventing booting into the operating system or causing delays or lockups in system startup. When set to Disabled, both the Option ROM and UEFI driver are disabled, the card is not enumerated on the PCI bus, and will not be available to the operating system. When set to Boot Driver Disabled, the Option ROM and UEFI driver from that slot will not run during POST. As a result,the system will not boot from the card, and its pre-boot services will not be available. However, the card is available to the operating system. Note: This option is not available if the slot contains a Dell PowerEdge RAID card (PERC). This option is not available if the slot contains the primary video display adapter. Note: Some PCIe device manufacturers implement a master boot driver that can initialize and manage all the similar devices in the system. In this case, to make sure that the Option ROM and UEFI driver do not run, you must select Boot Driver Disabled for all the cards from the same manufacturer (including its integrated device versions such as NDCs).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotDisablement.Slot2 (Read or Write)

Description	Controls the configuration of PCIe cards installed in the specified slot. Slot disablement must be used only when the installed peripheral card is preventing booting into the operating system or causing delays or lockups in system startup. When set to Disabled, both the Option ROM and UEFI driver are disabled, the card is not enumerated on

	the PCI bus, and will not be available to the operating system. When set to Boot Driver Disabled, the Option ROM and UEFI driver from that slot will not run during POST. As a result, the system will not boot from the card, and its pre-boot services will not be available. However, the card is available to the operating system. Note: This option is not available if the slot contains a Dell PowerEdge RAID card (PERC). This option is not available if the slot contains the primary video display adapter. Note: Some PCIe device manufacturers implement a master boot driver that can initialize and manage all the similar devices in the system. In this case, to make sure that the Option ROM and UEFI driver do not run, you must select Boot Driver Disabled for all the cards from the same manufacturer (including its integrated device versions such as NDCs).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotDisablement.Slot3 (Read or Write)

Description	Controls the configuration of PCIe cards installed in the specified slot. Slot disablement must be used only when the installed peripheral card is preventing booting into the operating system or causing delays or lockups in system startup. When set to Disabled, both the Option ROM and UEFI driver are disabled, the card is not enumerated on the PCI bus, and will not be available to the operating system. When set to Boot Driver Disabled, the Option ROM and UEFI driver from that slot will not run during POST. As a result, the system will not boot from the card, and its pre-boot services will not be available. However, the card is available to the operating system. Note: This option is not available if the slot contains a Dell PowerEdge RAID card (PERC). This option is not available if the slot contains the primary video display adapter. Note: Some PCIe device manufacturers implement a master boot driver that can initialize and manage all the similar devices in the system. In this case, to make sure that the Option ROM and UEFI driver do not run, you must select Boot Driver Disabled for all the cards from the same manufacturer (including its integrated device versions such as NDCs).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotDisablement.Slot4 (Read or Write)

Description	Controls the configuration of PCIe cards installed in the specified slot. Slot disablement must be used only when the installed peripheral card is preventing booting into the operating system or causing delays or lockups in system startup. When set to Disabled, both the Option ROM and UEFI driver are disabled, the card is not enumerated on the PCI bus, and will not be available to the operating system. When set to Boot Driver Disabled, the Option ROM and UEFI driver from that slot will not run during POST. As a result, the system will not boot from the card, and its pre-boot services will not be available. However, the card is available to the operating system. Note: This option is not available if the slot contains a Dell PowerEdge RAID card (PERC). This option is not available if the slot contains the primary video display adapter. Note: Some PCIe device manufacturers implement a master boot driver that can initialize and manage all the similar devices in the system. In this case, to make sure that the Option ROM and UEFI driver do not run, you must select Boot Driver Disabled for all the cards from the same manufacturer (including its integrated device versions such as NDCs).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotDisablement.Slot5 (Read or Write)

Description	Controls the configuration of PCIe cards installed in the specified slot. Slot disablement must be used only when the installed peripheral card is preventing booting into the operating system or causing delays or lockups in system startup. When set to Disabled, both the Option ROM and UEFI driver are disabled, the card is not enumerated on the PCI bus, and will not be available to the operating system. When set to Boot Driver Disabled, the Option ROM and UEFI driver from that slot will not run during POST. As a result, the system will not boot from the card, and its pre-boot services will not be available. However, the card is available to the operating system. Note: This option is not available if the slot contains a Dell PowerEdge RAID card (PERC). This option is not available if the slot contains the primary video display adapter. Note: Some PCIe device manufacturers implement a master boot driver that can initialize and manage all the similar devices in the system. In this case, to make sure that the Option ROM and UEFI driver do not run, you must select Boot Driver Disabled for all the cards from the same manufacturer (including its integrated device versions such as NDCs).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotDisablement.Slot6 (Read or Write)

Description	Controls the configuration of PCIe cards installed in the specified slot. Slot disablement must be used only when the installed peripheral card is preventing booting into the operating system or causing delays or lockups in system startup. When set to Disabled, both the Option ROM and UEFI driver are disabled, the card is not enumerated on the PCI bus, and will not be available to the operating system. When set to Boot Driver Disabled, the Option ROM and UEFI driver from that slot will not run during POST. As a result, the system will not boot from the card, and its pre-boot services will not be available. However, the card is available to the operating system. Note: This option is not available if the slot contains a Dell PowerEdge RAID card (PERC). This option is not available if the slot contains the primary video display adapter. Note: Some PCIe device manufacturers implement a master boot driver that can initialize and manage all the similar devices in the system. In this case, to make sure that the Option ROM and UEFI driver do not run, you must select Boot Driver Disabled for all the cards from the same manufacturer (including its integrated device versions such as NDCs).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotDisablement.Slot7 (Read or Write)

Description	Controls the configuration of PCIe cards installed in the specified slot. Slot disablement must be used only when the installed peripheral card is preventing booting into the operating system or causing delays or lockups in system startup. When set to Disabled, both the Option ROM and UEFI driver are disabled, the card is not enumerated on the PCI bus, and will not be available to the operating system. When set to Boot Driver Disabled, the Option ROM and UEFI driver from that slot will not run during POST. As a result, the system will not boot from the card, and its pre-boot services will not be available. However, the card is available to the operating system. Note: This option is not available if the slot contains a Dell PowerEdge RAID card (PERC). This option is not available if the slot contains the primary video display adapter. Note: Some PCIe device manufacturers implement a master boot driver that can initialize and manage all the similar devices in the system. In this case, to make sure that the Option ROM and UEFI driver do not run, you must select Boot Driver Disabled for all the cards from the same manufacturer (including its integrated device versions such as NDCs).
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotDisablement.Slot8 (Read or Write)

Description	Controls the configuration of PCIe cards installed in the specified slot. Slot disablement must be used only when the installed peripheral card is preventing booting into the operating system or causing delays or lockups in system startup. When set to Disabled, both the Option ROM and UEFI driver are disabled, the card is not enumerated on the PCI bus, and will not be available to the operating system. When set to Boot Driver Disabled, the Option ROM and UEFI driver from that slot will not run during POST. As a result, the system will not boot from the card, and its pre-boot services will not be available. However, the card is available to the operating system. Note: This option is not available if the slot contains a Dell PowerEdge RAID card (PERC). This option is not available if the slot contains the primary video display adapter. Note: Some PCIe device manufacturers implement a master boot driver that can initialize and manage all the similar devices in the system. In this case, to make sure that the Option ROM and UEFI driver do not run, you must select Boot Driver Disabled for all the cards from the same manufacturer (including its integrated device versions such as NDCs).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotDisablement.Slot9 (Read or Write)

Description	Controls the configuration of PCIe cards installed in the specified slot. Slot disablement must be used only when the installed peripheral card is preventing booting into the operating system or causing delays or lockups in system startup. When set to Disabled, both the Option ROM and UEFI driver are disabled, the card is not enumerated on the PCI bus, and will not be available to the operating system. When set to Boot Driver Disabled, the Option ROM and UEFI driver from that slot will not run during POST. As a result, the system will not boot from the card, and its pre-boot services will not be available. However, the card is available to the operating system. Note: This option is not available if the slot contains a Dell PowerEdge RAID card (PERC). This option is not available if the slot contains the primary video display adapter. Note: Some PCIe device manufacturers implement a master boot driver that can initialize and manage all the similar devices in the system. In this case, to make sure that the Option ROM and UEFI driver do not run, you must select Boot Driver Disabled for all the cards from the same manufacturer (including its integrated device versions such as NDCs).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SlotDisablement.SlotDisablement (Read or Write)

Description	Controls the configuration of PCIe cards installed in the specified slot. Only slots that are present on the system will be available for control.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.SysInformation

To view information about system configuration, use the objects in this group.

BIOS.SysInformation.SysInformation (Read or Write)

Description	This field displays information which uniquely identifies this system.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysInformation.SysMfrContactInfo (Read or Write)

Description	Indicates the contact information of the Original Equipment Manufacturer (OEM).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysInformation.SystemBiosVersion (Read or Write)

Description	Indicates the current version of the BIOS firmware.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysInformation.SystemCpldVersion (Read or Write)

Description	Indicates the current firmware version of CPLD.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysInformation.SystemManufacturer (Read or Write)

Description	Indicates the name of the Original Equipment Manufacturer (OEM).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysInformation.SystemMeVersion (Read or Write)

Description	Indicates the current version of the Management Engine (ME) firmware.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysInformation.SystemModelName (Read or Write)

Description	Indicates the product name of the system.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysInformation.SystemServiceTag (Read or Write)

Description	Indicates the Service Tag of a system, a unique identifier assigned by the Original Equipment Manufacturer (OEM).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysInformation.UefiComplianceVersion (Read or Write)

Description	Indicates the UEFI compliance level of the system firmware.
Legal Values	Not Applicable

Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings

To manage the system profile settings, use the objects in this group.

BIOS.SysProfileSettings.CollaborativeCpuPerfCtrl (Read or Write)

Description	Allows for collaboration between the operating system and the hardware to dynamically control processor frequency for optimal power efficiency. This feature works only when CPU Power Management is set to System DBPM (DAPC), or Hardware P States. Otherwise, changing this setting does not impact system power or performance. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.CpuInterconnectBusLinkPower (Read or Write)

Description	When enabled, CPU interconnect bus link power management is enabled
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.DeterminismSlider (Read or Write)

Description	It controls whether BIOS will enable determinism to control performance. Performance - BIOS will enable 100% deterministic performance control. Power - BIOS will not enable deterministic performance control.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.EnergyEfficientTurbo (Read or Write)

Description	Energy Efficient Turbo (EET) is a mode of operation where a processor's core frequency is adjusted within the turbo range based on workload. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.EnergyPerformanceBias (Read or Write)

Description	The CPU uses the setting to manipulate the internal behavior of the processor and determine whether targeting higher performance or better power savings. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.MemFrequency (Read or Write)

Description	Governs the BIOS memory frequency. The variables that govern maximum memory frequency include the maximum rated frequency of the DIMMs, the DIMMs per channel population, the processor choice, and this BIOS option. Additional power savings can be achieved by reducing the memory frequency, at the expense of reduced performance. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.MemPatrolScrub (Read or Write)

Description	Patrol Scrubbing searches the memory for errors and repairs correctable errors to prevent the accumulation of memory errors. When set to Disabled, no patrol scrubbing will occur. When set to Standard Mode, the entire memory array will be scrubbed once in a 24 hour period. When set to Extended Mode, the entire memory array will be scrubbed more frequently to further increase system reliability. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.SysProfileSettings.MemPwrMgmt (Read or Write)

Description	When set to Enabled, the memory can operate in Power Management Mode. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.MemRefreshRate (Read or Write)

Description	The memory controller will periodically refresh the data in memory. The frequency at which memory is normally refreshed is referred to as 1X refresh rate. When memory modules are operating at a higher than normal temperature or to further increase system reliability, the refresh rate can be set to 2X, but may have a negative impact on memory subsystem performance under some circumstances. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.MemVolt (Read or Write)

Description	Sets the DIMM voltage selection. When set to Auto the system will automatically set the system voltage to the optimal setting based upon the DIMM capability and the installed DIMM population. Also enables setting the system DIMM voltage to a higher (1.5V) setting if the DIMMs support multiple voltages and have been Auto set to a lower voltage. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.MonitorMwait (Read or Write)

Description	Specifies whether Monitor/Mwait instructions are enabled. Monitor/Mwait is only active when C-states is set to Disabled in custom Mode. If the C-States are enabled, and the customer sets Monitor/Mwait to Disabled, Monitor/MWait is changed to Enabled in the next boot. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.PcieAspmL1 (Read or Write)

Description	When enabled, PCIe Advanced State Power Management (ASPM) can reduce overall system power a bit while slightly reducing system performance. NOTE: Some devices may not perform properly (they may hang or cause the system to hang) when ASPM is enabled; for this reason L1 will only be enabled for validated qualified cards.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.PowerDelivery (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.PowerSaver (Read or Write)

Description	When set to Enabled, maximizes power savings, at the expense of performance. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.Proc1TurboCoreNum (Read or Write)

Description	Controls the number of Turbo Boost enabled cores for processor 1. By reducing the number of cores enabled with Turbo Boost, the maximum turbo frequency on the cores with Turbo Boost may be higher. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.Proc2TurboCoreNum (Read or Write)

Description	Controls the number of Turbo Boost enabled cores for processor 2. By reducing the number of cores enabled with Turbo Boost, the maximum turbo frequency on the cores with Turbo Boost may be higher. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.Proc3TurboCoreNum (Read or Write)

Description	Controls the number of Turbo Boost enabled cores for processor 3. By reducing the number of cores enabled with Turbo Boost, the maximum turbo frequency on the cores with Turbo Boost may be higher. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.Proc4TurboCoreNum (Read or Write)

Description	Controls the number of Turbo Boost enabled cores for processor 4. By reducing the number of cores enabled with Turbo Boost, the maximum turbo frequency on the cores with Turbo Boost may be higher. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.ProcC1E (Read or Write)

Description	When set to Enabled, the processor is allowed to switch to minimum performance state when idle. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

BIOS.SysProfileSettings.ProcCStates (Read or Write)

Description	C States allow the processor to enter lower power states when idle. When set to Enabled (OS controlled) or when set to Autonomous (if Hardware controlled is supported), the processor can operate in all available Power States to save power, but may increase memory latency and frequency jitter. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.ProcPwrPerf (Read or Write)

Description	Allows selection of CPU power management methodology. System DBPM (Demand-based Power Management) utilizes a BIOS-controlled dynamic frequency manipulation scheme to save power across a variety of utilization levels as part of the Dell Advanced Power Control (DAPC) capability. The power saving features of this option typically are greatest at mid-to-lower processor utilization levels. Maximum Performance is typically selected for performance-centric workloads where it is acceptable to consume additional power to achieve the highest possible performance for the computing environment. This mode drives processor frequency to the maximum across all cores (although idled cores can still be frequency reduced by C-state enforcement through BIOS or OS mechanisms if enabled). This mode also offers the lowest latency of the CPU Power Management Mode options, so is always preferred for latency-sensitive environments. OS DBPM is another performance-per-watt option that relies on the operating system to dynamically control individual core frequency. Both Windows and Linux can take advantage of this mode to reduce frequency of idled or underutilized cores in order to save power. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.ProcTurboMode (Read or Write)

Description	Governs the Intel Turbo Boost Technology. This feature allows the processor cores to be automatically clocked up in frequency beyond the advertised processor speed. The amount of increased frequency (or 'turbo upside') one can expect from a Xeon processor depends on the processor model, thermal limitations of the operating environment, and in some cases power consumption. In general terms, the fewer cores being exercised with work the higher the potential turbo upside. The potential drawbacks for Turbo Boost are mainly centered on increased power consumption and possible frequency jitter than can affect a small minority of latency-sensitive environments. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.SysProfile (Read or Write)

Description	Allows optimizing the system for a specific profile, which presets multiple sub-options, or customizing the individual sub-options. When set to a mode other than Custom, BIOS will set each option accordingly. When set to Custom, you can change setting of each sub-option. Performance Per Watt (DAPC) represents an excellent mix of performance balanced with power consumption reduction. Dell Active Power Control (or DAPC) relies on a BIOS-centric power control mechanism which offers excellent power efficiency advantages with minimal performance impact in most environments, and is the CPU Power Management choice for this overall System Profile. Performance-per-watt (OS), otherwise known as 'OS Control', is similar to the DAPC profile for all sub-options except for the CPU Power Management. The power management scheme used for this profile is called 'OS DBPM', which allows the Operating System to manipulate processor frequencies for higher power efficiency. However, the effectiveness of this profile for reducing overall system power consumption is based on how well the Operating System is able to effectively control hardware resources, so the impacts are mixed across all supported Operating Systems Performance profile provides potentially increased performance by maximizing processor frequency and disabling certain power saving features such as C-states. Although not optimal for all environments, this is an excellent starting point for performance optimization baseline comparisons. Dense Configuration enhances reliability features and reduces power consumption at the cost of considerable performance. This profile is targeted for operating environments where enhanced reliability is desired and temperatures may exceed the thresholds encountered in less densely-packed data centers. When set to Dense Configuration mode, Memory Performance is set one speed lower than the Maximum Frequency to improve reliability. Under Custom mode when C states are enabled, Monitor/Mwait must also be enabled.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.SysProfileSettings (Read or Write)

Description	Indicates the fields by using which you can control the System Profile settings.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.UncoreFrequency (Read or Write)

Description	Selects the Processor Uncore Frequency. Dynamic mode allows processor to optimize power resources across the cores and uncore during runtime. The optimization of the uncore frequency to either save power or optimize performance is influenced by the setting of the Energy Efficiency Policy. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.WorkloadProfile (Read or Write)

Description	Allows optimization of performance based on the workload type. The WorkloadProfile setting is not a 'state'. Setting a workload profile is a one-time action that in turns modifies various BIOS settings to be optimized for the requested workload type.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysProfileSettings.WriteDataCrc (Read or Write)

Description	When set to Enabled, DDR4 data bus faults are detected and corrected during 'write' operations. Two additional cycles are required for CRC bit generation which results in performance impact. Read-only unless System Profile is set to Custom.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity

To manage the system security properties of the BIOS, use the objects in this group.

NOTE: After modifying the IntelTxt attribute value, the pending flag is enabled for the dependent attributes such as TpmActivation, TpmClear, and TpmSecurity.

BIOS.SysSecurity.AcPwrRcvry (Read or Write)

Description	Specifies how the system reacts after AC power has been restored to the system. It is especially useful when systems are turned off with a power strip. When set to Off, the system stays off after AC power is restored. When set to On, the system turns on after AC power is restored. When set to Last, the system turns on if the system was on at the moment when AC power was lost. The system will remain off if the system was turned off when AC power was lost. In case of an ungraceful shutdown, the system always turns on.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.AcPwrRcvryDelay (Read or Write)

Description	Allows staggering of power up after AC power is restored to the system. When set to Immediate, there is no delay for power-up. When set to Random, the system creates a random delay for power-up. When set to User Defined, the system delays power-up by that amount. The system supported user defined power-up delay is defined by the User Defined Delay field.
Legal Values	Not Applicable

Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.AcPwrRcvryUserDelay (Read or Write)

Description	Controls the duration for which the power-on process is delayed after the AC power supply is restored. The value is only effective if AC Power Recovery Delay is set to User Defined. The valid range is between 60s and 240s.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.AesNi (Read or Write)

Description	Indicates the status of the Intel Processor AES-NI feature. AES-NI improves the speed of applications by performing encryption and decryption using the Advanced Encryption Standard Instruction Set.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.AuthorizeDeviceFirmware (Read or Write)

Description	When set to Enabled, this field adds the SHA-256 hash of each third-party device firmware to the Secure Boot Authorized Signature Database. After the hashes are added, the field automatically reverts to Disabled. Note: This field is read-only unless Secure Boot is Enabled and Secure Boot Policy is Custom. This field is available only in secure system management consoles.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.BiosUpdateControl (Read or Write)

Description	When set to Unlocked, all BIOS update will be allowed. When set to Limited, local BIOS updates from DOS or UEFI shell based flash utilities, or from Lifecycle Controller User Interface are prohibited. Limited is recommended for environments that do not require local BIOS updates. These environments include Remote Enablement Update or executing Update Package from the OS.
Legal Values	Not Applicable

Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.BootmanagerPassword (Read or Write)

Description	Bootmanager password option is available only when Setup Password is enabled. If set to Always, setup password must be entered for accessing Boot Manager. If set to Never, setup password need not be entered for accessing Boot Manager, One-shot UEFI Boot Menu.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.InBandManageabilityInterface (Read or Write)

Description	When set to Disabled, this setting will hide the Management Engine's (ME) HECI devices and the system's IPMI devices from the operating system. This prevents the operating system from changing the ME power capping settings, and blocks access too all in-band management tools. All management must be managed via out-of-band. Note: BIOS update requires HECI devices to be operational and DUP updates require IPMI interface to be operational. This setting needs to be set to Enabled to avoid update errors.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.IntelSgx (Read or Write)

Description	Allows enabling or disabling of the Intel Software Guard Extension (SGX) Technology. When set to Off, BIOS disables the SGX technology. When set to On, BIOS enables the SGX technology. When set to Software, allows application to enable the SGX technology.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.IntelTxt (Read or Write)

Description	Allows enabling or disabling of the Intel Trusted Execution Technology (TXT). To enable Intel TXT, Virtualization Technology must be enabled, TPM Security must be set to On with Pre-boot Measurements, and TPM Status must be Enabled, Activated. When using TPM2, the hash algorithm must be set to SHA256.

Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.NewSetupPassword (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.NewSysPassword (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.NmiButton (Read or Write)

Description	Allows enabling or disabling of the NMI button on the front panel.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.OldSetupPassword (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.OldSysPassword (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.PasswordStatus (Read or Write)

Description	When set to Unlocked the system password can be changed without entering the setup password. This allows an administrator to maintain a setup password to protect against unauthorized BIOS Setup changes, while a user can freely change the system password. When set to Locked, the setup password must be entered to change the system password. To prevent the system password from being modified without providing the setup password, set this option to Locked and enable the setup password.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.PwrButton (Read or Write)

Description	Allows enabling or disabling of the power button on the front panel.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.SecureBoot (Read or Write)

Description	Allows enabling of Secure Boot, where the BIOS authenticates each component that is executed during the boot process using the certificates in the Secure Boot Policy. The following components are validated in the boot process: - UEFI drivers that are loaded from PCIe cards - UEFI drivers and executables from mass storage devices - Operating system boot loaders Note: Secure Boot is not available unless the Boot Mode (in the Boot Settings menu) is set to UEFI. Note: Secure Boot is not available unless the Load Legacy Video Option ROM setting (in the Miscellaneous Settings menu) is disabled. Note: You should create a setup password if you enable Secure Boot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.SecureBootMode (Read or Write)

Description	This field configures how the BIOS uses the Secure Boot Policy Objects (PK, KEK, db, dbx). In Setup Mode and Audit Mode, PK is not present, and BIOS does not authenticate programmatic updates to the policy objects. In User Mode and Deployed Mode, PK is present, and BIOS performs signature verification on programmatic attempts to update policy objects. Deployed Mode is the most secure mode. Use Setup, Audit, or User Mode when provisioning the system, then use Deployed Mode for normal operation. Available mode transitions depend on the current mode and PK presence. Refer to Figure 77 in the UEFI 2.6 specification for more information on transitions between the four modes. In Audit Mode, the BIOS performs signature verification on pre-boot images and logs results in the Image Execution Information Table, but executes the images whether they pass or fail verification. Audit Mode is useful for programmatically determining a working set of policy objects.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.SecureBootPolicy (Read or Write)

Description	Allows selecting the Secure Boot Policy. When set to Standard, the BIOS uses the key and certificates from the system manufacturer to authenticate pre-boot images. When set to Custom, the BIOS uses the user-customized key and certificates. Note: If Custom mode is selected, the Secure Boot Custom Policy Settings menu is displayed. Note: Changing the default security certificates may cause the system to fail booting from certain boot options.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.SetupPassword (Read or Write)

Description	The setup password is the password that must be entered to change any BIOS settings. However, the system password can be changed without entering the correct setup password if Password Status is set to Unlocked. The password is read-only if the password jumper (PWRD_EN) is not installed in the system.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.SHA256SetupPassword (Read or Write)

Description	SHA256 hash of the setup password.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.SHA256SetupPasswordSalt (Read or Write)

Description	Salt for hash of the setup password.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.SHA256SystemPassword (Read or Write)

Description	SHA256 hash of the system password.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.SHA256SystemPasswordSalt (Read or Write)

Description	Salt for hash of the system password.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.SignedFirmwareUpdate (Read or Write)

Description	When set to Enabled, this option supports the signed BIOS update feature. Warning! Once enabled, this option cannot be disabled. Note: When change the item from disabled to enabled, there will pup-up a Warning message: WARNING: This option enables the signed BIOS update feature. Once enabled, the BIOS will no longer support rollbacks to an unsigned image.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.SysPassword (Read or Write)

Description	The system password is the password that must be entered to allow the system to boot to an operating system. The password is read-only if the password jumper (PWRD_EN) is not installed in the system.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.SysSecurity (Read or Write)

Description	Controls the security features of the system.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.TcmActivation (Read or Write)

Description	Indicates the operational state of the Trusted Cryptography Module (TCM). When set to Activate, the TCM will be enabled and activated. When set to Deactivate, the TCM will be disabled and deactivated. When set to No Change, the operational state of the TCM remains unaltered. This field is read-only when TCM Security is set to Off.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.TcmClear (Read or Write)

Description	WARNING: Clearing the Trusted Cryptography Module (TCM) will clear all keys in the TCM. This could affect booting to the Operating System (OS). When set to Yes, all the contents of the TCM will be cleared. This field is Read-Only when TCM Security is set to Off.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.TcmSecurity (Read or Write)

Description	Controls the reporting of the Trusted Cryptography Module (TCM) in the system. When set to Off, presence of the TCM is not reported to the Operating System (OS). When set to On, presence of the TCM is reported to the OS.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.Tpm2Hierarchy (Read or Write)

Description	Allows enabling, disabling, or clearing the storage and endorsement hierarchies. When set to Enabled, the storage and endorsement hierarchies can be used. When set to Disabled, the storage and endorsement hierarchies cannot be used. When set to Clear, the storage and endorsement hierarchies are cleared of any values, and then reset to Enabled.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.TpmActivation (Read or Write)

Description	This field allows changing the operational state of the Trusted Platform Module (TPM). When set to Activate, the TPM will be enabled and activated. When set to Deactivate, the TPM will be disabled and deactivated. When set to No Change, the operational state of the TPM remains unaltered. This field is Read-Only when TPM Security is set to Off.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.TpmClear (Read or Write)

Description	WARNING: Clearing the Trusted Platform Module (TPM) will cause loss of all keys in the TPM. This could affect booting to the Operating System (OS). When set to Yes, all the contents of the TPM will be cleared. This field is read-only when TPM Security is set to Off.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.TpmCommand (Read or Write)

Description	Controls the Trusted Platform Module (TPM). When set to None, no command is sent to the TPM. When set to Activate, the TPM will be enabled and activated. When set to Deactivate, the TPM will be disabled and deactivated. When set to Clear, all the contents of the TPM will be cleared. WARNING: Clearing the TPM will result in losing all keys in the TPM. This could affect booting to the OS. This field is read-only when TPM Security is set to Off. The action requires an additional reboot before it can take effect.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.TpmFirmware (Read or Write)

Description	Indicates the firmware version of the Trusted Platform Module (TPM).
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.TpmInfo (Read or Write)

Description	Indicates the type of Trusted Platform Module, if present.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.TpmSecurity (Read or Write)

Description	Controls the reporting of the Trusted Platform Module (TPM) in the system. When set to Off, presence of the TPM is not reported to the Operating System (OS). When set to On with Pre-boot Measurements, BIOS will store Trusted Computing Group (TCG) compliant measurements to the TPM during POST. When set to On without Pre-boot Measurements, BIOS will bypass most pre-boot measurements. When set to On, presence of the TPM is reported to the OS and available for use.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.TpmStatus (Read or Write)

Description	Displays the current status of the Trusted Platform Module (TPM), and is applicable only for TPM 1.2. If the TPM is not present or TPM Security is set to Off, the value is set to Unknown.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.SysSecurity.UefiVariableAccess (Read or Write)

Description	Provides varying degrees of securing UEFI variables. When set to Standard, UEFI variables are accessible and can be modified in the Operating System (OS) per the UEFI specification. When set to Controlled, select UEFI variables are protected and cannot be modified in an OS environment. New UEFI boot entries are forced to be at the end of the current boot order.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.TpmAdvancedSettings

This group contains the attributes that provides details about `BIOS.TpmAdvancedSettings`.

BIOS.TpmAdvancedSettings.TpmPpiBypassClear (Read or Write)

Description	When set to Enabled, allows the Operating System to bypass Physical Presence Interface (PPI) prompts when issuing PPI Advanced Configuration and Power Interface (ACPI) clear operations.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.TpmAdvancedSettings.Tpm2Algorithm (Read or Write)

Description	Allows the user to change the cryptographic algorithms used in the Trusted Platform Module (TPM). The available options are dependent on the TPM firmware. To enable TPM2 Algorithm Selection, Intel(R) TXT technology must be disabled.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.TpmAdvancedSettings.TpmPpiBypassProvision (Read or Write)

Description	When set to Enabled, allows the Operating System to bypass Physical Presence Interface (PPI) prompts when issuing PPI Advanced Configuration and Power Interface (ACPI) provisioning operations.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSeqEnDis

This group contains the attributes that provides details about `BIOS.UefiBootSeqEnDis`.

BIOS.UefiBootSeqEnDis.UefiBootSeqEnDis (Read or Write)

Description	This field allows a boot option to be enabled or disabled. When disabled, the device will be skipped in the boot sequence when booting to the OS.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings

This group contains the attributes that provides details about `BIOS.UefiBootSettings`.

BIOS.UefiBootSettings.UefiBootSeq (Read or Write)

Description	This field controls the UEFI boot order. The first option in the list will be attempted first, and if unsuccessful, the second option will be attempted and so on. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis1 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis10 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis11 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis12 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis13 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis14 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis15 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis16 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis17 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis18 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis19 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis2 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis20 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis3 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis4 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis5 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis6 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis7 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis8 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDis9 (Read or Write)

Description	This field enables or disables this boot option in the UEFI Boot Sequence. The system will attempt to launch enabled boot options only; it will not launch disabled boot options. This field applies only when Boot Mode is 'UEFI'; it has no effect when Boot Mode is 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSeqEnDisRef (Read or Write)

Description	
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiBootSettings (Read or Write)

Description	This field controls system boot settings when Boot Mode is set to 'UEFI'. This field has no effect when Boot Mode is set to 'BIOS'.
Legal Values	Not Applicable
Default Values	Not Applicable

Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

BIOS.UefiBootSettings.UefiPxeIpVersion (Read or Write)

Description	This field enables you to select IPv4 PXE booting (default) or IPv6 PXE booting when in 'UEFI' Boot Mode. This field is disabled in 'BIOS' Boot Mode. Changing this field will cause the PXE options in the UEFI Boot Sequence to be replaced on the next reboot.
Legal Values	Not Applicable
Default Values	Not Applicable
Write Privilege	Server Control
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

6

NIC Attributes

Topics:

- NIC.ConfigureFormn
- NIC.DCBSettings
- NIC.DeviceLevelConfig
- NIC.FCOECapabilities
- NIC.FCOEConfiguration
- NIC.FCOEGenParams
- NIC.FrmimgMenu
- NIC.GlobalBandwidthAllocation
- NIC.iSCSIConfig
- NIC.IscsiFirstTgtParams
- NIC.IscsiGenParams
- NIC.IscsiInitiatorParams
- NIC.IscsiSecondaryDeviceParams
- NIC.IscsiSecondTgtParams
- NIC.NICConfig
- NIC.NICPartitioningConfig
- NIC.PortLevelConfig
- NIC.VndrConfigGroup

NIC.ConfigureFormn

The following section provides information about the objects in the `NIC.ConfigureFormn` group.

NIC.ConfigureFormn.FCoEOffloadMode (Read or Write)

Description	Enable/Disable the FCoE personality on the partition. Replace n with the number of the partition.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.FIPMacAddr (Read Only)

Description	Permanent FIP-MAC address for FCoE assigned during manufacturing. Specified on a per partition basis. Replace n with the number of the partition. If supported, the current address value should be readable at all times, irrespective of feature and partition enablement.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

NIC.ConfigureFormn.InstanceNumber (Read Only)

Description	Numeric instance of the partition (e.g. 1st, 2nd, etc.) on the port it belongs to. This identifier is unique for each partition on the port. Replace n with the number of the partition.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.IscsiFIPMacAddr (Read Only)

Description	Permanent combination MAC address for iSCSI offload and FIP for FCoE assigned during manufacturing. Specified on a per partition basis. Replace n with the number of the partition. If supported, the current address value should be readable at all times, irrespective of feature and partition enablement.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.IscsiMacAddr (Read Only)

Description	Permanent MAC address for iSCSI offload assigned during manufacturing. Specified on a per partition basis. Replace n with the number of the partition. If supported, the current address value should be readable at all times, irrespective of feature and partition enablement.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.iScsiOffloadMode (Read or Write)

Description	Enable/Disable the iSCSI offload personality on the partition. Replace n with the number of the partition.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.L2FIPMacAddr (Read Only)

Description	Permanent combination Ethernet and FIP-MAC address for FCoE assigned during manufacturing. Specified on a per partition basis. Replace n with the number of the partition. If supported, the current address value should be readable at all times, irrespective of feature and partition enablement.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.L2IscsiFIPMacAddr (Read Only)

Description	The Permanent combination Ethernet, iSCSI Offload and FIP for FCoE MAC address of the partition assigned during manufacturing. Replace n with the number of the partition. The current address value should be readable at all times, irrespective of feature and partition enablement.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.L2IscsiMacAddr (Read Only)

Description	The Permanent combination Ethernet and iSCSI Offload MAC address of the partition assigned during manufacturing. Replace n with the number of the partition. The current address value should be readable at all times, irrespective of feature and partition enablement.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.MacAddr (Read Only)

Description	The Permanent MAC address of the partition assigned during manufacturing. Replace n with the number of the partition. The current address value should be readable at all times, irrespective of feature and partition enablement.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.NicMode (Read or Write)

Description	Enable/Disable the NIC personality on the partition. Replace n with the number of the partition. Note: This personality type should be specified as the partition 1 default if RDMA is not supported or has dependencies on other device modes or settings. The default setting should be disabled for other partitions on the port.
Legal Values	• Enabled • Disabled
Default Values	Varies
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.NumberVFAdvertised (Read or Write)

Description	This value is the number of PCI Virtual Functions Advertised by the partition in PCI config space when operating in the NPar+SR-IOV virtualization mode. The value of this attribute may be the same across partitions or be settable on an individual partition basis depending on implementation. Note: This attribute is only defined for the browser and does NOT have any x-UEFI mapping. VF allocation is set via the VFDistribution attribute in x-UEFI. There will be an instance of this attribute for each partition. Replace n in the AttributeName with the number of the partition.
Legal Values	• N/A
Default Values	0
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.NumberVFSupported (Read Only)

Description	The number of Virtual Functions supported per partition. There will be an instance of this attribute for each partition. Replace n in the AttributeName with the number of the partition.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.PCIDeviceID (Read Only)

Description	PCI Device ID of the partition. Replace n with the number of the partition.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.PortNumber (Read Only)

Description	Port that the partition belongs to. Replace n with the number of the partition.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.SVID (Read or Write)

Description	When Switch Dependent Partitioning (SDP) is enabled,each partition will be assigned a pre-set Switch VLAN Identifier (SVID).The partitions are available for mapping to uplink ports at server I/O Module (IOM) as part of partition zoning. All packets sent from the switch to the NIC must be S-tagged when in SDP mode is enabled. Non-tagged packets will be dropped. When SDP is disabled SVID will be greyed out or disabled. There will be an instance of this attribute for each partition.Replace n with the number of the partition.The default value shall be number of the partitioning starting from 1001.
Legal Values	None
Default Values	1,001,100,210,031,000
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.VirtFIPMacAddr (Read or Write)

Description	Programmatically assignable FIP-MAC address for FCoE. Virtual addresses written will also generate corresponding VWWNN and VWWPN addresses as defined in Y741D. Replace n with the number of the partition. The supported method of reverting to the permanent MAC address is by writing 0's as the virtual address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. If supported, the current address value should be readable at all times, irrespective of feature and partition enablement.
Legal Values	None
Default Values	00:00:00:00:00:00
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.VirtIscsiFIPMacAddr (Read or Write)

Description	Programmatically assignable combination iSCSI Offload and FIP-MAC address for FCoE. Virtual addresses written will also generate corresponding VWWNN and VWWPN addresses as defined in Y741D. Replace n with the number of the partition. The supported method of reverting to the permanent MAC address is by writing 0's as the virtual address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. If supported, the current address value should be readable at all times, irrespective of feature and partition enablement.
Legal Values	None
Default Values	00:00:00:00:00:00
Write Privilege	None

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.VirtIscsiMacAddr (Read or Write)

Description	Programmatically assignable MAC address for iSCSI offload. Programmatic write for support of I/O Identity feature. Replace n with the number of the partition. The supported method of reverting to the permanent MAC address is by writing 0's as the virtual address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. If supported, the current address value should be readable at all times, irrespective of feature and partition enablement.
Legal Values	None
Default Values	00:00:00:00:00:00
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.VirtL2FIPMacAddr (Read or Write)

Description	Programmatically assignable combination FIP-MAC address for FCoE. Virtual addresses written will also generate corresponding VWWNN and VWWPN addresses as defined in Y741D. Replace n with the number of the partition. The supported method of reverting to the permanent MAC address is by writing 0's as the virtual address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. If supported, the current address value should be readable at all times, irrespective of feature and partition enablement.
Legal Values	None
Default Values	00:00:00:00:00:00
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.VirtL2IscsiFIPMacAddr (Read or Write)

Description	Programmatically assignable combination Ethernet, iSCSI Offload and FIP-MAC address for FCoE. Virtual addresses written will also generate corresponding VWWNN and VWWPN addresses as defined in Y741D. Replace n with the number of the partition. The supported method of reverting to the permanent MAC address is by writing 0's as the virtual address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. If supported, the current address value should be readable at all times, irrespective of feature and partition enablement.
Legal Values	None
Default Values	00:00:00:00:00:00
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.VirtL2IscsiMacAddr (Read or Write)

Description	Programmatically assignable combination MAC address for Ethernet and iSCSI offload. Programmatic write for support of I/O Identity feature. Replace n with the number of the partition. The supported method of reverting to the permanent MAC address is by writing 0's as the virtual address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. If supported, the current address value should be readable at all times, irrespective of feature and partition enablement.
Legal Values	None
Default Values	00:00:00:00:00:00
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.VirtMacAddr (Read or Write)

Description	Programmatically assignable MAC address. Programmatic write for support of I/O Identity feature. Replace n with the number of the partition. The supported method of reverting to the permanent MAC address is by writing 0's as the virtual address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. If supported, the current address value should be readable at all times, irrespective of feature and partition enablement.
Legal Values	None
Default Values	00:00:00:00:00:00
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.VirtWWN (Read or Write)

Description	Programmatically assignable Fibre Channel World Wide Node Name identifier for FCoE. Virtual addresses written will also be modified by subsequent writes to the VirtFIP-MAC addesss as defined in Y741D. Replace n with the number of the partition. The supported method of clearing this virtual address is by writing 0's as the address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. .
Legal Values	None
Default Values	00:00:00:00:00:00:00:00
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.VirtWWPN (Read or Write)

Description	Programmatically assignable Fibre Channel World Wide Port Name identifier for FCoE. Virtual addresses written will also be modified by subsequent writes to the VirtFIP-MAC addesss as defined in Y741D. Replace n with the number of the partition. The supported method of clearing this virtual address is by writing 0's as the address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's.
Legal Values	None
Default Values	00:00:00:00:00:00:00:00
Write Privilege	None

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.WWN (Read Only)

Description	Fibre Channel World Wide Node Name identifier for FCoE. Replace n with the number of the partition.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.ConfigureFormn.WWPN (Read Only)

Description	Fibre Channel World Wide Port Name identifier for FCoE assigned during manufacturing. Replace n with the number of the partition.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings

The following section provides information about the objects in the `NIC.DCBSettings` group.

NIC.DCBSettings.CongestionNotification (Read Only)

Description	Indicates whether Congestion Notification capability is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.EnhancedTransmissionSelection (Read Only)

Description	Indicates whether Enhanced Transmission Selection capability is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.LocalDCBXWillingMode (Read or Write)

Description	Indicates whether or not the controller will accept DCB configuration parameters from the link partner as defined in DCBX. Note: Only controllers that allow the disablement of Willing Mode should implement this and the associated Priority Group protocol and bandwidth attributes.
Legal Values	• Enabled • Disabled
Default Values	Enabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityFlowControl (Read Only)

Description	Indicates whether the Priority Flow Control capability is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup0BandwidthAllocation (Read or Write)

Description	Indicates the percentage of total port bandwidth is assigned to Priority Group 0. The summation of bandwidth allocations from all Priority Groups must equal 100%. Note: NO X-UEFI Mapping
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup0ProtocolAssignment (Read or Write)

Description	Indicates what protocol is assigned to Priority Group 0.
Legal Values	• All other LAN • iSCSI • FCoE

- RoCE
- None

Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup15BandwidthAllocation (Read or Write)

Description	Indicates the percentage of total port bandwidth is assigned to Priority Group 15. The summation of bandwidth allocations from all Priority Groups must equal 100%. Note: NO X-UEFI Mapping
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup15ProtocolAssignment (Read or Write)

Description	Indicates what protocol is assigned to Priority Group 15.
Legal Values	• All other LAN • iSCSI • FCoE • RoCE • None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup1BandwidthAllocation (Read or Write)

Description	Indicates the percentage of total port bandwidth is assigned to Priority Group 1. The summation of bandwidth allocations from all Priority Groups must equal 100%. Note: NO X-UEFI Mapping
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup1ProtocolAssignment (Read or Write)

Description	Indicates what protocol is assigned to Priority Group 1.
Legal Values	• All other LAN • iSCSI • FCoE • RoCE • None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup2BandwidthAllocation (Read or Write)

Description	Indicates the percentage of total port bandwidth is assigned to Priority Group 2. The summation of bandwidth allocations from all Priority Groups must equal 100%. Note: NO X-UEFI Mapping
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup2ProtocolAssignment (Read or Write)

Description	Indicates what protocol is assigned to Priority Group 2.
Legal Values	• All other LAN • iSCSI • FCoE • RoCE • None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup3BandwidthAllocation (Read or Write)

Description	Indicates the percentage of total port bandwidth is assigned to Priority Group 3. The summation of bandwidth allocations from all Priority Groups must equal 100%. Note: NO X-UEFI Mapping

Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup3ProtocolAssignment (Read or Write)

Description	Indicates what protocol is assigned to Priority Group 3.
Legal Values	• All other LAN • iSCSI • FCoE • RoCE • None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup4BandwidthAllocation (Read or Write)

Description	Indicates the percentage of total port bandwidth is assigned to Priority Group 4. The summation of bandwidth allocations from all Priority Groups must equal 100%. Note: NO X-UEFI Mapping
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup5BandwidthAllocation (Read or Write)

Description	Indicates the percentage of total port bandwidth is assigned to Priority Group 5. The summation of bandwidth allocations from all Priority Groups must equal 100%. Note: NO X-UEFI Mapping
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup5ProtocolAssignment (Read or Write)

Description	Indicates what protocol is assigned to Priority Group 5.
Legal Values	• All other LAN • iSCSI • FCoE • RoCE • None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup6BandwidthAllocation (Read or Write)

Description	Indicates the percentage of total port bandwidth is assigned to Priority Group 6. The summation of bandwidth allocations from all Priority Groups must equal 100%. Note: NO X-UEFI Mapping
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup6ProtocolAssignment (Read or Write)

Description	Indicates what protocol is assigned to Priority Group 6.
Legal Values	• All other LAN • iSCSI • FCoE • RoCE • None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup7BandwidthAllocation (Read or Write)

Description	Indicates the percentage of total port bandwidth is assigned to Priority Group 7. The summation of bandwidth allocations from all Priority Groups must equal 100%. Note: NO X-UEFI Mapping

Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup7ProtocolAssignment (Read or Write)

Description	Indicates what protocol is assigned to Priority Group 7.
Legal Values	• All other LAN • iSCSI • FCoE • RoCE • None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroupBandwidthAllocation (Read or Write)

Description	Defines the allocation of network port bandwidth by Priority Group. Bandwidth allocation values are provided in a colon-separated list for all Priority Groups without omission. Values in the list from left to right apply to PG0-7 and PG15 inclusively (e.g. PG0BW:PG1BW:PG2BW:PG3BW:PG4BW:PG5BW:PG6BW:PG7BW:PG15BW). The sum of all Priority Group allocations must equal 100.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DCBSettings.PriorityGroup4ProtocolAssignment (Read or Write)

Description	Indicates what protocol is assigned to Priority Group 4.
Legal Values	• All other LAN • iSCSI • FCoE • RoCE • None
Default Values	None
Write Privilege	None

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig

The following section provides information about the objects in the `NIC.DeviceLevelConfig` group.

NIC.DeviceLevelConfig.ConfigureLogicalPortsSupport (Read Only)

Description	Indicates whether the device supports ability to configure number of logical ports. Logical ports map 1:1 or N:1 to physical ports.
Legal Values	• Available • Unavailable
Default Values	Unavailable
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.EVBModesSupport (Read Only)

Description	Indicates the type of EVB Modes supported.
Legal Values	• VEB • VEPA • PE • Multi-channel
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.MaxNumberVFSupportedByDevice (Read Only)

Description	KILL - DUPLICATE OF NumberVFSupported
Legal Values	None
Default Values	0
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.NetworkPartitioningMode (Read or Write)

Description	This attribute governs whether an NPAR-enabled adapter operates in Switch Independent Partitioning, or Switch Dependent Partitioning mode. Preliminary attribute definition only, based on information available at the time of publication. Subject to change.
Legal Values	• Switch Independent Partitioning • Switch Dependent Partitioning
Default Values	SIP
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.NICPartitioningConfig (Read Only)

Description	The HII form for NIC Partitioning Configuration.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.NParEP (Read or Write)

Description	Controls enablement of NParEP mode in which more than 8 PCI Physical Functions are exposed by the device. When disabled, the device must expose only a maximum of 8 PFs in the traditional PCI B:D:F addressing mode, regardless of any ARI capability being advertised for SR-IOV support. [Not to be implemented if not supported] Note: Not all PCI slots in all servers are capable of supporting virtualization features based on ARI and SR-IOV. The controller should check PCI config space settings to ensure that vitualization modes are available before allowing their selection by the user.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.NPCP (Read or Write)

Description	Allows the use of Network Partition Control Protocol to be enabled or disabled when a network adapter is operating in Switch Dependent Partitioning mode. Note: Preliminary attribute definition only, based on the information available at the time of publication. Subject to change.
Legal Values	• Enabled • Disabled
Default Values	Enabled
Write Privilege	None

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.NumberPCIFunctionsSupported (Read Only)

Description	Defines the maximum number of PFs that can be enabled within the domain specified by VFAllocBasis.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.NumberVFSupported (Read Only)

Description	The total number of PCI Virtual Functions supported on this port (or device). Whether the number applies to the device as a whole, or to an individual port, is indicated by the value of the Virtual Function Allocation Basis.
Legal Values	• N/A
Default Values	0
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.PartitionStateInterpretation (Read Only)

Description	Describes how partitioning is implemented and how the PartitionState attribute is used in the controller. A value of Fixed signifies that partition states are locked and that the current values of PartitionState[n] will not change. A value of Variable signifies that PartitionState[n] may/will change values during the course of device operation as a result of user configuration. Implementations that support changes in PartitionState must implement this attribute. The Default value is implementation dependent.
Legal Values	• Fixed • Variable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.RDMAApplicationProfile (Read or Write)

Description	Indicates what RDMA configuration profiles are supported by the controller. [Vendor input requested if 1) additional profiles are thought to be needed, 2) if the appl profile can vary by port or partitionm and 3) if appl

profiles are supported on a partition basis]. Note: RoCE 1 and RoCE 2 are vendor-specific profiles and should not be interpreted as a version of RoCE.

Legal Values
- Storage
- HPCC
- RoCE 1
- RoCE 2

Default Values None

Write Privilege None

License Required iDRAC Express or iDRAC Enterprise

Dependency Not applicable

NIC.DeviceLevelConfig.RDMAProtocolSupport (Read Only)

Description Indicates what RDMA protocol support is enabled by the controller. Implement as ReadOnly and browser suppressed if the controller only supports one type of RDMA; R/W and not browser suppressed if multiple settings are supported and selectable. [Vendor to provide default setting information]

Legal Values
- iWARP
- RoCE
- iWARP + RoCE

Default Values None

Write Privilege None

License Required iDRAC Express or iDRAC Enterprise

Dependency Not applicable

NIC.DeviceLevelConfig.RDMASupport (Read Only)

Description Capability indicator for controllers supporting Remote Direct Memory Management (RDMA), the remote memory management capability that allows server to server data movement directly between application memory without any CPU involvement.

Legal Values
- Available
- Unavailable

Default Values None

Write Privilege None

License Required iDRAC Express or iDRAC Enterprise

Dependency Not applicable

NIC.DeviceLevelConfig.SRIOVSupport (Read Only)

Description Indicates whether SR-IOV capability is supported

Legal Values
- Available
- Unavailable

Default Values None

Write Privilege None

License Required iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

NIC.DeviceLevelConfig.TotalNumberLogicalPorts (Read or Write)

Description	Indicates total number of logical ports across all physical ports that are supported per device. Logical ports are distributed equally across physical ports
Legal Values	• 2 • 8
Default Values	2
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.VFAllocBasis (Read Only)

Description	Defines the domain in which Virtual Functions are allocated; either Port or Device. Note: A device which implements less than 1 PF per physical port must use Device level VF allocation.
Legal Values	• Port • Device
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.VFAllocMult (Read Only)

Description	Defines the multiple (e.g. x1, x4, x8, etc.) in which VFs must be allocated to a PF.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.DeviceLevelConfig.VirtualizationMode (Read or Write)

Description	The Virtualization Mode setting for the device. Note: Not all PCI slots in all servers are capable of supporting virtualization features based on ARI and SR-IOV. The implementation shall check the state of the ARI forwarding bit in the immediate upstream PCI port's config space settings (Device Control Register 2, bit 5) to ensure that it is set before before allowing the selection of SR-IOV and NParEP by the user, if not, those selections shall be disallowed.
Legal Values	• None • NPar • SR-IOV • NPar + SR-IOV

Default Values	NONE
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCOECapabilities

The following section provides information about the objects in the `NIC.FCOECapabilities` group.

NIC.FCOECapabilities.AddressingMode (Read Only)

Description	Addressing Mode utilized for FCoE transactions
Legal Values	• SPMA • FPMA
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCOECapabilities.MaxFrameSize (Read Only)

Description	The maximum frame size of each FCoE frame.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCOECapabilities.MaxIOsPerSession (Read Only)

Description	The maximum number of IOs supported per session.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCOECapabilities.MaxNPIVPerPort (Read Only)

Description	The maximum number of NPIV WWNs per port.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

NIC.FCOECapabilities.MaxNumberExchanges (Read Only)

Description	The maximum number of exchanges supported.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCOECapabilities.MaxNumberLogins (Read Only)

Description	The maximum number of logins supported per port.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCOECapabilities.MaxNumberOfFCTargets (Read Only)

Description	The maximum number of FC targets supported.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCOECapabilities.MaxNumberOutStandingCommands (Read Only)

Description	The maximum number of outstanding commands supported across all sessions.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCOECapabilities.MTUReconfigurationSupport (Read Only)

Description	Indicates whether the MTU Reconfiguration capability is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCOEConfiguration

The following section provides information about the objects in the `NIC.FCOEConfiguration` group.

NIC.FCoEConfiguration.BootOrderFirstFCoETarget (Read or Write)

Description	Setting to specify whether and in what order a boot from the port's first defined target is attempted. The current implementation allows for four potential boot targets to be defined per FCoE boot-capable port. Each target carries a boot order attribute. From all of the targets defined in all the vendors FCoE boot ports in the system, the user may select a maximum of four targets to attempt to boot from, assigning a boot order value from one to four (first to last). Targets not selected must be given a value of 0. The settings of one to four must be unique in the system; there must be no duplication of the values one to four in either the same port or in different ports across the system. The driver will enforce this requirement (a target previously assigned a boot order value of x is set to 0 when a new target is assigned a value of x).
Legal Values	• N/A
Default Values	0
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCoEConfiguration.BootOrderFourthFCoETarget (Read or Write)

Description	Setting to specify whether and in what order a boot from the ports fourth defined target is attempted.
Legal Values	• N/A
Default Values	0
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCoEConfiguration.BootOrderSecondFCoETarget (Read or Write)

Description	Setting to specify whether and in what order a boot from the ports second defined target is attempted.
Legal Values	• N/A
Default Values	0
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCoEConfiguration.BootOrderThirdFCoETarget (Read or Write)

Description	Setting to specify whether and in what order a boot from the port's third defined target is attempted.
Legal Values	• N/A
Default Values	0
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCoEConfiguration.ConnectFirstFCoETarget (Read or Write)

Description	Setting to enable whether first target connection is attempted.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCoEConfiguration.FCoEGenParams (Read Only)

Description	HII form for FCoE General Parameters configuration.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCoEConfiguration.FCoEGenParamsRef (Read Only)

Description	Link to the FCoE General Parameters configuration form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCoEConfiguration.FirstFCoEBootTargetLUN (Read or Write)

Description	LUN of the first FCoE storage target that the FCoE initiator will boot the system from when the Connect attribute is enabled.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCoEConfiguration.FirstFCoEFCFVLANID (Read or Write)

Description	Attribute for configuring the VLAN ID to be used to connect to the first FC storage target.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCoEConfiguration.FirstFCoEWWPNTarget (Read or Write)

Description	World Wide Port Name of the first FCoE storage target. Note: At present, the Dell FCoE information model only defines one storage target.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCoEConfiguration.MTUParams (Read or Write)

Description	Configure scoping of the MTU setting.
Legal Values	• Global • Per DCB Priority • Per VLAN
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCOEGenParams

The following section provides information about the objects in the `NIC.FCOEGenParams` group.

NIC.FCoEGenParams.FCoEBootScanSelection (Read or Write)

Description	Configuration of the port's behavior in booting the system from FC Target(s). Only behaviors supported by the option-ROM need to be implemented. In the following cases, no fabric discovery shall be attempted: Disabled - Initiator does not attempt to boot. Specified LUN - Initiator attempts to boot to the specified World Wide Port Name and LUN for 1st target, if that fails then a boot using the 2nd target parameters shall be attempted. In the following cases, fabric discovery shall be attempted and the resulting discovered targets will be put in a list sorted by the reported FC destination ID. This list will be checked in order until the selected LUN policy is met: First LUN - attempt boot from the first bootable LUN of the targets discovered by adapter. First LUN 0 - attempt boot from the first bootable LUN 0 of the targets discovered by adapter. First LUN Not LUN 0 - attempt boot from the first bootable LUN that is not LUN 0 of the targets discovered by adapter. Fabric Discovered LUN - attempt boot based on the LUN assignment provided by management infrastructure in the fabric.
Legal Values	• Disabled • First LUN • First LUN 0 • First LUN Not LUN 0 • Fabric Discovered LUN • Specified LUN
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCoEGenParams.FCoEFabricDiscoveryRetryCnt (Read or Write)

Description	Retry count for FCoE fabric discovery.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

NIC.FCoEGenParams.FCoEFirstHddTarget (Read or Write)

Description	Specifies whether the FCoE target is represented as the first HDD to the system.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCoEGenParams.FCoELnkUpDelayTime (Read or Write)

Description	Controls how long the FCoE initiator waits, in seconds, after an Ethernet link is established before sending any data over the network
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCoEGenParams.FCoELunBusyRetryCnt (Read or Write)

Description	Controls the number of connection retries the FCoE boot initiator will attempt if the FCoE target LUN is busy.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FCoEGenParams.FCoETgtBoot (Read or Write)

Description	Attribute for setting whether system boot to the FCoE target is attempted.
Legal Values	• Enabled • Disabled • One Time Disabled
Default Values	Disabled
Write Privilege	None

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FrmimgMenu

The following section provides information about the objects in the `NIC.FrmimgMenu` group.

NIC.FrmwImgMenu.ControllerBIOSVersion (Read Only)

Description	Controller BIOS version information
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FrmwImgMenu.EFIVersion (Read Only)

Description	EFI device driver version information.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.FrmwImgMenu.FamilyVersion (Read Only)

Description	Firmware family version information. Same as what is returned in the PackageVersionName field by the Firmware Management Protocol GetPackageInfo() call.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.GlobalBandwidthAllocation

The following section provides information about the objects in the `NIC.GlobalBandwidthAllocation` group.

NIC.GlobalBandwidthAllocation.MaxBandwidth (Read or Write)

Description	The maximum percentage of port TX bandwidth allocated to the partition. Oversubscription is allowed. Specified on a per partition basis. Replace n with the number of the partition.
Legal Values	None

Default Values	100
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.GlobalBandwidthAllocation.MinBandwidth (Read or Write)

Description	The minimum percentage of port TX bandwidth allocated to the partition. Alternatively, this value represents a relative bandwidth weighting of partition traffic to other partitions. Specified on a per partition basis. Replace n with the number of the partition.
Legal Values	None
Default Values	0
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.iSCSIConfig

The following section provides information about the objects in the `NIC.iSCSIConfig` group.

NIC.iSCSIConfig.IscsiFirstTgtParams (Read Only)

Description	HII form title for the first iSCSI target configuration parameters.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.iSCSIConfig.IscsiFirstTgtParamsRef (Read Only)

Description	Link to the iSCSI First Target Parameters configuration form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.iSCSIConfig.IscsiGenParams (Read Only)

Description	HII form title for the iSCSI General Parameters configuration form.
Legal Values	None
Default Values	None

Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.iSCSIConfig.IscsiGenParamsRef (Read Only)

Description	Link to the iSCSI General Parameters configuration form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.iSCSIConfig.IscsiInitiatorParams (Read Only)

Description	HII form title for the iSCSI initiator configuration form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.iSCSIConfig.IscsiInitiatorParamsRef (Read Only)

Description	Link to the iSCSI Initiator parameters configuration form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.iSCSIConfig.IscsiSecondaryDeviceParams (Read Only)

Description	The HII form title for the secondary iSCSI Device parameters form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.iSCSIConfig.IscsiSecondaryDeviceParamsRef (Read Only)

Description	The link to the iSCSI Secondary Device Parameters configuration form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.iSCSIConfig.IscsiSecondTgtParams (Read Only)

Description	The HII form title for the second iSCSI target configuration form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.iSCSIConfig.IscsiSecondTgtParamsRef (Read Only)

Description	The link to the iSCSI Second Target Parameters configuration form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiFirstTgtParams

The following section provides information about the objects in the `NIC.IscsiFirstTgtParams` group.

NIC.IscsiFirstTgtParams.ConnectFirstTgt (Read or Write)

Description	Setting to enable whether connection to the first target is attempted.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiFirstTgtParams.FirstTgtBootLun (Read or Write)

Description	Specifies the first iSCSI target boot LUN.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiFirstTgtParams.FirstTgtChapId (Read or Write)

Description	First Target CHAP ID (up to 128 characters in length). If only a single value of CHAP ID supported then it is stored here.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiFirstTgtParams.FirstTgtChapPwd (Read or Write)

Description	First Target CHAP Secret (0 or 12 to 16 characters in length). If only a single value of CHAP Secret is supported then it is stored here.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiFirstTgtParams.FirstTgtIpAddress (Read or Write)

Description	First iSCSI target IP address. Will be either IPv4 or IPv6 format depending on the value of the FirstTgtIpVer attribute.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiFirstTgtParams.FirstTgtIpVer (Read or Write)

Description	Setting displays and allows configuration of IP version used for first iSCSI target when iSCSIDualIPVersionSupport is available.
Legal Values	• IPv4 • IPv6
Default Values	IPv4
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiFirstTgtParams.FirstTgtIscsiName (Read or Write)

Description	The iSCSI Qualified Name (IQN) of the first target.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiFirstTgtParams.FirstTgtTcpPort (Read or Write)

Description	TCP Port number of the first iSCSI target.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiGenParams

The following section provides information about the objects in the `NIC.IscsiGenParams` group.

NIC.IscsiGenParams.ChapAuthEnable (Read or Write)

Description	Setting to enable CHAP Authentication for iSCSI initiator.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiGenParams.ChapMutualAuth (Read or Write)

Description	Setting to enable mutual CHAP authentication between the iSCSI initiator and target.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiGenParams.DhcpVendId (Read or Write)

Description	Vendor ID as presented to DHCP service.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiGenParams.FirstHddTarget (Read or Write)

Description	Enable/Disable the target appearing as the first hard disk drive (HDD) in the system when iSCSI booting.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiGenParams.IpAutoConfig (Read or Write)

Description	Setting to enable acquisition of IPv6 TCP/IP parameters from DHCP.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiGenParams.IpVer (Read or Write)

Description	Setting displays and allows configuration of the IP version used by iSCSI initiator and targets (Initiator only when a seperate target ipver is implemented). If only one IP version is supported, this attribute should be set to that version and be made Read Only.

Legal Values	• IPv4 • IPv6 • None
Default Values	IPv4
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiGenParams.IscsiTgtBoot (Read or Write)

Description	Boot to iSCSI target after connection.
Legal Values	• Enabled • Disabled • One Time Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiGenParams.IscsiViaDHCP (Read or Write)

Description	Setting to enable acquisition of iSCSI target parameters from DHCP.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiGenParams.IscsiVLanId (Read or Write)

Description	VLAN ID used for iSCSI boot.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiGenParams.IscsiVLanMode (Read or Write)

Description	Enable/Disable Virtual LAN mode for iSCSI boot.
Legal Values	• Enabled • Disabled

Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiGenParams.LnkUpDelayTime (Read or Write)

Description	The time to wait for the link to establish before driver initialization.
Legal Values	None
Default Values	0
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiGenParams.LunBusyRetryCnt (Read or Write)

Description	Controls the retry count for target.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiGenParams.TcpIpViaDHCP (Read or Write)

Description	Setting to enable acquisition of IPv4 TCP/IP parameters from DHCP
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiGenParams.TcpTimestmp (Read or Write)

Description	Enable/Disable use of TCP timestamps in network packets
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiGenParams.WinHbaBootMode (Read or Write)

Description	Controls if adapter boots as an iSCSI Offload HBA or uses software initiator mode
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams

The following section provides information about the objects in the **NIC.IscsiInitiatorParams** group.

NIC.IscsiInitiatorParams.IscsiInitiatorChapId (Read or Write)

Description	Initiator CHAP ID (up to 128 characters in length). If this can be set on a per target basis, then the first target value shall be stored here.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorChapPwd (Read or Write)

Description	iSCSI initiator CHAP secret (0 or 12 to 16 characters in length). If this can be set on a per target basis, then the value for the first target shall be stored here.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorGateway (Read or Write)

Description	iSCSI initiator default Gateway IP address. Will be in either IPv4 or IPv6 format depending on the value of the IpVer attribute.
Legal Values	None
Default Values	None
Write Privilege	None

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorIpAddr (Read or Write)

Description	The iSCSI initiator IP address. Will be either in IPv4 or IPv6 format depending on value of the IpVer attribute.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorIpv4Addr (Read or Write)

Description	The iSCSI initiator IP address in IPv4 format when iSCSIDualIPVersionSupport is available.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorIpv4Gateway (Read or Write)

Description	The iSCSI initiator default Gateway IP address in IPv4 format when iSCSIDualIPVersionSupport is available.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorIpv4PrimDns (Read or Write)

Description	iSCSI initiator Primary DNS IP Address in IPv4 format when iSCSIDualIPVersionSupport is Available.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorIpv4SecDns (Read or Write)

Description	iSCSI initiator Secondary DNS IP address in IPv4 format when iSCSIDualIPVersionSupport is Available.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorIpv6Addr (Read or Write)

Description	The iSCSI initiator IP address in IPv6 format when iSCSIDualIPVersionSupport is available.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorIpv6Gateway (Read or Write)

Description	The iSCSI initiator default Gateway IP address in IPv6 format when iSCSIDualIPVersionSupport is available.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorIpv6PrimDns (Read or Write)

Description	The iSCSI initiator Primary DNS IP Address in IPv6 format when iSCSIDualIPVersionSupport is Available.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorIpv6SecDns (Read or Write)

Description	The iSCSI initiator Secondary DNS IP address in IPv6 format when iSCSIDualIPVersionSupport is Available.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorName (Read or Write)

Description	Setting to represent and set the iSCSI initiator iSCSI Qualified Name (IQN).
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorPrimDns (Read or Write)

Description	The iSCSI initiator Primary DNS IP Address. Will be in either IPv4 or IPv6 format depending on the value of the IpVer attribute.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorSecDns (Read or Write)

Description	The iSCSI initiator Secondary DNS IP address. Will be in either IPv4 or IPv6 format depending on the value of the IpVer attribute.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorSubnet (Read or Write)

Description	The iSCSI initiator Subnet Mask for an IPv4 initiator configuration.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiInitiatorParams.IscsiInitiatorSubnetPrefix (Read or Write)

Description	The iSCSI initiator Subnet Mask Prefix for an IPv6 initiator configuration.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiSecondaryDeviceParams

The following section provides information about the objects in the `NIC.IscsiSecondaryDeviceParams` group.

NIC.IscsiSecondaryDeviceParams.SecondaryDeviceMacAddr (Read or Write)

Description	MAC address of the secondary iSCSI boot adapter.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiSecondaryDeviceParams.UseIndTgtName (Read or Write)

Description	Use Independent Target Name when multipath I/O is enabled
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiSecondaryDeviceParams.UseIndTgtPortal (Read or Write)

Description	Setting to use independent target portal when multipath I/O is enabled
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiSecondTgtParams

To configure the `iSCSIsecond` storage, use the objects in this group.

NIC.IscsiSecondTgtParams.ConnectSecondTgt (Read or Write)

Description	Setting to enable whether connection to the second target is attempted.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiSecondTgtParams.SecondTgtBootLun (Read or Write)

Description	Specifies the second iSCSI target boot LUN.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiSecondTgtParams.SecondTgtChapId (Read or Write)

Description	Second Target CHAP ID (up to 128 characters in length). If only a single value of CHAP ID supported for all targets then it is stored here
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiSecondTgtParams.SecondTgtChapPwd (Read or Write)

Description	Second Target CHAP Secret (0 or 12 to 16 characters in length). If only a single value of CHAP Secret is supported then it is stored here
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiSecondTgtParams.SecondTgtIpAddress (Read or Write)

Description	Second iSCSI target IP address. Will be either IPv4 or IPv6 format depending on the value of the SecondTgtIpVer attribute
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiSecondTgtParams.SecondTgtIpVer (Read or Write)

Description	Setting displays and allows configuration of IP version used for second iSCSI target when iSCSIDualIPVersionSupport is available
Legal Values	• IPv4 • IPv6
Default Values	IPv4
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

NIC.IscsiSecondTgtParams.SecondTgtIscsiName (Read or Write)

Description	The iSCSI Qualified Name (IQN) of the second target
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.IscsiSecondTgtParams.SecondTgtTcpPort (Read or Write)

Description	TCP Port number of second iSCSI target
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICConfig

To configure the `NICConfig` properties, use the objects in this group.

NIC.NICConfig.BannerMessageTimeout (Read or Write)

Description	Timeout in seconds for banner display during POST
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICConfig.BootOptionROM (Read or Write)

Description	This attribute provides enable/disable functionality to the boot entry point (i.e. undi_init) of the legacy Option ROM of the port, effectively controlling the ability to legacy boot via PXE, iSCSI or FCoE. The Option ROM is still required to advertise itself to BIOS and to expose other entry points (such as CLP and UEFI) for configuration purposes if this control is set to disabled. This control must be prohibited from being set to Disabled if the Legacy Boot Protocol attribute is set to anything but None.
Legal Values	• Enabled • Disabled

Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICConfig.BootRetryCnt (Read or Write)

Description	Configure the number of retries in case of boot failure.
Legal Values	• No Retry • 1 Retry • 2 Retries • 3 Retries • 4 Retries • 5 Retries • 6 Retries • Indefinite Retries
Default Values	NoRetry
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICConfig.BootStrapType (Read or Write)

Description	Configure the boot strap mechanism used to boot to the OS.
Legal Values	• Auto Detect • BBS • Int 18h • Int 19h
Default Values	AutoDetect
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICConfig.FWBootProtocol (Read or Write)

Description	Selection of the boot protocol for the CNA port when the boot process is local to the controller.
Legal Values	• Legacy PXE • UEFI iSCSI HBA • UEFI FCoE • None
Default Values	varies
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICConfig.HideSetupPrompt (Read or Write)

Description	Enable/Disable the option ROM setup prompt (banner) during POST.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICConfig.LegacyBootProto (Read or Write)

Description	Selection of the boot protocol for the port to use in legacy BIOS (non-UEFI) boot mode. The default value of the setting varies by implementation and is defined in ENG0012856.
Legal Values	• PXE • iSCSI • FCoE • None • iSCSI Primary • iSCSI Secondary • iPXE without failover • iSCSI without failover
Default Values	varies
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICConfig.LnkSpeed (Read or Write)

Description	Configure the Link Speed to be used for boot operations.
Legal Values	• Auto Negotiated • 10 Mbps Half • 10 Mbps Full • 100 Mbps Half • 100 Mbps Full • 1 Gbps • 10 Gbps • 25 Gbps • 40 Gbps • 50 Gbps • 100 Gbps • 200 Gbps
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICConfig.NumberVFAdvertised (Read or Write)

Description	This value is the number of PCI Virtual Functions Advertised by the port (function) in PCI config space when SR-IOV is enabled in non-NPar mode.
Legal Values	• N/A
Default Values	0
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICConfig.VLanId (Read or Write)

Description	Specifies the VLAN tag to be used with the selected boot protocol.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICConfig.VLanMode (Read or Write)

Description	Enable/Disable VLAN tagging on the selected boot protocol. Note: The vendor will have to customize help text to define what boot protocols can use VLAN tagging.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICConfig.WakeOnLan (Read or Write)

Description	Enable/Disable Wake On LAN feature
Legal Values	• Enabled • Disabled
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICConfig.WakeOnLanLnkSpeed (Read or Write)

Description	Link speed for Wake On LAN feature

Legal Values	• Auto Negotiated • 10 Mbps Half • 10 Mbps Full • 100 Mbps Half • 100 Mbps Full • 1 Gbps • 10 Gbps • 25 Gbps • 40 Gbps • 50 Gbps • 100 Gbps • 200 Gbps
Default Values	AutoNeg
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICPartitioningConfig

To configure the `NICPartitioning` properties, use the objects in this group.

NIC.NICPartitioningConfig.ConfigureFormn (Read Only)

Description	HII form title for Partition Configuration form. There shall be one form for each partition. Replace n with the number of the partition (e.g., ConfigureForm1, ConfigureForm2).
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICPartitioningConfig.ConfigureFormRef (Read Only)

Description	Link for Partition Configuration form. Individual configuration forms are required for each partition. Replace n with the number of the partition.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICPartitioningConfig.FlowControlSetting (Read or Write)

Description	Representation and configuration field for Ethernet Flow Control. Note: This setting only controls the port's Flow Control behavior when in NPar modes of operation, but not when PFC is enabled; The OS driver retains control of Flow Control when NPar is not enabled.

Legal Values	• Auto • TX:Send Pause on RX Overflow • RX:Throttle TX on Pause Received • TX / RX Flow Control • None
Default Values	Auto
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICPartitioningConfig.GlobalBandwidthAllocation (Read Only)

Description	HII form title for Global Bandwidth Allocation across partitions. Note: These settings are intended for use in non-DCB environments and are subject to change via DCBX.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICPartitioningConfig.GlobalBandwidthAllocationRef (Read Only)

Description	HII link for the Global Bandwidth Allocation form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICPartitioningConfig.MgmtSVID (Read Only)

Description	The Management SVID is the Switch VLAN Identifier for the iDRAC service processor when the port is in shared mode.
Legal Values	None
Default Values	1000
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICPartitioningConfig.NicPartitioning (Read or Write)

Description	Representation and configuration of enablement of partitioning for the device. Note: This attribute is for current HII/UEFI drivers that implement the control ONLY. New HII implementations should only implement the Virtualization Mode attribute. Existing implementations should maintain support for legacy reasons.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICPartitioningConfig.NumberPCIFunctionsEnabled (Read Only)

Description	The number of PCI Physical Functions currently enabled on this port.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICPartitioningConfig.NumberPCIFunctionsSupported (Read Only)

Description	The number of PCI Physical Functions supported on this port. This value may change depending on the support and configuration of NParEP.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.NICPartitioningConfig.PartitionState (Read Only)

Description	Representation of the current enablement state of the partition. There will be an instance of this attribute for each partition. Replace n with the number of the partition.
Legal Values	• Enabled • Disabled
Default Values	Enabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

NIC.NICPartitioningConfig.RDMANICModeOnPartition (Read or Write)

Description	Enable/Disable the NIC + RDMA personality on the partition. This setting is for when operating in NPar mode only. Replace n with the number of the partition. Note: This personality type may be specified as the partition default if RDMA traffic can be supported irrespective of any other device setting.
Legal Values	• Enabled • Disabled
Default Values	Varies
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.PortLevelConfig

The following section provides information about the objects in `NIC.PortLevelConfig` the group.

NIC.PortLevelConfig.VFDistribution (Read or Write)

Description	The value is a string of numbers, each seperated by a colon that defines the distribution of VFs to PFs within the domain specified by VFAllocBasis. Each number represents the number of PVI Virtual Functions to be advertised in PCI config space by each partition (PF). The numbers must sum to an amount less than or equal to the NumberVFSupported attribute value. A value appears in the colon separated list for each Physical Function that can potentially be present within the allocation domain, independent of its enablement state. Values in the list from left to right apply to function numbers in the domain from least to greatest. Note1: The regex can only perform basic validation of the string format. Note2: Implementers should replace the "*" in the regex with a bound expression that accurately describes the expected string in the context of a given solution (e.g. where NumberVFSupported is 4, the "*" will be replaced with "{3}"). The vendor must provide the appropriate default string for the implementation.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigGroup

The objects in this group manage the vendor configuration settings.

NIC.VndrConfigPage.BlnkLeds (Read or Write)

Description	Blink LEDs for a duration of up to 15 seconds. Only valid for adapters with link LEDs.
Legal Values	None
Default Values	15
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

NIC.VndrConfigPage.BusDeviceFunction (Read Only)

Description	The value of this attribute depends on the state of the NParEP Mode setting. If NParEP Mode is Disabled, the value is the BIOS assigned PCIe Bus:Device:Function identifier. If NParEP Mode is Enabled, the value is the BIOS assigned PCIe Bus:Function identifier.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.ChipMdl (Read Only)

Description	This attribute consists of the concatenation of 2 different elements, a vendor-defined silicon marketing name and the silicon revision information as specified in PCI configuration space, separated by space. For example: R720 B0.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.DCBSettings (Read Only)

Description	HII form title for Data Center Bridging (DCB) Settings Form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.DCBSettingsRef (Read Only)

Description	Configuration page form reference for Data Center Bridge (DCB) Settings Form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.DCBXSupport (Read Only)

Description	Indicates whether Data Center Bridging eXchange Protocol (DCBX) is supported.

Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.DeviceLevelConfig (Read Only)

Description	HII form title for device configuration. Note: Modify the help text and form placement as appropriate to the controller architecture.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.DeviceLevelConfigurationRef (Read Only)

Description	Configuration form reference for the Device Level Configuration Form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.DeviceName (Read Only)

Description	Official product name of the device.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.EEEControl (Read or Write)

Description	Enables or Disables the Energy Efficient Ethernet feature on the port if supported by the device. If the scope of the control is not port level, then consultation with Dell is required. The default value of this attribute is specified in the EHRD for the implementation and will not be the same for all adapters. Note: Do not implement if EEE is not supported by the implementation (i.e., the EnergyEfficientEthernet attribute setting).
Legal Values	• Maximum Power Savings • Disabled

Default Values	varies
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.EnergyEfficientEthernet (Read Only)

Description	Indicates whether Energy Efficient Ethernet capability is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.FCoEBootSupport (Read Only)

Description	Indicates whether Fibre Channel over Ethernet Boot capability is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.FCOECapabilities (Read Only)

Description	HII form title for the FCoE Capabilities form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.FCoECapabilitiesRef (Read Only)

Description	Configuration page form reference for the FCoE Capabilities Form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.FCoEConfigRef (Read Only)

Description	Configuration form reference for port level FCoE configuration.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.FCoEConfiguration (Read Only)

Description	HII form title for the port level FCoE Configuration form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.FCoEOffloadMode (Read or Write)

Description	Enable/Disable the FCoE personality on the port. This setting is for when operating in non-NPar mode only.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.FCoEOffloadSupport (Read Only)

Description	Indicates whether FCoE is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.FeatureLicensingSupport (Read Only)

Description	Indicates whether the Dell Feature Licensing capability is supported.

Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.FIPMacAddr (Read Only)

Description	Permanent FIP-MAC address for FCoE assigned during manufacturing. If supported, the current address value should be readable at all times, irrespective of feature enablement.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.FlexAddressing (Read Only)

Description	Indicates whether the Dell FlexAddressing feature is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.FrmwImgMenu (Read Only)

Description	HII form title for Firmware Image Properties.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.FrmwImgMenuRef (Read Only)

Description	Configuration page form reference for the Firmware Image Properties Form.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise

Dependency	Not applicable

NIC.VndrConfigPage.HairpinMode (Read or Write)

Description	Traffic from one partition to another on separate physical ports is forwarded by the external switch. The e-switch external port can enable hairpin mode when NPar 2.0 is selected on the physical port. A configuration option would enable hairpin mode on a per partition basis. The server IOM will also support hairpin mode such that it can forward NIC partition to partition traffic on the same physical port. Hairpin mode will be disabled by default and is configurable when when NPar 2.0 capability is enabled.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.InfiniBand (Read Only)

Description	Indicates whether InfiniBand functionality is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.iSCSIBootSupport (Read Only)

Description	Indicates whether iSCSI Boot is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.iSCSIConfig (Read Only)

Description	HII form title for port level iSCSI configuration.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.iSCSIConfigRef (Read Only)

Description	Configuration form reference for port level iSCSI configuration.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.iSCSIDualIPVersionSupport (Read Only)

Description	Indicates support for simultaneous IPv4 and IPv6 configurations of the iSCSI initiator and iSCSI primary and secondary targets.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.IscsiMacAddr (Read Only)

Description	Permanent MAC address for iSCSI offload assigned during manufacturing. If supported, the current address value should be readable at all times, irrespective of feature enablement.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.iScsiOffloadMode (Read or Write)

Description	Enable/Disable the iSCSI offload personality on the port. This setting is for when operating in non-NPar mode only.
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.iSCSIOffloadSupport (Read Only)

Description	Indicates whether the iSCSI Offload capability is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.LinkStatus (Read Only)

Description	Physical link status of the network port as reported by the controller.
Legal Values	• Connected • Disconnected
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.LogicalPortEnable (Read or Write)

Description	Indicates whether the logical port is enabled or disabled. If disabled the port will not appear as a physical function in PCI Configuration space
Legal Values	• Enabled • Disabled
Default Values	Disabled
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.MacAddr (Read Only)

Description	The Permanent MAC address assigned during manufacturing.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.NetworkLinkType (Read or Write)

Description	Select the protocol type to be used on a port that supports multiple fabric types. NOTE: Implement ONLY if VPI Mode is supported

Legal Values	• Ethernet • InfiniBand
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.NICConfig (Read Only)

Description	The HII form title for NIC configuration.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.NICConfigRef (Read Only)

Description	The Configuration form reference for port level NIC configuration.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.NicMode (Read or Write)

Description	Enable/Disable the NIC personality on the port. This setting is for when operating in non-NPar mode only. Note: This personality type should be specified as the port default if RDMA is not supported or has dependencies on other device modes or settings.
Legal Values	• Enabled • Disabled
Default Values	Varies
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.NICPartitioningConfigRef (Read Only)

Description	HII link for the NIC Partitioning Configuration form.
Legal Values	None
Default Values	None

Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.NicPartitioningSupport (Read Only)

Description	Indicates whether the NIC Partitioning capability is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.NodeGUID (Read Only)

Description	The Permanent Node GUID assigned during manufacturing.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.NWManagementPassThrough (Read Only)

Description	Indicates whether the Network Management Pass Through capability is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.OmniPath (Read Only)

Description	Indicates whether Omni-Path functionality is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.OnChipThermalSensor (Read Only)

Description	Indicates whether an on-chip thermal sensor is available.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.OSBMCManagementPassThrough (Read Only)

Description	Indicates whether OS-BMC Management Pass Through capability is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.PCIDeviceID (Read Only)

Description	PCI Device ID reported by the controller when operating in non-NPar mode only. The value of the attribute is undefined for controllers operating in NPar mode that change their device IDs or support multiple PCI Device IDs at the partition level.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.PKey (Read or Write)

Description	PKey ID to be used by PXE boot in the InfiniBand environment
Legal Values	None
Default Values	0
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.PortGUID (Read Only)

Description	The Permanent Port GUID assigned during manufacturing.

Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.PXEBootSupport (Read Only)

Description	Indicates whether the PXE Boot capability is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.RDMANICModeOnPort (Read or Write)

Description	Enable/Disable the NIC + RDMA personality on the port. This setting is for when operating in non-NPar mode only. Note: This personality type may be specified as the port default if RDMA traffic can be supported irrespective of any other device mode or setting.
Legal Values	• Enabled • Disabled
Default Values	Varies
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.RemotePHY (Read Only)

Description	Indicates whether RemotePHY capability is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.RXFlowControl (Read Only)

Description	Indicates whether Receive (RX) Flow control capability is supported.
Legal Values	• Available

- Unavailable

Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.SNAPI (Read Only)

Description	Indicates the adapter supports SNAPI functionality by either special interfacing to the PCI slot connector or via cabling to another PCI slot.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.SNAPIState (Read Only)

Description	Indicates whether SNAPI functionality is enabled. Note: Implement only if SNAPI support is set to Available
Legal Values	• Enabled • Disabled
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.SwitchDepPartitioningSupport (Read Only)

Description	Indicates whether Switch Dependent Partitioning capability is supported. Note: Preliminary attribute definition only, based on the information available at the publication, subject to change.
Legal Values	• Available • Unavailable
Default Values	N/A
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.TOESupport (Read Only)

Description	Indicates whether TCP/IP Offload Engine capability is supported

Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.TXBandwidthControlMaximum (Read Only)

Description	Indicates whether Transmit(TX) Bandwidth Control Maximum capability is supported
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.TXBandwidthControlMinimum (Read Only)

Description	Indicates whether Transmit (TX) Bandwidth Control Minimum capability is supported
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.TXFlowControl (Read Only)

Description	Indicates whether Transmit (TX) Flow Control capability is supported
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.VirtFIPMacAddr (Read or Write)

Description	Programmatically assignable FIP-MAC address for FCoE. Virtual addresses written will also generate corresponding VWWNN and VWWPN addresses as defined in Y741D. The supported method of reverting to the permanent FIP-MAC address is by writing 0's as the virtual address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. If supported, the current address value should be readable at all times, irrespective of feature enablement.
Legal Values	None
Default Values	00:00:00:00:00:00
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.VirtIscsiMacAddr (Read or Write)

Description	Programmatically assignable MAC address for iSCSI offload. Programmatic write for support of I/O Identity feature. The supported method of reverting to the permanent MAC address is by writing 0's as the virtual address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. If supported, the current address value should be readable at all times, irrespective of feature enablement.
Legal Values	None
Default Values	00:00:00:00:00:00
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.VirtMacAddr (Read or Write)

Description	Programmatically assignable MAC address. Programmatic write for support of I/O Identity feature. The supported method of reverting to the permanent MAC address is by writing 0's to the virtual MAC. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. If supported, the current address value should be readable at all times, irrespective of feature enablement.
Legal Values	None
Default Values	00:00:00:00:00:00
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.VirtPortGUID (Read or Write)

Description	Programmatically assignable Port GUID. Virtual addresses written will also generate corresponding GUID as defined in Y741D. The supported method of reverting to the permanent GUID is by writing 0's as the virtual address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. If supported, the current address value should be readable at all times, irrespective of feature enablement.
Legal Values	None
Default Values	0000:0000:0000:0000
Write Privilege	None

License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.VirtWWN (Read or Write)

Description	Programmatically assignable Fibre Channel World Wide Node Name identifier for FCoE. Virtual addresses written will also be modified by subsequent writes to the VirtFIP-MAC addesss as defined in Y741D. The supported method of clearing this virtual address is by writing 0's as the address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's.
Legal Values	None
Default Values	00:00:00:00:00:00:00:00
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.VirtWWPN (Read or Write)

Description	Programmatically assignable Fibre Channel World Wide Port Name identifier for FCoE. Virtual addresses written will also be modified by subsequent writes to the VirtFIP-MAC addesss as defined in Y741D The supported method of clearing this virtual address is by writing 0's as the address. If the virtual address has not been set or if it has been cleared by the defined method, its value shall be returned as 0's. .
Legal Values	None
Default Values	00:00:00:00:00:00:00:00
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.VndrConfigPage (Read Only)

Description	Main configuration page form reference for the Vendor Main Configuration Page Form
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.VndrFormSet (Read Only)

Description	Title of HII form set for Vendor Form Set. The MAC address should be the current active MAC address on the port or first partition. In case a virtual address is assigned, it should be used. Otherwise, the permanent MAC address should be displayed.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.VPI (Read Only)

Description	Indicates whether Virtual Protocol Interconnect (VPI) functionality is supported.
Legal Values	• Available • Unavailable
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.WWN (Read Only)

Description	Fibre Channel World Wide Node Name identifier for FCoE
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

NIC.VndrConfigPage.WWPN (Read Only)

Description	Fibre Channel World Wide Port Name identifier for FCoE
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Express or iDRAC Enterprise
Dependency	Not applicable

7

Storage Attributes

Topics:

- Storage.Controller
- Storage.Enclosure
- Storage.PhysicalDisk
- Storage.VirtualDisk

Storage.Controller

The following sections provide information about the objects in this group Storage.Controller.

Storage.Controller.Background Initialization Rate (Read or Write)

Description	The Background Initialization (BGI) rate is the percentage of the system's resources dedicated to performing the background initialization of a virtual disk after it is created
Legal Values	None
Default Values	100
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Battery Learn Mode (Read or Write)

Description	Battery Learn Mode controls a RAID Controller's Battery Learn Cycle.
Legal Values	• Automatic • Warn only • Disabled
Default Values	None
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	A battery should be present on the controller.

Storage.Controller.Check Consistency Mode (Read or Write)

Description	Check Consistency feature is used to verify the accuracy of the redundant (parity) information.
Legal Values	• Normal • StopOnError
Default Values	Normal

Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Check Consistency Rate (Read or Write)

Description	The Check Consistency rate is the percentage of the system's resources dedicated to performing a check consistency on a redundant virtual disk.
Legal Values	None
Default Values	100
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Controller Boot Mode (Read or Write)

Description	This indicates the current BootMode setting of the Controller. Configurable via XML configuration feature only.
Legal Values	• User Mode • Continue Boot On Error • Headless Mode Continue On Error • Headless Safe Mode
Default Values	None
Write Privilege	None
License Required	
Dependency	None

Storage.Controller.Controller Encryption Mode (Read Only)

Description	This attribute represents encryption mode on the controller. It could be used to set the encryption mode to Local Key Management or Dell Key Management on the controller through XML configuration feature.Configurable via XML configuration feature only.
Legal Values	• None • Local Key Management • Dell Key Management
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	If set to 'Local Key Management' you must set KeyID and NewControllerKey.

Storage.Controller.Controller Rekey (Read or Write)

Description	This pseudo attribute represents whether a rekey operation needs to be performed on the RAID controller.Configurable via XML configuration feature only.
Legal Values	• True • False
Default Values	FALSE
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Controller Reset Configuration (Read or Write)

Description	This pseudo attribute represents whether a reset config operation needs to be performed on the RAID controller.Reset Config operation deletes all the virtual disks that exists on the RAID controller. Configurable via XML configuration feature only.
Legal Values	• True • False
Default Values	FALSE
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Copyback Mode (Read or Write)

Description	This attribute represents the mode of restoring configuration of a virtual disk when a failed physical disk is replaced in an array.
Legal Values	• On • On with SMART • Off
Default Values	On
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Current Controller Mode (Read Only)

Description	This indicates controllers current personaility mode , which could be RAID or Non-RAID. PERC9 supports RAID and HBA.Starting PERC 10, modes supported are RAID and Enhanced HBA
Legal Values	• RAID • HBA • Enhanced HBA
Default Values	None
Write Privilege	None

License Required	
Dependency	Controller needs to support.

Storage.Controller.Enhanced Import Foreign Configuration (Read or Write)

Description	This indicates the current EnhancedAutoImportForeignConfig setting of the controller. Configurable via XML configuration feature only.
Legal Values	• Disabled • Enabled
Default Values	None
Write Privilege	None
License Required	
Dependency	None

Storage.Controller.Foreign Configuration (Read or Write)

Description	This pseudo attribute represents foreign configuration operation to be performed on the RAID controller via XML configuration feature.Configurable via XML configuration feature only.
Legal Values	• Ignore • Import • Clear
Default Values	Ignore
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Key identifier (Read Only)

Description	This attribute represents the controller key identifier for Local Key Management or Dell Key Management controller encryption modes. Configurable via XML configuration feature only.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	Applicable only if EncryptionMode is 'Local Key Management' and NewControllerKey is set to any valid value.

Storage.Controller.Load Balanced Mode (Read or Write)

Description	This attribute reprsents the ability to automatically use both controller ports connected to the same enclosure to route I/O requests.
Legal Values	• Automatic • Disabled
Default Values	Automatic

Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Maximum Capable Speed (Read Only)

Description	This attribute represents the maximum link speed supported by the controller.
Legal Values	• 1_5_GBS • 3_GBS • 6_GBS • 12_GBS
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Maximum Physical Disks in Span (Read Only)

Description	This attribute represents the maximum number of Physical Disks in a single Span, as supported by the controller.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Maximum Spans in Virtual Disk (Read Only)

Description	This attribute represents the maximum number of spans in a Virtual Disk, as supported by the controller.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Maximum Supported Virtual Disks (Read Only)

Description	This attribute represents the maximum number of virtual disks supported by the controller.
Legal Values	None
Default Values	None

Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.New Controller Key (Read or Write)

Description	This attribute represents the controller passphrase for Local Key Management encryption mode. This is used during a ReKey operation to specify the new controller key. Configurable via XML configuration feature only.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	Applicable only if EncryptionMode is 'Local Key Management' and KeyID is set to any valid value.

Storage.Controller.Old Controller Key (Read or Write)

Description	This attribute represents the controller passphrase for Local Key Management encryption mode. This is used during a ReKey operation to specify the old controller key. Configurable via XML configuration feature only.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	Applicable only if 'RAIDrekey' is set to True

Storage.Controller.Patrol Read Iterations (Read Only)

Description	
Legal Values	None
Default Values	None
Write Privilege	None
License Required	
Dependency	None

Storage.Controller.Patrol Read Mode (Read or Write)

Description	Patrol Read is a feature for identifying disk errors in order to avoid disk failures and data loss or corruption. The Patrol Read only runs on disks that are being used in a virtual disk or that are hot spares.
Legal Values	• Automatic • Manual • Disabled
Default Values	Automatic
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Patrol Read on Unconfigured area (Read or Write)

Description	Patrol Read is Performed on area of physical disk not configured for use.
Legal Values	• Disabled • Enabled
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Patrol Read Rate (Read Only)

Description	The Patrol Read Rate is the percentage of the system's resources dedicated to perform Patrol Read.
Legal Values	None
Default Values	30
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Rebuild Rate (Read or Write)

Description	The Rebuild Rate is the percentage of the system's resources dedicated to rebuilding a failed disk when a rebuild is necessary.
Legal Values	None
Default Values	100
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Reconstruction Rate (Read or Write)

Description	The Reconstruct Rate is the percentage of the system's resources dedicated to reconstructing a disk group after adding a physical disk or changing the RAID level of a virtual disk residing on the disk group
Legal Values	None
Default Values	100
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Remove Controller key (Read or Write)

Description	This pseudo attribute represents whether a rekey operation needs to be performed on the RAID controller.Configurable via XML configuration feature only.

Legal Values	• True • False
Default Values	FALSE
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Requested Controller Mode (Read or Write)

Description	This indicates controllers requested personaility mode and can be RAID or Non-RAID. PERC 9 supports RAID and HBA. Starting PERC 10, modes supported are RAID and Enhanced HBA. Supported with SET command and not SCP
Legal Values	• RAID • HBA • Enhanced HBA
Default Values	None
Write Privilege	None
License Required	
Dependency	Controller needs to support.

Storage.Controller.Spin Down Idle Time (Read Only)

Description	Spindown idle time is the amount of time in seconds an uncofigured or hotspare can be idle before being spinned down by the controller.
Legal Values	None
Default Values	30
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Supported Disk Protocols (Read Only)

Description	This attribute provides a list of Disk Protocols supported by the controller.
Legal Values	• SAS • SATA
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Controller.Supported Encryption types (Read Only)

Description	
Legal Values	None
Default Values	None
Write Privilege	None
License Required	
Dependency	None

Storage.Controller.Supported Initialization types (Read Only)

Description	
Legal Values	None
Default Values	None
Write Privilege	None
License Required	
Dependency	None

Storage.Controller.Supported RAID Levels (Read Only)

Description	This attribute provides a list of RAID levels supported by the controller.
Legal Values	• RAID-0 • RAID-1 • RAID-5 • RAID-10 • RAID-50 • RAID-60
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Enclosure

This group contains the attributes that provides details about Storage.Controller

Storage.Enclosure.Asset Tag (Read Only)

Description	Displays the Asset Tag information for the enclosure.
Legal Values	None
Default Values	None
Write Privilege	None

License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Enclosure.Backplane Type (Read Only)

Description	This indicates enclosures type.
Legal Values	• Shared • Not Shared
Default Values	None
Write Privilege	None
License Required	
Dependency	Backplane needs to support it.

Storage.Enclosure.Block Size In Bytes (Read Only)

Description	
Legal Values	None
Default Values	None
Write Privilege	None
License Required	
Dependency	None

Storage.Enclosure.Effective SAS Address (Read Only)

Description	This attribute represents the effective SAS Address of an enclosure.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.Enclosure.Enclosure Current Configuration Mode (Read Only)

Description	This indicates enclosures current configuration mode setting
Legal Values	• Unified Mode • Split Mode
Default Values	None
Write Privilege	None
License Required	
Dependency	Backplane needs to support it.

Storage.Enclosure.Enclousre Requested Configuration Mode (Read or Write)

Description	This indicates enclosures requested configuration mode setting.
Legal Values	• Unified Mode • Split Mode • None
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	Backplane needs to support it.

Storage.PhysicalDisk

This group contains the attributes that provides details about Storage.PhysicalDisk

Storage.PhysicalDisk.Bus Protocol (Read Only)

Description	
Legal Values	None
Default Values	None
Write Privilege	None
License Required	
Dependency	None

Storage.PhysicalDisk.Full Initiallzation (Read or Write)

Description	Performs full initialization on the selected physical device. This operation deletes all data on the device.
Legal Values	• True • False
Default Values	FALSE
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.PhysicalDisk.Hotspare Status (Read Only)

Description	On RAID controllers, a hot spare is a backup for a disk that fails. The attribute indicates whether a physical disk is Hot Spare and/or the type of hot spare.Configurable via XML configuration only.
Legal Values	• No • Dedicated • Global
Default Values	No
Write Privilege	None

License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.PhysicalDisk.Media Type (Read Only)

Description	
Legal Values	None
Default Values	None
Write Privilege	None
License Required	
Dependency	None

Storage.PhysicalDisk.Negotiated Speed (Read Only)

Description	Negotiated Speed shows the speed of data transfer that the disk negotiated while spinning up and upon initial communication with the controller. This speed is dependent on the speed of the disk, the capable speed of the controller, the current speed of the controller on that connector, and the speed of the EMM (Enclosure Management Module) on the enclosure.
Legal Values	• 1_5_GBS • 3_GBS • 6_GBS • 12_GBS
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.PhysicalDisk.Nominal Medium Rotation Rate (Read Only)

Description	This attribute represents the nominal medium rotation speed of a physical disk.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.PhysicalDisk.Physical Disk State (Read Only)

Description	Physical Disk State shows the state of Physical disk that is part of a Virtual Disk.Configurable via XML configuration feature only.
Legal Values	• Unknown • Ready • Online • Foreign

- Blocked
- Failed
- Non-RAID
- Missing

Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.PhysicalDisk.Software RAID Mode (Read or Write)

Description	
Legal Values	• Windows • Linux
Default Values	Windows
Write Privilege	None
License Required	
Dependency	None

Storage.PhysicalDisk.T10PI capable (Read Only)

Description	
Legal Values	None
Default Values	None
Write Privilege	None
License Required	
Dependency	None

Storage.VirtualDisk

This group contains the attributes that provides details about Storage.VirtualDisk

Storage.VirtualDisk.Action (Read or Write)

Description	This pseudo attribute represents RAID action to be performed on the virtual disk. It is used to specify Delete, Create , CreateAuto or Update virtual disk operations. Configurable via XML configuration feature only.
Legal Values	• Create • CreateAuto • Delete • Update
Default Values	Update
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise

Dependency	None

Storage.VirtualDisk.Cachecade State (Read Only)

Description	This attribute represents the cachecade state of the virtual disk. It can be modified to create a cachecaded virtual disk using XML configuration feature. Configurable via XML configuration feature only.
Legal Values	• Cachecade Virtual Disk • Not a Cachecade Virtual Disk
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	Applicable only if RAIDaction is 'Create'

Storage.VirtualDisk.Dedicated Spare (Read or Write)

Description	This pseudo attribute represents the dedicated spare to be assigned to a virtual disk. It could be set to physical disk FQDD to be assigned as a dedicated spare to the virtual disk. If a Spare is intended to be assigned when RAIDaction is set as CreateAuto, this attribute value should be set to AutoSelect. Configurable via XML configuration feature only.
Legal Values	• AutoSelect
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.VirtualDisk.Disk Cache Policy (Read or Write)

Description	Set the physical disk caching policy of all members of a Virtual Disk by enabling the Disk Cache Policy. When this feature is enabled, the physical disk writes data to the physical disk cache before writing it to the physical disk. Because it is faster to write data to the cache than to a disk, enabling this feature can improve system performance.
Legal Values	• Default • Enabled • Disabled
Default Values	Default
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.VirtualDisk.Initialization Operation (Read or Write)

Description	This pseudo attribute represents initialization configuration operation to be performed on the virtual disk via XML configuration feature. Configurable via XML configuration feature only.
Legal Values	• None

- Fast

Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	Applicable only if RAIDaction is 'Update' or 'Create'

Storage.VirtualDisk.Lock Status (Read Only)

Description	This attribute represents security status of the virtual disk. It is used to secure a virtual disk using XML configuration feature. Configurable via XML configuration feature only.
Legal Values	• Unlocked • Locked
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	Applicable only if EncryptionMode is 'Local Key Mananegment' or 'Dell Key Management' and 'KeyID' is set to any valid value.

Storage.VirtualDisk.Name (Read Only)

Description	Diplays the name associated with a Virtual Disk.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.VirtualDisk.Physical Disk ID (Read or Write)

Description	This is a pseudo attribute for XML configuration feature. It is used for specifying physical disk FQDD for creating a virtual disk. Configurable via XML configuration feature only.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	Applicable only if RAIDaction is 'Create'

Storage.VirtualDisk.RAID Level (Read Only)

Description	This indicates the type of RAID level on the virtual disk. Configurable via XML configuration feature only.
Legal Values	• RAID 0 • RAID 1 • RAID 5 • RAID 6

- RAID 10
- RAID 50
- RAID 60

Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	Applicable only if RAIDaction is 'Create'

Storage.VirtualDisk.Read Policy (Read or Write)

Description	The read policies indicate whether or not the controller should read sequential sectors of the virtual disk when seeking data.
Legal Values	• NoReadAhead • ReadAhead • AdaptiveReadAhead
Default Values	ReadAhead
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None

Storage.VirtualDisk.Size (Read Only)

Description	This indicates the size in bytes of the virtual disk. When creating a virtual disk, size of 0 indicates using full size of the physical disks for the specified RAIDTypes.Configurable via XML configuration feature only.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	Applicable only if RAIDaction is 'Create'

Storage.VirtualDisk.Span Depth (Read Only)

Description	This indicates number of spans in the virtual disk.Configurable via XML configuration feature only.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	Applicable only if RAIDaction is 'Create'

Storage.VirtualDisk.Span Length (Read Only)

Description	This indicates the number of physical disks per span on a virtual disk.Configurable via XML configuration feature only.
Legal Values	None

Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	Applicable only if RAIDaction is 'Create'

Storage.VirtualDisk.Stripe Size (Read Only)

Description	This indicates the stripe size of the virtual disk. Configurable via XML configuration feature only.
Legal Values	None
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	Applicable only if RAIDaction is 'Create'

Storage.VirtualDisk.T10PIStatus (Read or Write)

Description	This indicates virtual disks T10PIStatus.
Legal Values	• Enabled • Disabled
Default Values	None
Write Privilege	None
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	Controller needs to support.

Storage.VirtualDisk.Write Policy (Read or Write)

Description	The write policies specify whether the controller sends a write-request completion signal as soon as the data is in the cache or after it has been written to disk.
Legal Values	• WriteThrough • WriteBack • WriteBackForce
Default Values	WriteBack
Write Privilege	Server Configuration
License Required	iDRAC Basic, iDRAC Express, or iDRAC Enterprise
Dependency	None