

Philips
Potato masher paddle



CP9722

to replace your current masher paddle

With the masher accessory for the Philips hand blender you can mash potatoes silky smooth. Also other vegetables can be mashed or pureed.

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

PHILIPS

Specifications

Replaceable part

- Fits product types:: HR1640/0x, HR1641/0x, HR1642/0x, HR1643/0x, HR1644/0x, HR1645/0x,

HR1646/0x, HR1647/0x, HR1670/0x, HR1671/0x, HR1672/0x, HR1673/0x, HR1674/0x, HR1675/0x, HR1676/0x, HR1677/0x

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.



Issue date 2023-01-19

Version: 6.6.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com