

PHILIPS

Potato masher paddle

CP9722



to replace your current masher paddle

With the masher accessory for the Philips hand blender you can mash potatoes silky smooth. Also other vegetables can be mashed or pureed.

Ease of using Philips spare parts

- Easy renew your product with original Philips parts

Highlights

Easy renew of product parts

From time to time your product needs a facelift but it was never so easy like with Philips consumer replacement parts to renew your product. This all with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types :: HR1640/0x, HR1641/0x, HR1642/0x, HR1643/0x, HR1644/0x, HR1645/0x, HR1646/0x, HR1647/0x, HR1670/0x, HR1671/0x, HR1672/0x, HR1673/0x, HR1674/0x, HR1675/0x, HR1676/0x, HR1677/0x

