

# Quick start guide





Step A *Connect*

Step B *Setup*





Step C *Enjoy*

## What's in the Box?

You should find these items upon opening the box.



Pull out the plastic protective sheet before use.



# Step A *Connect*



1 Connect the speaker cables.

2 Connect the FM and AM antennas.

3 Connect the control cable.

4 Connect the docking cradle.

5 Connect the power cord of the system.




## Step B Setup

### Setting the clock

#### IMPORTANT!

– To set clock in the Eco Power mode, press and hold ECO POWER/STANDBY-ON  on the set for 3 seconds or more to switch to normal standby mode first before proceeding with the procedures below.


- 1 In standby mode, press and hold **CLOCK** on the remote.
- 2 When the hour digits flash, turn **VOLUME-/+** on the system or press **VOL+/-** on the remote to set the hours.
- 3 Press **CLOCK** again and the minute digits flash. Then turn **VOLUME-/+** on the system or press **VOL+/-** on the remote to set the minutes.
- 4 Press **CLOCK** again to confirm the time setting.



## Step C Enjoy

### Playing a disc

- 1 Press **SOURCE** on the top of the system to select DISC or press **CD** on the remote.
- 2 Press  to open the CD compartment.
- 3 Insert a disc with the printed side facing up. Press  again to close the compartment.
- 4 Playback will start automatically.
- 5 To stop playback, press .



## Playing a USB mass storage device

With the Hi-Fi system, you can use USB flash memory (USB 2.0 or USB1.1), USB flash players (USB 2.0 or USB1.1), memory cards (requires an additional card reader to work with this Hi-Fi system).

1

Insert the USB device's USB plug into the socket  on the set.

2

Press **SOURCE** once or more (or **USB** on the remote control) to select **USB**.

3

Play the USB's audio files as you do with the albums/tracks on a CD.

## Playing Apple iPod using MCM704D

1

Select the correct dock adaptor, as indicated on each adaptor, then fit it in the dock.

2

Correctly place the compatible iPod player into the dock.

3

Press **SOURCE** on the system repeatedly or **iPod** on the remote control to select the iPod source.

4

Power on your iPod player.

5

Select and play your favourite songs stored in the iPod player.

### Tip

*Detailed playback features and additional functions are described in the accompany owner's manual.*

