

# PHILIPS

Dust bag holder

Performer

Grey

FC6041



## Keeps the dust bag in the correct position

Find matching products on the specifications tab

Is your current dust bag holder lost or broken? This part of your Philips vacuum cleaner, which is necessary for using it, can easily be replaced.

### **Ease of using Philips spare parts**

- Easily renew your product with original Philips parts

## Highlights

### Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

## Specifications

### Replaceable part

**Fits product types:** FC9150/01, FC9150/02, FC9150/09, FC9160/01, FC9170/01, FC9170/02, FC9170/03, FC9170/09, FC9171/01, FC9172/01, FC9172/02, FC9172/03, FC9173/01, FC9174/01, FC9175/01, FC9176/01, HR8903/12

