

| | |
|---|------------|
| Brand | Candy |
| Type of cooktop | Elektrisch |
| Number of cooking zones and or areas | 4 |
| Number of gas burners | 0 |
| Energy efficiency per gas burner, EEgas burner | |
| Heating technology per electric cooking zones and cooking areas | |
| Energy efficiency for the gas hob, EEgas hob | |
| Min pot detection | - |
| For non-circular cooking zones/areas: length and width of useful surface area, L/W (cm)* | |
| Energy consumption per cooking zone or area calculated per kg, ECelectric cooking (Wh/kg) | |
| Energy consumption for the hob calculated per kg, ECelectric hob (Wh/kg) | |