

Wing - Freestanding

Assembly Instructions


Tools Required:

- All tools provided

Sheet Code: BP-IM-072_REV1

Release Date: 24/05/2021

Copyright 2016 Spotspot Ltd. (T/A Bouncepad) all rights reserved. Confidential, no part of this publication may be reproduced or transmitted in any form without the written permission of the copyright holder.



8x M4x8mm
Buttonhead
screw

10x M6x10mm
Buttonhead
screw


*fixings to attach the stand to the ground are not provided.




In the Box




Fixings List




1 Locate the Mounting Arm onto the Freestanding Base.




2 Secure the Mounting Arm to the Mount Bracket, with 5x M6x10mm screws.




3 Remove the Mounting Arm Access Panel. Safely store this aside for use later.



4 Remove the Faceplate from the Case Back. Store this aside.




5 Locate and secure the Case Back to the Mounting Arm, with 4x M6x10mm screws. Ensure good Case alignment.




6 Complete the separate tablet setup document - specific to your tablet, device orientation & locking method.

**The Case is configured to your order.
If requiring a different tablet
configuration, please contact us.*



7 Install the tablet and the tablet power cable.




8 Locate the Faceplate onto the Case Back




**If requiring an upgrade to a
keyed Case, please contact us.*


9 Secure the Faceplate shut with your chosen locking method.



10 Connect the tablet cable to a power source.




11 Locate and secure the Access Panel to the Mounting Arm.



**Kensington security
cable not provided.*

12 For added security, install a Kensington security cable.



13 Installation is now complete.