

Wing - Slim

Assembly Instructions


Tools Required:

- All tools provided

Sheet Code: BP-IM-071_REV0

Release Date: 24/05/2021

Copyright 2016 Spotspot Ltd. (T/A Bouncepad) all rights reserved. Confidential, no part of this publication may be reproduced or transmitted in any form without the written permission of the copyright holder.



In the Box




Fixings List

2x M4x10mm
Buttonhead
screw


10x M6x10mm
Buttonhead
screw

**fixings to attach the stand to the ground are not provided.*




1

Position the Mount Bracket on the ground where the stand is to be located.




2

Mark your mounting surface, then drill (as appropriate to your chosen fixing method).




3

Secure the Mount Bracket to your mounting surface, with your chosen fixing method.




4

Remove the Access Panel from the Mounting Arm. Store all parts safely aside for use later.




5

If using a hard-wired power supply, feed the cable into the Mounting Arm.




6


Locate the Mounting Arm onto the Mount Bracket as shown.




7 Secure the Mounting Arm to the Mount Bracket, with 5x M6x10mm screws.




8 Unlock and remove the Faceplate from the Case Back. Store this aside.



9 Locate and secure the Case Back to the Mounting Arm, with 4x M6x10mm screws. Ensure good Case alignment.




10 Install the tablet and the tablet power cable.




11 Connect the tablet to a power source.




12 Locate and lock the Faceplate onto the Case Back. For additional security, install 2x M4x10mm screws to retain the Faceplate.



13 Locate and secure the Access Panel to the Mounting Arm.



14 For additional security, the stand has multiple Kensington Security Slots. Where required, install the cable.



15 Installation is now complete.