

## Wing - Freestanding

### Assembly Instructions


#### Tools Required:

- All tools provided

Sheet Code: BP-IM-072\_REV0

Release Date: 24/05/2021

Copyright 2016 Spotspot Ltd. (T/A Bouncepad) all rights reserved. Confidential, no part of this publication may be reproduced or transmitted in any form without the written permission of the copyright holder.



2x M4x10mm  
Buttonhead  
screw



10x M6x10mm  
Buttonhead  
screw




*\*fixings to attach the stand to the ground are not provided.*




In the Box




Fixings  
List




**1** Locate the Mounting Arm onto the Freestanding Base.




**2** Secure the Mounting Arm to the Mount Bracket, with 5x M6x10mm screws.




**3** Remove the Mounting Arm Access Panel. Safely store this aside for use later.



**4** Unlock and remove the Faceplate from the Case Back. Store this aside.




**5** Locate and secure the Case Back to the Mounting Arm, with 4x M6x10mm screws. Ensure good Case alignment.




**6** Install the tablet and the tablet power cable.


*\*The Case is configured to your order. If requiring a different tablet configuration, please contact us.*




**7** Locate and lock the Faceplate onto the Case Back. For additional security, install 2x M4x10mm screws to retain the Faceplate.




**8** Connect the tablet cable to a power source.



**9** Locate and secure the Access Panel to the Mounting Arm.



**10** For additional security, the stand has multiple Kensington Security Slots. Where required, install the cable.



**11** Installation is now complete.