


User Manual TTSDS101

Product Description



- ① USB plug, connect to power
- ② 3.5mm AUX input plug
- ③ Power button, Volume control, Change AUX/Bluetooth input
- ④ LED light
- ⑤ Host speaker top is LED light change Switch
Touch change LED light colors

1. Connect the USB power "①" and connect the 3.5mm audio plug "②"
2. Open the music.
3. Open the speaker [Long press "③" open/shut down speaker].
4. In AUX mode, the music come from the 3.5mm audio cable.
Rotate to the right "③" make volume up;
Rotate to the left "③" make volume down.
5. Short press "③" switch to Bluetooth mode, you can make a pair with "TTSDS101" by phone.

Rotate to the right "③" make volume up;
Rotate to the Left "③" make volume down.
6. Short touch LED Switch "⑤", open/shut down LED light and you can get the different lighting effects "④"

Adjust the volume by the plus and minus signs

When the sound is loudest, the color of the light is monochromatic purple. The purple color will run up from the bottom as the volume increases, until the light bar is entirely purple, indicating that the sound is the loudest. Monochromatic cyan is the minimum sound or when there is no sound. The cyan color will run from top to bottom with the decreasing of the sound, until the light bar is completely cyan, it means that the sound is the most.


Note: If the audio cable is connected to the computer or the mobile phone has current noise, please turn the audio cable head to adjust until there is no current noise.

www.itekvevo.com



Manuale Utente TTSDS101

Numeri collegati a disegno



- ① Presa USB, collegare l'alimentatore
- ② Ingresso cavo AUX
- ③ Pulsante di accensione; regolazione del volume, cambiare da modalità AUX a modalità Bluetooth
- ④ Luce a LED
- ⑤ La parte superiore dell'altoparlante host è l'interruttore di modifica della luce a LED che cambia i colori della luce a LED

1. Collegare l'alimentatore USB "①" e collegare il cavo audio "②" da 3,5 mm
2. Accendere la musica
3. Accendere l'altoparlante [premere a lungo "③"]
4. In modalità AUX, la musica proviene dal cavo audio da 3,5 mm.
Ruotare a destra "③" per alzare il volume.
Ruotare a sinistra "③" per abbassare il volume.

5. Premere rapidamente "③" per passare alla modalità Bluetooth, è possibile accoppiare con "TTSDS101" attraverso il telefono.
Ruotare a destra "③" per alzare il volume.
Ruotare a sinistra "③" per abbassare il volume.
6. Premere rapidamente "⑤", ovvero l'interruttore di modifica della luce a LED, per avere i diversi effetti luminosi "④".

Regolare il volume mediante i segni più e meno

Quando il suono è al massimo il colore della luce è porpora monochromatica. Il color porpora risale dal basso man mano che il volume aumenta, fino a che la barra luminosa non diventa interamente porpora, indicando che il suono è al massimo della sua potenza.

Il ciano monochromatico rappresenta il suono minimo o quando non vi è alcun suono. Il colore ciano scende dall'alto verso il basso man mano che il suono si abbassa, fino a che la barra luminosa non diventa completamente color ciano, il che significa che il suono si interrompe.

N.B.: Se il cavo audio è collegato al computer o il telefono cellulare presenta un rumore di fondo, ruotare l'estremità del cavo audio per regolare fino a quando non si sentirà più alcun rumore.

www.itekvevo.com