Dell USB-C Monitor P2423DE/P2723DE Dell Display Manager User's Guide



Model :P2423DE/P2723DE Regulatory model : P2423DEc/P2723DEc



NOTE: A NOTE indicates important information that helps you make better use of your computer.

- \wedge CAUTION: A CAUTION indicates potential damage to hardware or loss of data if instructions are not followed.
- MARNING: A WARNING indicates a potential for property damage, personal injury, or death.

Copyright @ 2022 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

2022 - 02

Contents

Overview 4
Selecting Quick Settings options5
Setting basic display options7
Assigning preset modes to applications9
Organizing windows with Easy Arrange10
Managing Multiple Video Inputs13
Restoring Application Positions14
Attach DDM to active window (Windows 10 and Windows 11 only)16
Setting energy conservation options17
Other Shortcut Keys18
Troubleshooting

Overview

Dell Display Manager is an application that allows users to configure their supported Dell monitor settings such as brightness, contrast, and preset modes. After its installation, Dell Display Manager is accessible from the notification tray. Information about monitors connected to the system is available when the mouse is hovered over the notification tray icon.



NOTE: Dell Display Manager uses Display Data Channel Command Interface (DDC/CI) channel to communicate with your monitor. Ensure that DDC/CI is enabled in the menu as follows:

D \$34	2X Monitor			
Ó.	Brightness/Contrast	Display Info		
Ð	Input Source			
G	Color		on	
Ţ	Display			
	Menu			
습	Personalize	Self-Diagnostic		
			<	Exit



Selecting Quick Settings options

Clicking Dell Display Manager's notification tray opens the **Quick Setings** window.

If more than one supported Dell monitor is connected to the system, a specific target monitor can be selected from the Display drop-down list.

In the **Quick Settings** window, you can also change the following:

- * Resolution
- * Auto Mode or Manual Mode the screen appearance
- * Brightness and contrast levels
- * Easy Arrange window layouts for the monitor

Display	Manager	x
Display:	Dell P2X23DE	
Resolution:	2560×1440	Change
 Auto Mode Manual Mode 	Standard	Configure ~
Brightness:		75%
Contrast:		75%
Recently used:		More options
	Open Dell Display Manager	

In the **Quick Settings** window, you can also click **Open Dell Display Manager** for more advanced settings.

Dell



Feature	Function	Description
Quick DDM Access	Quick key to call up DDM UI.	Ctrl+Shift+D
	Control individual monitor in multi- monitor setup Move DDM UI to controlled. Press Ctrl+Shift+ UI under the mou	From dropdown box to select monitor, selected monitor has Dell logo shown.
		Move DDM UI to the monitor to be controlled.
		Press Ctrl+Shift+D to bring up the mini UI under the mouse pointer.

Setting basic display options

You can select **Manual Mode** to manually select a preset mode or select **Auto Mode** that applies a preset mode based on the active application. An on-screen message displays the current preset mode whenever it changes. The selected monitor's brightness and contrast levels can also be directly adjusted from the **Basic** tab.

Display I	Manager		Del	I P2X23DE ?
Basic	Auto Mode	Easy Arrange	Input Manager	Options
Resolution:	2560×1440			Change
 Auto Mode Use preset mod 	de assignments for activ	e applications		Configure
Manual Mode Choose a prese	et mode:		Standard	~
Brightness:	1 1 1 1 1 1	75	%	
Contrast:		75	%	

NOTE: When multiple Dell monitors are connected, select "Enable display matrix control" to apply brightness, contrast, and color presets controls to all monitors.

DEL

Display	Manager			Dell P2	2X23DE 👻 ?	x
Basic	Auto Mode	Easy Arrange	Inp	ut Manager	Options	
Resolution:	2560×1440				Change	
O Auto Mode Use preset mo	de assignments for active	e applications			Configure	
Manual Mode Choose a pres	et mode:		[Standard	~	
Brightness:			75%			
Contrast:	1 1 1 1		75%			
Enable display	matrix control					

(D&LL

Assigning preset modes to applications

The **Auto Mode** tab enables you to associate a specific Preset Mode with a specific application, and apply it automatically. When **Auto Mode** is enabled, Dell Display Manager will automatically switch to the corresponding **Preset Mode** whenever the associated application is activated. The **Preset Mode** assigned to a particular application may be the same on each connected monitor, or it can vary from one monitor to the next.

Dell Display Manager is pre-configured for many popular applications. To add a new application to the assignment list, simply drag the application from the desktop, Windows Start Menu or elsewhere, and drop it onto the current list.

NOTE: Preset Mode assignments for batch files, scripts, loaders, and non-executable files such as zip archives or packed files, are not supported.

You can also configure the Game preset mode to be used whenever a Direct3D application runs in full-screen mode. To prevent an application from using mode, assign a different preset mode to it.

Basic Auto Mode	Easy Arrange	Input Manage	er Options
ssign a preset mode to a specific a	pplication. To add an app	lication, drag it to the li	st:
Application	Preset Mod	le	í
(Default for desktop apps)	Standard	~	
😵 (Default for fullscreen Direct3	D) Game	~	
(Default for universal Window)	warm Warm	~	
Adobe Reader 9.2	Standard	~	
🥖 Internet Explorer	Warm	~	
📋 Microsoft Edge	Warm	~	

Organizing windows with Easy Arrange

On supported Dell monitors, the **Easy Arrange** tab enables you to easily arrange the open windows in one of the predefined layouts by dragging them in the zones. Press ">" or use Page Up/Page Down key to find more layouts. To create a custom layout, arrange the open windows and then click **Save**.

To get started with **Easy Arrange**, choose a target monitor and select one of the predefined layouts. The regions for that layout are displayed momentarily on the monitor. Next, drag an open window across the monitor. While the window is being dragged, the current window layout is displayed and an active region gets highlighted as the window passes over it. At any time, drop the window into the active region to place the window in that region.



To create a custom window layout, size and position the windows on the desktop and then click the Save link in **Easy Arrange**. The size and position of the windows is saved as a custom layout and the custom layout icon is created.

NOTE: This option does not save or remember the applications that are open. Only the size and position of the windows is saved.



Easy Arrange	\times
No desktop windows were found. The custom layout has been deleted.	
OK	

To use the custom layout, select the custom layout icon. To delete the currently saved custom layout, close all windows on the desktop and then click the Save link in **Easy Arrange**.

Display	Manager		Del	I P2X23DE ?	x
Basic	Auto Mode	Easy Arrange	Input Manager	Options	
Select a predefine position and resize	ed or custom window layout fo e automatically:	r this monitor.Open	n windows dragged into	each zone will	
×					
					>
To create a custor Overlap trans Hold down the	m layout, arrange your windo parent borders e SHIFT key to enable zone po	ws and then dick Sa sitioning	ve		

DELI

There are other advanced ways for the usage of Easy Arrange. Please refer to table below.

Feature	Function	Description			
Enhanced Easy Arrange	Custom layouts	Save and name 5 customized Easy Arrange patterns.			
		Configure x*y patterns.			
	6 MRU (most- recently-used) layouts	Press Ctrl+Shift+Home to cycle among the last 6 MRU layouts.			
	On the fly partition resizing	Hold down Ctrl while resizing current Easy Arrange layout to adjust the size and numbers of cells in a layout.			
		Newly formed Easy Arrange pattern is saved into the Easy Arrange icon position.			
		Hold down Ctrl while clicking on a modified layout icon to restore it to default layout.			
	Easy Arrange layouts for portrait mode	Portrait mode Easy Arrange icons are presented when monitor is rotated.			

D&LI

NOTE: An application may require a minimum effective resolution for its application window. Such application may not fit in an Ease Arrange zone if the zone is smaller than the required window size.

Managing Multiple Video Inputs

The **Input Manager** tab enables you to manage multiple video inputs connected to your Dell monitor. It makes it very easy to switch between inputs while you work with multiple computers.

All video input ports available to your monitor are listed. You can give each input a name as you like. Please save your changes after editing.

You can define a shortcut key to quickly switch to your favorite input and another shortcut key to quickly switch between two inputs if you often work between them.

Dasic	Auto Mo	de	Easy Arrange	П	Inpu	it Manager	Options	5
Input port:	Inpu	ut name:						
USB-C	(Clic	k to edit)						
DP	(Clic	k to edit)						
HDMI (Active)	(Clic	k to edit)				S	ave	
Favorite input short	cut key:							
	>>	USB-C		~		Change ad	tive input	
None								
None Input switch shortcu	ut key:							

NOTE: Dell Display Manager (DDM) communicates with your monitor even when the monitor is displaying video from another computer. You can install Dell Display Manager on the computer you frequently use and control input switching from it. You may also install Dell Display Manager on other computers connected to the monitor.

Déi

Restoring Application Positions

Dell Display Manager can help you restore application windows into their positions when you reconnect your computer to the monitor(s). You can quickly access this feature by right-clicking on Dell Display Manager icon in the notification tray.

0	Open Dell Display Manager
ŀ	Attach to active window
S	Save current window layout
F	Restore saved window layout
ŀ	Auto-restore window layout
0	Check for new version
E	ixit

If you choose "**Auto-restore window layout**", your application windows' positions are tracked and remembered by Dell Display Manager. Dell Display Manager automatically puts the application windows into their original positions when you reconnect your computer to your monitor(s).

	Open Dell Display Manager Attach to active window
	Save current window layout
	Restore saved window layout
\checkmark	Auto-restore window layout
	Check for new version
	Exit



DEL

If you want to go back to a favorite layout after you have moved the application windows around, you can first "Save current window layout" and later "Restore saved window layout".

	Open Dell Display Manager Attach to active window
	Save current window layout
	Restore saved window layout
	Auto-restore window layout
	Check for new version
	Exit

You may use monitors with different models or resolutions in your daily routine, and you may apply different window layouts on them. Dell Display Manager is able to know the monitor you have reconnected and restore application positions accordingly. In case you need to replace a monitor in a monitor matrix configuration, you can save the window layout before replacement and restore the layout after a new monitor is installed.

NOTE: You should keep your applications running in order to benefit from this feature. Dell Display Manager does not launch applications.

Déi

Attach DDM to active window (Windows 10 and Windows 11 only)

DDM icon can be attached to the active window you are working on. Click on the icon for easy access to the following features.

Feature	Function	Description
Attach DDM to Active Window (Windows 10 and Windows 11 only)	Change preset or snap to different partitions	DDM icon attached to active window and user can easily switch window position, change color preset mode, and associate auto preset mode.
	Shortcut key trigger	On a running app window, press Ctrl+Shift+Ins also triggers the attached DDM menu.
	Move app window among Easy Arrange cells	Send the app window to previous/next Easy Arrange cell.
	Move app window among monitors	Send the app window to previous/next monitor.



DELI

16

Setting energy conservation options

On supported Dell monitor models, an **Options** tab is available for selecting PowerNap energy conservation options. You can set the monitor's brightness to the minimum level or to put the monitor to sleep when the screensaver is activated.

Display	Manager		Dell	I P2X23DE ? X
Basic	Auto Mode	Easy Arrange	Input Manager	Options
PowerNap options: Configure Reduce brightness when screensaver activates Put the display to sleep when screensaver activates 				
Program shortcut I Ctrl + Shift + D Easy Arrange MRU	key:	Application Ctrl + Shi	n window shortcut key: ft + Num 0	
Ctrl + Shift + Hon	ne			

DELL

Other Shortcut Keys

Shortcut keys can be defined for the following operations:

- Program shortcut key: to quickly open the Quick Settings dialog box.
- Easy Arrange MRU shortcut key: to quickly apply the 5 recently used window layouts.
- Application window shortcut key: to launch a quick menu for options under Auto Mode and Easy Arrange.

Display	Display Manager				
Basic	Auto Mode	Easy Arrange	Input Manager	Options	
PowerNap op Reduce b O Put the d	PowerNap options: Configure Reduce brightness when screensaver activates Put the display to sleep when screensaver activates 				
Program shortcu Ctrl + Shift + D Easy Arrange MR	t key:	Application Ctrl + Shi	n window shortcut key: ft + Num 0		
Ctrl + Shift + Ho	ome				

DELI

Troubleshooting

DDM only works with supported Dell monitors. DDM does not support monitors from other manufacturers. If DDM cannot work with your monitor, DDM will show the following icon in your notification tray.



When the icon is clicked, **DDM** shows a more detailed error message.



If DDM is unable to detect and/or communicate with a supported Dell monitor, try the following troubleshooting steps:

- **1.** Ensure the video cable is properly connected to your monitor and your computer. The connectors should be firmly inserted into position.
- 2. Check the monitor OSD to ensure DDC/CI is enabled.
- **3.** Ensure you have the correct and latest graphics-card driver from your graphiccard manufacturer such as Intel, AMD, and NVIDIA. Incompatible or old version of graphics-card driver causes DDM to fail.

Déi

- **4.** Remove any docking stations or cable extenders or converters between the monitor and the graphics port. Some low-cost extenders, hubs or converters may not support DDC/CI properly and may cause the DDM application to fail. Update the driver of such device if the latest version is available.
- 5. Restart your computer.

DDM may not work on the following monitors:

- Dell monitor models from 2013 or earlier and D-series of Dell monitors. You can refer to Dell Product Support websites for more information.
- · Gaming monitors using Nvidia-based G-sync technology.
- · Virtual and wireless displays do not support DDC/Cl.
- On older models of monitors with DisplayPort version 1.2, you may need to disable MST/DP 1.2 using the OSD menu on the monitor.

If your computer is connected to the Internet, you will be prompted with a message when a newer version of DDM application is available. It is recommended to download and install the latest DDM application.

You may also check for new version by right-clicking on DDM icon while pressing and holding the Shift key.

	Open Dell Display Manager Attach to active window	
	Re <u>f</u> resh <u>Bypass Windows DDI where appropriate</u> Sa <u>v</u> e monitor asset report	
	Save <u>d</u> iagnostic report <u>S</u> ave current window layout <u>R</u> estore saved window layout A <u>u</u> to-restore window layout	
×	Auto-load at startup O <u>n</u> screen notifications <u>P</u> rogram language <u>C</u> heck for new version	>
	<u>E</u> xit	