Artwork: 17057Quick Start Guide
Extend: 4pp + 4pp
Size: Open: 594W x 210Hmm Close: 148.5W x 210H (mm)
Material: 100gsm White, woodfree coated
Printing: Both side printing - 2C x 2C – Pantone 3005C + Black
Finishing: Folded sheet
Date prepared: 16 Feb 2006



LCD Monitor 170S7

Quick start guide

1 Installation
2 Connectivity
3 Ergonomic Adjustments

PHILIPS

Display design may differ from that illustrated

4107180413124

Specifications are subject to change without notice.
Trademarks are property of Koninklijke Philips Electronics N.V. or their respective owners.
© 2006 Koninklijke Philips Electronics N.V. All rights reserved.
www.philips.com

Need help?
User manual
Ist die digital User manual für dein Gerät nicht verfügbar?
Gebruik Help: www.philips.com
H170S0S1

What's in the box

Monitor

Quick Start Guide

EDFU CD

Power cord

VGA cable

1 Installation

A Unfold the base



Put monitor face down on the safe surface.

Pull up the base.

B Fold the base

Push down the head of monitor.

C Cable management

Plug the power cord and VGA cable into monitor firmly.

2 Connectivity

A Monitor Connections



1 AC power input
2 VGA input
3 Kensington anti-thief lock

B VGA



For best performance, use your VGA input and ensure that your display settings are set at 1280 ×1024 @60Hz

C POWER

3 Ergonomic Adjustments

A Tilt



B Quick reference for control buttons



1 To switch monitor's power On and Off
2 To access OSD menu
3 To adjust the OSD menu
4 To adjust brightness of the display
5 To adjust OSD menu
6 AUTO Automatically adjust the horizontal position, vertical position, phase and clock settings.

Moniteur LCD / Monitor LCD / LCD-Monitor
Monitor LCD / LCD显示器 / LCD 顯示器

170S7

Quick start guide

Guide de démarrage rapide / Guía rápida / Kurzanleitung / Guida rapida / 快速入门指南 / 快速入門指南

Illustration non contractuelle
El diseño del reproductor puede diferir con respecto al de la ilustración
Das Display-Design kann von der Abbildung abweichen
La visualizzazione può differire da quella presente nella figura
显示屏设计可能与插图有所不同 顯示器設計可能與圖解示意不

1 Installation / Instalación / Installation / Installazione / 安装 / 安裝
2 Connectivité / Conectividad / Verbindungsfähigkeit / Connettività / 连接性 / 連接
3 Réglages ergonomiques / Ajustes ergonómicos / Ergonomische Einstellmöglichkeiten / Regolazioni ergonomiche / 人体工程学调整 / 人體工學調整

PHILIPS

Contenu de la boîte / Contenido del embalaje / Lieferumfang / Contenuto della confezione / 包装盒内的物品清单 / 包裝盒內物品清單

1 Monitor
2 Moniteur
3 Monitor
4 Monitor
5 显示器
6 顯示器

1 Guide de démarrage rapide
2 Guía rápida
3 Kurzanleitung
4 Guida rapida
5 快速入门指南
6 快速入門指南

1 EDFU CD
2 EDFU CD
3 EDFU CD
4 EDFU CD
5 EDFU CD
6 EDFU CD

1 Câble d'alimentation
2 Cable de conexión a la energía
3 Netzkabel
4 Cavo di alimentazione
5 电源线
6 電源線

1 Câble VGA
2 Cable VGA
3 VGA Kabel
4 Cavo VGA
5 VGA 连接线
6 VGA 連線

1 Installation / Instalación / Installation / Installazione / 安装 / 安裝

A Relever le socle / Apertura de la base / Ausklappen des Monitorfußes / Per aprire il basamento / 打开底座 / 打開底座

1 Placez l'écran du moniteur sur un surface stable.
2 Coloque la cara del monitor sobre una superficie segura.
3 Das Monitor mit der Vorderseite nach unten auf eine stabile Oberfläche legen.
4 Posizionare il monitor a faccia in giù su una superficie sicura.
5 将显示器面朝下置于安全的表面上。
6 將顯示器面朝下置於安全的表面上。

1 Tirez la socle vers le haut.
2 Tire de la base.
3 Zum Ausklappen nach oben ziehen.
4 Sollevare il basamento.
5 拉起底座。
6 拉起底座。

B Rabattre le socle / Para plegar la base / Einklappen des Monitorfußes / Per chiudere il basamento / 折叠底座 / 折疊底座

1 Poussez vers le bas la tête du moniteur.
2 Empuje hacia abajo la cabeza del monitor.
3 Das Monitor mit sanftem Druck nach unten drücken.
4 Spingere verso il basso la parte superiore del monitor.
5 将显示器顶部下推。
6 將顯示器頂部下推。

C Gestion de câble / Gerencia del cable / Kabel management / Amministrazione del cavo / 电缆管理 / 電線管理

1 Enfichez fermamente le câble & câble VGA d'alimentation dans le moniteur.
2 Conecte el cable VGA y el alimentador firmemente.
3 Das Netzkabel & VGA Kabel fest mit dem Monitor verbinden.
4 Inserire il cavo VGA e il cavo di alimentazione nel monitor.
5 把电源线和 VGA 线已牢固地插入到显示器中。
6 將電源線和 VGA 連線牢固地插入顯示器中。

2 Connectivité / Conectividad / Verbindungsfähigkeit / Connettività / 连接性 / 連接

A Connectivité / Conectividad / Verbindungsfähigkeit / Connettività / 连接性 / 連接



1 Entrée alimentation CA
2 Entrée VGA
3 Verrouillage antivol Kensington
1 Entrada de alimentación (c.a.)
2 Entrada VGA
3 Ranura antirrobo Kensington
1 Ingresso AC
2 Ingresso VGA
3 Kensingtonsicherungsschlitz
1 交流电源输入
2 VGA 输入
3 Kensington 防盗锁
1 電源輸入
2 VGA 輸入
3 Kensington 防盜鎖

1 Interrutore/tasto
2 VGA diagnosi
3 Kensington
1 Interruptor/botón
2 Toma de entrada VGA
3 Kensington
1 开关/按钮
2 VGA 诊断
3 Kensington
1 開關/按鈕
2 VGA 診斷
3 Kensington

B VGA

Pour des performances optimales, utilisez votre entrée VGA et vérifiez que vos paramètres d'affichage sont réglés sur 1280 x 1024@60Hz

Para un rendimiento óptimo, utilice la entrada VGA y asegúrese de que la configuración de la pantalla está establecida en 1280 x 1024 y 60 Hz

Verwenden Sie den VGA-Eingang, um eine optimale Leistung zu erzielen, und achten Sie darauf, dass Ihr Display auf 1280 x 1024@60Hz eingestellt ist.

Per una prestazione migliore, usare l'ingresso VGA ed accertarsi che le impostazioni del monitor siano impostate a 1280 x 1024@60Hz

为获得最佳性能，请使用 VGA 输入，并确保显示器设置设定为 1280 x 1024@60Hz。

為獲得最佳效能，請使用 VGA 輸入，並確保顯示器設定設定為 1280 x 1024@60Hz。

C POWER

3 Réglages ergonomiques / Ajustes ergonómicos / Ergonomische Einstellmöglichkeiten / Regolazioni ergonomiche / 人体工程学调整 / 人體工學調整

A Réglage de l'inclinaison / Inclinación / Kippen / Inclinazione / 倾斜 / 傾斜



B Référence rapide pour les boutons de contrôle / Guía Rápida para los botones de control / Kurzreference fur Bedienteasen / Riferimenti rapidi per i tasti di controllo / 控制键快速参考 / 控制按鍵參考快速指南



1 Pour mettre moniteur (ON) et hors tension (OFF) du moniteur
2 Accès au menu OSD
3 Réglage des options OSD
4 Réglage de la luminosité de l'écran
5 Accès au menu OSD
6 AUTO Réglage automatique de la position horizontale, de la position verticale, du réglage de phase et d'horloge

1 Encendido y apagado del monitor
2 Para acceder al menú OSD
3 Configuración del menú
4 Ajuste de la luminosidad de la pantalla
5 Para acceder al menú OSD
6 AUTO Ajuste automático de posición horizontal, posición vertical, fase y reloj

1 Zum Ein- und Ausschalten des Monitors
2 Zum Zugriff auf das OSD-Menüsystem
3 Zum Einstellen der OSD-Funktionen
4 Zum Einstellen der Helligkeit des Bildes
5 Zum Zugriff auf das OSD-Menüsystem
6 AUTO Automatische Einstellung der horizontalen und vertikalen Bildlage, Phasenlage und Taktsteuerung

1 Per accendere e spegnere il monitor
2 Per accedere al menu OSD
3 Per regolare la funzione del display
4 Per regolare l'OSD
5 Per accedere al menu OSD
6 AUTO Per regolare la posizione orizzontale, posizione verticale, fase e clock

1 开/关显示器电源按钮
2 访问 OSD 菜单
3 调节 OSD 菜单
4 调节亮度显示器
5 访问 OSD 菜单
6 AUTO 自动调节水平位置、垂直位置、相位和时钟设置

1 開/關顯示器電源
2 存取 OSD 選單
3 調整 OSD 選單
4 調整顯示器亮度
5 存取 OSD 選單
6 AUTO 自動調整水平位置、垂直位置、相位、及時脈設定

Besoin d'aide ?
Manuel d'utilisation
Voir le manuel utilisateur (CD-ROM) fourni avec le cadre photo numérique

Aide en ligne: www.p4c.philips.com

¿Necesita ayuda?
Manual de uso
Consulte el manual de uso digital suministrado con el reproductor de fotos digitales

Ayuda en línea: www.p4c.philips.com

Benötigen Sie Hilfe?
Benutzerhandbuch
Lesen Sie im digitalen Bezuerherhandbuch nach, das mit dem Fotoalbum mitgeliefert wurde.

Online-Hilfe: www.p4c.philips.com

Avete bisogno di aiuto?
Manuale d'istruzione
Consultare il manuale d'istruzione in formato elettronico fornito insieme al visore

Guida in linea: www.p4c.philips.com

需要帮助?
用户手册
参考随数码相框提供的数字版用户手册

在线帮助: www.p4c.philips.com

需要幫助?
使用手冊
參考隨數位相框提供的電子版手冊

線上協助: www.p4c.philips.com

H170S0S1

Specifications are subject to change without notice.
Trademarks are property of Koninklijke Philips Electronics N.V. or their respective owners.
© 2006 Koninklijke Philips Electronics N.V. All rights reserved.
www.philips.com