

7

Bluetooth Pairing mode

- Press and hold buttons a, b, and c simultaneously.
- Click the mouse button.
- Press and hold buttons a, b, and c simultaneously.
- Wait for 5 seconds.
- The LED lights will flash in a sequence: green, white, green, white, green, white, green.

8. Windows 10/8

(a) Right-click the taskbar icon and select **Show Bluetooth Devices**.

(b) In the **PC and devices** window, click **Bluetooth**.

(c) In the **Manage Bluetooth devices** window, click **Pair** next to **Trust EVO-RX Ready to pair**.

9. Windows 7

(a) Click **Add a Device** in the Start menu.

(b) In the **Add a device** window, click **Trust EVO-RX Bluetooth Mouse**.

(c) Click **Next** in the **Add a device** window.

10. Mac

(a) Click **Turn Bluetooth On** in the top status bar.

(b) Click **Bluetooth Keyboard** in the **Bluetooth: On** menu.

(c) Click **Pair** next to **Trust EVO-RX** in the **Bluetooth: On** menu.

11. Android

(a) Open **Settings**.

(b) Click **Bluetooth**.

(c) Click **Trust EVO-RX** to pair.

FAQ

www.trust.com/22975/faq

Trust EVO-RX | ADVANCED LASER MOUSE

User Guide
Bedienungsanleitung
Mode d'emploi
Gebruikershandleiding
Manuale utente
Manual del usuario
Guia do utilizador
Brukerveiledning
Bruksanvisning
Käyttöopas
Brugsvejledning
Instrukcja obsługi
Návod k použití
Návod na používanie
Használati útmutató
Manual de utilizare
Ръководство за потребителя
Εγχειρίδιο χρήσης
Kullanıcı kılavuzu
Руководство пользователя
Uporabniški priročnik
Korisnički priručnik
Guia do usuário
Посібник користувача

©2019 Trust International B.V. - All rights reserved | Laan van Barcelona 600, 3317DD, Dordrecht, NL

