### NFTGFAR RIISINESS

# Installation Guide

- 5-Port Gigabit Ethernet Smart Managed Plus Switch with PoE+ (63W) GS305FP
- 5-Port Gigabit Ethernet Smart Managed Plus Switch with High-Power PoE+ (120W) GS305EPP



### Package contents

- NETGEAR Smart Managed Plus Switch
- Power adapter
- Detachable power cable (varies by region)
- Wall installation kit
- Rubber feet
- Installation guide

## 1. Register with the NETGEAR Insight app

1. Search for **NETGEAR Insight** and download the latest app.





- 2. Set up a NETGEAR account if you do not have one.
- 3. Tap the menu in the upper left corner.

#### 4. Tap REGISTER ANY NETGEAR DEVICE.

- 5. Enter the serial number located on the bottom of the switch, or use the camera on your mobile device to scan the serial number bar code.
- 6. Tap **GO**.

The switch is registered and added to your account. You can now view the switch in the NETGEAR Insight app.

### 2. Connect the switch

Sample connection

### Left port LFD

(The status of

the switch's PoE



Note: We recommend that you use a Category 5e (Cat 5e) cable or higher-rated cable for Gigabit Ethernet connections.

This switch is designed for indoor use only. If you want to connect to a device located outdoors, the outdoor device must be properly grounded and surge protected, and you must install an Ethernet surge protector inline between the switch and the outdoor device. Failure to do so can damage the switch.

When you connect the power cord to the switch and plug it into an electrical outlet the LEDs indicate the status.

LED

Power

PoF Max

budaet)

WARNING: Before connecting this switch to outdoor cables or devices, see https://kb.netgear.com/000057103 for safety and warranty information.

### 3. Check the I FDs

#### Description



**Off.** Sufficient (more than 7W of) PoE power is available.

**Solid vellow**. Less than 7W of PoE power is available.

Blinking yellow. At least once during the previous two minutes, less than 7W of PoE power was available.



Solid green.1000 Mbps link on this port.

Blinking green. 1000 Mbps activity on this port.

Solid yellow. 100 Mbps or 10 Mbps link on this port.

Blinking yellow. 100 Mbps or 10 Mbps activity on this port.

**Off.** No link is detected on this port.

|   | _ | _ |  |
|---|---|---|--|
| J |   |   |  |
|   |   |   |  |
|   |   |   |  |

Solid Green. The port is delivering PoE power..

**Off.** The port is not delivering PoE power

Solid yellow. A PoE fault occurred.

### PoF considerations

The PoE and PoE+ power supplied by the switch is prioritized in ascending port order: Ports 1-4 support PoE and PoE+ with a total power budget of 63W for the GS305EP and 120W for the GS305EPP

If the power requirements for the attached powered devices (PDs) exceed the total power budget of the switch, the PD on the highest-numbered port is disabled to make sure that the PDs connected to the higher-priority, lowernumbered ports are supported first.

A PD listed as an 802.3at PoE powered device does not necessarily require the maximum power limit of the specification. Many PDs require less power. potentially allowing more PoE ports to be active simultaneously.

The following table shows the standard power ranges calculated with the maximum cable length of 328 feet (100 meters).

| Device<br>Class | Standard     | Class Description    | Power<br>Reserved by<br>the Device | Power<br>Delivered to<br>the Device |
|-----------------|--------------|----------------------|------------------------------------|-------------------------------------|
| 0               | PoE and PoE+ | Default power (full) | 0.44W                              | 0.44W-12.95W                        |
| 1               | PoE and PoE+ | Very low power       | 4.0W                               | 0.44W-3.84W                         |
| 2               | PoE and PoE+ | Low power            | 7.0W                               | 3.84W-6.49W                         |
| 3               | PoE and PoE+ | Mid power            | 15.4W                              | 6.49W-12.95W                        |
| 4               | PoE+ only    | High power           | 30.0W                              | 12.95W-25.5W                        |

If a device receives insufficient PoE power from the switch, consider using a shorter cable.



September 2020

© NETGEAR, Inc., NETGEAR and the NETGEAR Logo are trademarks of NETGEAR, Inc. Any non-NETGEAR trademarks are used for reference purposes only.

### PoE troubleshooting

Here are some tips for correcting PoE problems that might occur:

- If the PoE Max LED is solid vellow, disconnect one or more PoE devices to prevent PoE oversubscription.
- For each powered device (PD) that is connected to the switch, the associated PoE LED on the switch lights solid green. If the PoE LED lights solid vellow, a PoE fault occurred and PoE halted because of one of the conditions listed in the following table.

| PoE Fault Condition   | Possible Solution   |  |  |
|---|---|--|--|
|   | Possible Solution   |  |  |
| A PoE-related short circuit occurred on the port.   | The problem is most likely with<br>the attached PD. Check the<br>condition of the PD, or restart<br>the PD by disconnecting and |  |  |
| The PoE power demand of the PD exceeded the maximum level that the switch permits. The maximum level is 15.4W for a PoE connection and 30W for a PoE+ connection. |   |  |  |
| The PoE current on the port exceeded the classification limit of the PD.  | reconnecting the PD.  |  |  |
| The PoE voltage of the port is outside the range that the switch permits  | Restart the switch to see if the condition resolves itself.   |  |  |
|   |   |  |  |

### Mount the switch on a wall

We recommend that you use the wall-mount screws that came with the switch.

- 1. Locate the two mounting holes on the bottom panel of the switch.
- 2. Mark and drill two mounting holes in the wall where you want to mount the switch.

The two mounting holes must be 2.95 in. (75 mm) apart, center-to-center.

3. Insert the supplied anchors into the wall and tighten the screws with a No. 2 Phillips screwdriver.

Leave about 0.125 in. (4 mm) of each screw protruding from the wall so that you can insert the screws into the holes on the bottom panel.

Note: The screws are 6.5 mm in diameter, 16 mm in length.

downloads.

You can also check out our NETGEAR Community for helpful advice at community.netgear.com.

### Regulatory and Legal

Si ce produit est vendu au Canada, vous pouvez accéder à ce document en français canadien à https://www.netgear.com/support/download/.

(If this product is sold in Canada, you can access this document in Canadian French at https://www.netgear.com/support/download/.)

For regulatory compliance information including the EU Declaration of Conformity, visit https://www.netgear.com/about/regulatory/.

See the regulatory compliance document before connecting the power supply.

For NETGEAR's Privacy Policy, visit https://www.netgear.com/about/privacy-policy.

Do not use this device outdoors. The PoE source is intended for intra building connection only.

**NETGEAR**, Inc. 350 East Plumeria Drive San Jose, CA 95134, USA

### Support and Community

Visit netgear.com/support to get your questions answered and access the latest

By using this device, you are agreeing to NETGEAR's Terms and Conditions at https://www.netgear.com/about/terms-and-conditions. If you do not agree, return the device to your place of purchase within your return period.

#### NETGEAR INTERNATIONAL LTD

Floor 1, Building 3 University Technology Centre Curraheen Road, Cork, T12EF21, Ireland