


AC600 Wireless Dual Band USB Adapter



1 Connect to a Computer

Insert the adapter into a USB port on your computer directly.



2 Install Driver and Utility

 a. Download the driver and utility from this product's Support page at www.tp-link.com.

Note

If your computer has a CD drive, you can also run the included CD to install the driver and utility.

- b. Unzip the downloaded folder and run the Installer.pkg.
- c. Follow the instructions to complete the installation.




3 Join a Wireless Network

- a. Select the **Site Survey** tab of the pop-up utility window.
- Select your Wi-Fi network and click CONNECT. The connection status can be viewed on the Link Status screen.



Connect to a Computer

Insert the adapter into a USB port on your computer directly.



In Windows XP, a Found New Hardware Wizard window will appear when the adapter is detected. Please click Cancel


2 Install Driver

a. Insert the CD and run the Autorun.exe.

You can also download the driver from this product's Support page at www.tp-link.com.


b. Select Archer T2U and follow the instructions to complete the installation.

Note: If you can't install the driver successfully, disable the



Join a Wireless Network

- a. Click the network icon (* or * on the taskbar.
- b. Select your Wi-Fi network, click Connect and enter the password when prompted.





For detailed instructions, please refer to the User Manual from this product's Support page at www.tp-link.com.



For technical support and other information, please visit http://www.tp-link.com/support, or simply scan the QR code.

This USB Adapter can only be powered by computers that comply with Limited Power Source (LPS)







