








Quick Start Guide / Guide de démarrage rapide



optional

i For FAQs, Downloads, Manuals, Tech Specs and Help Chat, go to:
 Pour consulter la FAQ, les téléchargements, les manuels, fiches techniques et l'assistance par chat, rendez-vous sur :
<http://support.fujitsupc.com/CS/Portal/support.do?srch=GUIDES>

4G WWAN Installation and Activation

Only applies to systems with an embedded 4G module.

Carrier support may vary depending up on your model.

To activate 4G WWAN service on your device, you will need to perform the following steps.

Obtaining and installing a UCCID (SIMcard):

► Contact your carrier and request a SIM/UCCID card.

For LIFEBOOK® E734/E744, T725, T726, T734, T904, T935, and T936, you will need a 2FF SIM.

For STYLISTIC® Q616, Q665, Q704, Q736 and Q775, you will need a 3FF SIM.

Installing a SIMcard

► For the LIFEBOOK E734/E744, T725, T726, T734, T904, T935 and T936, the SIM slot is located under the battery (Battery must be removed to access the SIM slot.) See your User's Guide on how to properly remove your battery.

► For the STYLISTIC Q704, the SIM slot is located on the "Right Side" of the Tablet. See your User's Guide for locating this slot.

► For STYLISTIC Q616, Q665, Q736 and Q775, the SIM slot is located on the "Left Side" of the Tablet. See your User's Guide for locating this slot.

Caution

Specific WWAN modules are tested with this computer for compliance with FCC regulations. These WWAN modules are authenticated to work in your computer. Other WWAN modules will not work in your computer. You are strongly advised to order your WWAN module from a FUJITSU-authorized source. In the event you install a WWAN module that has not been authorized by FUJITSU, FUJITSU assumes no responsibility for damages to the device or your computer that may result from its installation.

Activating your wireless device


Carrier support may vary depending upon your model.

► Before using your wireless device, you need to contact your carrier to activate your Mobile Broadband service.


You will need to have your IMEI (International Mobile Equipment Identity) readily available in order to activate your account.

1. IMPORTANT: Ensure that you select the correct firmware for your carrier in *Skylight*.


2. To find your IMEI number, click on the Skylight icon on your desktop, then click on the small Menu icon in the taskbar at the top of the Skylight window (it's the fourth from the right).




3. Select *About...*, then click *Device* in the left pane. The IMEI numbers (15 digits) will be displayed in the right pane. The IMEI number can also be found on the label on the unit's box.



4. Firmware change: Click on the Skylight icon on your desktop, then click on the *Option* (Wrench sign).



5. Select *Firmware*, then select the proper firmware for your network carrier, the click *Apply*.



6. Contact your carrier with the information:
 AT&T: Call 1-800-908-9403 or contact your account representative
 Verizon Wireless: Call 1-800-256-4646 or contact your account representative.

Published by
 FUJITSU AMERICA, INC.
 1250 East Arques Ave.
 Sunnyvale, CA 94084-3470, U.S.A.

Creation
 Xerox Global Services

Edition: 1
 01/2016

Order No.: B5FK-6951-01EN-00



B5FK-6951-01EN-00



EN: Important notes

Please read the safety information provided in the User's Guide.

Have questions or need help?

- Visit our website at solutions.us.fujitsu.com
- Call us anytime at 1.800.8FUJITSU
- Email us at 8fujitsu@us.fujitsu.com

If your system is configured with Mobile Broadband, you can find information about it on <http://solutions.us.fujitsu.com/www/content/support/mobile/wwan/>

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



FR: Remarques importantes

Prière de lire les informations de sécurité incluses dans le guide d'utilisation.

Vous avez des questions ou besoin d'aide ?

- Rendez-vous sur notre site Web solutions.us.fujitsu.com
- Appelez-nous à toute heure au 1.800.8FUJITSU
- Envoyez-nous un courrier électronique au 8fujitsu@us.fujitsu.com

Si votre système est configuré avec Mobile Broadband, vous trouvez des information sur Mobile Broadband à l'adresse <http://solutions.us.fujitsu.com/www/content/support/mobile/wwan/>

Cet appareil est conforme à la section 15 de la réglementation FCC. Son fonctionnement dépend des deux conditions suivantes : (1) cet appareil ne doit pas générer d'interférences nuisibles et (2) il doit accepter toute autre interférence reçue, y compris celles pouvant entraîner un fonctionnement non désiré.

1. Starting Windows® for the First Time

- After you boot up the system the first time and follow the instructions on the screen, you will eventually come to the Welcome window. After the Welcome window appears, the screen will black out for up to several minutes. This is normal.

DO NOT ATTEMPT TO POWER DOWN THE SYSTEM AT THIS POINT.

While the screen is blacked out, your system configuration is being set up and the necessary files are being installed.

- During the course of the first start up, you will need to read and accept the End User License Agreements (EULAs) for Microsoft and Fujitsu.



If you reject the terms of the license agreement you will be asked to review the license agreement for information on returning Windows® or to shut down your STYLISTIC. You cannot use your STYLISTIC until you have accepted the license agreement. If you stop the process your STYLISTIC will return to the beginning of the Windows® Welcome Process even if you shut down your STYLISTIC and start it up again.

2. Connect to the Internet or Network

- To connect to the internet in Windows 10 and/or Windows 7, go to *Settings > Network* and connect to a WiFi network (see User's Guide).

or

- Use the microUSB to LAN Ethernet adapter cable (sold separately by Fujitsu) to connect a wall jack or Ethernet router (not included).
- Register your STYLISTIC with Fujitsu Service and Support via our website <http://solutions.us.fujitsu.com/www/content/support/>. This helps us to better serve you.

3. User's Guide

You will need to be connected to the Internet.

- Your electronic User's Guide contains important detailed information about your new computer. You can access your User's Guide by selecting its icon from the traditional Windows desktop.

or

- on the Internet at <http://support.fujitsupc.com/CS/Portal/support.do?srch=GUIDES>

1. Premier démarrage de Windows®

- Après avoir démarré le système pour la première fois et avoir suivi les instructions à l'écran, vous verrez apparaître la fenêtre de bienvenue. Une fois que cette fenêtre apparaît, l'écran s'éteint pendant plusieurs minutes. Cela est normal.

DURANT CETTE PÉRIODE, VOUS NE DEVEZ PAS TENTER D'ÉTEINDRE LE SYSTÈME.

Pendant que l'écran est vide, le système se configure et plusieurs ichiers importants sont installés.

- Lors du premier démarrage, vous devrez lire et accepter les contrats de licence d'utilisation de Microsoft et Fujitsu.



Si vous refusez d'accepter le contrat de licence, le système vous demande de revoir le contrat de licence et d'y lire les informations traitant de la procédure de retour de Windows® à son fabricant, ou de simplement éteindre l'ordinateur STYLISTIC. Vous ne devez pas utiliser votre STYLISTIC avant d'avoir accepté le contrat de licence. Si vous interrompez le processus, votre STYLISTIC reviendra au début du processus d'accueil Windows® même si vous éteignez et redémarrez votre STYLISTIC.

2. Connexion à Internet ou à un réseau

- Pour connecter à Internet dans Windows 10 et/ou Windows 7, sélectionnez *Paramètres > Réseau* et connectez à un réseau WiFi (voir Manuel d'utilisation).

ou

- Utilisez l'adaptateur Micro-USB/LAN (vendu séparément par Fujitsu) pour brancher sur une prise murale ou sur un routeur Ethernet (non inclus).
- Enregistrez votre STYLISTIC auprès du service d'assistance Fujitsu via notre site Web <http://solutions.us.fujitsu.com/www/content/support/>. Nous serons ainsi mieux en mesure de vous aider.

3. Guide d'utilisation

Vous aurez besoin d'un accès Internet.

- Votre guide d'utilisation électronique contient des informations importantes à propos de votre nouvel ordinateur. Pour accéder à votre Guide d'utilisation, sélectionnez l'icône correspondante sur le bureau Windows traditionnel.

ou

- sur le site <http://support.fujitsupc.com/CS/Portal/support.do?srch=GUIDES>