

# iDRAC9 with Lifecycle Controller Version 3.30.30.30

Redfish API Guide

## Notes, cautions, and warnings

 **NOTE:** A NOTE indicates important information that helps you make better use of your product.

 **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

© 2019 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

# Contents

<b>1 Overview</b>	<b>22</b>
New in this release	22
Benefits	22
Key technologies	23
Other documents you may need	23
<b>2 Redfish-based systems management</b>	<b>24</b>
URL support	24
Redfish configuration	25
Configuring Redfish service using iDRAC web interface	25
Configuring Redfish service by using iDRAC RACADM	25
Configuring Redfish service by using WS-MAN	25
Redfish schema	25
Redfish authentication and authorization	25
Roles and privileges	26
iDRAC licensing	27
HTTP methods	27
GET	27
HEAD	27
POST	27
PUT	28
PATCH	28
DELETE	28
HTTP headers	28
HTTP status codes and error messages	29
SSL certificates of iDRAC	29
Eventing	29
Event delivery retry settings in RACADM	30
Eventing operations	30
Updating firmware using SimpleUpdate	30
Updating firmware using a local image	31
Updating firmware using HTTP share	31
Query Parameters	31
Supported Status Codes	32
<b>3 Redfish resources</b>	<b>33</b>
AccountService	36
Description	36
URL	36
Supported HTTP Method and Privileges	36
Supported Status Codes	36
DellJobCollection	36

Description.....	36
URL.....	36
Supported HTTP Method and Privileges.....	37
Navigation URL.....	37
Supported HTTP Method and Privileges.....	37
Updatable Properties.....	37
AttributeRegistry.....	38
Description.....	38
URL.....	38
Methods and privileges.....	38
Supported Status Codes.....	38
AssemblyCollection.....	38
Description.....	38
URL.....	39
Supported HTTP Method and Privileges.....	39
Supported Status Codes.....	39
Navigation URL.....	39
Supported HTTP Method and Privileges.....	39
Supported Status Codes.....	39
BaseMessages.....	40
Description.....	40
URL.....	40
HTTP methods and privileges.....	40
Supported Status Codes.....	40
Bios.....	40
Description.....	40
URL.....	40
Supported HTTP Method and Privileges.....	41
Supported Status Codes.....	41
Supported Action — ChangePassword.....	41
Supported Action — ClearPending.....	42
Supported Action — ResetBios.....	42
Settings resource.....	43
Description.....	43
URL.....	43
HTTP methods and privileges.....	43
Updatable properties.....	43
Status codes.....	44
BootOption.....	44
Description.....	44
URL.....	44
Supported HTTP Method and Privileges.....	44
Supported Status Codes.....	44
Instance URL.....	45
Supported HTTP Method and Privileges.....	45

Updatable Properties.....	45
Supported Status Codes.....	45
ChassisCollection.....	45
Description.....	45
URL.....	45
Supported HTTP Method and Privileges.....	46
Supported Status Codes.....	46
Navigation URL.....	46
Supported HTTP Method and Privileges.....	46
Updatable Properties.....	46
Supported Status Codes.....	47
Supported action — Reset.....	47
Contained resources.....	48
ComputerSystemCollection.....	48
Description.....	48
URL.....	48
Supported HTTP Method and Privileges.....	48
Supported Status Codes.....	48
Navigation URL.....	49
Supported HTTP Method and Privileges.....	49
Updatable Properties.....	49
Supported Status Codes.....	49
Supported Action — Reset.....	49
DellAttributes.....	50
Description.....	50
URL.....	51
Supported HTTP Method and Privileges.....	51
Updatable properties.....	51
Supported action — ClearPending.....	51
DellBootSources.....	52
Description.....	52
URL.....	52
HTTP methods and privileges.....	52
Status codes.....	52
Settings resource.....	53
Description.....	53
URL.....	53
HTTP methods and privileges.....	53
Updatable properties.....	53
Status codes.....	53
DellBootSourcesRegistry.....	54
Description.....	54
URL.....	54
HTTP methods and privileges.....	54
Status codes.....	54

DellCertificatesCollection.....	54
Description.....	54
URL.....	54
HTTP methods and privileges.....	55
Status codes.....	55
Navigation URL.....	55
HTTP methods and privileges.....	55
Updatable properties.....	55
Status codes.....	56
Navigation URL.....	56
HTTP methods and privileges.....	56
Status codes.....	56
DellController.....	57
Description.....	57
URL.....	57
Supported HTTP Method and Privileges.....	57
DelliDRACCardCollection.....	57
Description.....	57
URL.....	57
Supported HTTP Method and Privileges.....	57
Supported Status Codes.....	58
DelliDRACCard.....	58
Description.....	58
URL.....	58
Supported HTTP Method and Privileges.....	58
DelliDRACCardService.....	58
Description.....	58
URL.....	58
Supported HTTP Method and Privileges.....	59
Supported Action — ExportSSLCertificate.....	59
Supported Action — iDRACReset.....	60
Supported Action — iDRACResetCfg.....	60
Supported Action — ImportSSLCertificate.....	61
DellEnclosureCollection.....	62
Description.....	62
URL.....	62
Supported HTTP Method and Privileges.....	62
DellEnclosure.....	63
Description.....	63
URL.....	63
Supported HTTP Method and Privileges.....	63
DellEnclosureEMMCollection.....	63
Description.....	63
URL.....	63
Supported HTTP Method and Privileges.....	64

DellEnclosureEMM.....	64
Description.....	64
URL.....	64
Supported HTTP Method and Privileges.....	64
DellEnclosureFanSensorCollection.....	64
Description.....	64
URL.....	65
Supported HTTP Method and Privileges.....	65
DellEnclosureFanSensor.....	65
Description.....	65
URL.....	65
Supported HTTP Method and Privileges.....	65
DellEnclosurePowerSupplyCollection.....	66
Description.....	66
URL.....	66
Supported HTTP Method and Privileges.....	66
DellEnclosurePowerSupply.....	66
Description.....	66
URL.....	66
Supported HTTP Method and Privileges.....	66
DellEnclosureTemperatureSensorCollection.....	67
Description.....	67
URL.....	67
Supported HTTP Method and Privileges.....	67
DellEnclosureTemperatureSensor.....	67
Description.....	67
URL.....	67
Supported HTTP Method and Privileges.....	68
DellFCCollection.....	68
Description.....	68
URL.....	68
Supported HTTP Method and Privileges.....	68
Supported Status Codes.....	68
DellFC.....	68
Description.....	68
URL.....	69
Supported HTTP Method and Privileges.....	69
Supported Status Codes.....	69
DellFCStatisticsCollection.....	69
Description.....	69
URL.....	69
Supported HTTP Method and Privileges.....	69
Supported Status Codes.....	69
DellFCStatistics.....	70
Description.....	70

URL.....	70
Supported HTTP Method and Privileges.....	70
Supported Status Codes.....	70
DellJobService.....	70
Description.....	70
URL.....	70
HTTP methods and privileges.....	70
Supported Action — DeleteJobQueue.....	71
Supported Action — SetupJobQueue.....	72
DellLCService.....	72
Description.....	72
URL.....	73
Supported HTTP Method and Privileges.....	73
Supported Status Codes.....	73
Supported Action — BackupImage.....	73
Supported Action — ClearProvisioningServer.....	75
Supported Action — ExportFactoryConfiguration.....	76
Supported Action — ExportLCLog.....	77
Supported Action — ExportHWInventory.....	79
Supported Action — ExportTechSupportReport.....	80
Supported Action — GetRemoteServicesAPIStatus.....	81
Supported Action — GetRSStatus.....	82
Supported Action — LCWipe.....	83
Supported Action — ReInitiateDHS.....	83
Supported Action — RestoreImage.....	84
DellLicenseCollection.....	86
Description.....	86
URL.....	86
Supported HTTP Method and Privileges.....	86
DellLicenseManagementService.....	86
Description.....	86
URL.....	86
Supported HTTP Method and Privileges.....	86
Supported Action — ExportLicenseToNetworkShare.....	87
Supported Action — ImportLicenseFromNetworkShare.....	88
Supported Action — ImportLicense.....	90
Supported Action — ShowLicenseBits.....	91
Supported Action — DeleteLicense.....	91
Supported Action — ExportLicense.....	92
ActionSupported Action — ExportLicenseByDeviceToNetworkShare.....	93
DellMemoryCollection.....	94
Description.....	94
URL.....	94
Supported HTTP Method and Privileges.....	94
Supported Status Codes.....	94



DellMemory.....	94
Description.....	94
URL.....	95
Supported HTTP Method and Privileges.....	95
DellNICCapabilitiesCollection.....	95
Description.....	95
URL.....	95
Supported HTTP Method and Privileges.....	95
DellNIC.....	96
Description.....	96
URL.....	96
Supported HTTP Method and Privileges.....	96
DellNICCapabilitiesCollection.....	96
Description.....	96
URL.....	96
Supported HTTP Method and Privileges.....	96
DellNICCapabilities.....	97
Description.....	97
URL.....	97
Supported HTTP Method and Privileges.....	97
DellNICStatisticsCollection.....	97
Description.....	97
URL.....	97
Supported HTTP Method and Privileges.....	98
DellNICStatistics.....	98
Description.....	98
URL.....	98
Supported HTTP Method and Privileges.....	98
DellNumericSensorCollection.....	98
Description.....	98
URL.....	99
Supported HTTP Method and Privileges.....	99
DellNumericSensor.....	99
Description.....	99
URL.....	99
Supported HTTP Method and Privileges.....	99
DellOSDeploymentService.....	100
Description.....	100
URL.....	100
Supported HTTP Method and Privileges.....	100
Supported Status Codes.....	100
Supported Action — BootToHD.....	101
Supported Action — BootToISOFromVFlash.....	101
Supported Action — BootToNetworkISO.....	102
Supported Action — ConfigurableBootToNetworkISO.....	103

Supported Action — ConnectNetworkISOImage.....	104
Supported Action — DeleteISOFromVFlash.....	106
Supported Action — DetachISOFromVFlash.....	106
Supported Action — DetachDrivers.....	107
Supported Action — DetachISOImage.....	107
Supported Action — DisconnectNetworkISOImage.....	108
Supported Action — DownloadISOToVFlash.....	108
Supported Action — GetAttachStatus.....	109
Supported Action — GetDriverPackInfo.....	110
Supported Action — GetNetworkISOImageConnectionInfo.....	111
Supported Action — UnpackAndAttach.....	111
Supported Action — UnpackAndShare.....	112
DellPCleSSDExtenderCollection.....	113
Description.....	113
URL.....	113
Supported HTTP Method and Privileges.....	113
DellPCleSSDExtender.....	114
Description.....	114
URL.....	114
Supported HTTP Method and Privileges.....	114
DellPCleSSDCollection.....	114
Description.....	114
URL.....	114
Supported HTTP Method and Privileges.....	114
DellPCleSSD.....	115
Description.....	115
URL.....	115
Supported HTTP Method and Privileges.....	115
DellPCleSSDBackPlaneCollection.....	115
Description.....	115
URL.....	115
Supported HTTP Method and Privileges.....	116
DellPCleSSDBackPlane.....	116
Description.....	116
URL.....	116
Supported HTTP Method and Privileges.....	116
DellPCleFunctionCollection.....	116
Description.....	116
URL.....	117
Supported HTTP Method and Privileges.....	117
Supported Status Codes.....	117
DellPCleFunction.....	117
Description.....	117
URL.....	117
Supported HTTP Method and Privileges.....	117

Supported Status Codes.....	117
DellPersistentStorageService.....	118
Description.....	118
URL.....	118
Supported HTTP Method and Privileges.....	118
Supported Status Codes.....	118
Supported Action — FormatPartition.....	118
DellPhysicalDiskCollection.....	119
Description.....	119
URL.....	119
Supported HTTP Method and Privileges.....	119
Supported Status Codes.....	119
DellPhysicalDisk.....	120
Description.....	120
URL.....	120
Supported HTTP Method and Privileges.....	120
Supported Status Codes.....	120
DellPresenceAndStatusSensorCollection.....	120
Description.....	120
URL.....	120
Supported HTTP Method and Privileges.....	120
Supported Status Codes.....	121
DellPresenceAndStatusSensor.....	121
Description.....	121
URL.....	121
Supported HTTP Method and Privileges.....	121
Supported Status Codes.....	121
DellPowerSupplyCollection.....	121
Description.....	121
URL.....	121
Supported HTTP Method and Privileges.....	122
Supported Status Codes.....	122
DellPowerSupply.....	122
Description.....	122
URL.....	122
Supported HTTP Method and Privileges.....	122
Supported Status Codes.....	122
DellPowerSupplyViewCollection.....	122
Description.....	122
URL.....	123
Supported HTTP Method and Privileges.....	123
Supported Status Codes.....	123
DellPowerSupplyView.....	123
Description.....	123
URL.....	123

Supported HTTP Method and Privileges.....	123
Supported Status Codes.....	123
DellProcessorCollection .....	124
Description.....	124
URL.....	124
Supported HTTP Method and Privileges.....	124
Supported Status Codes.....	124
DellProcessor.....	124
Description.....	124
URL.....	124
Supported HTTP Method and Privileges.....	124
Supported Status Codes.....	125
DellRaidService.....	125
Description.....	125
URL.....	125
Supported HTTP Method and Privileges.....	125
Supported Status Codes.....	125
Supported Action — AssignSpare.....	126
Supported Action — BlinkTarget.....	127
Supported Action — CheckVDValues.....	127
Supported Action — ClearForeignConfig.....	128
Supported Action — ConvertToRAID.....	129
Supported Action — ConvertToNonRAID.....	130
Supported Action — EnableControllerEncryption.....	131
Supported Action — GetAvailableDisks.....	132
Supported Action — GetDHSDisks.....	133
Supported Action — GetRAIDLevels.....	134
Supported Action — LockVirtualDisk.....	135
Supported Action — ReKey.....	136
Supported Action — RemoveControllerKey.....	137
Supported Action — ResetConfig.....	137
Supported Action — SetControllerKey.....	138
Supported Action — UnBlinkTarget.....	139
DellSensorCollection.....	140
Description.....	140
URL.....	140
Supported HTTP Method and Privileges.....	140
Supported Status Codes.....	140
DellSensor.....	140
Description.....	140
URL.....	140
Supported HTTP Method and Privileges.....	141
Supported Status Codes.....	141
DellSoftwareInstallationService.....	141
Description.....	141

URL.....	141
Supported HTTP Method and Privileges.....	141
Supported Status Codes.....	141
Supported Action — GetRepoBasedUpdateList.....	142
Supported Action — InstallFromRepository.....	142
Supported Action — InstallFromURI.....	144
DellSwitchConnectionCollection.....	146
Description.....	146
URL.....	146
Supported HTTP Method and Privileges.....	146
Supported Status Codes.....	146
DellSwitchConnection.....	146
Description.....	146
URL.....	146
Supported HTTP Method and Privileges.....	146
Supported Status Codes.....	147
DellSystem.....	147
Description.....	147
URL.....	147
Supported HTTP Method and Privileges.....	147
Supported Status Codes.....	147
DellvFlashCollection.....	147
Description.....	147
URL.....	147
Supported HTTP Method and Privileges.....	148
Supported Status Codes.....	148
DellvFlash .....	148
Description.....	148
URL.....	148
Supported HTTP Method and Privileges.....	148
Supported Status Codes.....	148
DellVirtualDiskCollection.....	148
Description.....	148
URL.....	149
Supported HTTP Method and Privileges.....	149
Supported Status Codes.....	149
DellVirtualDisk.....	149
Description.....	149
URL.....	149
Supported HTTP Method and Privileges.....	149
Supported Status Codes.....	149
DellServiceRoot.....	150
Description.....	150
URL.....	150
HTTP methods and privileges.....	150

Supported Status Codes.....	150
DellUpdateService.....	150
Description.....	150
Supported action — Install.....	150
DellManager.....	152
Description.....	152
Supported Action — ResetToDefaults.....	152
Supported action — Export, Import, and Preview.....	153
Drive.....	156
Description.....	156
URL.....	156
Supported HTTP Method and Privileges.....	156
Updatable Properties.....	156
Supported Status Codes.....	156
Supported Action—SecureErase.....	156
EthernetInterfaceCollection.....	157
Description.....	157
URL.....	157
Supported HTTP Method and Privileges.....	157
Supported Status Codes.....	158
EthernetInterfaces.....	158
Description.....	158
URL.....	158
HTTP methods and privileges.....	158
Ethernet — Instance.....	158
Reference Properties.....	159
EventService.....	160
Description.....	160
URL.....	160
Supported HTTP Method and Privileges.....	160
Supported Status Codes.....	161
Contained Resource.....	161
Supported Action — SubmitTestEvent.....	161
FabricCollection.....	161
Description.....	161
URL.....	161
Supported HTTP Method and Privileges.....	162
Contained resources.....	162
PCle.....	162
Description.....	162
URL.....	162
Supported HTTP Method and Privileges.....	162
Supported Status Codes.....	162
Contained resources.....	163
HostInterfaceCollection.....	163

Description.....	163
URL.....	163
Supported HTTP Method and Privileges.....	163
Supported Status Codes.....	163
Navigation URL.....	163
Supported HTTP Method and Privileges.....	164
JSONSchemas.....	164
Description.....	164
URL.....	164
HTTP methods and privileges.....	164
Supported Status Codes.....	164
LogEntryCollection.....	164
Description.....	164
URL.....	165
Supported HTTP Method and Privileges.....	165
Supported Status Codes.....	165
LogService.....	165
Description.....	165
URL.....	165
Supported HTTP Method and Privileges.....	165
Supported Parameters.....	166
Supported Status Codes.....	166
LogServiceCollection.....	166
Description.....	166
URL.....	166
Supported HTTP Method and Privileges.....	166
Supported Action — ClearLog.....	166
ManagerCollection.....	167
Description.....	167
URL.....	167
Supported HTTP Method and Privileges.....	167
Supported Status Codes.....	167
Navigation URL.....	168
Supported HTTP Method and Privileges.....	168
Updatable properties.....	168
Supported Status Codes.....	168
Supported Action — Reset.....	169
ManagerAccountCollection.....	169
Description.....	169
URL.....	169
HTTP methods and privileges.....	170
Navigation URL.....	170
HTTP methods and privileges.....	170
Updatable properties.....	170
Status codes.....	170

ManagerNetworkProtocol.....	171
Description.....	171
URL.....	171
Supported HTTP Method and Privileges.....	171
Updatable properties.....	171
Status codes.....	172
MemoryCollection.....	172
Description.....	172
URL.....	172
Supported HTTP Method and Privileges.....	172
Supported Status Codes.....	172
Navigation URL.....	173
Supported HTTP Method and Privileges.....	173
Supported Parameters.....	173
Supported Status Codes.....	173
Supported Action — MemoryMetrics.....	173
MessageRegistryFile.....	174
Description.....	174
URL.....	174
Supported HTTP Method and Privileges.....	174
Supported Status Codes.....	174
MessageRegistryFileCollection.....	175
Description.....	175
URL.....	175
Supported HTTP Method and Privileges.....	175
Supported Status Codes.....	175
Messages.....	175
Description.....	175
URL.....	175
HTTP methods and privileges.....	176
Supported Status Codes.....	176
NetworkAdapterCollection.....	176
Description.....	176
URL.....	176
Supported HTTP Method and Privileges.....	176
Supported Status Codes.....	177
NetworkDeviceFunctions.....	177
NetworkInterfaceCollection.....	182
Description.....	182
URL.....	182
Supported HTTP Method and Privileges.....	182
Supported Status Codes.....	182
PCleDevice.....	183
Description.....	183
URL.....	183



Supported HTTP Method and Privileges.....	183
Supported Status Codes.....	183
PCIeFunction.....	183
Description.....	183
URL.....	184
Supported HTTP Method and Privileges.....	184
Supported Status Codes.....	184
Port.....	184
Description.....	184
URL.....	184
Supported HTTP Method and Privileges.....	184
Supported Status Codes.....	185
PortCollection.....	185
Description.....	185
URL.....	185
Supported HTTP Method and Privileges.....	185
Supported Status Codes.....	185
Power.....	186
Description.....	186
URL.....	186
Supported HTTP Method and Privileges.....	186
Supported Status Codes.....	186
Reference Properties.....	186
PrivilegeRegistry.....	187
Description.....	187
URL.....	187
Supported HTTP Method and Privileges.....	187
Supported Status Codes.....	188
ProcessorCollection.....	188
Description.....	188
URL.....	188
Supported HTTP Method and Privileges.....	188
Supported Status Codes.....	188
Navigation URL.....	189
Supported HTTP Method and Privileges.....	189
Supported Status Codes.....	189
Role.....	189
Description.....	189
URL.....	189
Supported HTTP Method and Privileges.....	189
Supported Status Codes.....	190
RoleCollection.....	190
Description.....	190
URL.....	190
Supported HTTP Method and Privileges.....	190

Supported Status Codes.....	190
SecureBoot.....	191
Description.....	191
URL.....	191
Supported HTTP Method and Privileges.....	191
Updatable properties.....	191
Supported Status Codes.....	191
Supported Action — ResetKeys.....	192
SerialInterfaceCollection.....	192
Description.....	192
URL.....	192
Supported HTTP Method and Privileges.....	193
Supported Status Codes.....	193
Navigation URL.....	193
Supported HTTP Method and Privileges.....	193
Updatable properties.....	193
ServiceRoot.....	194
Description.....	194
URL.....	194
Supported HTTP Method and Privileges.....	194
Supported Status Codes.....	194
Session.....	194
URL.....	194
Description.....	194
HTTP methods and privileges.....	195
Updatable properties.....	195
Status codes.....	195
Action — Delete.....	195
SessionService.....	196
Description.....	196
URL.....	196
Supported HTTP Method and Privileges.....	196
Updatable properties.....	196
Supported Status Codes.....	197
SimpleStorage.....	197
Description.....	197
URL.....	197
HTTP methods and privileges.....	197
Supported Status Codes.....	197
SoftwareInventoryCollection.....	198
Description.....	198
URL.....	198
Supported HTTP Method and Privileges.....	198
Status codes.....	198
Navigation URL.....	199

Supported HTTP Method and Privileges.....	199
Supported Status Codes.....	199
Status codes.....	199
StorageCollection.....	200
Description.....	200
URL.....	200
Supported HTTP Method and Privileges.....	200
Supported Status Codes.....	200
Navigation URL.....	200
Supported HTTP Method and Privileges.....	200
Supported Status Codes.....	201
StorageController.....	201
Description.....	201
URL.....	201
Supported HTTP Method and Privileges.....	201
Subscriptions.....	201
Description.....	201
URL.....	201
HTTP methods and privileges.....	202
Properties.....	202
Status codes.....	202
Switches.....	202
Description.....	202
URL.....	203
Supported HTTP Method and Privileges.....	203
TaskCollection.....	203
Description.....	203
URL.....	203
Supported HTTP Method and Privileges.....	203
Supported Status Codes.....	203
TaskService.....	204
Description.....	204
URL.....	204
Supported HTTP Method and Privileges.....	204
Supported Status Codes.....	204
Thermal.....	204
Description.....	204
URL.....	204
Supported HTTP Method and Privileges.....	205
Supported Parameters.....	205
Reference Properties.....	205
UpdateService.....	206
Description.....	206
URL.....	206
Supported HTTP Method and Privileges.....	206

Supported Status Codes.....	206
Supported action — SimpleUpdate.....	206
VirtualMedia.....	207
Description.....	207
URL.....	208
HTTP methods and privileges.....	208
Status codes .....	208
Properties and values.....	208
VLANNetworkInterface.....	209
Description.....	209
URL.....	209
HTTP methods and response content type.....	209
Status codes.....	209
VolumeCollection.....	209
Description.....	209
URL.....	209
Supported HTTP Method and Privileges.....	210
Navigation URL.....	210
Supported HTTP Method and Privileges.....	210
Supported Parameters.....	210
Supported Status Codes.....	210
Supported Action — CheckConsistency.....	210
Supported Action — Initialize.....	211
NetworkPort.....	212
Description.....	212
URL.....	212
Supported HTTP Method and Privileges.....	212
Supported Status Codes.....	212
NetworkPortCollection.....	213
Description.....	213
URL.....	213
Supported HTTP Method and Privileges.....	213
Supported Status Codes.....	213
NetworkDeviceFunctionCollection.....	213
Description.....	213
URL.....	213
Supported HTTP Method and Privileges.....	214
Supported Status Codes.....	214
Redundancy.....	214
Description.....	214
URL.....	214
Supported HTTP Method and Privileges.....	214
Supported Status Codes.....	214
<b>4 Examples.....</b>	<b>216</b>
Example for GET.....	216

Example for PATCH.....	216
Example for POST.....	217
Example for DELETE.....	217
Example of Job Creation.....	217
Request.....	217
Response.....	218
Examples for \$expand.....	218
Examples for \$select.....	219
Examples for \$filter.....	219

# Overview

The Redfish Scalable Platforms Management API is a standard defined by the Distributed Management Task Force (DMTF). Redfish is a next-generation systems management interface standard, which enables scalable, secure, and open server management. It is a new interface that uses RESTful interface semantics to access data that is defined in model format to perform out-of-band systems management. It is suitable for a wide range of servers ranging from stand-alone servers to rack mount and bladed environments and for large scale cloud environments.

Dell PowerEdge servers offer a comprehensive range of embedded systems management functions enabled by the Integrated Dell Remote Access Controller (iDRAC) with Lifecycle Controller. These functions are designed by adhering industry standard application programming interfaces (APIs) including Redfish.

iDRAC with Lifecycle Controller technology is part of a larger data center solution that helps keep business critical applications and workloads available always. The technology allows administrators to deploy, monitor, manage, configure, update, troubleshoot, and remediate Dell servers from any location, and without the use of agents. It accomplishes this regardless of an operating system or a Hypervisor presence or state.

This document provides a brief overview on Redfish and information on various aspects of Redfish protocol, supported schema, and Redfish Eventing implemented in iDRAC. It also provides guidelines for using the Dell Redfish APIs.

Topics:

- [New in this release](#)
- [Benefits](#)
- [Key technologies](#)
- [Other documents you may need](#)

## New in this release

- Added support for Redfish 2016 R2 and R3 APIs including PCIe device and NVDIMM inventory, OS Host Interface access, and Privilege registry.
- Added support for Redfish 2017 R1, R2, and R3 APIs including boot source configuration, virtual media management, and maintenance window scheduling.
- Added support for Dell OEM APIs mapping WS-Man methods to iDRAC RESTful APIs.
- Added support for Memory (DIMMs) inventory and statistics
- Added support for query parameters

## Benefits

Redfish is a global standard for open server management. It has the capabilities to support single servers, converged infrastructure, and hyper—scale architecture. It provides the following benefits over existing server management methods:

- Increased simplicity and usability
- High data security
- Programmable interface that can be easily scripted
- Widely-used standard

# Key technologies

Redfish uses web and cloud-based technologies that enable communications with servers using common programming and scripting languages such as Python, JAVA, and C. The key technologies are as follows:

- REpresentational State Transfer (REST) interface — REST is a web based API, which provides a way to interact with a system over a normal web connection. It supports both HTTPS and HTTP.
- Java Script Notation (JSON) — JSON represents data in such a way that it is much easier to read than XML. It also provides the formatting that is required for scripting languages to interface with the data.
- OData — It is important to standardize the data format when implementing a common interface across multiple vendors. OData provides the required framework to ensure that the data structure remains interchangeable between server vendors.

# Other documents you may need

For more information about Redfish, see the DMTF website <https://www.dmtf.org/standards/redfish>. This website provides access to schema files, white papers, technical notes, and so on.

To download or access a file, go to <https://www.dmtf.org/standards/redfish>, locate the desired section, and click the link to open or download the files.

You can download the OEM schemas from the Dell website at <https://downloads.dell.com/redfish/bmc/schemas/>.

# Redfish-based systems management

This section provides an overview of the Redfish service implemented in the iDRAC firmware. It includes information about the Redfish API, schema, configuration, authentication, authorization, and so on.

Topics:

- [URL support](#)
- [Redfish configuration](#)
- [Redfish schema](#)
- [Redfish authentication and authorization](#)
- [Roles and privileges](#)
- [iDRAC licensing](#)
- [HTTP methods](#)
- [HTTP headers](#)
- [HTTP status codes and error messages](#)
- [SSL certificates of iDRAC](#)
- [Eventing](#)
- [Updating firmware using SimpleUpdate](#)
- [Query Parameters](#)

## URL support

Redfish is a web-based API which implies that resources are accessed using client supplied URLs. URLs are required to identify the Redfish resources. The Redfish API uses a simple URL hierarchy which follows a `/redfish/v1/` pattern for all resources. To access a Redfish resource, use the URL pattern `https://<iDRAC IP>/redfish/v1/<Resource Path>`. For more information on the supported resources, see [Redfish resources](#). iDRAC supports the following URL patterns:

- `/redfish` — URL for the Redfish version object.
- `/redfish/v1` — Root URL for version 1 of the Redfish services.
- `/redfish/v1/odata` — Redfish services expose an OData service document at this URI. This service document provides a standard format for enumerating resources that are exposed by the service by enabling all generic hypermedia-driven OData clients to navigate to the resources of the service.
- `/redfish/v1/$metadata` — Redfish services expose a metadata document in XML format. This document describes the resources and collections that are available at the service root URI. It also provides references to other metadata documents, which describe the complete set of resource types that are exposed by the service.
- `/redfish/v1/$metadata#<Collection or a Singleton resource>` — Metadata URL specified as a part of `@odata.context` property for all resources. This URL returns data in XML format.
- `/redfish/v1/JsonSchemas` — This URL returns data in JSON format. The output is a collection of the `JsonSchemaFile` resource instances.
- `/redfish/v1/JsonSchemas/<resource URI>` — The JSON Schema File resource instance describes the location (URI) of a particular Redfish schema definition being implemented or referenced by a Redfish service. This URL returns data in JSON format.
- `/redfish/v1/<other resource specific URIs>` — All instrumentation resources follow this pattern.

**NOTE:** The Redfish standard implemented in iDRAC supports only HTTPS protocol.



**NOTE:** In previous versions of Redfish implementation, # character was parsed as #. Because this character is treated as a break character by the code, any characters after # were ignored. Now, # character is automatically converted to %23. This conversion allows the consoles or REST clients to use the URL without any errors.

## Redfish configuration

You can configure the Redfish interface on iDRAC by enabling or disabling the iDRAC attribute. If this attribute is disabled, HTTPS requests to Redfish URIs fail with an HTTP status code of 404 and an error message indicating that this attribute is disabled.

**NOTE:** You do not need to restart the web server when enabling or disabling Redfish attribute.

## Configuring Redfish service using iDRAC web interface

To enable or disable the Redfish service on iDRAC, perform the following tasks:

- 1 In the iDRAC web interface, navigate to the following screen:
  - 13<sup>th</sup> generation of PowerEdge servers: **Overview > iDRAC Settings > Network > Services**
  - 14<sup>th</sup> generation of PowerEdge servers: **iDRAC Settings > Services > Redfish**
- 2 Under **Redfish**, select **Enabled** and click **Apply** to enable the service.

## Configuring Redfish service by using iDRAC RACADM

You can enable or disable the Redfish service using the iDRAC attribute `iDRAC.Redfish.Enable` (Read or Write).

## Configuring Redfish service by using WS-MAN

The Redfish attribute `iDRAC.Redfish.Enable` is modeled under the existing `DCIM_iDRACCardEnumeration` class. You can configure the Redfish service using existing methods such as `SetAttribute`, `SetAttributes`, and `ApplyAttributes` of `DCIM_iDRACCardService` class.

## Redfish schema

The Schemas for the Redfish resources are defined according to the OData Schema representation, which can be directly translated to a JSON Schema representation.

## Redfish authentication and authorization

For certain resources, the Redfish clients may require to authenticate access. Redfish relies on the managed system for the required credentials and supported forms of authentication. In iDRAC, authentication is based on local credentials and remote protocols such as Active Directory and LDAP.

**NOTE:** You must have the required iDRAC license to use Active Directory and LDAP.

Authorization includes both user privilege and license authorization. Redfish support is included in all levels of iDRAC licensing. The following table details the authentication and authorization required for each Redfish action:

**Table 1. Redfish authentication and authorization**

Redfish actions	Authentication required	Authorization required
Read operation on any instrumentation data	Yes	Yes
Modify instrumentation data	Yes	Yes
Invoke actions	Yes	Yes
View service root	No	No
View metadata document	No	No
View OData service document	No	No
View message registry	No	No
View Redfish version URI	No	No
View JSONSchemaFile resource URI	No	No
View JSON schemas URI	No	No

The Redfish service provides access to Redfish URLs by using the following methods:

- **Basic authentication:** In this method, user name and password are provided for each Redfish API request.
- **Session-based authentication:** This method is used while issuing multiple Redfish operation requests.
  - Session login is initiated by accessing the Create session URI. The response for this request includes an X-Auth-Token header with a session token. Authentication for subsequent requests is made using the X-Auth-Token header.
  - Session logout is performed by issuing a DELETE of the Session resource provided by the Login operation including the X-Auth-Token header.

**NOTE:** The iDRAC firmware incorporates the concept of application sessions for various existing interfaces such as the web interface, WSMAN, and RACADM. With the introduction of Redfish-specific sessions, Redfish inherits the characteristics of web server sessions and the property Session Timeout inherits the web server session timeout value.

**NOTE:** To ensure a secure connection, Dell recommends using TLS 1.1 or later.

## Roles and privileges

To allow different levels of access to Redfish services, you can create user accounts with specific roles. The following table lists the roles and the privileges assigned to them:

**Table 2. Roles and privileges**

Role	Assigned privileges	OEM privileges
Administrator	<ul style="list-style-type: none"><li>• Login</li><li>• ConfigureComponents</li><li>• ConfigureManager</li><li>• ConfigureSelf</li><li>• ConfigureUsers</li></ul>	<ul style="list-style-type: none"><li>• ClearLogs</li><li>• AccessVirtualConsole</li><li>• AccessVirtualMedia</li><li>• TestAlerts</li><li>• ExecuteDebugCommands</li></ul>
Operator	<ul style="list-style-type: none"><li>• Login</li><li>• ConfigureComponents</li><li>• ConfigureSelf</li></ul>	-

Role	Assigned privileges	OEM privileges
ReadOnly	<ul style="list-style-type: none"> <li>Login</li> </ul>	-

## iDRAC licensing

Redfish support is included in all license types of iDRAC. However, some of the iDRAC features require specific licenses. If a required license is not present, certain Redfish APIs may not be accessible and return an HTTP 403 status code. 403 implies that there is no sufficient privileges. In other cases, some of the properties in certain resource may not be returned in a response. The service may also return errors when such properties are modified. For information of specific license requirements for the resources, see [Redfish resources](#).

## HTTP methods

The REST API allows you to specify the type of request. It adheres to the Create, Retrieve, Update, and Delete (CRUD) standard format. The data is generated by accessing URIs that can be accessed by using the following HTTP methods:

- GET
- HEAD
- POST
- PUT
- PATCH
- DELETE

### GET

Use the GET method to retrieve a representation of a resource. The representation can either be a single resource or a collection. Depending on the media type, the service returns the resource representation by using one of the media types specified in the Accept header. If the Accept header is not present, the service returns the resource representations either as **application/json** or **application/xml**. The resources support the formats defined by the Redfish standard.

The HTTP GET method is used to retrieve a resource. The service ignores the content of the body on a GET. The GET operation is unchanged in the absence of external changes to the resource.

### HEAD

All URLs support the HEAD method. This method returns the response headers.

### POST

Use the POST method to invoke actions and create a resource. The POST request is submitted to the resource collection to which the new resource belongs. Submitting a POST request to a resource that represents a collection is equivalent to submitting the request to the Members property of that resource. Services that support adding members to a collection support both forms.


Services support the POST method for creating resources. If the resource does not support this method, status code 405 is returned. The body of the create request contains a representation of the object to be created. The service can ignore any service-controlled properties such as ID, forcing those properties for the service to be overridden. The service sets the Location header to the URI of the newly created resource.

# PUT

Use the PUT method to replace the property values of a resource. Properties omitted from the request body are reset to their default value. Services support the PUT method to replace a resource completely. If a service does not support this method, status code 405 is returned. Services may return a representation of the resource after any server-side transformations occur in the body of the response. The PUT operation must be unchanged in the absence of external changes to the resource. The exception is that the ETag values may change as a result of this operation.

# PATCH

Use the PATCH method to update pre-existing resources. Changes to the resource are sent in the request body. This method does not change the properties that are not specified in the request body. The response is either empty or a representation of the resource after the update is done, or a success code if the operation is successful. Depending on the policies, the implementation may reject the update operation on certain fields and not apply any of the requested updates.

 **NOTE:** Starting from iDRAC version 3.15.15.15 release, you can use the PATCH method with up to 50 attributes at a time.

# DELETE

Use the DELETE method to remove a resource. Services support the DELETE method for resources that can be deleted. If the resource cannot be deleted, status code 405 is returned. Services return a representation of the deleted resource in the response body.

# HTTP headers

The server response contains only basic information about related resources. Any metadata that is required to process a request or response is accessed by using HTTP headers. iDRAC supports the following request headers:

Header	Description
If-Match	Supported only for AccountService and FirmwareInventory URIs.
If-None-Match	Supported only for AccountService, FirmwareInventory, and metadata URIs.
Content-Length	Returned on all responses except responses that have Transfer-Encoding: chunked.
Content-Type	<ul style="list-style-type: none"><li>Responses other than OData metadata—application/json;charset=utf-8</li><li>OData responses—application/xml;charset=utf-8</li></ul>
ETag	Supported on AccountService, FirmwareInventory, and metadata URIs.
Location	Service sets this header when resources are created or when HTTP requests are redirected to other resources.
Cache-Control	Returned on all responses. Metadata URIs support cached responses. Instrumentation resources cannot be cached.
X-Auth-Token	Used for authentication of user sessions. See “Session-based authentication” under <a href="#">Redfish authentication and authorization</a> .

# HTTP status codes and error messages

HTTP defines the status codes that are returned in response messages. When the HTTP status code indicates a failure, the response body contains an extended error resource, which provides meaningful and deterministic error semantics.

The extended-error information for the Redfish service that Dell has implemented contains error or exception information that is unique to Dell. This information provides more details and recommendations for error resolution. To learn more about extended-error information, see the *Event and Error Message Reference Guide* available at [www.dell.com/manuals](http://www.dell.com/manuals).

For more details about the error messages, see the following:

- Base messages: **Registries > BaseMessage** schema. Examples of base messages are GeneralError, PropertyUnknown, InsufficientPrivilege, and so on.
- Event and Error messages: **Registries > Message** schema. Examples of Event and Error messages are AMP0300, ASR0001, HWC7014, and so on.

For more information about supported status codes and error messages, see the *Redfish Scalable Platforms Management API Specification* document available at [www.dmtf.org/standards/redfish](http://www.dmtf.org/standards/redfish).

## NOTE:

- For some URLs, if you execute an unsupported method, the response code may not indicate that the method is unsupported. To see the methods that the URL supports, see the relevant section in this document. You can also use the Get method on the URL and see the supported methods in the response.
- If you perform a Patch operation on multiple attributes, and if some attributes do not get updated due to dependency issues, HTTP code 400 is returned.

# SSL certificates of iDRAC

iDRAC includes a web server that uses the industry-standard SSL security protocol to transfer encrypted data over a network. Built upon asymmetric encryption technology, SSL is widely accepted for providing authenticated and encrypted communication between clients and servers to prevent eavesdropping across a network.

By default, the iDRAC web server has a Dell self-signed SSL digital certificate. Redfish service reuses this certificate installed on the iDRAC web server. You can replace the default SSL certificate with a certificate signed by a well-known Certificate Authority (CA). You can replace SSL certificates using the iDRAC interfaces such as web interface, RACADM, or WSMAN. For more information on managing SSL certificates of iDRAC, see the latest iDRAC User's Guide available at [Dell.com/idracmanuals](http://Dell.com/idracmanuals).

# Eventing

The Redfish service generates asynchronous notifications (events) that are defined by Redfish subscription for the eventing service. These events are sent to an event destination by using HTTP POST method. Events are generated when some significant change or error condition typically of time critical nature occurs. When an event occurs on the service, it notifies the clients. Redfish service must be enabled and iDRAC must be configured to create event subscriptions and to gain read-only privilege for viewing event subscriptions.

The iDRAC implementation of a Redfish service supports only HTTPS notifications. In certain situations, iDRAC may not be able to verify certificates sent by a peer. To handle such situations, iDRAC can be configured to skip certificate verification by using the attribute `iDRAC.RedfishEventing.IgnoreCertificateErrors`. This attribute can be configured to True or False (Default) using RACADM or the WS-MAN interface. Set this attribute to True if certificate validation is not required.

Redfish service provides Lifecycle and Alert events. Lifecycle events may occur when resources are created, modified, or destroyed. Alert events occur when a resource needs to indicate a significant event. Alert events may be either directly or indirectly pertaining to the resource. Examples of these kinds of event are a chassis being opened, button being pressed, cable being unplugged, or threshold being exceeded. iDRAC supports up to 20 event subscriptions.

**NOTE:** In this release, iDRAC supports only Alert event notifications.

If an event delivery fails, the event service of iDRAC retries delivering the failed event. The number of retries and delivery intervals can be configured using the following attributes:

- `iDRAC.RedfishEventing.DeliveryRetryAttempts`
- `iDRAC.RedfishEventing.DeliveryRetryIntervalInSeconds`

## Event delivery retry settings in RACADM

`iDRAC.RedfishEventing.DeliveryRetryAttempts` (Read or Write)

<b>Description</b>	Specifies the number of retry attempts made for Redfish event delivery
<b>Legal values</b>	Value ranges from 0 to 5
<b>Default value</b>	3
<b>Write privilege</b>	Configure iDRAC

`iDRAC.RedfishEventing.DeliveryRetryIntervalInSeconds` (Read or Write)

<b>Description</b>	Specifies the intervals (in seconds) of retry attempts made for Redfish event delivery
<b>Legal values</b>	Value ranges from 5 to 60
<b>Default value</b>	30
<b>Write privilege</b>	Configure iDRAC

## Eventing operations

The Redfish event service provides the following URIs:

**Table 3. Eventing operations**

HTTP method type	Description	URI	Metadata reference
GET	Get detailed information about Event Service	<code>/redfish/v1/EventService</code>	EventService.xml
PATCH	Property Name: ServiceEnabled Indicates whether this service is enabled	<code>/redfish/v1/EventService</code>	EventService_v1.xml
POST	Register an event notification receiver	<code>/redfish/v1/EventService/Subscriptions</code>	EventDestination.xml
DELETE	Remove a subscription	<code>/redfish/v1/EventService/Subscriptions/&lt;Subscription ID&gt;</code>	EventService.xml

## Updating firmware using SimpleUpdate

Using Redfish API you can update the iDRAC, BIOS, and all device firmware. The firmware image can be uploaded locally or using HTTP share. Depending on the component, to apply the update the system automatically reboots or requires a manual reboot.

**NOTE:** Redfish API only supports uploading one firmware image at a time.

# Updating firmware using a local image

To perform a component firmware update using the image file available on the local system:

- 1 To get the value of header ETag, execute GET on **SoftwareInventoryCollection** URL  
`/redfish/v1/UpdateService/FirmwareInventory`
- 2 Upload the package by executing POST on **SoftwareInventoryCollection** with additional header as **Content-Type** and value multipart/form-data and header **if-Match** with ETag as value.

Once the upload is complete, the firmware image is represented with (available package)

```
/redfish/v1/UpdateService/FirmwareInventory/Available
```

along with component and version ids.

- 3 Execute POST on URL **SimpleUpdate** with the available package URL (`/redfish/v1/UpdateService/Actions/UpdateService.SimpleUpdate`) added in payload.

A job id gets created that can be used to check the status of the job.

**NOTE:** The name of the component being updated is not displayed in the JOB ID, instead it is displayed as a Firmware update.

**NOTE:** While the firmware update job is in process, the JobState displays the status as scheduled, check the PercentComplete function to get status of the job.

- 4 Reboot the system to apply the update by executing POST on URL **Reset** (`/redfish/v1/Managers/iDRAC.Embedded.1/Actions/Manager.Reset`).

# Updating firmware using HTTP share

To perform a component firmware update using the image file from HTTP share:

- 1 Execute POST on URL **SimpleUpdate** (`/redfish/v1/UpdateService/Actions/UpdateService.SimpleUpdate`) with an open HTTP share added in the payload.

A job id gets created that can be used to check the status of the job.

**NOTE:** The name of the component being updated is not displayed in the JOB ID, instead it is displayed as a Firmware update.

**NOTE:** While the firmware update job is in process, the JobState displays the status as scheduled, check the PercentComplete function to get the status of the job.

- 2 Reboot the system to apply the update by executing POST on URL **Reset** (`/redfish/v1/Managers/iDRAC.Embedded.1/Actions/Manager.Reset`).

# Query Parameters

There are various query parameters available that can be used to request information from a service. Features like filtering, selecting, and expansion add support for query parameters on GET request to receive additional information. These features are explained below:

- **Select**— The \$select parameter indicates to the implementation that it should return a subset of the properties of the resource based on the value of the select clause.
- **Filter**— The \$filter parameter indicates to the implementation that it should include a subset of the members of a collection based on the expression specified as the value of the filter clause. The \$query parameter is a set of properties and literal values with an operator.
- **Expand**— The \$expand parameter indicates to the implementation that it should include a hyperlink as well as the contents of that hyperlink in the current response as if a GET had been performed and included in line with that hyperlink.

 **NOTE:** The \$expand parameter is not supported for resources under OEM section.

See the section [Examples](#) for the examples of the above parameters.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
400	QueryNotSupported	SYS457
400	MalformedJSON	SYS405
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		



# Redfish resources

This section describes the resource URIs and related operations that are available in the iDRAC implementation of a Redfish service API.

## Topics:

- [AccountService](#)
- [DellJobCollection](#)
- [AttributeRegistry](#)
- [AssemblyCollection](#)
- [BaseMessages](#)
- [Bios](#)
- [Settings resource](#)
- [BootOption](#)
- [ChassisCollection](#)
- [ComputerSystemCollection](#)
- [DellAttributes](#)
- [DellBootSources](#)
- [Settings resource](#)
- [DellBootSourcesRegistry](#)
- [DellCertificatesCollection](#)
- [DellController](#)
- [DellIDRACCardCollection](#)
- [DellIDRACCard](#)
- [DellIDRACCardService](#)
- [DellEnclosureCollection](#)
- [DellEnclosure](#)
- [DellEnclosureEMMCollection](#)
- [DellEnclosureEMM](#)
- [DellEnclosureFanSensorCollection](#)
- [DellEnclosureFanSensor](#)
- [DellEnclosurePowerSupplyCollection](#)
- [DellEnclosurePowerSupply](#)
- [DellEnclosureTemperatureSensorCollection](#)
- [DellEnclosureTemperatureSensor](#)
- [DellFCCollection](#)
- [DellFC](#)
- [DellFCStatisticsCollection](#)
- [DellFCStatistics](#)
- [DellJobService](#)
- [DellLCService](#)
- [DellLicenseCollection](#)
- [DellLicenseManagementService](#)

- DellMemoryCollection
- DellMemory
- DellNICCapabilitiesCollection
- DellNIC
- DellNICCapabilitiesCollection
- DellNICCapabilities
- DellNICStatisticsCollection
- DellNICStatistics
- DellNumericSensorCollection
- DellNumericSensor
- DellOSDeploymentService
- DellPCleSSDExtenderCollection
- DellPCleSSDExtender
- DellPCleSSDCollection
- DellPCleSSD
- DellPCleSSDBackPlaneCollection
- DellPCleSSDBackPlane
- DellPCleFunctionCollection
- DellPCleFunction
- DellPersistentStorageService
- DellPhysicalDiskCollection
- DellPhysicalDisk
- DellPresenceAndStatusSensorCollection
- DellPresenceAndStatusSensor
- DellPowerSupplyCollection
- DellPowerSupply
- DellPowerSupplyViewCollection
- DellPowerSupplyView
- DellProcessorCollection
- DellProcessor
- DellRaidService
- DellSensorCollection
- DellSensor
- DellSoftwareInstallationService
- DellSwitchConnectionCollection
- DellSwitchConnection
- DellSystem
- DellvFlashCollection
- DellvFlash
- DellVirtualDiskCollection
- DellVirtualDisk
- DellServiceRoot
- DellUpdateService
- DellManager
- Drive
- EthernetInterfaceCollection
- EthernetInterfaces

- EventService
- FabricCollection
- PCIe
- HostInterfaceCollection
- JSONSchemas
- LogEntryCollection
- LogService
- LogServiceCollection
- ManagerCollection
- ManagerAccountCollection
- ManagerNetworkProtocol
- MemoryCollection
- MessageRegistryFile
- MessageRegistryFileCollection
- Messages
- NetworkAdapterCollection
- NetworkInterfaceCollection
- PCIeDevice
- PCIeFunction
- Port
- PortCollection
- Power
- PrivilegeRegistry
- ProcessorCollection
- Role
- RoleCollection
- SecureBoot
- SerialInterfaceCollection
- ServiceRoot
- Session
- SessionService
- SimpleStorage
- SoftwareInventoryCollection
- StorageCollection
- StorageController
- Subscriptions
- Switches
- TaskCollection
- TaskService
- Thermal
- UpdateService
- VirtualMedia
- VlanNetworkInterface
- VolumeCollection
- NetworkPort
- NetworkPortCollection
- NetworkDeviceFunctionCollection

# AccountService

## Description

The AccountService schema contains properties for managing user accounts. The properties are common to all user accounts, such as password requirements, and control features such as account lockout. The schema also contains links to the collections of Manager Accounts and Roles.

## URL

`/redfish/v1/Managers/iDRAC.Embedded.1/AccountService`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# DellJobCollection

## Description

A Collection of Job resource instances.

## URL

`/redfish/v1/Managers/iDRAC.Embedded.1/Jobs`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login
GET	Login

Table 4. Status codes

HTTP status code	Extended Information	Error Code
200		
202	Base.1.2.Success	SYS413
400		SYS446

## Navigation URL

```
/redfish/v1/Managers/iDRAC.Embedded.1/Jobs/<id>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
DELETE	ConfigureComponents, Login
GET	Login

## Updatable Properties

Property	Value
JobType	FirmwareUpdate, FirmwareRollback, RepositoryUpdate, RebootPowerCycle, RebootForce, RebootNoForce, Shutdown
JobState	New, Scheduled, Running, Completed, unknown

Table 5. Status codes

HTTP status code
200
404

# AttributeRegistry

## Description

An Attribute Registry is a set of key-value pairs that are specific to a particular implementation or product. This schema describes the structure of a registry and also includes mechanisms for building user interfaces allowing consistent navigation of the contents.

## URL

- Manager:  
`/redfish/v1/Registries/ManagerAttributeRegistry/ManagerAttributeRegistry.v1_0_0.json`
- BIOS:  
`/redfish/v1/Registries/BiosAttributeRegistry.v1_0_0`

## Methods and privileges

Table 6. Methods and privileges for AttributeRegistry

HTTP method	Required privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## AssemblyCollection

### Description

This is the schema definition for the Assembly properties.

# URL

/redfish/v1/Chassis/System.Embedded.1/Assembly

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## Navigation URL

/redfish/v1/Chassis/System.Embedded.1/Assembly/<id>

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# BaseMessages

## Description

This resource is used to represent the base message registry for a Redfish implementation.

## URL

`/redfish/v1/Registries/BaseMessages`

## HTTP methods and privileges

Table 7. HTTP methods and privileges for BaseMessages

HTTP method	Required privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## Bios

### Description

The Bios schema contains properties related to the BIOS Attribute Registry. The Attribute Registry describes the system-specific BIOS attributes and Actions for changing to BIOS settings. Changes to the BIOS typically require a system reset before they take effect.

### URL

`/redfish/v1/Systems/System.Embedded.1/Bios`



## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
400	Base.1.2.GeneralError	IDRAC.1.6.RAC1035
405		SYS402

[Supported Action — ChangePassword](#)

[Supported Action — ClearPending](#)

[Supported Action — ResetBios](#)

[Settings resource](#)

## Supported Action — ChangePassword

### Description

This action is used to change the BIOS passwords.

### URL

```
/redfish/v1/Systems/System.Embedded.1/Bios/Actions/Bios.ChangePassword
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.2.Success	RAC1133
405	Base.1.2.GeneralError	SYS402

## Supported Action — ClearPending

### Description

This action is used to clear all the pending values.

### URL

```
/redfish/v1/Systems/System.Embedded.1/Bios/Settings/Actions/Oem/DellManager.ClearPending
```

### Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login

### Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400	Base.1.2.GeneralError	RAC1035

## Supported Action — ResetBios

### Description

This action is used to reset the BIOS attributes to default.

### URL

```
/redfish/v1/Systems/System.Embedded.1/Bios/Actions/Bios.ResetBios
```

### Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.2.Success	RAC1133
405	Base.1.2.GeneralError	SYS402

## Settings resource

### Description

This resource is used for representing the pending configuration and related resources to clear pending and navigation to Jobs resource.

### URL

- BIOS:  
`/redfish/v1/Systems/<ID>/Bios/Settings`
- Attributes:  
`/redfish/v1/Managers/<ID>/Attributes/Settings`

## HTTP methods and privileges

Table 8. HTTP methods and privileges for the Settings resource

HTTP method	Required privilege
GET	Login
PATCH	ConfigureComponents, Login

## Updatable properties

Table 9. Properties for the Settings resource

Property	Description
Attributes	Collection of all the attributes and their values supported by the BIOS configuration

# Status codes

Table 10. Status codes for the Settings resource

HTTP status code	Extended information	Error Code
202		
400	<ul style="list-style-type: none"><li>Base.1.2.PropertyMissing</li><li>Base.1.0.PropertyValueTypeError</li><li>Base.1.0.PropertyValueNotInList</li></ul>	
400		SYS426, SYS011, SYS428, SYS405, SUP017, SUP447
403		
500		

# BootOption

## Description

A Collection of BootOption resource instances.

## URL

/redfish/v1/Systems/System.Embedded.1/BootOptions

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405	Base.1.2.GeneralError	SYS402
500	Base.1.2.InternalError	SYS446
503		

## Instance URL

/redfish/v1/Systems/System.Embedded.1/BootOptions/<id>

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login
PATCH	ConfigureComponents, Login

## Updatable Properties

- BootOptionEnabled

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.2.Success	SYS430, SYS455
400	Base.1.2.InternalError	SYS446
400	Base.1.2.PropertyMissing	
400	Base.1.2.MalformedJSON	SYS405
400		SYS406, SYS434
403	InsufficientPrivilege	RAC0506
403		LIC501
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446

## ChassisCollection

### Description

A Collection of Chassis resource instances.

### URL

/redfish/v1/Chassis

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## Navigation URL

/redfish/v1/Chassis/<id>

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login
PATCH	ConfigureManager, Login
POST	ConfigureManager, Login

## Updatable Properties

Property	Value
ResetType	On, Off
IndicatorLed	Blinking, Off
ChassisType	Rack, Blade, Enclosure, StandAlone, Sled, Other

# Supported Status Codes

HTTP Status Code	Extended Information
200	Base.1.0.success
400	<ul style="list-style-type: none"><li>Base.1.0.PropertyValueTypeError</li><li>Base.1.0.PropertyValueNotInList</li><li>Base.1.0.PropertyUnknown</li><li>Base.1.0.PropertyNotWritable</li><li>Base.1.0.PropertyValueFormatError</li></ul>
500	Base.1.0.InternalError

Supported action — Reset

Supported action — ClearPending

## Supported action — Reset

### Description

This action is used to reset the chassis. This action resets the chassis, not Systems or other contained resources, although side effects may occur which affect those resources.

### URL

```
/redfish/v1/Chassis/System.Embedded.1/Actions/Chassis.Reset
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login

## Action Parameters

Parameter	Value
Reset	On, ForceOff
ChassisType	Rack, Blade, Enclosure, StandAlone, Sled, Other
IndicatorLED	Blinking, Off
PowerState	On, Off
IntrusionSensor	Normal, HardwareIntrusion, null
IntrusionSensorReArm	Manual, null

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
204		
400	Base.1.2.PropertyValueNotInList	SYS426
404	Base.1.2.ResourceMissingAtURI	SYS403
409		PSU501, PSU502
500	Base.1.2.InternalError	SYS446

Supported action — ClearPending

## Contained resources

Power  
Thermal

# ComputerSystemCollection

## Description

This resource is used to represent resources that represent a computing system in the Redfish specification.

## URL

/redfish/v1/Systems

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446



503

## Navigation URL

```
/redfish/v1/Systems/<id>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login
GET	Login
PATCH	ConfigureComponents, Login

## Updatable Properties

### Property

BootOrder  
 BootSourceOverrideEnabled  
 BootSourceOverrideMode  
 BootSourceOverrideTarget  
 UefiTargetBootSourceOverride

## Supported Status Codes

HTTP Status Code	Extended Information
200	Base.1.0.success
400	Base.1.0.PropertyValueTypeError, Base.1.0.PropertyValueNotInList, Base.1.0.PropertyUnknown, Base.1.0.PropertyNotWritable, Base.1.0.PropertyValueFormatError
500	Base.1.0.InternalError

[Supported Action — Reset](#)

## Supported Action — Reset

### Description

This action is used to reset the system.

# URL

/redfish/v1/Systems/System.Embedded.1/Actions/ComputerSystem.Reset

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login

## Supported Parameters

Parameter	Value
ResetType	On, ForceOff, ForceRestart, GracefulShutdown, PushPowerButton, Nmi
SystemType	Physical
IndicatorLED	Blinking, Off
PowerState	On, null
BootSourceOverrideTarget	None, Pxe, Floppy, Cd, Hdd, BiosSetup, Utilities, UefiTarget, SDCard, UefiHttp
BootSourceOverrideEnabled	Once, Continuous, Disabled
MemoryMirroring	None, System
BootSourceOverrideMode	UEFI, Legacy
InterfaceType	TCM1_0, TPM2_0, TPM1_2

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
204		
400	PropertyValueTypeError	
400	Base.1.2.PropertyValueNotInList	SYS426
404	Base.1.2.ResourceMissingAtURI	SYS403
409		PSU501, PSU502
500	Base.1.2.InternalError	SYS446

# DellAttributes

## Description

DellAttributes contains properties of additional properties to complement the Attribute Registry DMTF schema. It contains attributes surrounding attribute registry and Actions needed to perform changes to settings, which typically doesn't require a manager reset to apply.

# URL

`/redfish/v1/Managers/<ID>/Attributes`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login
PATCH	SystemControl

## Updatable properties

Property	Description
Attributes	Collection of all the attributes and their values supported by the iDRAC configuration.

Table 11. Status codes

HTTP status code	Extended information
200	Base.1.0.Success
400	Base.1.0.PropertyValueNotInList, Base.1.0.PropertyValueTypeError
500	Base.1.0.InternalError

## Supported action —ClearPending

### Description

This action is used to clear all the pending values.

# URL

`/redfish/v1/Managers/System.Embedded.1/Attributes/Settings/Actions/Oem/DellManager.ClearPending`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureManager, Login

## Status codes

Table 12. Status codes for the Settings resource

HTTP status code	Extended information	Error Code
200		
400		RAC1035, HWC0001, RAC947
404	Base.1.2.ResourceMissingAtURI	SYS403
500	Base.1.2.InternalError	SYS446

## DellBootSources

### Description

This resource is used to represent the Dell Boot Sources Configuration and the related resources to the settings resource.

### URL

```
/redfish/v1/Systems/<ID>/BootSources
```

### HTTP methods and privileges

Table 13. HTTP methods and privileges for DellBootSources

HTTP method	Required privilege
GET	Login

### Status codes

Table 14. Status codes for DellBootSources

HTTP status code	Extended information	Error Code
200		
405		SYS402

# Settings resource

## Description

This resource is used to represent the Boot Sources pending configuration and related resources to clear pending and navigation to Jobs resource.

## URL

```
/redfish/v1/Systems/<ID>/BootSources/Settings
```

## HTTP methods and privileges

Table 15. HTTP methods and privileges for the Settings resource

HTTP method	Required privilege
GET	Login
PATCH	SystemControl
POST	ConfigureComponents, Login

## Updatable properties

Table 16. Properties for the Settings resource

Property	Description
Attributes	Collection of all the attributes and their values supported for Boot Sources.

## Status codes

Table 17. Status codes for the Settings resource

HTTP status code	Extended information	Error Code
202		
400	<ul style="list-style-type: none"><li>Base.1.2.PropertyMissing</li><li>Base.1.0.PropertyValueTypeError</li><li>Base.1.0.PropertyValueNotInList</li></ul>	
400		SYS426, SYS011, SYS428, SYS405, SUP017, SUP447
403		

500

# DellBootSourcesRegistry

## Description

A Boot Sources Registry is a set of key-value pairs that are specific to a particular implementation or product. This schema describes the structure of a registry and also includes mechanisms for building user interfaces allowing consistent navigation of the contents.

## URL

```
/redfish/v1/Systems/<ID>/BootSources/BootSourcesRegistry
```

## HTTP methods and privileges

Table 18. HTTP methods and privileges for DellBootSourcesRegistry

HTTP method	Required privilege
GET	Login

## Status codes

Table 19. Status codes for DellBootSourcesRegistry

HTTP status code	Extended information
200	Base.1.0.Success
500	Base.1.0.InternalError

# DellCertificatesCollection

## Description

This resource is used to represent Secure Boot certificates for a Redfish implementation.

## URL

```
/redfish/v1/Systems/<ID>/SecureBoot/Certificates
```

# HTTP methods and privileges

Table 20. HTTP methods and privileges for DellCertificates

HTTP method	Required privilege
GET	Login

# Status codes

Table 21. Status codes for DellCertificates

HTTP status code	Extended information
200	Base.1.0.Success
400	Base.1.0.PropertyValueTypeError, Base.1.0.PropertyValueNotInList
403	Base.1.0. InsufficientPrivilege
500	Base.1.0.InternalError

# Navigation URL

/redfish/v1/Systems/<ID>/SecureBoot/Certificates/<CertificateStore-ID>

# HTTP methods and privileges

Table 22. HTTP methods and privileges for the instance of CertificateStore

HTTP method	Required privilege
GET	Login
POST	SystemControl

# Updatable properties

Table 23. Properties for the instance of CertificateStore

Parameter	Description
CryptographicHash	A string providing the Cryptographic Hash value of SHA256, SHA384, or SHA512.

# Status codes

Table 24. Status codes for the instance of CertificateStore

HTTP status code	Extended information
200	Base.1.0.Success
400	<ul style="list-style-type: none"><li>Base.1.0.PropertyValueTypeError</li><li>Base.1.0.PropertyValueNotInList</li></ul>
403	Base.1.0. InsufficientPrivilege
500	Base.1.0.InternalError

# Navigation URL

```
/redfish/v1/Systems/<ID>/SecureBoot/Certificates/<CertificateStore-ID>/<Certificate-ID>
```

# HTTP methods and privileges

Table 25. HTTP methods and privileges for instance of Certificate

HTTP method	Required privilege
GET	Login
DELETE	SystemControl

**NOTE:** By default, GET requests on the Certificate member resource generate an output of application/json. Use GET request with Accept header application/pkix-cert to download certificate and use application/octet-stream to download the Hash files.

# Status codes

Table 26. Status codes for the instance of Certificate

HTTP status code	Extended information
200	Base.1.0.Success
400	<ul style="list-style-type: none"><li>Base.1.0.PropertyValueTypeError</li><li>Base.1.0.PropertyValueNotInList</li></ul>
403	Base.1.0. InsufficientPrivilege
500	Base.1.0.InternalError



# DellController

## Description

An instance of DellController will have RAID Controller specific data.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/Storage/DellController/<id>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

Table 27. Status codes

HTTP status code
200
404

# DelliDRACCardCollection

## Description

A collection of DelliDRACCard resource

## URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DelliDRACCardCollection
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

# Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		

## DelliDRACCard

### Description

An instance of DelliDRACCard will have data specific to the Integrated Dell Remote Access Controller (iDRAC) in the managed system.

### URL

`/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DelliDRACCard/<id>`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

Table 28. Status codes

HTTP status code
200
404

## DelliDRACCardService

### Description

The DelliDRACCardService resource provides support for actions intended for features specific to iDRAC.

### URL

`/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DelliDRACCardService`

# Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

Table 29. Status codes

HTTP status code
200
404

- Supported Action — ExportSSLCertificate
- Supported Action — iDRACReset
- Supported Action — ImportSSLCertificate
- Supported Action — iDRACResetCfg

## Supported Action — ExportSSLCertificate

### Description

This action is used to export SSL certificate from iDRAC. Based on input parameter type ExportSSLCertificate returns the certificate.

### URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DelliDRACCardService/Actions/DelliDRACCardService.ExportSSLCertificate
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureManager, Login

### Action Parameters

Parameter	Type	Value	Description
SSLCertificateType	ENUM	CA, CSC, ClientTrustCertificate, Server	The type of the certificate to be exported.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	LC067
400	<null>	LC074

## Supported Action — iDRACReset

### Description

This action is used to reset iDRAC.

### URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellIDRACCardService/Actions/DellIDRACCardService.iDRACReset
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureManager, Login

## Action Parameters

Parameter	Type	Value	Description
Force	ENU M	Force, Graceful	This option is used to reset the iDRAC by force or gracefully.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	RAC064
400		RAC065, RAC071, RAC073

## Supported Action — iDRACResetCfg

### Description

This action is used to reset the iDRAC to the factory default configurations.

## URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellIDRACCardService/Actions/DellIDRACCardService.iDRACResetCfg
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureManager, Login

## Action Parameters

Parameter	Type	Value	Description
Force	EN UM	Force, Graceful	This option is used to reset the iDRAC to factory defaults by force or gracefully.
Preserve	EN UM	All, Default, ResetAllWithRoot tDefaults	<ul style="list-style-type: none"><li>• Default—Reset all configuration to default except network and users.</li><li>• All—Reset all configuration to default including network and users.</li><li>• ResetAllWithRootDefaults—Reset all configuration to default including network preserve default user as root/calvin.</li></ul>

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	RAC066
400	<null>	RAC067, RAC072, RAC074, RAC095

## Supported Action — ImportSSLCertificate

### Description

This action is used to import the SSL certificate to iDRAC, on the basis of input parameter type. After importing the certificate, iDRAC automatically restarts.

## URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellIDRACCardService/Actions/DellIDRACCardService.ImportSSLCertificate
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureManager, Login

## Action Parameters

Parameter	Type	Value	Description
Certificate Type	ENUM	CA, CSC, ClientTrustCertificate, Server	Type of the certificate to be imported.
Passphrase	String		A passphrase for certificate file. Note: This is optional parameter for CSC certificate, and not required for Server and CA certificates.
SSLCertificateFile	String		A base-64 encoded string of the XML Certificate file. Note: For importing CSC certificate, user has to convert PKCS file to base64 format. Use the openssl command. The CTC file content must be in PEM the format (base-64 encoded).

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	
400		LC011, LC077, RAC095, DH010

# DellEnclosureCollection

## Description

A collection of DellEnclosure resource.

## URL

```
/redfish/v1/Dell/Chassis/System.Embedded.1/DellEnclosureCollection
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

**Table 30. Status codes**

**HTTP status code**

---

200

404

## DellEnclosure

### Description

An instance of DellEnclosure will have storage enclosure specific data.

### URL

`/redfish/v1/Dell/Chassis/System.Embedded.1/DellEnclosure/<Enclosure ID>`

### Supported HTTP Method and Privileges

**HTTP Method**

**Required Privilege**

---

GET

Login

**Table 31. Status codes**

**HTTP status code**

---

200

404

## DellEnclosureEMMCollection

### Description

A collection of DellEnclosureEMM resource.

### URL

`/redfish/v1/Dell/Chassis/System.Embedded.1/DellEnclosureEMMCollection`

# Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

Table 32. Status codes

HTTP status code
200
404

## DellEnclosureEMM

### Description

An instance of DellEnclosureEMM contains Enclosure Management Module specific data.

### URL

```
/redfish/v1/Dell/Chassis/System.Embedded.1/DellEnclosureEMM/<ID>
```

# Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

Table 33. Status codes

HTTP status code
200
404

## DellEnclosureFanSensorCollection

### Description

A collection of DellEnclosureFanSensor resource.



# URL

`/redfish/v1/Dell/Chassis/System.Embedded.1/DellEnclosureFanSensorCollection`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

**Table 34. Status codes**

HTTP status code
200
404

# DellEnclosureFanSensor

## Description

An instance of DellEnclosureFanSensor contains Storage Enclosure fan sensor specific data.

# URL

`/redfish/v1/Dell/Chassis/System.Embedded.1/DellEnclosureFanSensor/<ID>`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

**Table 35. Status codes**

HTTP status code
200
404

# DellEnclosurePowerSupplyCollection

## Description

A collection of DellEnclosurePowerSupply resource.

## URL

```
/redfish/v1/Dell/Chassis/System.Embedded.1/DellEnclosurePowerSupplyCollection
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

Table 36. Status codes

HTTP status code
200
404

# DellEnclosurePowerSupply

## Description

An instance of DellEnclosurePowerSupply contains Storage Enclosure power supply unit specific data.

## URL

```
/redfish/v1/Dell/Chassis/System.Embedded.1/DellEnclosurePowerSupply/<ID>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

**Table 37. Status codes**

**HTTP status code**

---

200

404

# DellEnclosureTemperatureSensorCollection

## Description

A collection of DellEnclosureTemperatureSensor resource.

## URL

`/redfish/v1/Dell/Chassis/System.Embedded.1/DellEnclosureTemperatureSensorCollection`

## Supported HTTP Method and Privileges

**HTTP Method**

**Required Privilege**

---

GET

Login

**Table 38. Status codes**

**HTTP status code**

---

200

404

# DellEnclosureTemperatureSensor

## Description

An instance of DellEnclosureTemperatureSensor will have Storage Enclosure temperature sensor specific data.

## URL

`/redfish/v1/Dell/Chassis/System.Embedded.1/DellEnclosureTemperatureSensor/<ID>`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

Table 39. Status codes

HTTP status code
200
404

## DellFCCollection

### Description

A collection of Dell Fiber Channel resource.

### URL

```
/redfish/v1/Dell/Chassis/System.Embedded.1/NetworkAdapters/DellFCCollection
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

## DellFC

### Description

An instance of DellFC contains data specific to Fiber Channel devices.

## URL

/redfish/v1/Dell/Chassis/System.Embedded.1/NetworkAdapters/DellFC/<ID>

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		

## DellFCStatisticsCollection

### Description

A collection of Dell Fiber Channel Statistics resource.

## URL

/redfish/v1/Dell/Chassis/System.Embedded.1/NetworkPorts/DellFCStatisticsCollection

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

# DellFCStatistics

## Description

An instance of DellFCStatistics will have the statistics of the Fiber Channel HBA port.

## URL

```
/redfish/v1/Dell/Chassis/System.Embedded.1/NetworkPorts/DellFCStatistics/<ID>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

# DellJobService

## Description

The DellJobService resource provides some actions to support Job management functionality.

## URL

```
/redfish/v1/Dell/Managers/<ID>/DellJobService
```

## HTTP methods and privileges

Table 40. HTTP methods and privileges for DellJob

HTTP method	Required privilege
GET	Login
POST	SystemControl

**Table 41. Status codes**

**HTTP status code**

---

200

404

Supported Action — [DeleteJobQueue](#)

Supported Action — [SetupJobQueue](#)

## Supported Action — DeleteJobQueue

### Description

The DeleteJobQueue action is used for deleting jobs from the JobQueue or the job store. To clear all the jobs, use the keyword JID\_CLEARALL for the JobID. Successful execution of this method with the JID\_CLEARALL parameter value also clears all the pending attribute values. When the number of jobs in the JobQueue reaches the maximum limit, jobs in the Completed state are deleted automatically.

**NOTE:** On the older PowerEdge systems, jobs in the Failed state are not deleted automatically and must be removed manually one at a time, or all together using the keyword JID\_CLEARALL.

### URL

`/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellJobService/Actions/DellJobService.DeleteJobQueue`

### Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login

### Action Parameters

Parameter	Type	Value	Description
JobID	String		The JobID parameter specifies the job to be deleted. The value "JID_CLEARALL" for the JobID clears all the jobs.

### Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	SUP020
400	Base.1.0.PropertyMissing	JCP013
400	<null>	JCP012, JCP015, SUP011

# Supported Action — SetupJobQueue

## Description

This method is used for creating a job queue that shall contain one or more DellJobs with a specified order of execution within the queue.

## URL

`/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellJobService/Actions/DellJobService.SetupJobQueue`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login

## Action Parameters

Parameter	Type	Value	Description
JobArray	String		The JobArray parameter will contain the array of JobIDs which represent the set of jobs to add to the job queue. This is an ordered array that represents the sequence in which the jobs are run.
StartTimeInterval	String		Start time for the job execution in the format <code>yyyymmddhhmmss</code> . The string "TIME_NOW" indicates immediate start.
UntilTime	String		End time for the job execution in the format <code>yyyymmddhhmmss</code> . If this parameter is not NULL then the StartTimeInterval parameter must be specified.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	JCP010
400	Base.1.0.PropertyMissing	JCP013
400	<null>	JCP011, JCP012, JCP014, JCP015, JCP016, SUP011, SUP017, SUP018, SUP022, SUP023

# DellLCService

## Description

The DellLCService resource provides some actions to support Lifecycle Controller functionality.



## URL

/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLCService

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
400	Maximum job limit reached, cannot create new jobs	JCP017

- Supported Action — [ExportFactoryConfiguration](#)
- Supported Action — [BackupImage](#)
- Supported Action — [ClearProvisioningServer](#)
- Supported Action — [GetRSSStatus](#)
- Supported Action — [ExportLCLog](#)
- Supported Action — [GetRemoteServicesAPIStatus](#)
- Supported Action — [ExportTechSupportReport](#)
- Supported Action — [ExportHWInventory](#)
- Supported Action — [LCWipe](#)
- Supported Action — [ReInitiateDHS](#)
- Supported Action — [RestoreImage](#)

## Supported Action — BackupImage

### Description

The BackupImage action is used for backing-up the firmware and configurations for Lifecycle Controller.

## URL

/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLCService/Actions/DellLCService.BackupImage

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Action Parameters

Parameter	Type	Value	Description
CheckBackupDestinationAvailability	ENUM	Check, DoNotCheck	Check backup destination availability. Default is Check.
IgnoreCertificateWarning	ENUM	Off, On	Specifies if certificate warning should be ignored when HTTPS is specified. Default is On.
ProxySupport	ENUM	DefaultProxy, Off, ParametersProxy	Specifies if proxy should be used. Default is Off.
ProxyType	ENUM	HTTP, SOCKS	The proxy type of the proxy server. Default is HTTP.
ShareType	ENUM	CIFS, HTTP, HTTPS, Local, NFS, VFLASH	If ShareType is blank or null, it shall be considered as NFS type. The parameter shall be required, if the ShareType parameter has value NFS, CIFS, or not specified.
IPAddress	String		IP address of the NFS or CIFS share such as 192.168.10.12. The parameter shall be required, if the ShareType parameter has value NFS, CIFS, or not specified.
ImageName	String		The name of the backup file. The parameter shall be required, if the ShareType parameter has value NFS, CIFS, or not specified.
JobName	String		A name for the job. Default is "Backup:Image"
Passphrase	String		The passphrase for the image. The parameter shall be required, if the ShareType parameter has value NFS, CIFS, or not specified.
Password	String		The password for the remote share.
ProxyPassword	String		The password for the proxy server.
ProxyPort	String		Port for the proxy server. Default is set to 80.
ProxyServer	String		The IP address of the proxy server.
ProxyUsername	String		The user name for the proxy server.
ScheduledStartTime	String		The start time for the job execution in format: yyyyymmddhhmmss. The string "TIME_NOW" means immediate.
ShareName	String		Share name for the network share such as "imageshare". The parameter shall be required, if the ShareType parameter has value NFS, CIFS, or not specified. Sharename shall be considered as a path to a sub-folder in case of HTTP/HTTPS.

Parameter	Type	Value	Description
UntilTime	String		End time for the job execution in format: yyyyymmddhhmmss. : If this parameter is not NULL, then ScheduledStartTime parameter shall also be specified.
UserName	String		The user name for the remote share
Workgroup	String		The Workgroup for the share.
UntilTime	String		Scheduled end time for job execution in datetime format: yyyyymmddhhmmss. If not specified, there is no end time.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400	Maximum job limit reached, cannot create new jobs	JCP017
400	<null>	JCP018, JCP019, LC002, LC017, LC023, LC051, SUP017, SUP018

## Supported Action — ClearProvisioningServer

### Description

The ClearProvisioningServer action is used for clearing the provisioning server values.

### URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLCService/Actions/DellLCService.ClearProvisioningServer
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400		LC002

# Supported Action — ExportFactoryConfiguration

## Description

The ExportFactoryConfiguration action is used for exporting the factory configuration from Lifecycle Controller to a remote share.

## URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLCService/Actions/  
DellLCService.ExportFactoryConfiguration
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Action Parameters

Parameter	Type	Value	Description
IgnoreCertificateWarning	ENUM	Off, On	Specifies if certificate warning should be ignored when HTTPS is specified. Default is On.
ProxySupport	ENUM	DefaultProxy, Off, ParametersProxy	Specifies if proxy should be used. Default is Off.
ProxyType	ENUM	HTTP, SOCKS	The proxy type of the proxy server. Default is HTTP.
ShareType	ENUM	CIFS, HTTP, HTTPS, Local, NFS, VFLASH	If ShareType is blank or null, it shall be considered as NFS type. The parameter shall be required, if the ShareType parameter has value NFS, CIFS, or not specified.
IPAddress	String		IP address of the NFS or CIFS share such as 192.168.10.12. The parameter shall be required, if the ShareType parameter has value NFS, CIFS, or not specified.
Password	String		The password for the remote share.
ProxyPassword	String		The password for the proxy server.
ProxyPort	String		Port for the proxy server. Default is set to 80.
ProxyServer	String		The IP address of the proxy server.
ProxyUsername	String		The user name for the proxy server.

Parameter	Type	Value	Description
FileName	String		The target output file name. A file name is not required if the share type is Local.
ShareName	String		Share name for the network share such as "imageshare". The parameter shall be required, if the ShareType parameter has value NFS, CIFS, or not specified. Sharename shall be considered as a path to a sub-folder in case of HTTP/HTTPS.
UserName	String		The user name for the remote share
Workgroup	String		The Workgroup for the share.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400	Maximum job limit reached, cannot create new jobs	JCP017

## Supported Action — ExportLCLog

### Description

The ExportLCLog action is used for exporting the log from the Lifecycle Controller to a remote share.

### URL

`/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLCService/Actions/DellLCService.ExportLCLog`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Action Parameters

Parameter	Type	Value	Description
IgnoreCertWarning	ENUM	Off, On	Specifies if certificate warning should be ignored when HTTPS is specified. Default is On.
ProxySupport	ENUM	DefaultProxy, Off, ParametersProxy	Specifies if proxy should be used. Default is Off.

Parameter	Type	Value	Description
ProxyType	ENUM	HTTP, SOCKS	The proxy type of the proxy server. Default is HTTP.
ShareType	ENUM	CIFS, HTTP, HTTPS, Local, NFS, VFLASH	If ShareType is blank or null, it shall be considered as NFS type. The parameter shall be required, if the ShareType parameter has value NFS, CIFS, or not specified.
IPAddress	String		IP address of the NFS or CIFS share such as 192.168.10.12. The parameter shall be required, if the ShareType parameter has value NFS, CIFS, or not specified.
Password	String		The password for the remote share.
ProxyPasswd	String		The password for the proxy server.
ProxyPort	String		Port for the proxy server. Default is set to 80.
ProxyServer	String		The IP address of the proxy server.
ProxyUname	String		The user name for the proxy server.
FileName	String		The target output file name. A file name is not required if the share type is Local.
ShareName	String		Share name for the network share such as "imageshare". The parameter shall be required, if the ShareType parameter has value NFS, CIFS, or not specified. Sharename shall be considered as a path to a sub-folder in case of HTTP/HTTPS.
UserName	String		The user name for the remote share
Workgroup	String		The Workgroup for the share.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400	Maximum job limit reached, cannot create new jobs	JCP017
400	Base.1.0.PropertyMissing	LC016
400	<null>	JCP018, JCP019, LC017, LC022, LC023, LC030, LC037, LC040

# Supported Action — ExportHWInventory

## Description

The ExportHWInventory action is used for exporting the hardware inventory from the Lifecycle Controller to a remote share.

## URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLCService/Actions/DellLCService.ExportHWInventory
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Action Parameters

Parameter	Type	Value	Description
IgnoreCertWarning	EN UM	Off, On	Specifies if certificate warning should be ignored when HTTPS is specified. Default is On.
ProxySupport	EN UM	DefaultProxy, Off, ParametersProxy	Specifies if proxy should be used. Default is Off.
ProxyType	EN UM	HTTP, SOCKS	The proxy type of the proxy server. Default is HTTP.
ShareType	EN UM	CIFS, HTTP, HTTPS, Local, NFS, VFLASH	If ShareType is blank or null, it shall be considered as NFS type. The parameter shall be required, if the ShareType parameter has value NFS, CIFS, or not specified.
XMLSchema	EN UM	CIM-XML, Simple	Type of XML output format. Default is CIM-XML.
IPAddress	String		IP address of the NFS or CIFS share such as 192.168.10.12. The parameter shall be required, if the ShareType parameter has value NFS, CIFS, or not specified.
Password	String		The password for the remote share.
ProxyPasswd	String		The password for the proxy server.
ProxyPort	String		Port for the proxy server. Default is set to 80.
ProxyServer	String		The IP address of the proxy server.
ProxyUname	String		The user name for the proxy server.

Parameter	Type	Value	Description
FileName	String		The target output file name. A file name is not required if the share type is Local.
ShareName	String		Share name for the network share such as "imageshare". The parameter shall be required, if the ShareType parameter has value NFS, CIFS, or not specified. Sharename shall be considered as a path to a sub-folder in case of HTTP/HTTPS.
UserName	String		The user name for the remote share
Workgroup	String		The Workgroup for the share.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
400	Maximum job limit reached, cannot create new jobs	JCP017
400	Base.1.0.PropertyMissing	LC016
400	Base.1.0.PropertyValueFormatError	LC017
400	<null>	JCP018, JCP019, LC023, LC025, LC027, LC029, LC030, LC038, LC040

## Supported Action — ExportTechSupportReport

### Description

This action is used to collect the TSR that includes hardware, OS, and application data. The data is compressed into a zip file and saved on the remote share (CIFS/NFS).

### URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLCService/Actions/DellLCService.ExportTechSupportReport
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login



## Action Parameters

Parameter	Type	Value	Description
ShareType	ENUM	CIFS, NFS	Type of the network share.
DataSelectorArrayIn	ENUM	HWData, OSAppData, OSAppDataWithoutPII, TTYLogs	Array of integer values to select TSR components.
IPAddress	String		IP address of the network share.
Password	String		Password of the account to access the share.
FileName	String		File name of the export tech support report.
ShareName	String		Name of the CIFS share or full path to the NFS share. Optional for HTTP/HTTPS share, which may be treated as the path of the directory containing the file.
UserName	String		The user name for the remote share

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400	<null>	SYS094

## Supported Action — GetRemoteServicesAPIStatus

### Description

The GetRemoteServicesAPIStatus action is used for obtaining the overall remote services API status that includes host system status, the remote services (Data Manager) status, and real-time status. The overall rolled up status is reflected in the Status output parameter.

**NOTE:** The LCStatus output parameter value includes the status reported by the DMStatus output parameter in the GetRSStatus action and the Lifecycle Controller status. Thus, GetRSStatus action invocation is redundant.

### URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLCService/Actions/DellLCService.GetRemoteServicesAPIStatus
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	LC061
400	<null>	LC060

## Supported Action — GetRSStatus

### Description

The GetRSStatus action is used for obtaining the Data Manager (Remote Services) status.

**NOTE:** The `GetRemoteServicesAPIStatus` action execution reports more granular and detailed status of the Remote Services API.

### URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLCService/Actions/DellLCService.GetRSStatus
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	RSI0001
400		RSI0002, RSI0003, RSI0004

# Supported Action — LCWipe

## Description

The LCWipe action is used for deleting all configurations from Lifecycle Controller before the system is retired. Host must be manually rebooted for the changes to take effect.

## URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLCService/Actions/DellLCService.LCWipe
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400	<null>	LC012, LC044

# Supported Action — ReInitiateDHS

## Description

The ReInitiateDHS action is used for reinitiating the provisioning server discovery and handshake.

## URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLCService/Actions/DellLCService.ReInitiateDHS
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Action Parameters

Parameter	Type	Value	Description
PerformAutoDiscovery	Enumeration	Off, Now, NextBoot	A value of "Off = 1" disables auto discovery. A value of "Now = 2" enables and initiates auto discovery immediately. A value of "NextBoot = 3" delays reconfiguration and auto discovery until next AC powercycle. Note—If NextBoot has a value of 3 then after successful execution, the Discovery Factory Defaults attribute is set to "On".
ProvisioningServer	String		This property specifies the provisioning server addresses and ports used for auto discovery. If omitted, Lifecycle Controller gets the value from DHCP or DNS.
ResetToFactoryDefaults	Boolean		If ResetToFactoryDefaults is True, all configuration information is replaced with auto-discovery factory default properties. If False, an error is returned.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400	<null>	LC002, LC004, LC008, LC009

## Supported Action — RestoreImage

### Description

This RestoreImage action is used to restore firmware and configurations.

### URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLCService/Actions/DellLCService.RestoreImage
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Action Parameters

Parameter	Type	Value	Description
IgnoreCertificateWarning	Enumeration	Off, On	Specifies if certificate warning should be ignored when HTTPS is specified. Default is On.
PreserveVDCOnfig	Enumeration	False, True	Specifies whether to preserve the virtual drive configuration.

Parameter	Type	Value	Description
ProxySupport	EN UM	DefaultProxy, Off, ParametersProxy	Specifies if proxy should be used. Default is Off.
ProxyType	EN UM	HTTP, SOCKS	The proxy type of the proxy server. Default is HTTP.
ShareType	EN UM	CIFS, HTTP, HTTPS, Local, NFS, VFLASH	Type of the network share. Default is NFS, when this parameter is not passed.
ImageName	String		Name of the image file.
IPAddress	String		IP address of the NFS or CIFS share such as 192.168.10.12. The parameter is required if the ShareType parameter has value NFS, CIFS, or not specified.
Password	String		The password for the remote share.
ProxyPasswd	String		The password for the proxy server.
ProxyPort	String		Port for the proxy server. Default is set to 80.
ProxyServer	String		The IP address of the proxy server.
ProxyUname	String		The user name for the proxy server.
ScheduledStartTime	String		Schedules the job at the time specified. The format is yyyyymmddhhmmss. Default setting is TIME_NOW, which will start the job immediately.
UntilTime	String		End time for the job execution in format: yyyyymmddhhmmss. If not specified, there is no end time.
FileName	String		The target output file name. A file name is not required if the share type is Local.
ShareName	String		Name of the CIFS share or full path to the NFS share. Optional for HTTP/HTTPS share, which may be treated as the path of the directory containing the file.
UserName	String		The user name for the remote share
Workgroup	String		The Workgroup for the share.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400	<null>	JCP017, JCP018, JCP019, LC002, LC017, LC023, LC052, SUP017, SUP018

# DellLicenseCollection

## Description

A collection of DellLicense resource

## URL

/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLicenseCollection

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

Table 42. Status codes

HTTP status code
200
404

# DellLicenseManagementService

## Description

The DellLicenseManagementService resource provides some actions to support License Management functionality.

## URL

/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLicenseManagementService

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login
GET	Login

**Table 43. Status codes**

**HTTP status code**

---

200  
404

Supported Action — ExportLicenseToNetworkShare  
Supported Action — ImportLicenseFromNetworkShare  
Supported Action — ImportLicense  
Supported Action — ShowLicenseBitsSupported Action — DeleteLicenseSupported Action — ExportLicenseActionSupported Action — ExportLicenseByDeviceToNetworkShare

## Supported Action — ExportLicenseToNetworkShare

### Description

ExportLicenseToNetworkShare is an action used to export License files from IDRAC. The ExportLicenseToNetworkShare action exports a License specified by EntitlementID to a user defined location.

### URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLicenseManagementService/Actions/DellLicenseManagementService.ExportLicenseToNetworkShare
```

### Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

### Action Parameters

Parameter	Type	Value	Description
EntitlementID	String		Entitlement ID of the license being exported.
FileName	String		If included, the exported license is renamed as <FileName>.
IPAddress	String		IP address of the server hosting the network share.
IgnoreCertWarning	ENUM	Off, On	Specifies if certificate warning is to be ignored when HTTPS is specified. If IgnoreCertWarning is on, certificate will be ignored. Default is 1 (Off).
Password	String		Password for Network share authentication.

Parameter	Type	Value	Description
ProxyPasswd	String		The password to log in to the proxy server.
ProxyPort	String		Port for the proxy server. Default is set to 80.
ProxyServer	String		The IP Address of the proxy server.
ProxySupport	ENUM	Off, DefaultProxy, ParametersProxy	Specifies if proxy is to be used or not. Default is 1 (Off).
ProxyType	ENUM	HTTP, SOCKS	The proxy type of the proxy server. Default is 0 (HTTP).
ProxyUname	String		The user name for proxy server.
ShareName	String		Name of the CIFS share or full path to the NFS share. Optional for HTTP or HTTPS share, which may be treated as the path of the directory containing the file.
ShareType	ENUM	NFS, CIFS, HTTP, HTTPS	Type of the network share.
UserName	String		Username for the network share authentication.
Workgroup	String		Optional. Workgroup for the CIFS share.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	LIC900
400	<null>	JCP017, LIC001, LIC002, LIC003, LIC004, LIC006, LIC007, LIC008, LIC009, LIC010, LIC011, LIC012, LIC014, LIC016, LIC901, LIC902, LIC903, LIC904

## Supported Action — ImportLicenseFromNetworkShare

### Description

The ImportLicenseFromNetworkShare action imports the license given in the network share location.

### URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLicenseManagementService/Actions/DellLicenseManagementService.ImportLicenseFromNetworkShare
```



## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Action Parameters

Parameter	Type	Value	Description
FQDD	String		FQDD of the device to export licenses to.
IPAddress	String		IP address of the server hosting the network share.
IgnoreCertWarning	ENUM	Off, On	Specifies if certificate warning is to be ignored when HTTPS is specified. If IgnoreCertWarning is On, the certificate will be ignored. Default is 1 (Off).
ImportOptions	ENUM	NoOption, Force, All	Flag to force or install for all similar devices.
LicenseName	String		The file name of the license file to be imported.
Password	String		Password for Network share authentication.
ProxyPasswd	String		The password to log in proxy server.
ProxyPort	String		Port for the proxy server. Default is set to 80.
ProxyServer	String		The IP Address of the proxy server.
ProxySupport	ENUM	Off, DefaultProxy, ParametersProxy	Specifies if proxy is to be used or not. Default is 1 (Off).
ProxyType	ENUM	HTTP, SOCKS	The proxy type of the proxy server. Default is 0 (HTTP).
ProxyUname	String		The username for proxy server.
ShareName	String		Name of the CIFS share or full path to the NFS share. Optional for HTTP/HTTPS share, this may be treated as the path of the directory containing the file.
ShareType	ENUM	NFS, CIFS, HTTP, HTTPS	Type of the network share.
UserName	String		User name for network share authentication.
Workgroup	String		Optional. Workgroup for the CIFS share.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	LIC900
400	<null>	JCP017, LIC001, LIC002, LIC003, LIC004, LIC006, LIC007, LIC008, LIC009, LIC010, LIC011, LIC012, LIC014, LIC016, LIC901, LIC902, LIC903, LIC904, LIC905, LIC906

## Supported Action — ImportLicense

### Description

The ImportLicense() method imports the License given in the input parameter to the License Manager Data Store.

### URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLicenseManagementService/Actions/DellLicenseManagementService.ImportLicense
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Action Parameters

Parameter	Type	Value	Description
FGDD	String		FGDD of the device to apply the license to.
ImportOptions	ENUM	NoOption, Force, All	Flag to force or install for all similar devices.
LicenseFile	String		A base-64 encoded string of the XML License file.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	LIC900
400	<null>	JCP017, LIC001, LIC002, LIC003, LIC004, LIC006, LIC007, LIC008, LIC009, LIC010, LIC011, LIC012, LIC014, LIC016, LIC901, LIC902, LIC903, LIC904

# Supported Action — ShowLicenseBits

## Description

The ShowLicenseBits action is used to retrieve the iDRAC feature license bit string for the Licenses in iDRAC in a hexadecimal representation of a 256 bit-string. To read the output, you'll need to see which bit position is TRUE from right-to-left. Please refer to the Appendix section that will show which bit represents what feature.

## URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLicenseManagementService/Actions/  
DellLicenseManagementService.ShowLicenseBits
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		

# Supported Action — DeleteLicense

## Description

This action is used to delete assigned licenses. The DeleteLicense action deletes a specific license from all devices it is assigned to if only the EntitlementID parameter is present, all licenses from a specific device if only the FQDD parameter is present, or a specific license from a specific device if both the EntitlementID and FQDD parameters are present. Either the EntitlementID or FQDD parameter shall be present.

## URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLicenseManagementService/Actions/  
DellLicenseManagementService.DeleteLicense
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Action Parameters

Parameter	Type	Value	Description
FGDD	String		FGDD of the device to delete the license from.
DeleteOptions	ENUM	NoOption, Force, All	Flag used to force delete or delete license from all like devices.
EntitlementID	String		Entitlement ID of the license to delete.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400	<null>	LIC001, LIC002, LIC003, LIC004, LIC006, LIC007, LIC008, LIC009, LIC010, LIC011, LIC012, LIC014, LIC015, LIC016, LIC019, LIC900, LIC901, LIC902, LIC903

## Supported Action — ExportLicense

### Description

ExportLicense is an action used to export License files from the iDRAC. The ExportLicense action returns a License, specified by Entitlement ID, as a base64 encoded string.

### URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLicenseManagementService/Actions/DellLicenseManagementService.ExportLicense
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Action Parameters

Parameter	Qualifier	Type	Value	Description
EntitlementID	Input	String		Entitlement ID of the license being exported.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	LIC900
400	<null>	LIC001, LIC002, LIC003, LIC004, LIC006, LIC007, LIC008, LIC009, LIC010, LIC011, LIC012, LIC014, LIC016, LIC901, LIC902, LIC903

## ActionSupported Action — ExportLicenseByDeviceToNetworkShare

### Description

ExportLicenseByDeviceToNetworkShare is an action used to export License files from the iDRAC. The ExportLicenseByDeviceToNetworkShare action exports all licenses from a device, specified by FQDD, to a user defined location. The following tables specify ExportLicenseByDeviceToNetworkShare return values and parameters.

### URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellLicenseManagementService/Actions/DellLicenseManagementService.ExportLicenseByDeviceToNetworkShare
```

### Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

### Action Parameters

Parameter	Type	Value	Description
FQDD	String		FQDD of the device to export licenses from.
FileName	String		The exported license is renamed to <FileName>.
IPAddress	String		IP Address of the machine hosting the CIFS, NFS, HTTP, or HTTPS share.
Password	String		Password for CIFS share authentication.
ShareName	String		Name of the CIFS share or full file folder path to the NFS share. Optional for HTTP/HTTPS share, which may be treated as the path of the directory containing the file.
ShareType	ENUM	NFS, CIFS	Type of the network share.

Parameter	Type	Value	Description
UserName	String		Username for CIFS share authentication.
Workgroup	String		Workgroup for the CIFS share, optional.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	LIC900
400	<null>	JCP017, LIC001, LIC002, LIC003, LIC004, LIC006, LIC007, LIC008, LIC009, LIC010, LIC011, LIC012, LIC014, LIC016, LIC901, LIC902, LIC903, LIC904

# DellMemoryCollection

## Description

A collection of DellMemory resource.

## URL

`/redfish/v1/Dell/Systems/System.Embedded.1/Memory/DellMemoryCollection`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

# DellMemory

## Description

An instance of DellMemory will have Memory Device specific data.

# URL

/redfish/v1/Dell/Systems/System.Embedded.1/Memory/DellMemory/<ID>

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

Table 44. Status codes

HTTP status code
200
404

# DellNICCapabilitiesCollection

## Description

A collection of DellNICCapabilities resource.

# URL

/redfish/v1/Dell/Systems/System.Embedded.1/NetworkDeviceFunctions/DellNICCollection

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

Table 45. Status codes

HTTP status code
200
404

# DellNIC

## Description

An instance of DellNIC will have NIC device specific data.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/NetworkDeviceFunctions/DellNIC/<ID>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

**Table 46. Status codes**

HTTP status code
200
404

# DellNICCapabilitiesCollection

## Description

A collection of DellNICCapabilities resource.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/NetworkDeviceFunctions/DellNICCapabilitiesCollection
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login



**Table 47. Status codes**

**HTTP status code**

---

200

404

## DellNICCapabilities

### Description

An instance of DellNICCapabilities will have data specific to NIC and its port and partitions capabilities.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/NetworkDeviceFunctions/DellNICCapabilities/<ID>
```

### Supported HTTP Method and Privileges

**HTTP Method**

**Required Privilege**

---

GET

Login

**Table 48. Status codes**

**HTTP status code**

---

200

404

## DellNICStatisticsCollection

### Description

A collection of DellNICStatistics resource.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/NetworkAdapters/NetworkDeviceFunctions/DellNICStatisticsCollection
```

# Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

Table 49. Status codes

HTTP status code
200
404

# DellNICStatistics

## Description

An instance of DellNICStatistics will have the statistics of the NIC, NIC port or partition.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/NetworkAdapters/NetworkDeviceFunctions/DellNICStatistics/<ID>
```

# Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

Table 50. Status codes

HTTP status code
200
404

# DellNumericSensorCollection

## Description

A collection of DellNumericSensor resource

# URL

`/redfish/v1/Dell/Systems/System.Embedded.1/DellNumericSensorCollection`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

**Table 51. Status codes**

HTTP status code
200
404

# DellNumericSensor

## Description

An instance of DellNumericSensor will have data specific to sensor devices that returns only numeric readings and optionally supports thresholds settings.

# URL

`/redfish/v1/Dell/Systems/System.Embedded.1/DellNumericSensor/<id>`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

**Table 52. Status codes**

HTTP status code
200
404

# DellOSDeploymentService

## Description

The DellOSDeploymentService resource provides some actions that support operating system deployment configurations.

## URL

`/redfish/v1/Dell/Systems/System.Embedded.1/DellOSDeploymentService`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	OSD1

- Supported Action — [BootToHD](#)
- Supported Action — [BootToISOFromVFlash](#)
- Supported Action — [BootToNetworkISO](#)
- Supported Action — [ConfigurableBootToNetworkISO](#)
- Supported Action — [ConnectNetworkISOImage](#)
- Supported Action — [DeleteISOFromVFlash](#)
- Supported Action — [DetachISOFromVFlash](#)
- Supported Action — [DetachDrivers](#)
- Supported Action — [DetachISOImage](#)
- Supported Action — [UnpackAndShare](#)
- Supported Action — [DownloadISOToVFlash](#)
- Supported Action — [GetNetworkISOImageConnectionInfo](#)
- Supported Action — [GetDriverPackInfo](#)
- Supported Action — [GetAttachStatus](#)
- Supported Action — [DisconnectNetworkISOImage](#)
- Supported Action — [UnpackAndAttach](#)

# Supported Action — BootToHD

## Description

The BootToHD action is used for one time boot to the host server's hard disk. Return values for BootToHD are specified below, where the method-execution behavior matches the return- code description. BootToHD action's parameters are also specified in the table below.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellOSDeploymentService/Actions/  
DellOSDeploymentService.BootToHD
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
400	Base.1.0.Success	OSD3, OSD35, OSD8, OSD9

# Supported Action — BootToISOFromVFlash

## Description

The BootToISOFromVFlash action is used to boot to the downloaded pre-operating system image on the vFlash SD card. The following table lists the return values for BootToISOFromVFlash action, where the action-execution behavior matches the return-code description.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellOSDeploymentService/Actions/  
DellOSDeploymentService.BootToISOFromVFlash
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
ExposeDuration	DateTimeOffset		Identifies the amount of time, up to 18 hours, for the drivers to be exposed as a USB device to the host. The default value shall be 18 hours, if the parameter is not specified. The format for intervals is: YYYY-MM-DDThh:mm:ss[.SSS] (Z   (+ -) hh:mm).

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	OSD1
400		OSD19, OSD21, OSD3, OSD36, OSD40, OSD41, OSD43, OSD50, OSD51, OSD52, OSD53, OSD55, OSD9

## Supported Action — BootToNetworkISO

### Description

The BootToNetworkISO action is used to boot to the iDRAC pre-operating system image that was already downloaded. The following table lists the return values for BootToNetworkISO action, where the action-execution behavior matches the return-code description.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellOSDeploymentService/Actions/DellOSDeploymentService.BootToNetworkISO
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
ExposeDuration	DateTimeOffset		Identifies the amount of time (up to 18 hours) for the ISO image file to be exposed as a local CD-ROM device to the host server after which it will be automatically detached. The default value shall be 18 hours, if the parameter is not specified. The format for intervals is: YYYY-MM-DDThh:mm:ss[.SSS] (Z   (+ -) hh:mm)
FolderName	String		Folder name containing the ISO image file.

Parameter	Type	Value	Description
HashType	ENUM	MD5, SHA1	Type of hash algorithm used to compute checksum.
HashValue	String		Checksum value in string format computed by using the 'HashType' algorithm.
IPAddress	String		NFS, CIFS, HTTP, HTTPS share IPv4 address. For example, 192.168.10.100.
ImageName	String		Name of the image file.
Password	String		Password, if applicable.
ShareName	String		Name of the CIFS share or full path to the NFS share. Optional for HTTP or HTTPS share, which may be treated as the path of the directory containing the file.
ShareType	ENUM	NFS, CIFS	Type of the network share.
UserName	String		User name, if applicable. If the value contains domain name—for example, domain name or user name—the "domain name" will be considered as the work group. Work group parameter will take precedence if value is separately passed for it along with a user name. Supports only " and '/' for separator.
Workgroup	String		Optional. Workgroup for the CIFS share.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
400		OSD1, OSD16, OSD17, OSD19, OSD21, OSD28, OSD3, OSD30, OSD35, OSD36, OSD47, OSD50, OSD51, OSD9

## Supported Action — ConfigurableBootToNetworkISO

### Description

The ConfigurableBootToNetworkISO action exposes an ISO Image present on a network share as a CDROM device to the host server for a specified exposure duration interval or by default for 18 hrs. Upon the successful execution, based on the ResetType parameter, the host system shall either immediately cold boot or warm boot. Upon this reset, the system shall then boot to the ISO Image. If ResetType specifies no immediate reboot, then upon the next host system reset, the system shall boot to the ISO Image. Furthermore, if immediate reset is not specified, then the system should be rebooted before the exposure duration interval expires, otherwise the system shall fail to boot to the ISO Image.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellOSDeploymentService/Actions/DellOSDeploymentService.ConfigurableBootToNetworkISO
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
ExposeDuration	DateTimeOffset		Identifies the amount of time (up to 18 hours) for the ISO image file to be exposed as a local CD-ROM device to the host server after which it will be automatically detached. The default value shall be 18 hours, if the parameter is not specified. The format for intervals is: YYYY-MM-DDThh:mm:ss[.SSS] (Z (+ -)hh:mm)
HashType	ENUM	MD5, SHA1	Type of hash algorithm used to compute checksum.
HashValue	String		Checksum value in string format computed by using the 'HashType' algorithm.
IPAddress	String		NFS, CIFS, HTTP, HTTPS share IPv4 address. For example, 192.168.10.100.
ImageName	String		Name of the image file.
Password	String		Password, if applicable.
ResetType	ENUM	NoReset, WarmReset, ColdReset	Specifies if the host system needs to be immediately forced to cold- or warm reset in order to boot to the ISO Image.
ShareName	String		Name of the CIFS share or full path to the NFS share. Optional for HTTP or HTTPS share, which may be treated as the path of the directory containing the file.
ShareType	ENUM	NFS, CIFS	Type of the network share.
UserName	String		User name, if applicable.
Workgroup	String		Optional. Workgroup for the CIFS share.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
400		OSD1, OSD16, OSD17, OSD19, OSD21, OSD28, OSD3, OSD30, OSD35, OSD36, OSD47, OSD50, OSD51, OSD64, OSD65, OSD9

## Supported Action — ConnectNetworkISOImage

### Description

The ConnectNetworkISOImage action is used to connect to the ISO present on the network share and expose the ISO as a local USB CD-ROM device to the host system. This action will connect to the ISO located on an NFS/CIFS share and expose it as a virtual CDROM



device to the host server. Even though the successful action execution shall not change the boot order of that device, the host shall always boot to the virtual CDROM. Also, note that after the ISO is exposed to the host server, Lifecycle Controller shall be locked and no other jobs like configuration/update etc shall be performed until the ISO is detached using the DisconnectNetworkISOImage action. The successful execution of the DisconnectNetworkISOImage shall revert the host system to the regular boot list.

**NOTE:** The recommended methodology for connecting to an ISO image is by using the ConnectRFSISOImage action that utilizes the remote file system (RFS).

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DelOSDeploymentService/Actions/DelOSDeploymentService.ConnectNetworkISOImage
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
HashType	ENUM	MD5, SHA1	Type of hash algorithm used to compute checksum.
HashValue	String		Checksum value in string format computed by using the 'HashType' algorithm.
IPAddress	String		NFS, CIFS, HTTP, HTTPS share IPv4 address. For example, 192.168.10.100.
ImageName	String		Name of the image file.
Password	String		Password, if applicable.
ShareName	String		Name of the CIFS share or full path to the NFS share. Optional for HTTP or HTTPS share, which may be treated as the path of the directory containing the file.
ShareType	ENUM	NFS, CIFS	Type of the network share.
UserName	String		User name, if applicable.
Workgroup	String		Optional. Workgroup for the CIFS share.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	OSD1, OSD16, OSD17, OSD19, OSD28, OSD3, OSD35, OSD47, OSD50, OSD51, OSD61

## Supported Action — DeleteISOFromVFlash

### Description

The DeleteISOFromVFlash action is used to delete the ISO Image from vFlash SD card. The following table lists the return values for the DeleteISOFromVFlash action, where the action-execution behavior matches the return-code description.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellOSDeploymentService/Actions/  
DellOSDeploymentService.DeleteISOFromVFlash
```

### Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

### Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
400		OSD3, OSD39, OSD40, OSD41, OSD43, OSD45, OSD52, OSD53

## Supported Action — DetachISOFromVFlash

### Description

The DetachISOFromVFlash action is used to detach the ISO Image (on a vFlash SD card) from the host system.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellOSDeploymentService/Actions/  
DellOSDeploymentService.DetachISOFromVFlash
```

### Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
400		OSD23, OSD39, OSD40, OSD41, OSD43, OSD44, OSD52, OSD53

## Supported Action — DetachDrivers

### Description

This OSDeploymentService.DetachDrivers action is used to detach the USB device containing the drivers from the host server. The following table lists the return values for DetachDrivers action, where the action-execution behavior matches the return-code description.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellOSDeploymentService/Actions/DellOSDeploymentService.DetachDrivers
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
400		OSD24, OSD25, OSD7

## Supported Action — DetachISOImage

### Description

The DetachISOImage action is used to detach the ISO Image from the host server. The following table lists the return values for DetachISOImage action, where the action-execution behavior matches the return-code description. The following table lists the return values for BootToNetworkISO action, where the method-execution behavior matches the return-code description.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellOSDeploymentService/Actions/DellOSDeploymentService.DetachISOImage
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
400		OSD22, OSD23, OSD32, OSD7

## Supported Action — DisconnectNetworkISOImage

### Description

The DisconnectNetworkISOImage action is used to disconnect and detach the ISO Image from the host system. The following table lists the return values for the DisconnectNetworkISOImage action, where the action-execution behavior matches the return-code description.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellOSDeploymentService/Actions/  
DellOSDeploymentService.DisconnectNetworkISOImage
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
400		OSD22, OSD32, OSD7

## Supported Action — DownloadISOToVFlash

### Description

The DownloadISOToVFlash action is used to download the pre-operating system ISO Image to the vFlash SD card. The following table lists the return values for DownloadISOToVFlash action, where the action-execution behavior matches the return-code description.

# URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellOSDeploymentService/Actions/DellOSDeploymentService.DownloadISOToVFlash
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
HashType	ENUM	MD5, SHA1	Type of hash algorithm used to compute checksum.
HashValue	String		Checksum value in string format computed by using the 'HashType' algorithm.
IPAddress	String		The TFTP, CIFS, NFS, HTTP, or HTTPS share IPv4 address. For example, 192.168.10.100.
ImageName	String		Name of the image file.
Password	String		Password, if applicable.
Port	ENUM		Port Number
ShareName	String		Name of the CIFS share or full path to the NFS share. Optional for HTTP or HTTPS share, which may be treated as the path of the directory containing the file.
ShareType	ENUM	NFS, CIFS	Type of the network share.
UserName	String		User name, if applicable.
Workgroup	String		Optional. Workgroup for the CIFS share.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	OSD1
400		OSD16, OSD18, OSD19, OSD28, OSD3, OSD37, OSD40, OSD42, OSD43, OSD47, OSD48, OSD52, OSD53, OSD54, OSD55

## Supported Action — GetAttachStatus

### Description

The GetAttachStatus() method will give the status of the Drivers and ISO Image that has been exposed to host.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DelIOSDeploymentService/Actions/  
DelIOSDeploymentService.GetAttachStatus
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	OSD1

## Supported Action — GetDriverPackInfo

### Description

The GetDriverPackInfo action is used get the list of operating systems that can be installed on the host system using the embedded device drivers present in the Lifecycle Controller.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DelIOSDeploymentService/Actions/  
DelIOSDeploymentService.GetDriverPackInfo
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
400		OSD2, OSD29, OSD3, OSD35, OSD4, OSD5, OSD6

# Supported Action — GetNetworkISOImageConnectionInfo

## Description

The GetNetworkISOImageConnectionInfo action is used to give the status of the ISO Image that has been exposed to the host system. The following table lists the return values for GetNetworkISOImageConnectionInfo, where the action-execution behavior matches the return-code description.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellOSDeploymentService/Actions/  
DellOSDeploymentService.GetNetworkISOImageConnectionInfo
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
400		OSD32

# Supported Action — UnpackAndAttach

## Description

The UnpackAndAttach action is used to extract the drivers for the selected operating system to a USB device that is attached locally to the server for the specified time interval. The following table specifies the return values for UnpackAndAttach action, where the action-execution behavior matches the return-code description.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellOSDeploymentService/Actions/  
DellOSDeploymentService.UnpackAndAttach
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
ExposeDuration	DateTime Offset		Identifies the amount of time (up to 18 hours) for the drivers to be exposed as an USB device to the host. The default value shall be 18 hours, if the parameter is not specified. The format for intervals is: YYYY-MM-DDThh:mm:ss[.SSS][Z](+ -)hh:mm)
OSName	String		Name of the OS to unpack drivers for, this value shall match one of the strings in OSList returned for GetDriverPackInfo.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	OSD1
400		OSD10, OSD11, OSD12, OSD13, OSD19, OSD2, OSD20, OSD27, OSD3, OSD30, OSD35, OSD4, OSD5

## Supported Action — UnpackAndShare

### Description

The UnpackAndShare action is used to extract the drivers for the selected operating system, and copy them to the specified network share. The following table lists the return values for UnpackAndShare, where the action-execution behavior matches the return-code description.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DelloSDeploymentService/Actions/  
DelloSDeploymentService.UnpackAndShare
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
FolderName	String		Folder name.
IPAddress	String		CIFS, NFS, HTTP, or HTTPS share IPv4 address. For example, 192.168.10.100.
OSName	String		The OS name.



Parameter	Type	Value	Description
Password	String		Password, if applicable.
ShareName	String		Name of the CIFS share or full path to the NFS share. Optional for HTTP/HTTPS share, which may be treated as the path of the directory containing the file.
ShareType	ENUM	NFS, CIFS	Type of the network share.
UserName	String		User name, if applicable.
Workgroup	String		Optional. Workgroup for the CIFS share.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	OSD1
400		OSD10, OSD11, OSD12, OSD13, OSD19, OSD2, OSD20, OSD27, OSD3, OSD30, OSD35, OSD4, OSD47, OSD5

# DellPCleSSDExtenderCollection

## Description

A collection of DellPCleSSDExtender resource.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/Storage/DellPCleSSDExtenderCollection
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

**Table 53. Status codes**

HTTP status code
200
404

# DellPCleSSDExtender

## Description

An instance of DellPCleSSDExtender will have data specific to the PCIeSSD extender in the managed system.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/Storage/DellPCleSSDExtender/<ID>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

**Table 54. Status codes**

HTTP status code
200
404

# DellPCleSSDCollection

## Description

A collection of DellPCleSSD resource.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/Storage/DellPCleSSDCollection
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

**Table 55. Status codes**

**HTTP status code**

---

200

404

## DellPCleSSD

### Description

An instance of DellPCleSSD will have PCIe Solid State Drive specific data.

### URL

`/redfish/v1/Dell/Systems/System.Embedded.1/Storage/DellPCleSSD/<ID>`

### Supported HTTP Method and Privileges

**HTTP Method**

**Required Privilege**

---

GET

Login

**Table 56. Status codes**

**HTTP status code**

---

200

404

## DellPCleSSDBackPlaneCollection

### Description

A collection of DellPCleSSDBackPlane resource.

### URL

`/redfish/v1/Dell/Systems/System.Embedded.1/Storage/DellPCleSSDBackPlaneCollection`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

Table 57. Status codes

HTTP status code
200
404

## DellPCleSSDBackPlane

### Description

An instance of DellPCleSSDBackPlane will have PCIeSSD back plane specific data.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/Storage/DellPCleSSDBackPlane/<ID>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

Table 58. Status codes

HTTP status code
200
404

## DellPCleFunctionCollection

### Description

A collection of DellPCleFunction resource.

## URL

/redfish/v1/Dell/Systems/System.Embedded.1/DellPCIeFunctionCollection

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

## DellPCIeFunction

### Description

An instance of DellPCIeFunction will have PCI device specific data.

## URL

/redfish/v1/Dell/Systems/System.Embedded.1/DellPCIeFunction/<id>

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

# DellPersistentStorageService

## Description

The DellPersistentStorageService resource provides some actions to support VFlash functionality.

## URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellPersistentStorageService
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	AccessVirtualMedia, Login
GET	Login

## Supported Status Codes

HTTP status code
200
404

[Supported Action — FormatPartition](#)

## Supported Action — FormatPartition

### Description

The FormatPartition action is used for formatting a partition on a vFlash.

### URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellPersistentStorageService/Actions/DellPersistentStorageService.FormatPartition
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	AccessVirtualMedia, Login

## Supported Parameters

Parameter	Type	Value	Description
FormatType	ENUM	EXT2, EXT3, FAT16, FAT32	Folder name.
PartitionIndex	ENUM		CIFS, NFS, HTTP, or HTTPS share IPv4 address. For example, 192.168.10.100.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
400		JCP17, JCP18, JCP19, VF001, VF002, VF004, VF012, VF013, VF015, VF016, VF018, VF019, VF021, VF024, VF026, VF027, VF033, VF047, VF052

# DellPhysicalDiskCollection

## Description

A collection of DellPhysicalDisk resource.

## URL

`/redfish/v1/Dell/Systems/System.Embedded.1/Storage/Drives/DellPhysicalDiskCollection`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

# DellPhysicalDisk

## Description

An instance of DellPhysicalDisk will have Physical Disk specific data.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/Storage/Drives/DellPhysicalDisk/<id>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

# DellPresenceAndStatusSensorCollection

## Description

A collection of DellPresenceAndStatusSensor resource

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellPresenceAndStatusSensorCollection
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login



## Supported Status Codes

### HTTP status code

---

200

404

## DellPresenceAndStatusSensor

### Description

An instance of DellPresenceAndStatusSensor will have presence and status sensor specific data.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellPresenceAndStatusSensor/<id>
```

## Supported HTTP Method and Privileges

### HTTP Method

### Required Privilege

---

GET

Login

## Supported Status Codes

### HTTP status code

---

200

404

## DellPowerSupplyCollection

### Description

A collection of DellPowerSupply resource.

### URL

```
/redfish/v1/Dell/Chassis/System.Embedded.1/Power/PowerSupplies/DellPowerSupplyCollection
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

### HTTP status code

200  
404

# DellPowerSupply

## Description

An instance of DellPowerSupply will have data specific to the Power Supply devices in the managed system.

## URL

```
/redfish/v1/Dell/Chassis/System.Embedded.1/Power/PowerSupplies/DellPowerSupply/<ID>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

### HTTP status code

200  
404

# DellPowerSupplyViewCollection

## Description

A collection of DellPowerSupplyView resource.

## URL

`/redfish/v1/Dell/Chassis/System.Embedded.1/Power/PowerSupplies/DellPowerSupplyViewCollection`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

## DellPowerSupplyView

### Description

An instance of DellPowerSupplyView will have data specific to the Power Supply devices in the managed system.

## URL

`/redfish/v1/Dell/Chassis/System.Embedded.1/Power/PowerSupplies/DellPowerSupplyView/<ID>`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

# DellProcessorCollection

## Description

A collection of DellProcessor resource.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/Processors/DellProcessorCollection
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

# DellProcessor

## Description

An instance of DellProcessor will have CPU specific data.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/Processors/DellProcessor/<id>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

# Supported Status Codes

## HTTP status code

---

200

404

# DellRaidService

## Description

The DellRaidService resource provides some actions to support RAID functionality.

## URL

`/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login
GET	Login

# Supported Status Codes

## HTTP status code

---

200

404

### Supported Action

— AssignSpare

Supported Action — BlinkTarget

Supported Action — CheckVDValues

Supported Action — ClearForeignConfig

Supported Action — ConvertToRAID

Supported Action — ConvertToNonRAID

Supported Action — GetDHSDisks

Supported Action — LockVirtualDisk

Supported Action — GetRAIDLevels

Supported Action — SetControllerKey

Supported Action — RemoveControllerKey

Supported Action — UnBlinkTarget

Supported Action — EnableControllerEncryption

Supported Action — ReKey  
Supported Action — ResetConfig

## Supported Action — AssignSpare

### Description

The AssignSpare action is used to assign a physical disk as a dedicated hot spare for a virtual disk, or as a global hot spare.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/DellRaidService.AssignSpare
```

### Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

### Supported Parameters

Parameter	Type	Value	Description
Target	String		This parameter is the FQDD of the target device (physical drive).
VirtualDiskArray	String		Array of ElementName(s) where each identifies a different Virtual Drive (VD). Currently only one VD can be passed. Array of ElementName(s) where each ElementName identifies a different virtual disk.

### Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
202		
400		STOR003, STOR004, STOR006, STOR007, STOR009, STOR017, STOR028, STOR029, STOR037, STOR038

# Supported Action — BlinkTarget

## Description

The BlinkTarget action is used to identify a single physical disk by blinking the disk slot LED for the physical disk / Virtual disk. The successful execution of this action results in setting the LED to blink the identify pattern or turns off the blinking of the identify pattern. The action is real time, blink cannot be scheduled as part of a job.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/DellRaidService.BlinkTarget
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
Target	String		This parameter is the FQDD of the physical drive, SSD, or VD.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400		STOR003, STOR004, STOR006, STOR007, STOR037, STOR038

# Supported Action — CheckVDValues

## Description

The CheckVDValues action is used to determine the possible sizes of Virtual disks and the default settings, provided a RAID level and set of physical disks. The VDPropArray property is filled with Size and other values, so that the method is successfully executed. If the SpanDepth is not provided, a default value of 2 shall be used for RAID levels 10, 50, and 60.

**NOTE:** For certain numbers of disks such as nine or fifteen, it may be necessary for the user to provide another SpanDepth.

# URL

/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/DellRaidService.CheckVDValues

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
PDArray	String		Array of FQDDs where each identifies a physical drive.
Target	String		FQDD of the target device (Controller).
VDPropNameArrayIn	String	RAIDLevel, Size, SpanDepth, SpanLength, StartingLBA, T10PIStatus	Indexed array of VD property names. The property names can be Size, SpanDepth, SpanLength, RAIDLevel, StartingLBA or T10PIStatus. The values for the property needs to be provided in VDPropValueArrayIn in the same order.
VDPropValueArrayIn	String		Indexed array of VD property values for the respective VDPropNameArrayIn parameter.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400		STOR003, STOR004, STOR006, STOR007, STOR009, STOR010, STOR011, STOR013, STOR017, STOR029, STOR030, STOR035, STOR037, STOR038, STOR043, STOR045, STOR046, STOR051, STOR052

## Supported Action — ClearForeignConfig

### Description

The ClearForeignConfig action is used to prepare any foreign physical disks for inclusion in the local configuration.



## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/DellRaidService.ClearForeignConfig
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
Target	String		FQDD of the target device (Controller).

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
202		
400		STOR003, STOR004, STOR006, STOR007, STOR018, STOR030, STOR037, STOR038

## Supported Action — ConvertToRAID

### Description

The ConvertToRAID action is used to convert a physical disks in Non-RAID state to a state usable for RAID. After the action is successfully executed the PhysicalDiskView.RAIDStatus property of that physical disk should reflect the new state.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/DellRaidService.ConvertToRAID
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Action Parameters

Parameter	Type	Value	Description
PDArray	String		An array of FQDDs where each identifies a physical drive.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
202		
400		STOR003, STOR004, STOR006, STOR037, STOR038

## Supported Action — ConvertToNonRAID

### Description

The ConvertToNonRAID action is used to convert a physical disks in RAID state of "Ready" to a Non-RAID state. After the action is successfully executed, the PhysicalDiskView.RAIDStatus property of that physical disk should reflect the new state.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/DellRaidService.ConvertToNonRAID
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Action Parameters

Parameter	Type	Value	Description
PDArray	String		An array of FQDDs where each identifies a physical drive.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
202		
400		STOR003, STOR004, STOR006, STOR037, STOR038, STOR074

## Supported Action — EnableControllerEncryption

### Description

The EnableControllerEncryption action sets either Local Key Management (LKM) or Dell Key Management (DKM) on controllers that support encryption of the drives.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/DellRaidService.EnableControllerEncryption
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
Key	String		Key is the passcode. This parameter is required if the mode is set to Local Key Management. The key shall be maximum of 32 characters in length, where the expanded form of the special character is counted as a single character. The Key shall have one character from each of the following set—Upper case, lower case, number, special character. The special characters in the following set must be passed as <code>&amp;</code> , <code>&lt;</code> , <code>&gt;</code> , <code>&amp;lt;</code> , <code>&amp;gt;</code> , <code>"</code> , <code>&amp;quot;</code> , and <code>'</code> <code>&amp;apos;</code> .
Keyid	String		Key identifier describes the key. This parameter is required if the mode is set to Local Key Management. The key ID shall be maximum of 32 characters in length and must not have any white spaces.
Mode	ENUM	LKM, DKM	Mode of the controller 1 - Local Key Management (LKM).

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
202		
400		STOR003, STOR004, STOR006, STOR007, STOR019, STOR020, STOR022, STOR030, STOR037, STOR038

## Supported Action — GetAvailableDisks

### Description

The GetAvailableDisks action is used to determine minimum number of drives required to create virtual disks.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/DellRaidService.GetAvailableDisks
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
BlockSizeInBytes	ENUM	All, 4096, 512	The parameter specifies the physical drive block size in bytes.
DiskEncrypt	ENUM	All, FDE, NonFDE	The parameter specifies the drive encryption capability.
DiskType	ENUM	All, HDD, SSD	The property represents the drive type.
DiskProtocol	ENUM	AllProtocols, SATA, SAS, NVMe	The parameter specifies the type of drive protocol.
FormFactor	ENUM	All, M.2	This parameter is used to specify the form factor of drives and shall be one of the following: <ul style="list-style-type: none"><li>· 0—Include all</li><li>· 1—Include only BOSS M.2</li></ul>
RaidLevel	ENUM	NoRAID, RAID6, RAID60, RAID0,	The parameter represents the type of RAID configuration.

Parameter	Type	Value	Description
		RAID10, RAID1, RAID5, RAID50	
T10PIStatus	ENUM	All, T10PICapable, T10PIIncapable	The parameter specifies the T10-Protection Information (PI) capability status.
Target	String		This parameter is the FQDD of the target device (Controller).

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400		STOR003, STOR004, STOR006, STOR007, STOR030, STOR037, STOR038

## Supported Action — GetDHSDisks

### Description

The GetDHSDisks action is used to determine possible choices of physical drives that can be used to set a dedicated hot spare for the identified virtual disk. GetDHSDisks returns success if it has evaluated the physical disks for potential hot spares, the PDArray return list can be empty if no physical disks are suitable for hot spares.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/DellRaidService.GetDHSDisks
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
Target	String		This parameter is the FQDD of the target device (VD).

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400		STOR003, STOR004, STOR006, STOR007, STOR017, STOR028, STOR037, STOR038

## Supported Action — GetRAIDLevels

### Description

The GetRAIDLevels action is used to determine the possible choices of RAID Levels to create virtual disks. If the list of physical disks is not provided, this action accesses information for all the connected disks.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/DellRaidService.GetRAIDLevels
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
BlockSizeInBytes	ENUM	All, 4096, 512	The parameter specifies the physical drive block size in bytes.
DiskEncrypt	ENUM	All, FDE, NonFDE	The parameter specifies the drive encryption capability.
DiskType	ENUM	All, HDD, SSD	The parameter specifies the type of the drive.
Diskprotocol	ENUM	AllProtocols, SATA, SAS, NVMe	The parameter specifies the type of drive protocol.
FormFactor	ENUM	All, M.2	This parameter is used to specify the form factor of drives and shall be one of the following: <ul style="list-style-type: none"><li>0—Include all</li><li>1—Include only BOSS M.2</li></ul>
PDArray	String		Array of FGDDs where each identifies a physical drive.

Parameter	Type	Value	Description
T10PIStatus	ENUM	All, T10PICapable, T10PIIncapable	The parameter specifies the T10-Protection Information (PI) capability status.
Target	String		FQDD of target device (Controller).

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400		STOR003, STOR004, STOR006, STOR007, STOR030, STOR037, STOR038

## Supported Action — LockVirtualDisk

### Description

The LockVirtualDisk action encrypts the virtual disk.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/  
DellRaidService.LockVirtualDisk
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
Target	String		FQDD of target device (Controller).

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
202		
400		STOR003, STOR004, STOR006, STOR007, STOR030, STOR037, STOR038

# Supported Action — ReKey

## Description

The ReKey action resets the key on the controller that support encryption of the of drives. This method switches the controller mode.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/DellRaidService.ReKey
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
Keyid	String		Key identifier describes the key. The key ID shall be maximum 32 characters in length and must not have any white spaces.
Mode	ENUM	LKM, DKM	Mode of the controller: 1 - Local Key Management (LKM), 2 - Dell Key Manager.
NewKey	String		New controller key. The key shall be maximum of 32 characters in length, where the expanded form of the special character is counted as a single character. The Key shall have one character from each of the following set. Upper case, lower case, number, special character. The special characters in the following set need to be passed as mentioned below and are counted as a single character for the maximum length of the key. <code>&amp;-&gt;&amp;amp;</code> , <code>&lt; -&gt;&amp;lt;</code> , <code>&gt;-&gt;&amp;gt;</code> , <code>"-&gt;&amp;quot;</code> , and <code>'-&gt;&amp;apos;</code> "
OldKey	String		The old controller key.
Target	String		This parameter is the FQDD of the target device (Controller).

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
202		
400		STOR003, STOR004, STOR006, STOR007, STOR019, STOR020, STOR030, STOR037, STOR038, STOR048, STOR050, STOR053



# Supported Action — RemoveControllerKey

## Description

The RemoveControllerKey action erases the encryption key on controller.

**⚠ CAUTION: This action erases all encrypted drives.**

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/  
DellRaidService.RemoveControllerKey
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
Target	String		FQDD of target device (Controller).

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
202		
400		STOR003, STOR004, STOR006, STOR007, STOR021, STOR022, STOR030, STOR037, STOR038

# Supported Action — ResetConfig

## Description

The ResetConfig action is used to delete all the virtual disks and unassign all hot spare physical disks.

**⚠ CAUTION: This action deletes all the data on the existing virtual disks.**

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/DellRaidService.ResetConfig
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
Target	String		FQDD of target device (Controller).

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
202		
400		STOR003, STOR004, STOR006, STOR007, STOR021, STOR022, STOR030, STOR037, STOR038

## Supported Action — SetControllerKey

### Description

The SetControllerKey action is used to set the key on controllers and set the controller in Local key Management (LKM) to encrypt the drives.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/DellRaidService.SetControllerKey
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
Key	String		The parameter specifies the key passcode. The Key shall be maximum of 32 characters in length, where the expanded form of the special character is counted as a single character. The Key shall have at least one character from each of the following sets. Upper case, lower case, number, special character, The special characters in the following set need to be passed as mentioned below: &->&amp;;, < ->&lt;;, >->&gt;;, "->&quot;;, ' ->&apos;;"
Keyid	String		Key identifier describes the key. The key ID shall be maximum 32 characters in length and must not have any white spaces.
Target	String		This parameter is the FQDD of the target device (Controller).

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
202		
400		STOR003, STOR004, STOR006, STOR007, STOR021, STOR022, STOR030, STOR037, STOR038

## Supported Action — UnBlinkTarget

### Description

The UnblinkTarget action is used to stop blinking the light present on the physical disk represented by the Target FQDD. The action is real time, unblink cannot be scheduled as part of a job.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellRaidService/Actions/DellRaidService.UnBlinkTarget
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login

## Supported Parameters

Parameter	Type	Value	Description
Target	String		This parameter is the FQDD of the physical drive, SSD, and VD.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400		STOR003, STOR004, STOR006, STOR007, STOR037, STOR038

# DellSensorCollection

## Description

A collection of DellSensor resource

## URL

`/redfish/v1/Dell/Systems/System.Embedded.1/DellSensorCollection`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

# DellSensor

## Description

An instance of DellSensor will represent a sensor, a hardware device that is capable of measuring the characteristics of a physical property.

## URL

`/redfish/v1/Dell/Systems/System.Embedded.1/DellSensor/<id>`

# Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

# Supported Status Codes

## HTTP status code

- 200
- 404

# DellSoftwareInstallationService

## Description

The DellSoftwareInstallationService resource provides some actions to support software installation functionality.

## URL

`/redfish/v1/Dell/Systems/System.Embedded.1/DellSoftwareInstallationService`

# Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login
GET	Login

# Supported Status Codes

## HTTP status code

- 200
- 404

- Supported Action — `GetRepoBasedUpdateList`
- Supported Action — `InstallFromRepository`
- Supported Action — `InstallFromURI`

# Supported Action — GetRepoBasedUpdateList

## Description

This action is used for getting the list of packages and a list of devices that will be updated when a particular repository is used. You must run InstallFromRepository command before running GetRepoBasedUpdateList. If Applyupdate is False, no updates are applied or scheduled. If ApplyUpdate is True, the list contains job IDs for all the jobs queued for the devices.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellSoftwareInstallationService/Actions/DellSoftwareInstallationService.GetRepoBasedUpdateList
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	SUP028
400		SUP029, SUP030

# Supported Action — InstallFromRepository

## Description

This action creates the list of the updates contained in the repository that are supported by LC and are applicable to the system and installed hardware. The successful execution of this action creates a job. The list is copied to a persistent location so that you can query for the updatable list by using GetRepoBasedUpdateList WSMAN Command. If the input parameter ApplyUpdate value is True, only the applicable packages are applied and GetRepoBasedUpdateList gives the JOBIDs for all the jobs queued for the devices.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellSoftwareInstallationService/Actions/DellSoftwareInstallationService.InstallFromRepository
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login

## Supported Parameters

Parameter	Type	Value	Description
ApplyUpdate	ENUM	False, True	If ApplyUpdate is set to True, the updatable packages from Catalog XML are staged. If it is set to False, no updates are applied. The list of updatable packages can be seen by invoking the GetRepoBasedUpdateList. Default value is True.
CatalogFile	String		Name of the catalog file on the repository. Default is Catalog.xml.
IPAddress	String		IP address for the remote share.
IgnoreCertWarning	ENUM	Off, On	Specifies if certificate warning should be ignored when HTTPS is used. If IgnoreCertWarning is On, warnings are ignored. Default is 2 (On).
Mountpoint	String		The local directory where the share should be mounted. This is applicable for CIFS.
Password	String		Password for the remote share. This parameter must be provided for CIFS.
ProxyPasswd	String		The password for the proxy server.
ProxyPort	uint64		Port for the proxy server. Default is set to 80.
ProxyServer	String		The IP address of the proxy server.
ProxySupport	ENUM	DefaultProxy, Off, ParametersProxy	Specifies if a proxy should be used. Default is 1 (Off).
ProxyType	ENUM	HTTP, SOCKS	The proxy type of the proxy server. Default is 0 (HTTP).
ProxyUname	String		The user name for the proxy server.

Parameter	Type	Value	Description
RebootNeeded	Boolean		This property indicates if a reboot should be performed. True indicates that the system (host) is rebooted during the update process. False indicates that the updates take effect after the system is rebooted the next time. Default value is set to False.
ShareName	String		Name of the CIFS share or full path to the NFS share. Optional for HTTP/HTTPS share, this may be treated as the path of the directory containing the file.
ShareType	ENUM	CIFS, FTP, HTTP, HTTPS, NFS, TFTP	Type of the network share. Default value is NFS.
UserName	String		User name for the remote share. This parameter must be provided for CIFS.
Workgroup	String		Workgroup for the CIFS share - optional.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400		SUP001, SUP002, SUP019, SUP026, SUP027

## Supported Action — InstallFromURI

### Description

InstallFromURI action is used for creating a job for update service. The successful execution of this action creates a job.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellSoftwareInstallationService/Actions/DellSoftwareInstallationService.InstallFromURI
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login



## Supported Parameters

Parameter	Type	Value	Description
IgnoreCertWarning	ENUM	Off, On	Specifies if certificate warning should be ignored when HTTPS is used. If IgnoreCertWarning is On, warnings are ignored. Default is 2 (On).
ProxyPasswd	String		The password for the proxy server.
ProxyPort	uint64		Port for the proxy server. Default is set to 80.
ProxyServer	String		The IP address of the proxy server.
ProxySupport	ENUM	DefaultProxy, Off, ParametersProxy	Specifies if a proxy should be used. Default is 1 (Off).
ProxyType	ENUM	HTTP, SOCKS	The proxy type of the proxy server. Default is 0 (HTTP).
ProxyUname	String		The user name for the proxy server.
Target	String		A Link to the DellSoftwareInventory resource whose firmware needs to be updated. It shall be the @odata.id of the DellSoftwareInventory Resource.
URI	String		Network file location of the firmware to be installed. Supported network share types are HTTP, HTTPS, CIFS, NFS, TFTP, and FTP. Special characters must be encoded in the URI format.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
400		SUP001, SUP002, SUP003, SUP006, SUP007, SUP019, SUP024

# DellSwitchConnectionCollection

## Description

A collection of DellSwitchConnection resource

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/NetworkPorts/DellSwitchConnectionCollection
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

# DellSwitchConnection

## Description

An instance of DellSwitchConnection will have the switch connection view information of all the ports.

## URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/NetworkPorts/DellSwitchConnection/<id>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

### HTTP status code

---

200

404

## DellSystem

### Description

An instance of DellSystem will have data representing the overall system devices in the managed system.

### URL

```
/redfish/v1/Dell/Systems/System.Embedded.1/DellSystem/<id>
```

## Supported HTTP Method and Privileges

### HTTP Method

### Required Privilege

---

GET

Login

## Supported Status Codes

### HTTP status code

---

200

404

## DellvFlashCollection

### Description

A collection of DellvFlash resource

### URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellvFlashCollection
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

## DellvFlash

### Description

An instance of DellvFlash will have VFlash specific data.

### URL

```
/redfish/v1/Dell/Managers/iDRAC.Embedded.1/DellvFlash/<ID>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code
200
404

## DellVirtualDiskCollection

### Description

A collection of DellVirtualDisk resource.

## URL

/redfish/v1/Dell/Systems/System.Embedded.1/Storage/Volumes/DellVirtualDiskCollection

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

## DellVirtualDisk

### Description

An instance of DellVirtualDisk will have data specific to the Virtual Disks in the system.

## URL

/redfish/v1/Dell/Systems/System.Embedded.1/Storage/Volumes/DellVirtualDisk/<ID>

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP status code
200
404

# DellServiceRoot

## Description

This object represents the Redfish OEM extensions for root service.

## URL

/redfish/v1

## HTTP methods and privileges

Table 59. HTTP methods and privileges for DellServiceRoot

HTTP method	Required privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# DellUpdateService

## Description

This action is used to perform firmware updates.

## Supported action — Install

## Description

This resource is used to represent extension of the Update Service schema of Redfish.

Starting from the iDRAC version 3.15.15.15 release, you can use this action to update only one component at a time. Although the SoftwareIdentityURLs parameter of the Install OEM action is of the type Collection, only one relative URI of the firmware inventory to be installed is allowed. If you attempt to update multiple components at once, error SYS442 is returned. To update multiple components, perform the updates one at a time.

## URL

```
/redfish/v1/UpdateService/Actions/Oem/DellUpdateService.Install
```

## HTTP methods and privileges

**Table 60. HTTP methods and privileges for Install**

HTTP method	Required privilege
POST	<ul style="list-style-type: none"> <li>.<b>d9</b> file type — ConfigureComponents, Login</li> <li>.<b>pm</b> file type — ConfigureComponents, Login</li> <li>.<b>exe</b> file type — ConfigureComponents, Login</li> </ul>

## Updatable properties

**Table 61. Properties and values for Install**

Property	Values
InstallUpon	<ul style="list-style-type: none"> <li>Now</li> <li>NowAndReboot</li> <li>NextReboot</li> </ul>

## Status codes

**Table 62. Status codes for Install**

HTTP status code	Extended information	Error Message Code
202		SYS408
400		<ul style="list-style-type: none"> <li>SUP024</li> <li>SYS406</li> <li>OSD35</li> </ul>
400	Base.1.0. PropertyValueTypeError	
400	Base.1.0. PropertyMissing	
400	Base.1.0.MalformedJSON	SYS405
403	Base.1.0.InsufficientPrivilege	RAC0506
403		LIC501
404	Base.1.0.ResourceMissingAtURI	SYS403

HTTP status code	Extended information	Error Message Code
415		SYS401
500	Base.1.0.InternalError	RAC964
503		SUP0108

# DellManager

## Description

This resource is used to export, import, and preview the Server Configuration Profile (SCP) files Redfish implementation.

**NOTE:** For SCP export, import, and preview, if Lifecycle Controller is disabled, ensure that you enable Lifecycle Controller and retry the operation. To enable Lifecycle Controller, run the following command:

```
racadm set LifecycleController.LCAttributes.LifecycleControllerState 1
```

Redfish SCP is an OEM action and requires OEM privileges ALL and role as ADMIN. Redfish privileges are not applicable for SCP.

For more information about this schema, the location header, and other details, see the *RESTful Server Configuration with iDRAC REST API* white paper at [dell.com/support](http://dell.com/support).

## Supported Action — ResetToDefaults

### Description

This defines the name of the OEM action supported when used in conjunction with a POST operation to this resource. When issued, this operation resets the Manager attributes to default settings.

### URL

```
/redfish/v1/Managers/<ID>/Actions/Oem/DellManager.ResetToDefaults
```

### HTTP methods and privileges

Table 63. HTTP methods and privileges for ResetToDefaults

HTTP method	Required privilege
POST	SystemControl

### Updatable properties

Table 64. Supported properties and values for ResetToDefaults

Property	Values
ResetType	· All



Property	Values
	<ul style="list-style-type: none"> <li>ResetAllWithRootDefaults</li> <li>Default</li> </ul>

## Status codes

**Table 65. Status codes for ResetToDefaults**

HTTP status code	Extended information	Error Message Code
200		
400		RAC1035, HWC0001, RAC947
403	InsufficientPrivilege	RAC0506
404	Base.1.2.ResourceMissingAtURI	SYS403
500	Base.1.2.InternalError	SYS446

## Supported action — Export, Import, and Preview

**Table 66. Supported HTTP methods and features**

HTTP method	Feature
POST	Exporting configuration
POST	Importing configuration
POST	Preview configuration

## Export resource URL and response details

### URL

`redfish/v1/Managers/<id>/Actions/Oem/EID_674_Manager.ExportSystemConfiguration`

### Properties and values

**Table 67. Properties and values for the action**

Property	Values
ExportFormat	XML, JSON
ExportUse	Default, Clone, Replace
IncludeInExport	Default, IncludeReadOnly, IncludePasswordHashValues
ShareParameters	See <a href="#">Share parameters and values</a> .

## Status codes

Table 68. Status codes for the action

HTTP status code	Extended information	Error Message Code
202		
400	Base.1.2.PropertyMissing	
400	Base.1.2.PropertyValueTypeError	
400	Base.1.2.PropertyValueNotInList	
400		RAC013, SYS406, SYS433, RAC1155
500	Base.1.2.InternalError	SWC0058
503		RAC052
503		RAC0679

## Import resource URL and response details

### URL

```
redfish/v1/Managers/<id>/Actions/Oem/EID_674_Manager.ImportSystemConfiguration
```

### Properties and values

Table 69. Properties and values for the action

Property	Values
ImportBuffer	Buffer content to perform import. Required only for LOCAL and not required for CIFS, NFS, HTTP, or HTTPS.
ShutdownType	Graceful, Forced, NoReboot
HostPowerState	On, Off
TimeToWait	The time to wait for the host to shut down. Default and minimum value is 300 seconds. Maximum value is 3600 seconds.
ShareParameters	See <a href="#">Share parameters and values</a> .

## Status codes

Table 70. Status codes for the action

HTTP status code	Extended information	Error Message Code
202		
400	Base.1.2.PropertyMissing	
400	Base.1.2.PropertyValueTypeError	
400	Base.1.2.PropertyValueNotInList	

HTTP status code	Extended information	Error Message Code
400		RAC013, SYS406, SYS433, RAC1155
500	Base.1.2.InternalError	SWC0058
503		RAC052
503		RAC0679

## Preview resource URL and response details

### URL

```
redfish/v1/Managers/<id>/Actions/Oem/EID_674_Manager.ImportSystemConfigurationPreview
```

### Status codes

**Table 71. Status codes for the action**

HTTP status code	Extended information	Error Message Code
202		
400	Base.1.2.PropertyMissing	
400	Base.1.2.PropertyValueTypeError	
400	Base.1.2.PropertyValueNotInList	
400		RAC013, SYS406, SYS433, RAC1155
500	Base.1.2.InternalError	SWC0058
503		RAC052
503		RAC0679

## Share parameters and values

**Table 72. Share parameters and values**

Parameter	Values
IPAddress	IP address of the network share
ShareName	Name of network share
FileName	File name for the SCP
ShareType	LOCAL, CIFS, NFS, HTTP, HTTPS
Username	User name to log on to the share — for CIFS share only.
Password	Password to log on to the share — for CIFS share only.
Workgroup	Workgroup name to log on to the share
Target	Can be the component name or an FQDD. The default value is ALL.

# Drive

## Description

The Drive schema represents a single physical disk drive for a system, including links to associated Volumes.

## URL

```
/redfish/v1/Systems/<id>/Storage/Drives/<id>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login
GET	Login
PATCH	ConfigureComponents, Login

## Updatable Properties

Property	Value
HotspareType	None, Global, Dedicated,
EncryptionStatus	Unencrypted, Unlocked, Locked, Foregin,
EncryptionAbility	None, SelfEncryptingDrive,
MediaType	HDD, SSD

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
202		

## Supported Action—SecureErase

### Description

This action is used to securely erase the contents of the drive.

## URL

/redfish/v1/Systems/<ID>/Storage/Drives/<ID>/Actions/Drive.SecureErase

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login

## Supported Parameters

Parameter	Value
HotspareType	None, Global, Dedicated,
EncryptionStatus	Unencrypted, Unlocked, Locked, Foregin,
EncryptionAbility	None, SelfEncryptingDrive,
MediaType	HDD, SSD

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	
202		

## EthernetInterfaceCollection

### Description

A Collection of EthernetInterface resource instances.

## URL

/redfish/v1/Systems/System.Embedded.1/EthernetInterfaces

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

# Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# EthernetInterfaces

## Description

This resource is used to represent NIC resources as part of the Redfish specification. It also updates the properties of Manager Ethernet Interface.

**NOTE:** Only device FQDDs that are associated with physical network controllers are displayed. If iSM is installed and running, and there are only software Ethernet interfaces available on the system, a response code of 200 and an empty collection is returned.

## URL

/redfish/v1/Managers/<ID>/EthernetInterfaces

## HTTP methods and privileges

Table 73. HTTP methods and privileges for EthernetInterfaces

HTTP method	Required privilege
GET	Login

## Ethernet — Instance

## URL

/redfish/v1/Managers/<ManagerInstanceID>/EthernetInterfaces/<EthernetInstanceID>

# HTTP methods and privileges

Table 74. HTTP methods and privileges for instance of EthernetInterfaces

HTTP method	Required privilege
PATCH	ConfigureManager

# Properties

Table 75. Properties for EthernetInterfaces

Property	Description
Hostname	Updates hostname
IPv4	Updates IPv4
IPv6	Updates IPv6
IPv6Static	Updates IPv6Static

# Status codes and error message codes

Table 76. Status codes and error message codes for EthernetInterfaces

HTTP status code	Extended information	Error Message Code
200	Base.1.0.success	
400	<ul style="list-style-type: none"><li>Base.1.0.PropertyValueTypeError</li><li>Base.1.0.PropertyValueNotInList</li><li>Base.1.0.PropertyUnknown</li><li>Base.1.0.PropertyNotWritable</li><li>Base.1.0.PropertyValueFormatError</li></ul>	<ul style="list-style-type: none"><li>ISM0013</li><li>RAC0253</li><li>RAC0254</li><li>RAC0255</li><li>RAC0259</li><li>SWC0296</li></ul>
500	Base.1.0.InternalError	

# Reference Properties

## URL

/redfish/v1/Systems/<ServiceTag+nodeid>/EthernetInterfaces

## Description

This resource is used to represent NIC resources as part of the Redfish specification.

## HTTP methods and privileges

Table 77. HTTP methods and privileges

HTTP method	Required privilege
GET	Login

## Status codes

Table 78. Status codes

HTTP status code
200
400
500

## Implementation notes

Some of the properties in this schema are dependent on the installed BIOS and iDRAC Service Module (iSM) version. If a compatible version of BIOS is not installed, **UefiDevicePath** is not supported in this resource. If a compatible version of iSM is not installed, certain properties may not be supported.

## EventService

### Description

The Event Service resource contains properties for managing event subscriptions and generates the events sent to subscribers. The resource has links to the actual collection of subscriptions (called Event Destinations).

**NOTE:** You can use the **IgnoreCertificateErrors** attribute in **OEMAttributes** to ignore certificate errors.

### URL

/redfish/v1/EventService

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureManager, Login
GET	Login
PATCH	ConfigureManager, Login



# Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.2.Success	SYS413
400	Base.1.2.GeneralError, Base.1.2.PropertyUnknown	
405	Base.1.2.GeneralError	SYS402

Supported Action — SubmitTestEvent

## Contained Resource

Subscriptions

# Supported Action — SubmitTestEvent

## Description

This action is used to generate a test event.

## URL

`/redfish/v1/EventService/Actions/EventService.SubmitTestEvent`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureManager, Login

# FabricCollection

## Description

A Collection of Fabric resource instances.

## URL

`/redfish/v1/Fabrics`

# Supported HTTP Method and Privileges

## Required Privilege

T  
T  
P  
M  
e  
t  
h  
o  
d

---

Login

E

T

## Contained resources

PCIe

# PCIe

## Description

The Fabric schema represents a simple fabric consisting of one or more switches, zero or more endpoints, and zero or more zones.

## URL

/redfish/v1/Fabrics/PCIe

# Supported HTTP Method and Privileges

## HTTP Method

## Required Privilege

---

GET

Login

## Supported Status Codes

### HTTP Status Code

### Extended Information

### Error Code

---

200

401

Base.1.2.AccessDenied

404

Base.1.2.ResourceMissingAtURI

SYS403

405

SYS402

HTTP Status Code	Extended Information	Error Code
500	Base.1.2.InternalError	SYS446
503		

## Contained resources

Switches

# HostInterfaceCollection

## Description

A Collection of HostInterface resource instances.

## URL

`/redfish/v1/Managers/iDRAC.Embedded.1/HostInterfaces`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## Navigation URL

`/redfish/v1/Managers/iDRAC.Embedded.1/HostInterfaces/<id>`

# Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	
GET	Login
PATCH	

## JSONSchemas

### Description

This resource is used for representing the Schema File locator resource for a Redfish implementation.

### URL

`/redfish/v1/JSONSchemas`

## HTTP methods and privileges

Table 79. HTTP methods and privileges for JSONSchemas

HTTP method	Required privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## LogEntryCollection

### Description

A Collection of LogEntry resource instances.

# URL

/redfish/v1/Managers/iDRAC.Embedded.1/Logs/FaultList

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# LogService

## Description

This resource represents the log service for the resource or service to which it is associated.

# URL

/redfish/v1/Managers/iDRAC.Embedded.1/LogServices/FaultList

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ClearLogs, Login
GET	Login
PATCH	ConfigureManager, Login

## Supported Parameters

Parameter	Value
OverWritePolicy	WrapsWhenFull

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
204		

## LogServiceCollection

### Description

A Collection of LogService resource instances.

### URL

```
/redfish/v1/Managers/iDRAC.Embedded.1/LogServices
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

Supported Action — ClearLog

## Supported Action — ClearLog

### Description

This action is used to clear the log for this Log Service.

### URL

```
/redfish/v1/Managers/iDRAC.Embedded.1/LogServices/Sel/Actions/LogService.ClearLog
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ClearLogs, Login

## Supported Parameters

Parameter	Value
OverWritePolicy	WrapsWhenFull

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
204		

# ManagerCollection

## Description

A Collection of Manager resource instances.

## URL

`/redfish/v1/Managers`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446

HTTP Status Code	Extended Information	Error Code
503		

## Navigation URL

/redfish/v1/Managers/<id>

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureManager, Login
GET	Login
PATCH	ConfigureManager, Login

## Updatable properties

Property	Value
ManagerType	BMC
CommandConnectTypesSupported	SSH, Telnet, IPMI
GraphicalConnectTypesSupported	KVMIP
ResetType	GracefulRestart

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
204		
400	MalformedJSON	SYS405
400	Base.1.2.PropertyValueNotInList	SYS426
400		SYS406
400	PropertyValueTypeError	
403	InsufficientPrivilege	RAC0506
403		LIC501
404	Base.1.2.ResourceMissingAtURI	SYS403
500	Base.1.2.InternalError	SYS446

[Supported Action — Reset](#)

[Supported Action — ResetToDefaults](#)

Related Link: [DellManager](#)



# Supported Action — Reset

## Description

The reset action resets/reboots the manager.

## URL

```
/redfish/v1/Managers/iDRAC.Embedded.1/Actions/Manager.Reset
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureManager, Login

## Supported Status Codes

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
204		
400	MalformedJSON	SYS405
400	Base.1.2.PropertyValueNotInList	SYS426
400		SYS406
400	PropertyValueTypeError	
403	InsufficientPrivilege	RAC0506
403		LIC501
404	Base.1.2.ResourceMissingAtURI	SYS403
500	Base.1.2.InternalError	SYS446

# ManagerAccountCollection

## Description

This resource represents the BMC user accounts collection for a Redfish implementation.

## URL

```
/redfish/v1/Managers/<ID>/Accounts
```

# HTTP methods and privileges

Table 80. HTTP methods and privileges for ManagerAccount

HTTP method	Required privilege
GET	Login

## Navigation URL

/redfish/v1/Managers/<ID>/Accounts/<Account-id>

# HTTP methods and privileges

Table 81. HTTP methods and privileges for the instance of the resource

HTTP method	Required privilege
GET	Login

## Updatable properties

Table 82. Properties and values for instance of the resource

Property	Value
UserName	Updates account user name
Password	Updates account password
RoleId	Updates account role
Enabled	Enables or disables the user

## Status codes

Table 83. Status codes for the instance of the resource

HTTP status code	Error message code
200	
400	<ul style="list-style-type: none"><li>· RAC0288</li><li>· RAC0291</li></ul>
404	
500	

Role

# ManagerNetworkProtocol

## Description

This resource is used to obtain or modify the network services managed by a given manager.

## URL

`/redfish/v1/Managers/iDRAC.Embedded.1/NetworkProtocol`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureManager, Login
GET	Login

**NOTE:** For information about the DHCP version, execute GET on URL

`/redfish/v1/Managers/iDRAC.Embedded.1/Attributes`

## Updatable properties

Property
FQDN
Hostname
HTTP
HTTPS
IPMI
KVMIP
SNMP
SSH
Telnet
VirtualMedia

# Status codes

HTTP status code	Extended information
200	Base.1.0.Success
400	Base.1.0.PropertyValueTypeError, Base.1.0.PropertyValueNotInList, Base.1.0.PropertyUnknown, Base.1.0.PropertyNotWritable, Base.1.0.PropertyValueFormatError
403	Insufficient privileges
500	Base.1.0.InternalError

# MemoryCollection

## Description

A Collection of Memory resource instances.

## URL

`/redfish/v1/Systems/System.Embedded.1/Memory`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# Navigation URL

`/redfish/v1/Systems/System.Embedded.1/Memory/<id>`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login, ConfigureComponents
GET	Login

## Supported Parameters

Parameter	Value
ErrorCorrection	NoECC SingleBitECC MultiBitECC AddressParity
MemoryDeviceType	ROM SDRAM DDR DDR2 DDR3 DDR4
MemoryMedia	null
OperatingMemoryModes	Null
BaseModuleType	Null
MemoryType	null

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
405	Base.1.2.GeneralError	IDRAC.1.6.SYS402

[Supported Action — MemoryMetrics](#)

## Supported Action — MemoryMetrics

### Description

MemoryMetrics contains usage and health statistics for a single Memory module or device instance.

### URL

`/redfish/v1/Systems/System.Embedded.1/Memory/iDRAC.Embedded.1%23DIMMSLOTA1/Metrics`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	Login, ConfigureComponents

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
405	Base.1.2.GeneralError	IDRAC.1.6.SYS402

# MessageRegistryFile

## Description

This is the schema definition for the Schema File locator resource.

## URL

/redfish/v1/Registries/Messages

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# MessageRegistryFileCollection

## Description

A Collection of MessageRegistryFile resource instances.

## URL

/redfish/v1/Registries

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## Messages

### Description

This resource is used to represent a Event and Error message registry for a Redfish implementation.

### URL

/redfish/v1/Registries/Messages

# HTTP methods and privileges

Table 84. HTTP methods and privileges for Messages

HTTP method	Required privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## NetworkAdapterCollection

### Description

A Collection of NetworkAdapter resource instances.

**NOTE:** The Manufacturer, Model, Serial Number, and Part Number attributes are not applicable for embedded NICs.

### URL

`/redfish/v1/Systems/System.Embedded.1/NetworkAdapters`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login



# Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# NetworkDeviceFunctions

## Description

This resource is used to represent the collection of NetworkDeviceFunction.

## URL

`/redfish/v1/Systems/System.Embedded.1/NetworkAdapters/<NetworkAdapters-Id/NetworkDeviceFunctions`

## HTTP methods and privileges

Table 85. HTTP methods and privileges for NetworkDeviceFunctions

HTTP method	Required privilege
GET	Login

## Updatable properties

Table 86. Properties for the Settings resource

Property	Description
@Redfish.SettingsApplyTime	Define when the settings are applied. This is supported on the Settings URL.

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## NetworkDeviceFunctions — Instance

### Description

This resource is used to represent a logical interface exposed by the network adapter.

### URL

```
/redfish/v1/Systems/System.Embedded.1/NetworkAdapters/<NetworkAdapters-Id/NetworkDeviceFunctions/<NetworkDeviceFunction-Id>
```

### HTTP methods and privileges

Table 87. HTTP methods and privileges for the instance of NetworkDeviceFunctions

HTTP method	Required privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## NetworkDeviceFunctions — Settings

### Description

This resource is used to set the new value and create job to update the attributes of the logical interface exposed by the network adapter.

## URL

```
/redfish/v1/Systems/System.Embedded.1/NetworkAdapters/<NetworkAdapters-Id/NetworkDeviceFunctions/<NetworkDeviceFunction-Id>/Settings
```

## HTTP methods and privileges

Table 88. HTTP methods and privileges for the resource

HTTP method	Required privilege
GET	Login
PATCH	Login + SystemControl

## Required parameters

Table 89. Parameters for NetworkDeviceFunction Settings

Parameter	Type	Description
Status		
MaxVirtualFunctions	Int64	The number of virtual functions (VFs) that are available for this Network Device Function.
NetDevFuncCapabilities	Collection(NetworkDeviceFunction.v1_0_0.NetworkDeviceTechnology)	Capabilities of this network device function. <b>i</b> <b>NOTE: The values of NetDevFuncCapabilities are determined by the port that the partition belongs to. The values of NetDevFuncCapabilities for all the partitions belonging to a particular port are the same.</b>
NetDevFuncType	NetworkDeviceFunction.v1_0_0.NetworkDeviceTechnology	The configured capability of this network device function.
<b>FibreChannel</b>		
WWPN	String	The effective current World-Wide Port Name (WWPN) of this network device function (physical function). If an assignable WWPN is not supported, WWPN is a read only alias of the PermanentWWPN.
PermanentWWPN	String	PermanentWWPN is the permanent WWPN address assigned to this network device function (physical function).
WWNN	String	The effective current World-Wide Node Name (WWNN) of this network device function (physical function). If an assignable WWNN is not supported, WWNN is a read only alias of the PermanentWWNN.

Parameter	Type	Description
WWNSource	NetworkDeviceFunction.v1_0_0.WWNSource	The configuration source of the World-Wide Names (WWNs) for this connection (WWPN and WWNN).
FCoELocalVLANId	Int64	For FCoE connections, The VLAN ID configured locally by setting this property. This value shall be used for FCoE traffic to this network device function during boot unless AllowFIPVLANDiscovery is true and a valid FCoE VLAN ID is found via the FIP VLAN Discovery Protocol.
FCoEActiveVLANId	Int64	The active FCoE VLAN ID.
<b>BootTargets</b>		
WWPN	String	World-Wide Port Name (WWPN) to boot from.
LUNID	String	The Logical Unit Number (LUN) ID to boot from on the device referred to by the corresponding WWPN.
<b>Ethernet</b>		
MACAddress	String	The effective current MAC Address of this network device function. If an assignable MAC address is not supported, this is a read-only alias of the PermanentMACAddress.
PermanentMACAddress	String	This is the permanent MAC address assigned to this network device function (physical function).
MTUSize	Int64	The Maximum Transmission Unit (MTU) configured for this Network Device Function. This value serves as a default for the OS driver when booting. The value only takes effect on boot.
<b>iSCSIBoot</b>		
IPAddressType	NetworkDeviceFunction.v1_0_0.IPAddressType	The type of IP address (IPv6 or IPv4) being populated in the iSCSIBoot IP address fields. Mixing of IPv6 and IPv4 addresses on the same network device function shall not be permissible.
InitiatorIPAddress	String	The IPv6 or IPv4 address of the iSCSI boot initiator.
InitiatorName	String	The iSCSI boot initiator name.
InitiatorDefaultGateway	String	The IPv6 or IPv4 iSCSI boot default gateway.
InitiatorNetmask	String	The IPv6 or IPv4 netmask of the iSCSI boot initiator.

Parameter	Type	Description
TargetInfoViaDHCP	String	A boolean indicating whether the iSCSI boot target name, LUN, IP address, and netmask should be obtained from DHCP.
PrimaryTargetName	String	The name of the primary iSCSI boot target (iSCSI Qualified Name, IQN).
PrimaryTargetIPAddress	String	The IP address (IPv6 or IPv4) for the primary iSCSI boot target.
PrimaryTargetTCPPort	Int64	The TCP port for the primary iSCSI boot target.
PrimaryLUN	Int64	The logical unit number (LUN) for the primary iSCSI boot target.
PrimaryVLANEnable	Boolean	It indicates if this VLAN is enabled for the primary iSCSI boot target.
PrimaryVLANId	Int64	The 802.1q VLAN ID to use for iSCSI boot from the primary target. This VLAN ID is only used if PrimaryVLANEnable is true.
PrimaryDNS	String	The IPv6 or IPv4 address of the primary DNS server for the iSCSI boot initiator.
SecondaryTargetName	String	The name of the Secondary iSCSI boot target (iSCSI Qualified Name, IQN).
SecondaryTargetIPAddress	String	The IP address (IPv6 or IPv4) for the Secondary iSCSI boot target.
SecondaryTargetTCPPort	Int64	The TCP port for the Secondary iSCSI boot target.
SecondaryLUN	Int64	The logical unit number (LUN) for the Secondary iSCSI boot target.
SecondaryVLANEnable	Boolean	It indicates if this VLAN is enabled for the Secondary iSCSI boot target.
SecondaryVLANId	Int64	The 802.1q VLAN ID to use for iSCSI boot from the Secondary target. This VLAN ID is only used if SecondaryVLANEnable is true.
SecondaryDNS	String	The IPv6 or IPv4 address of the Secondary DNS server for the iSCSI boot initiator.
IPMaskDNSViaDHCP	Boolean	A boolean indicating whether the iSCSI boot initiator uses DHCP to obtain the initiator name, IP address, and netmask.
AuthenticationMethod	NetworkDeviceFunction.v1_0_0.AuthenticationMethod	The iSCSI boot authentication method for this network device function.
CHAPUsername	String	The username for CHAP authentication.
CHAPSecret	String	The shared secret for CHAP authentication.

## Status codes

Table 90. Status codes

HTTP status code	Extended information	Error message code
200		
202		
400	<ul style="list-style-type: none"><li>Base.1.0.PropertyValueTypeError</li><li>Base.1.0.PropertyUnknown</li></ul>	
403	Base.1.0.InsufficientPrivilege	RAC0506
405	Base.1.0.GeneralError	SYS402
500	Base.1.0.InternalError	

# NetworkInterfaceCollection

## Description

A Collection of NetworkInterface resource instances.

## URL

/redfish/v1/Systems/System.Embedded.1/NetworkInterfaces

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# PCleDevice

## Description

This is the schema definition for the PCleDevice resource. It represents the properties of a PCleDevice attached to a System.

## URL

```
/redfish/v1/Systems/System.Embedded.1/PCleDevice/<id>
```

- NOTE:** Response for a Get operation for PCle device will not report Part number or Model for any entry.
- NOTE:** For SerialNumber, the value may or may not be displayed depending on the type of PCle device.
- NOTE:** Executing GET for the above URL for network devices may not display the firmware information of the card. For firmware information, execute GET on the other ports of the same card.

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# PCleFunction

## Description

This is the schema definition for the PCleFunction resource. It represents the properties of a PCleFunction attached to a System.

# URL

/redfish/v1/Systems/System.Embedded.1/PCIEFunction/<id>

**NOTE:** If you execute Get on the above URL, the properties Bus /Device/ Function are not displayed. However, their value is displayed in the format <BUS-Device-Function> for property id (for example <24-0-1>).

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# Port

## Description

Port contains properties describing a port of a PCIE switch. This resource is used to represent a PCIE switch port for a Redfish implementation.

# URL

/redfish/v1/Fabrics/PCIE/Switches/<PCIE switch ID>/Ports/<PCIE Switch port Id>

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login



## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## PortCollection

### Description

PortCollection resource contains the members of selected pcie switch device.

### URL

```
/redfish/v1/Fabrics/PCIE/Switches/<PCIE switch ID>/Ports
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# Power

## Description

This is the schema definition for the Power Metrics. It represents the properties for Power Consumption and Power Limiting.

## URL

```
/redfish/v1/Chassis/System.Embedded.1/Power
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## Reference Properties

[PowerControl](#)  
[Voltage](#)

## PowerControl

### Description

This is the base type for addressable members of an array.

### URL

```
/redfish/v1/Chassis/System.Embedded.1/Power/PowerControl
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login
PATCH	ConfigureManager, Login

## Voltage

### Description

This is the base type for addressable members of an array.

### URL

```
/redfish/v1/Chassis/System.Embedded.1/Sensors/Voltages/<id>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureManager, Login
GET	Login
PATCH	ConfigureManager, Login

## PrivilegeRegistry

### Description

This is the schema definition for Operation to Privilege mapping. The Privileges displayed for each entity are in accordance to the capabilities furnished in the corresponding schema and does not mandatorily imply support for that operation in the implementation.

### URL

```
/redfish/v1/Managers/iDRAC.Embedded.1/PrivilegeRegistry
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## ProcessorCollection

### Description

A Collection of Processor resource instances.

### URL

`/redfish/v1/Systems/System.Embedded.1/Processors`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# Navigation URL

/redfish/v1/Systems/System.Embedded.1/Processors/<id>

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# Role

## Description

This resource defines a user role to be used in conjunction with a Manager Account.

## URL

/redfish/v1/Managers/iDRAC.Embedded.1/Roles

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## RoleCollection

### Description

A Collection of Role resource instances.

### URL

`/redfish/v1/Managers/iDRAC.Embedded.1/Roles`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# SecureBoot

## Description

This resource contains UEFI Secure Boot information. It represents properties for managing the UEFI Secure Boot functionality of a system.

## URL

/redfish/v1/Systems/<ID>/SecureBoot

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login
GET	Login
PATCH	ConfigureComponents, Login

## Updatable properties

Property	Description
SecureBootEnable	Enable or disable UEFI Secure Boot (takes effect on next boot)

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200	Base.1.0.Success	
200	Base.1.2.Success	SYS413
400	Base.1.0.PropertyValueTypeError, Base.1.0.PropertyValueNotInList	
403	Base.1.0. InsufficientPrivilege	
404	Base.1.0.ResourceMissingAtURI	
405	Base.1.2.GeneralError	SYS402
500	Base.1.0.InternalError	

[Supported Action](#) — [ResetKeys](#)

# Supported Action — ResetKeys

## Description

This action is used to reset the Secure Boot keys.

## URL

```
/redfish/v1/Systems/System.Embedded.1/SecureBoot/Actions/SecureBoot.ResetKeys
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	
400	Base.1.0.PropertyValueTypeError	
	Base.1.0.PropertyValueNotInList	
403	Base.1.0. InsufficientPrivilege	
404	Base.1.0.ResourceMissingAtURI	
500	Base.1.0.InternalError	

# SerialInterfaceCollection

## Description

A Collection of SerialInterface resource instances.

## URL

```
/redfish/v1/Managers/<ID>/SerialInterfaces
```



## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## Navigation URL

/redfish/v1/Managers/<ID>/SerialInterfaces/<Serial-key>

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureManager, Login
GET	Login
PATCH	ConfigureManager, Login

## Updatable properties

Property	Description
SignalType	Rs232
BitRate	9600, 19200, 38400, 57600, 115200
PinOut	Cisco
Parity	None
DataBits	8
StopBits	1
FlowControl	Hardware

Property	Description
PinOut	Cisco
ConnectorType	DB9 Male

## ServiceRoot

### Description

This object represents the root Redfish service.

### URL

/redfish/<id>

### Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	

### Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## Session

### URL

/redfish/v1/Sessions

### Description

This resource is used to represent a session for a Redfish implementation.

# HTTP methods and privileges

Table 91. HTTP methods and privileges for Session

HTTP method	Required privilege
GET	Login
POST	ConfigureManager

## Updatable properties

Table 92. Properties and values for Session

Parameter	Description
UserName	Username
Password	Password

## Status codes

Table 93. Status codes for Session

HTTP status code	Extended information
200	
201	
400	<ul style="list-style-type: none"><li>Base.1.0.PropertyValueTypeError</li><li>Base.1.0.PropertyValueNotInList</li><li>Base.1.0.PropertyUnknown</li><li>Base.1.0.PropertyNotWritable</li><li>Base.1.0.PropertyValueFormatError</li></ul>
500	Base.1.0.InternalError

## Action — Delete

### URL

`/redfish/v1/Sessions/<session-id>`

### Description

Performs delete operation on the session ID.

## HTTP methods and privileges

Table 94. HTTP methods and privileges for Delete

HTTP method	Required privilege
DELETE	ConfigureManager, Login

## Status codes

Table 95. Status codes for Delete

HTTP status code
200
400
500

# SessionService

## Description

This is the schema definition for the Session Service. It represents the properties for the service itself and has links to the actual list of sessions.

## URL

`/redfish/v1/SessionService`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
PATCH	ConfigureManager, Login

## Updatable properties

Property	Description
SessionTimeout	Updates web server timeout

## Supported Status Codes

HTTP Status Code	Extended Information
200	Base.1.0.Success
400	Base.1.0.PropertyValueTypeError, Base.1.0.PropertyValueNotInList, Base.1.0.PropertyUnknown, Base.1.0.PropertyNotWritable, Base.1.0.PropertyValueFormatError
500	Base.1.0.InternalError

## SimpleStorage

### Description

This property contains the UEFI device path used to identify and locate a specific storage controller.

### URL

`/redfish/v1/Systems/System.Embedded.1/SimpleStorage/Controllers`

## HTTP methods and privileges

Table 96. HTTP methods and privileges for SimpleStorage

HTTP method	Required privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# SoftwareInventoryCollection

## Description

Collection of Firmware Inventory.

## URL

/redfish/v1/UpdateService/FirmwareInventory

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login
GET	Login

## Status codes

Table 97. Status codes for SoftwareInventory

HTTP status code	Extended information	Error message code
201		
400		<ul style="list-style-type: none"><li>· SYS406</li><li>· OSD35</li><li>· SYS0604</li><li>· SYS434</li></ul>
400	Base.1.2.InternalError	SYS446
403	Base.1.0.InsufficientPrivilege	RAC0506
403		LIC501
404	Base.1.0.ResourceMissingAtURI	SYS403
405		SYS402
412		SYS400
415		SYS4011
428		SYS404
500	Base.1.0.InternalError	SYS412
503		SUP0108

## Navigation URL

/redfish/v1/UpdateService/FirmwareInventory/<id>

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## Status codes

Table 98. Status codes for the action

HTTP status code	Extended information	Error message code
200		
400		<ul style="list-style-type: none"><li>· SYS406</li><li>· OSD35</li><li>· RAC0604</li></ul>
400	Base.1.2.InternalError	SYS446
403	InsufficientPrivilege	RAC0506
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
412		SYS400
428		SYS404
500	Base.1.2.InternalError	SYS446

# StorageCollection

## Description

A Collection of Storage resource instances.

## URL

```
/redfish/v1/Systems/System.Embedded.1/Storage
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## Navigation URL

```
/redfish/v1/Systems/System.Embedded.1/Storage/<id>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login
POST	ConfigureComponents, Login
PATCH	ConfigureComponents, Login



## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
405	Base.1.2.GeneralError	SYS402

## StorageController

### Description

This schema defines a storage controller and its respective properties. A storage controller represents a storage device (physical or virtual) that produces Volumes.

### URL

`/redfish/v1/Systems/System.Embedded.1/StorageControllers/<id>`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login
GET	Login
PATCH	ConfigureComponents, Login

## Subscriptions

### Description

This property contains a URL to the destination where the events are sent.

### URL

`/redfish/v1/EventService/Subscriptions`

# HTTP methods and privileges

Table 99. HTTP methods and privileges for EventDestination

HTTP method	Required privilege
GET	Login
POST	ConfigureManager

## Properties

Table 100. Properties for EventDestination

Property	Description
Destination	Destination IP to send event
EventTypes	Contains the type of the event
Context	Client-supplied string — Optional
Protocol	Protocol type used by event

## Status codes

Table 101. Status codes for EventDestination

HTTP status code	Extended information
200	
201	
400	<ul style="list-style-type: none"><li>Base.1.0.PropertyValueTypeError</li><li>Base.1.0.PropertyValueNotInList</li><li>Base.1.0.PropertyUnknown</li><li>Base.1.0.PropertyNotWritable</li><li>Base.1.0.PropertyValueFormatError</li></ul>
404	Base.1.0.ResourceMissingAtURI
500	Base.1.0.InternalError
503	

## Switches

### Description

A Collection of Switch resource instances.

# URL

/redfish/v1/Fabrics/PCIe/Switches

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

# TaskCollection

## Description

A Collection of Task resource instances.

# URL

/redfish/v1/TaskService/Tasks

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# TaskService

## Description

This is the schema definition for the Task Service. It represents the properties for the service itself and has links to the actual list of tasks.

## URL

```
/redfish/v1/TaskService
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# Thermal

## Description

This is the schema definition for the Thermal properties. It represents the properties for Temperature and Cooling.

## URL

```
/redfish/v1/Chassis/Chassis.Embedded.1/Thermal
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureManager, Login
GET	Login
PATCH	ConfigureManager, Login

## Supported Parameters

Parameter	Value
ReadingUnits	RPM

## Reference Properties

Temperature

### Temperature

#### Description

Above normal range.

#### URL

```
/redfish/v1/Chassis/System.Embedded.1/Sensors/Temperatures/<id>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureManager, Login
GET	Login
PATCH	ConfigureManager, Login

## Supported Parameters

Parameter	Value
ReadingUnits	RPM

# UpdateService

## Description

This is the schema definition for the Update Service. It represents the properties for the service itself and has links to collections of firmware and software inventory.

## URL

```
/redfish/v1/UpdateService
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login
POST	ConfigureComponents, Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		

## Supported action — SimpleUpdate

### Description

This resource is used to represent extension of the UpdateService schema of Redfish.

You can use the this action to update only one component at a time. If you attempt to update multiple components at once, error SYS442 is returned. To update multiple components, perform the updates one at a time.

If you use this action to update iDRAC, the update is applied immediately and the system reboots. For other components, the update is applied at the next reboot.

### URL

```
/redfish/v1/UpdateService/Actions/UpdateService.SimpleUpdate
```

# HTTP methods and privileges

Table 102. HTTP methods and privileges for SimpleUpdate

HTTP method	Required privilege
POST	<ul style="list-style-type: none"><li>• <b>.d9</b> file type — ConfigureComponents, Login</li><li>• <b>.pm</b> file type — ConfigureComponents, Login</li><li>• <b>.exe</b> file type — ConfigureComponents, Login</li></ul>

# Status codes

Table 103. Status codes for SimpleUpdate

HTTP status code	Extended information	Error Message Code
202		SYS408
400		<ul style="list-style-type: none"><li>• SYS406</li><li>• OSD35</li><li>• RAC0604</li><li>• SYS434</li><li>• SUP019</li><li>• SUP024</li><li>• SYS442</li></ul>
400	<ul style="list-style-type: none"><li>• Base.1.2.InternalError</li><li>• Base.1.2.PropertyMissing</li><li>• Base.1.2.PropertyValueTypeError</li><li>• Base.1.2.PropertyValueNotInList</li></ul>	SYS446
400	Base.1.2.MalformedJSON	SYS405
403	InsufficientPrivilege	RAC0506
403		LIC501
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	<ul style="list-style-type: none"><li>• SYS446</li><li>• SUP1907</li></ul>
503		SUP0108

# VirtualMedia

## Description

This resource is used to represent a virtual media service for a Redfish implementation.

① | **NOTE:** HTTP shares with authentication are not supported for virtual media.

① | **NOTE:** Using the character '@' in virtual media User name or Password is not supported.

## URL

/redfish/v1/Managers/<ID>/VirtualMedia

## HTTP methods and privileges

**Table 104. HTTP methods and privileges for VirtualMedia**

HTTP method	Required privilege
GET	Login
POST	ConfigureManager, Login

## Status codes

**Table 105. Status codes for VirtualMedia**

HTTP status code	Extended information
200	
400	
403	Insufficient privileges.
500	

## Properties and values

**Table 106. Properties and values for VirtualMedia**

Property	Values
MediaTypes	<ul style="list-style-type: none"><li>· CD</li><li>· DVD</li><li>· USBStick</li></ul>
ConnectedVia	<ul style="list-style-type: none"><li>· NotConnected</li><li>· Applet</li></ul>



# VlanNetworkInterface

## Description

The value of this property indicates if VLAN is enabled for this interface.

## URL

/redfish/v1/Systems/<ID>/EthernetInterfaces/<EthernetInstanceID>/Vlans

## HTTP methods and response content type

Table 107. HTTP methods and response content type for VlanNetworkInterface

HTTP method	Response content type
GET	application/json

## Status codes

Table 108. Status codes for VlanNetworkInterface

HTTP status code
200
400
500

# VolumeCollection

## Description

A Collection of Storage resource instances.

## URL

/redfish/v1/Systems/System.Embedded.1/Storage/<ID>/Volumes

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login
GET	Login

## Navigation URL

```
/redfish/v1/Systems/System.Embedded.1/Storage/Volumes/<id>
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
DELETE	ConfigureComponents, Login
POST	ConfigureComponents, Login
GET	Login
PATCH	ConfigureComponents, Login

## Supported Parameters

Parameter	Value
VolumeType	RawDevice, NonRedundant, Mirrored, StripedWithParity, SpannedMirrors, SpannedStripesWithParity
EncryptionTypes	NativeDriveEncryption, ControllerAssisted, SoftwareAssisted

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
200	Base.1.0.Success	

[Supported Action — Initialize](#)

[Supported Action — CheckConsistency](#)

## Supported Action — CheckConsistency

### Description

## URL

```
/redfish/v1/Systems/System.Embedded.1/Storage/Volumes/Disk.Direct.0-0:AHCI.Embedded.2-1/Actions/Volume.CheckConsistency
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login

## Supported Parameters

Parameter	Value
VolumeType	RawDevice, NonRedundant, Mirrored, StripedWithParity, SpannedMirrors, SpannedStripesWithParity
EncryptionTypes	NativeDriveEncryption, ControllerAssisted, SoftwareAssisted

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200	Base.1.0.Success	
200		

## Supported Action — Initialize

### Description

This action is used to prepare the contents of the volume for use by the system.

## URL

```
/redfish/v1/Systems/System.Embedded.1/Storage/Volumes/Disk.Direct.0-0:AHCI.Embedded.2-1/Actions/Volume.Initialize
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
POST	ConfigureComponents, Login

## Supported Parameters

Parameter	Value
VolumeType	RawDevice, NonRedundant, Mirrored, StripedWithParity, SpannedMirrors, SpannedStripesWithParity
EncryptionTypes	NativeDriveEncryption, ControllerAssisted, SoftwareAssisted

## Supported Status Codes

HTTP Status Code	Extended Information	Error Message Code
200		
200	Base.1.0.Success	

## NetworkPort

### Description

A Network Port represents a discrete physical port capable of connecting to a network.

### URL

```
/redfish/v1/Systems/System.Embedded.1/NetworkAdapters/NIC.Embedded.2/NetworkPorts/NIC.Embedded.2-1
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# NetworkPortCollection

## Description

A Collection of NetworkPort resource instances.

## URL

`/redfish/v1/Systems/System.Embedded.1/NetworkAdapters/NIC.Embedded.1/NetworkPorts`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# NetworkDeviceFunctionCollection

## Description

A Collection of NetworkDeviceFunction resource instances.

## URL

`/redfish/v1/Systems/System.Embedded.1/NetworkAdapters/NIC.Embedded.1/NetworkDeviceFunctions`

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

## Redundancy

### Description

This is the redundancy definition to be used in other resource schemas.

### URL

```
/redfish/v1/Chassis/System.Embedded.1/Thermal/Redundancy/iDRAC.Embedded.1%23SystemBoardFanRedundancy
```

## Supported HTTP Method and Privileges

HTTP Method	Required Privilege
GET	Login

## Supported Status Codes

HTTP Status Code	Extended Information	Error Code
200		
401	Base.1.2.AccessDenied	
404	Base.1.2.ResourceMissingAtURI	SYS403

<b>HTTP Status Code</b>	<b>Extended Information</b>	<b>Error Code</b>
405		SYS402
500	Base.1.2.InternalError	SYS446
503		

# Examples

**NOTE:** For more information about Redfish and detailed examples, see the white papers available at <https://www.dmtf.org/standards/redfish>.

The following table provides usage examples for the HTTP supported methods such as GET, POST, PATCH, and DELETE:

Topics:

- [Example for GET](#)
- [Example for PATCH](#)
- [Example for POST](#)
- [Example for DELETE](#)
- [Example of Job Creation](#)
- [Examples for \\$expand](#)
- [Examples for \\$select](#)
- [Examples for \\$filter](#)

## Example for GET

URL	<code>/redfish/v1/Managers/iDRAC.Embedded.1/SerialInterfaces</code>
Output	<pre>{   "@odata.context": "/redfish/v1/\$metadata#Managers/Members/iDRAC.Embedded.1/SerialInterfaces/\$entity",   "@odata.count": 1,   "@odata.id": "/redfish/v1/Managers/iDRAC.Embedded.1/SerialInterfaces",   "@odata.type": "#SerialInterface.1.0.0.SerialInterfaceCollection",   "Description": "Collection of Serial Interfaces for this System",   "Members": [     {       "@odata.id": "/redfish/v1/Managers/iDRAC.Embedded.1/SerialInterfaces/iDRAC.Embedded.1#Serial.1"     }   ],   "Name": "Serial Interface Collection" }</pre>

## Example for PATCH

URL	<code>/redfish/v1/Managers/iDRAC.Embedded.1/Accounts/&lt;Account-id&gt;</code>
Input	<code>{"Password": "123", "UserName": "reader"}</code>
Output	<pre>{   "Success": {     "Message": "Successfully Completed Request",     "MessageId": "Base.1.0.Success",     "Resolution": "None",     "Severity": "Ok"   } }</pre>



```
}  
}
```

## Example for POST

URL `/redfish/v1/Systems/System.Embedded.1/Actions/ComputerSystem.Reset`

Input `{"ResetType": "ForceRestart"}`

Output `204: No Content`

## Example for DELETE

URL `/redfish/v1/EventService/Subscriptions/<SubscriptionId>`

Output `200 Ok  
{  
 "INFO": "<SubscriptionId> subscription deleted successfully"  
}`

## Example of Job Creation

### Request

Method `POST`

URI `https://100.101.18.90/redfish/v1/Managers/iDRAC.Embedded.1/Jobs`

#### Headers

Authorization: Basic cm9vdDpjYWx2aW4=

Content-Type: application/json

#### Body

```
{  
  "TargetSettingsURI" : "/redfish/v1/Systems/System.Embedded.1/Bios/Settings",  
  "StartTime" : "TIME_NOW",  
  "EndTime" : "TIME_NA"  
}
```

Or

```
{  
  "TargetSettingsURI" : "/redfish/v1/Systems/System.Embedded.1/Bios/Settings",  
  "StartTime" : "2017-08-21T18:11:00",  
  "EndTime" : "2017-08-21T20:11:00"  
}
```

# Response

HTTP Status code: 200

## Headers

```
OData-Version: 4.0
Keep-Alive: timeout=60, max=199
Content-Type: application/json;odata.metadata=minimal;charset=utf-8
Server: Appweb/4.5.4
Location: /redfish/v1/Managers/iDRAC.Embedded.1/Jobs/JID_471269252011
Date: Thu, 06 Jan 2000 02:48:49 GMT
Cache-Control: no-cache
Content-Length: 501
Connection: Keep-Alive Access-Control-Allow-Origin: *
Accept-Ranges: bytes
```

## BODY

```
{
  "@Message.ExtendedInfo": [
    {
      "Message": "Successfully Completed Request",
      "MessageArgs": [],
      "MessageArgs@odata.count": 0,
      "MessageId": "Base.1.0.Success",
      "RelatedProperties": [],
      "RelatedProperties@odata.count": 0,
      "Resolution": "None",
      "Severity": "OK"
    },
    {
      "Message": "The operation successfully completed.",
      "MessageArgs": [],
      "MessageArgs@odata.count": 0,
      "MessageId": "iDRAC.1.5.SYS413",
      "RelatedProperties": [],
      "RelatedProperties@odata.count": 0,
      "Resolution": "No response action is required.",
      "Severity": "Informational"
    }
  ]
}
```

# Examples for \$expand

- 1 ManagerCollection Schema includes only NavigationProperties, it does not include Links. In this scenario, following behavior is expected:
  - a `/redfish/v1/Managers?$expand=*(levels=1) $expand` command will expand NavigationProperty
  - b `/redfish/v1/Managers?$expand=.(levels=1) $expand` command will expand NavigationProperty
- 2 ManagerAccount Schema includes only Links Property, it does not include NavigationProperties. In this scenario, following behavior is expected:
  - a `/redfish/v1/Managers/iDRAC.Embedded.1/Accounts/3?$expand=*(levels=1) $expand` command will expand all properties
  - b `/redfish/v1/Managers/iDRAC.Embedded.1/Accounts/3?$expand=~(levels=1) $expand` command will expand properties under links

# Examples for \$select

Resource Type	Example
Resource.Resource	<ul style="list-style-type: none"><li>• <a href="https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=AssetTag">https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=AssetTag</a></li><li>• <a href="https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Status">https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Status</a></li><li>• <a href="https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Status/State">https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Status/State</a></li><li>• <a href="https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Assembly">https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Assembly</a></li><li>• <a href="https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Links/ComputerSystems">https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Links/ComputerSystems</a></li><li>• <a href="https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Links/Oem/Dell/DellEnclosureEMMCollection">https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Links/Oem/Dell/DellEnclosureEMMCollection</a></li><li>• <a href="https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Location/Placement">https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Location/Placement</a></li><li>• <a href="https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Location/Placement/Rack">https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Location/Placement/Rack</a></li><li>• <a href="https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Assembly/@odata.id">https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1?\$select=Assembly/@odata.id</a></li></ul>
Resource.ResourceCollection	<ul style="list-style-type: none"><li>• <a href="https://&lt;IP&gt;/redfish/v1/Systems?\$select=Members">https://&lt;IP&gt;/redfish/v1/Systems?\$select=Members</a></li></ul>
Resource.ReferenceableMember	<ul style="list-style-type: none"><li>• <a href="https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1/Power?\$select=PowerControl">https://&lt;IP&gt;/redfish/v1/Chassis/System.Embedded.1/Power?\$select=PowerControl</a></li></ul>

# Examples for \$filter

Resource Type	Example
Resource.ResourceCollection	<a href="https://&lt;IP&gt;/redfish/v1/Managers/iDRAC.Embedded.1/Logs/Sel?\$filter=Severity eq 'OK'">https://&lt;IP&gt;/redfish/v1/Managers/iDRAC.Embedded.1/Logs/Sel?\$filter=Severity eq "OK"</a>