ЛОС

LCD Monitor User Manual AG272FCX LED backlight

WWW.AOC.COM ©2016 AOC. All Rights Reserved.

| Safety | 4 |
|----------------------------|----|
| National Conventions | 4 |
| Power | 5 |
| Installation | 6 |
| Cleaning | 7 |
| Other | 8 |
| Setup | 9 |
| Contents in Box | 9 |
| Setup Stand & Base | 10 |
| Adjusting Viewing Angle | 11 |
| Connecting the Monitor | 12 |
| Free-Sync function | 13 |
| Adjusting | 14 |
| Setting Optimal Resolution | 14 |
| Windows 10 | 14 |
| Windows 8 | 16 |
| Windows 7 | 18 |
| Hotkeys | 20 |
| Quick Switch | 21 |
| OSD Setting | 22 |
| Luminance | 23 |
| Image Setup | 24 |
| Color Setup | 25 |
| Picture Boost | 26 |
| OSD Setup | 27 |
| Game Setting | 28 |
| Extra | 29 |
| Exit | |
| LED Indicator | |
| Driver | 31 |
| Monitor Driver | 31 |
| Windows 10 | 31 |
| Windows 8 | 35 |
| Windows 7 | |
| i-Menu | 42 |
| e-Saver | 43 |
| Screen+ | 44 |
| Troubleshoot | 45 |
| Specification | 46 |
| General Specification | 46 |
| Preset Display Modes | 47 |
| Pin Assignments | 48 |
| Plug and Play | 50 |
| Regulation | 51 |
| FCC Notice | 51 |
| WEEE Declaration | 52 |

| RoHS Declaration | 52 |
|---|----|
| E-Waste Declaration for India | 53 |
| EPA Energy Star | 53 |
| Service | 54 |
| Warranty Statement for Europe | 54 |
| Warranty Statement for Middle East and Africa (MEA) | 56 |
| AOC PIXEL POLICY | 58 |
| ISO 9241-307 CLASS 1 | 58 |
| Warranty Statement for North & South America (excluding Brazil) | 59 |
| EASE PROGRAME | 61 |
| TCO DOCUMENT | 62 |

Safety

National Conventions

The following subsections describe notational conventions used in this document.

Notes, Cautions, and Warnings

Throughout this guide, blocks of text may be accompanied by an icon and printed in bold type or in italic type. These blocks are notes, cautions, and warnings, and they are used as follows:



NOTE: A NOTE indicates important information that helps you make better use of your computer system.



CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



WARNING: A WARNING indicates the potential for bodily harm and tells you how to avoid the problem. Some warnings may appear in alternate formats and may be unaccompanied by an icon. In such cases, the specific presentation of the warning is mandated by regulatory authority.

Power

The monitor should be operated only from the type of power source indicated on the label. If you are not sure of the type of power supplied to your home, consult your dealer or local power company.

The monitor is equipped with a three-pronged grounded plug, a plug with a third (grounding) pin. This plug will fit only into a grounded power outlet as a safety feature. If your outlet does not accommodate the three-wire plug, have an electrician install the correct outlet, or use an adapter to ground the appliance safely. Do not defeat the safety purpose of the grounded plug.

Unplug the unit during a lightning storm or when it will not be used for long periods of time. This will protect the monitor from damage due to power surges.

A Do not overload power strips and extension cords. Overloading can result in fire or electric shock.

To ensure satisfactory operation, use the monitor only with UL listed computers which have appropriate configured receptacles marked between 100-240V AC, Min. 5A.

A The wall socket shall be installed near the equipment and shall be easily accessible.

For use only with the attached power adapter (Output: 20Vdc, 4.5A) Manufacturers: TPV ELECTRONICS (FUJIAN) CO., LTD. Model: ADPC2090

Installation

Do not place the monitor on an unstable cart, stand, tripod, bracket, or table. If the monitor falls, it can injure a person and cause serious damage to this product. Use only a cart, stand, tripod, bracket, or table recommended by the manufacturer or sold with this product. Follow the manufacturer's instructions when installing the product and use mounting accessories recommended by the manufacturer. A product and cart combination should be moved with care.

Never push any object into the slot on the monitor cabinet. It could damage circuit parts causing a fire or electric shock. Never spill liquids on the monitor.


Lo not place the front of the product on the floor.

If you mount the monitor on a wall or shelf, use a mounting kit approved by the manufacturer and follow the kit instructions.

Leave some space around the monitor as shown below. Otherwise, air-circulation may be inadequate hence overheating may cause a fire or damage to the monitor.

See below the recommended ventilation areas around the monitor when the monitor is installed on the wall or on the stand:

Installed with stand



Cleaning

Clean the cabinet regularly with cloth. You can use soft-detergent to wipe out the stain, instead of strong-detergent which will cauterize the product cabinet.

When cleaning, make sure no detergent is leaked into the product. The cleaning cloth should not be too rough as it will scratch the screen surface.

Please disconnect the power cord before cleaning the product.



Other

If the product is emitting a strange smell, sound or smoke, disconnect the power plug IMMEDIATELY and contact a Service Center.


All Make sure that the ventilating openings are not blocked by a table or curtain.

Po not engage the LCD monitor in severe vibration or high impact conditions during operation.

Lo not knock or drop the monitor during operation or transportation.

Setup

Contents in Box





*Not all signal cables (Audio, Analog, DP, HDMI, USB and Micphone cables) will be provided for all countries and regions. Please check with the local dealer or AOC branch office for confirmation.

Setup Stand & Base

Please setup or remove the base following the steps as below.








Adjusting Viewing Angle

For optimal viewing it is recommended to look at the full face of the monitor, then adjust the monitor's angle to your own preference.

Hold the stand so you will not topple the monitor when you change the monitor's angle.

You are able to adjust the monitor as below:

Tilt angle:-5.5° ~28°






Do not adjust the viewing angle over 28 degrees in order to avoid damage.

Connecting the Monitor

Cable Connections In Back of Monitor and Computer:



- 1 Microphone in
- 2 Earphone (Combined with Microphone)
- 3 USB3.0 downstream + fast charging
- 4 USB3.0 downstream
- 5 USB3.0 upstream
- 6 HDMI-1
- 7 HDMI-2
- 8 DP
- 9 VGA
- 10 Line In
- 11 Microphone out (Connect to PC)
- 12 Quick Switch Keypad
- 13 DC in

To protect equipment, always turn off the PC and LCD monitor before connecting.

- 1 Connect the power cable to the DC port on the back of the monitor.
- 2 Connect one end of the 15-pin D-Sub cable to the back of the monitor and connect the other end to the computer's D-Sub port.
- 3 (Optional Requires a video card with HDMI port) Connect one end of the HDMI cable to the back of the monitor and connect the other end to the computer's HDMI port.
- 4 (Optional –Requires a video card with Audio port) Connect one end of the Audio cable to the back of the monitor and connect the other end to the computer's Audio port.
- 5 (Optional–Requires a video card with DP port) –Connect one end of the DP cable to the back of the monitor and connect the other end to the computer's DP port.
- 6 Turn on your monitor and computer.
- 7 Video content supporting resolution:
 - VGA: 1920 x1080@60Hz (Maximum)
 - HDMI/DP: 1920x1080@144Hz (Maximum)

If your monitor displays an image, installation is complete. If it does not display an image, please refer Troubleshooting.

Free-Sync function

- 1. Free-Sync function is working with DP/HDMI
- 2. Compatible Graphics Card: Recommend list is as the below, also could be checked by visiting

www.AMD.com

- A MD Radeon R9 300 Series (370 series except)
- A MD Radeon R9 Fury X
- A MD Radeon R7 360
- AMD Radeon R9 295X2
- AMD Radeon R9 290X
- AMD Radeon R9 290
- AMD Radeon R9 285
- AMD Radeon R7 260X
- AMD Radeon R7 260


Adjusting

Setting Optimal Resolution

Windows 10

For Windows 10:

- Right click START.
- Click "CONTROL PANEL".



Click "DISPLAY".

•

| · · · | | | | | | |
|---------|-------------------------------|--------------------------------------|-----------------------------------|-------------------------------|----------------------|--------------------------|
| 🔝 All C | ontrol Panel Items | | | | | – ø × |
| | 🗧 🕤 🕆 🔝 > Control Panel > All | I Control Panel Items | | | | ✓ Ŏ Search Control Panel |
| File I | dit View Tools Help | | | | | |
| Adju | ist your computer's settings | | | | | View by: Large icons * |
| 1 | Administrative Tools | AutoPlay | Backup and Restore (Windows 7) | RitLocker Drive Encryption | 🛃 Color Management | |
| | Credential Manager | Date and Time | Default Programs | Device Manager | Devices and Printers | |
| | Display | 🚱 Ease of Access Center | CO Elo 触摸屏配置 | File Explorer Options | 둲 File History | |
| £ | Flash Player (32-bit) | Fonts | • | lndexing Options | P Internet Options | |
| 4 | Keyboard | 📌 Language | I Mouse | Network and Sharing Center | Yersonalization | |
| 4 | Phone and Modem | Power Options | Programs and Features | 🔯 Realtek HD Audio Manager | la Recovery | |
| Ð | Region | RemoteApp and Desktop Connections | Security and Maintenance | Sound | Speech Recognition | |
| | Storage Spaces | Sync Center | System | Taskbar and Navigation | Troubleshooting | |
| 82 | User Accounts | Windows Defender | Windows Firewall | Work Folders | 🐊 邮件 (32-bit) | |
| | | | | | | |

• Click on the "Change display settings" button.

| 🛄 Display | | - | × |
|---------------------------|--|----------------------|---|
| ← → · ↑ 💷 > Control Panel | > All Control Panel Items > Display 🗸 🖑 | Search Control Panel | P |
| File Edit View Tools Help | | | |
| Control Panel Home | Change size of items | | ? |
| Calibrate color | To change the size of text, apps, and other items, <u>use these display settings</u> . If you want to temporarily enlarge a portion of your screen, use <u>Magnifier</u> . If neither of these makes the changes you want, you can <u>set a custom</u> <u>scaling level</u> (not recommended). Setting custom levels can lead to unexpected behavior on some displays. | | |
| | Change only the text size Instead of changing the size of everything on the desktop, change only the text size for a specific item. | | |
| | Title bars 9 Bold | | |
| | Apply | | |
| | | | |
| | | | |
| | | | |
| See also | | | |
| Personalization | | | |
| Devices and Printers | | | |

• Set the resolution **SLIDE-BAR** to Optimal preset resolution.

| Screen Resolution | | - | х |
|--|---|----------------------|---|
| $\leftarrow \rightarrow \ \ \ $ | > All Control Panel Items > Display > Screen Resolution V 🖉 | Search Control Panel | ٩ |
| File Edit View Tools Help | | | |
| | Change the appearance of your display | | |
| | Detect Identify | | |
| | Display: 1. B24 Resolution: 1920 × 1080 (Recommended) Orientation: Landscape V | | |
| | Advanced settings | | |
| | Make text and other items larger or smaller What display settings should I choose? | | |
| | OK Cancel Apply | | |
| | | | |
| | | | |

Windows 8


For Windows 8:

• Right click and click All apps at the bottom-right of the screen.




| Apps | | | | |
|---------------------|----------|------------------------------|-------------------------------|-----------------------------------|
| b Bing | Reader | | WordPad | Computer |
| Calendar | SkyDrive | Calculator | XPS Viewer | Control Panel |
| Camera | Sports | Character Map | | Default Programs |
| Desktop | Store 5 | Math Input Panel | Magniter | The byporer |
| Finance | Tavel | Notepad | Narrator | Help and Support |
| Games | Wideo | 🧭 Paint | On-Screen Keyboard | Pan Pan |
| C Internet Explorer | Weather | Remote Desktop Connection | Windows Speech Recognition | Task Manager |
| Mai | | Snipping Tool | | Windows Defender |
| Maps Naps | | Sound Recorder | GFU//ew | S Windows Eany Yamler |
| Messaging | | E Steps Recorder | GPUView Help | Windows Eatry Transfer Reports |
| Music | | Sticky Notes | Windows Performance | Windows PowerShell |
| News | | Windows Fax and Scan | Windows Performance | |
| People | | Windows Journal | | |
| Photos | | Windows Media Player | Command Prompt | |

- Set the "View by" to "Category".
- Click "Appearance and Personalization".



• Click "DISPLAY".



· Set the resolution SLIDE-BAR to Optimal preset resolution

| | Screen Resolution | - 🗆 × |
|--|---------------------------------------|----------------------------|
| (€) → ↑ ■ Control Panel → Appearance and Person | ization + Display + Screen Resolution | v 🖒 Search Control Panel 🔎 |
| Change | he appearance of your display | |
| | 1 | Detect Identify |
| Display: | 1. PLX2780H ¥ | |
| Resolution | 1920 × 1080 (Recommended) V | |
| Orientatio Make text | 1920 × 1080 (Recommended) | Advanced settings |
| What disp | y setting | |
| | ОК 1024 × 768 Low | Cancel Apply |
| | | |

Windows 7

For Windows 7:

- Click START.
- Click "CONTROL PANEL".




• Click "Appearance".


| Adjust your computer's settings | | | | View by: Small icons - |
|-----------------------------------|----------------------------|-----------------------------|------------------------------|------------------------|
| Action Center | C Administrative Tools | C AutoPlay | Backup and Restore | |
| Color Management | Credential Manager | Date and Time | Default Programs | |
| Desktop Gadgets | Device Manager | and Devices and Printers | Display | |
| Ease of Access Center | Folder Options | Fonts | Getting Started | |
| HomeGroup | Jindexing Options | Internet Options | Keyboard | |
| Location and Other Sensors | Mouse | Metwork and Sharing Center | Notification Area Icons | |
| NVIDIA Control Panel | MUDIA PhysX | Received and sharing center | / Pen and Touch | |
| Performance Information and Tools | Personalization | A Phone and Modern | Power Options | |
| R. Programs and Features | P Realtek HD Audio Manager | Recovery | Segion and Language | |
| RemoteApp and Desktop Connections | Sound | Speech Recognition | Sync Center | |
| System | Tablet PC Settings | Taskbar and Start Menu | Troubleshooting | |
| System | Sundows Anytime Upgrade | Windows CardSpace | Windows Defender | |
| Windows Firewall | Windows Update | Cardopace | | |
| Windows Filewaii | Windows opdate | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

Click "DISPLAY".

•




• Click on the "Change display settings" button.



Set the resolution SLIDE-BAR to Optimal preset resolution

| | Screen Resolution | | | - | × |
|-----------------------------------|--------------------------------|-------------------|-----|----------------------|---|
| 🛞 🕘 * ↑ 🜉 > Control Panel > Appea | Display Screen Resolution | Detect | ~ C | Search Control Panel | Q |
| | | Advanced settings | | | |
| | 1024 × 768 Low | OK Cancel Apply | | | |

Hotkeys



| 3 | Game Mode/Left | |
|---|-------------------|--|
| 4 | LED color/Right | |
| 5 | Power/ Menu/Enter | |

Power/Menu/Enter

Press the Power button to turn on the monitor.

When there is no OSD, Press to display the OSD or confirm the selection. Press about 2 second to turn off the monitor.

Shadow Control

When there is no OSD, Press Shadow Control button to active Shadow Control adjustment bar, Press "Left" or "Right" to adjust contrast for clear picture.

Game Mode/Left

When there is no OSD, press "Left" key to open game mode function, then press "Left" or "Right" key to select game mode (FPS, RTS, Racing, Gamer 1, Gamer 2 or Gamer 3) basing on the different game types.


LED Light Effects Control/Right

When there is no OSD, press "Right" key to active LED Light Effects Control function.

Source/Auto/Exit

When the OSD is closed, press Source/Auto/Exit button will be Source hot key function. When the OSD is closed, press Source/Auto/Exit button continuously about 2 second to do auto configure (Only for the models with D-Sub).

Quick Switch



∢:

When there is no OSD, press the ◀ button to open game mode function, then press ◀ or ► key to select game mode (FPS, RTS, Racing, Gamer 1, Gamer 2 or Gamer 3) basing on the different game types.

▶:

When there is no OSD, press "Right" key to active LED Light Effects Control function.

Menu/OK:

When there is no OSD, Press to display the OSD or confirm the selection.

▲:

When the OSD is closed, press **A** button will be Source hot key function. When the OSD is closed, press Source/Auto/Exit button continuously about 2 second to do auto configure (Only for the models with D-Sub).

▼:

When there is no OSD, Press ▼ button to active Shadow Control adjustment bar, Press "Left" or "Right" to adjust contrast for clear picture.

1:

Press the 1 button to select Gamer 1 mode

2:

Press the 2 button to select Gamer 2 mode

3:

Press the 3 button to select Gamer 3 mode

OSD Setting

Basic and simple instruction on the control keys.

| < | Image Setup | Color Setup | Picture Boost | CSD Setup | Game Setting | X Extra | Exit |
|------------|-------------|-------------|---------------|-----------|--------------|------------|------|
| Contrast | | | | | | | |
| Brightness | | | DCR < | Off 🕨 | | | |
| Eco mode | | | | | | | |

- 1) Press the MENU-button to activate the OSD window.
- Press Left or right to navigate through the functions. Once the desired function is highlighted, press the MENU-button to activate it. press Left or right to navigate through the sub-menu functions. Once the desired function is highlighted, press MENU-button to activate it.
- 3) Press Left or right to change the settings of the selected function. Press AUTO-button to exit. If you want to adjust any other function, repeat steps 2-3.
- OSD Lock/Unlock Function: To lock or unlock the OSD, press and hold the **Down-button** for 10s while OSD function is not active.

Notes:

- 1) If the product has only one signal input, the item of "Input Select" is disable to adjust.
- 2) ECO modes (except Standard mode), DCR, DCB mode and Picture Boost, for these four states that only one state can exist.

Luminance

| < | Image Setup | Color Setup | Picture Boost | OSD Setup | Game Setting |)X Extra | Exit |
|------------|-------------|-------------|---------------|-----------|--------------|-------------|------|
| Contrast | | | | | | | |
| Brightness | | | DCR < | Off ► | | | |
| Eco mode | | | | | | | |

- 1. Press **MENU-button** to display menu.
- 2. Press Left or Right to select (Luminance), and press **MENU-button** to enter.
- 3. Press Left or Right to select submenu, and press **MENU-button** to enter.
- 4. Press Left or Right to adjust.
- 5. Press **AUTO-button** to exit.

| | Contrast | 0-100 | | Contrast from Digital-register. |
|--|------------|----------|----|---------------------------------|
| | Brightness | 0-100 | | Backlight Adjustment |
| | | Standard | > | Standard Mode |
| | | Text | T | Text Mode |
| | Eco mode | Internet | E | Internet Mode |
| | | Game | | Game Mode |
| | | Movie | ø | Movie Mode |
| | | Sports | 32 | Sports Mode |
| | | Gamma1 | | Adjust to Gamma 1 |
| | Gamma | Gamma2 | | Adjust to Gamma 2 |
| | | Gamma3 | | Adjust to Gamma 3 |
| | | Off | | Disable dynamic contrast ratio |
| | DCR | On | | Enable dynamic contrast ratio |

Image Setup

| Image Setup | Color Setup | Picture Boost | OSD Setup | Game Setting |) Extra | Exit | Luminance |
|-------------|-------------|---------------|-----------|--------------|------------|------|-----------|
| Clock | 50 | | Position | 50 | | | |
| Phase | 50 | | Position | 50 | | | |
| Sharpness | 50 | | | | | | |

- 1. Press **MENU-button** to display menu.
- 2. Press Left or Right to select (Image Setup), and press **MENU-button** to enter.
- 3. Press Left or Right to select submenu, and press **MENU-button** to enter.
- 4. Press Left or Right to adjust.
- 5. Press AUTO-button to exit.

| | Clock | 0-100 | Adjust picture Clock to reduce Vertical-Line noise. | | | | |
|------|-------------|-------|--|--|--|--|--|
| | Phase | 0-100 | Adjust Picture Phase to reduce Horizontal-Line noise | | | | |
| | Sharpness | 0-100 | Adjust picture sharpness | | | | |
| •••• | H. Position | 0-100 | Adjust the horizontal position of the picture. | | | | |
| | V. Position | 0-100 | Adjust the vertical position of the picture. | | | | |

Color Setup

| Color Setup | Picture Boc | ost | OSD Setup | Game Setting | X Extra | Exit | Luminance | Image Setup |
|-------------|-------------|-----|-----------|--------------|------------|------|-----------|-------------|
| Color Temp. | | | | _ | 50 | | | |
| DCB Mode | Off | | | en 📃 | 50 | | | |
| DCB Demo | Off | | | | 50 | | | |

- 1. Press **MENU-button** to display menu.
- 2. Press Left or Right to select (Color Setup), and press **MENU-button** to enter.
- 3. Press Left or Right to select submenu, and press **MENU-button** to enter.
- 4. Press Left or Right to adjust.
- 5. Press **AUTO-button** to exit.

| | | Warm | | Recall Warm Color Temperature from EEPROM. |
|--|-------------|--------------|-----------|--|
| | | Normal | | Recall Normal Color Temperature from EEPROM. |
| | | Cool | | Recall Cool Color Temperature from EEPROM. |
| | Color Temp. | sRGB | | Recall SRGB Color Temperature from EEPROM. |
| | | | Red | Red Gain from Digital-register |
| | | User | Green | Green Gain Digital-register. |
| | | | Blue | Blue Gain from Digital-register |
| | | Full Enhance | on or off | Disable or Enable Full Enhance Mode |
| | | Nature Skin | on or off | Disable or Enable Nature Skin Mode |
| | DCB Mode | Green Field | on or off | Disable or Enable Green Field Mode |
| | | Sky-blue | on or off | Disable or Enable Sky-blue Mode |
| | | AutoDetect | on or off | Disable or Enable AutoDetect Mode |
| | DCB Demo | | On or off | Disable or Enable Demo |

Picture Boost

| Clark Picture Boost | OSD Setup | Game Setting | X Extra | Exit | Luminance | Image Setup | Color Setup |
|---------------------|-----------|--------------|------------|------|-----------|-------------|-------------|
| Bright Frame ◀ | off | | Brightness | | 50 50 | H. Position | 0 0 |

- 1. Press **MENU-button** to display menu.
- 2. Press Left or Right to select (Picture Boost), and press **MENU-button** to enter.
- 3. Press Left or Right to select submenu, and press **MENU-button** to enter.
- 4. Press Left or Right to adjust.
- 5. Press **AUTO-button** to exit.

| | Bright Frame | on or off | Disable or Enable Bright Frame | | | | | |
|---|-------------------|-----------|----------------------------------|--|--|--|--|--|
| - | Frame Size 14-100 | | Adjust Frame Size | | | | | |
| | Brightness 0-100 | | Adjust Frame Brightness | | | | | |
| • | Contrast 0-100 | | Adjust Frame Contrast | | | | | |
| | H. position | 0-100 | Adjust Frame horizontal Position | | | | | |
| | V. position | 0-100 | Adjust Frame vertical Position | | | | | |

Note:

Adjust the brightness, contrast, and position of the Bright Frame for better viewing experience.

OSD Setup

| < Contraction of the second se | Game Setting Extra | | Exit | | | Color Setup | Picture Boost | |
|--|--------------------|--|------|--|--|--------------|---------------|--|
| Language | | | | | | Transparence | | |
| Timeout | | | | | | | Off 🕨 | |
| DP Capability | | | | | | | | |

- 1. Press **MENU-button** to display menu.
- 2. Press Left or Right to select (OSD Setup), and press **MENU-button** to enter.
- 3. Press Left or Right to select submenu, and press **MENU-button** to enter.
- 4. Press Left or Right to adjust.
- 5. Press **AUTO-button** to exit.

| | Language | | Select the OSD language | | | | |
|-----------|-----------------------|-----------|---|--|--|--|--|
| | Timeout | 5-120 | Adjust the OSD Timeout | | | | |
| | H. Position | 0-100 | Adjust the horizontal position of OSD | | | | |
| | V. Position | 0-100 | Adjust the vertical position of OSD | | | | |
| | Transparence | 0-100 | Adjust the transparence of OSD | | | | |
| \$ | Break Reminder | on or off | Break reminder if the user continuously work for more than 1hrs | | | | |
| | DP Capability 1.1/1.2 | | please be noted that only DP1.2 support free sync function | | | | |
| | Volume | 0-100 | Volume Adjustment. | | | | |

Notes:

If the DP video content supports DP1.2, please select DP1.2 for DP Capability; otherwise, please select DP1.1

Game Setting

| ✓ ✓ ✓ Game Setting | X Extra | Exit | Luminance | e Setup | Color Setup | Picture Boost | OSD Setup |
|--|------------|------|-----------|---------|-------------|---------------|-----------|
| Game Mode | Off | | | Off | | | |
| Shadow Control | | | | Off | | | |
| Game Color | | | Overdrive | Off | | | |

- 1. Press **MENU-button** to display menu.
- 2. Press Left or Right to select (Game setting), and press **MENU-button** to enter.
- 3. Press Left or Right to select submenu, and press **MENU-button** to enter.
- 4. Press Left or Right to adjust.
- 5. Press AUTO-button to exit.

| | | FPS | For playing FPS (first Person Shooters) games. Improves dark theme black level details. | | | |
|------|----------------------|----------------------------|--|--|--|--|
| | | RTS | For playing RTS (Real Time Strategy). Improves the image quality. | | | |
| | | Racing | For playing Racing games, Provides fastest response time and high color saturation. | | | |
| | Game Mode | Gamer 1 | User's preference settings saved as Gamer 1. | | | |
| | | Gamer 2 | User's preference settings saved as Gamer 2. | | | |
| | | Gamer 3 | User's preference settings saved as Gamer 3. | | | |
| | | off | No optimization by Smart image game | | | |
| ···· | Shadow Control 0-100 | | Shadow Control Default is 50, then end-user can adju from 50 to 100 or 0 to increase contrast for clear pictu 1. If picture is too dark to be saw the detail clearly, adjusting from 50 to100 for clear picture 2. If picture is too white to be saw the detail clearly, adjusting from 50 to0 for clear picture | | | |
| | Game Color 0-20 | | Game Color will provide 0-20 level for adjusting saturation to get better picture. | | | |
| | Low Blue Light | Off/Weak/ Medium/Strong | Decrease blue light wave by controlling color temperature. | | | |
| | Low input Lag | On/off | Turn off frame buffer to decrease input lag | | | |
| | | Weak | | | | |
| | Quandria | Medium | Adjust the response time. | | | |
| | Overdrive | Strong | | | | |
| | | Off | | | | |

Extra

| < 🔀 > | Exit | Luminance | Image Setup | Color Setup | Picture Boost | OSD Setup | ونينې Game Setting |
|--------------|------|-----------|-------------|-------------|---------------|------------------|-----------------------|
| Input Select | | | | | | on : 1920(H)X108 | 0(V) |
| Auto Config. | | | DDC/CI | | | iency : 67KHz | |
| Off Timer | | | | | | | |

- 1. Press **MENU-button** to display menu.
- 2. Press Left or Right to select X (Extra), and press **MENU-button** to enter.
- 3. Press Left or Right to select submenu, and press **MENU-button** to enter.
- 4. Press Left or Right to adjust.
- 5. Press **AUTO-button** to exit.

| | Input Select | AUTO/D-SUB/HDMI1/HDMI2 /DP | Select Input Signal Source |
|----------|--------------|-------------------------------|------------------------------------|
| | Auto Config | yes or no | Auto adjust the picture to default |
| | Off timer | 0-24hrs | Select DC off time |
| | | Wide | |
| | | 4:3 | |
| | | 1:1 | |
| | | 17" (4:3) | |
| 01 | Image Ratio | 19" (4:3) | |
| \times | | 19" (5:4) | Calact image ratio for display |
| | | 19"W (16:10) | Select image ratio for display. |
| | | 21.5"W (16:9) | |
| | | 22"W (16:10) | |
| | | 23"W (16:9) | |
| | | 23.6"W (16:9) | |
| | | 24"W (16:9) | |
| | DDC-CI | yes or no | Turn ON/OFF DDC-CI Support |
| | Reset | Yes or no | Reset the menu to default |

Exit

| < | Exit | > | Luminance | Image Setup | Q Color Setup | Picture Boost | OSD Setup | Game Setting | X Extra |
|---|------|---|-----------|-------------|------------------|---------------|-----------|--------------|------------|
| | | | | | | | | | |
| | | | | | | | | | |

- 1. Press **MENU-button** to display menu.

2. Press Left or Right to select (Exit), and press **MENU-button** to enter.

3. Press AUTO-button to exit.

| - | Exit | | Exit the main OSD |
|---|------|--|-------------------|
|---|------|--|-------------------|

LED Indicator


| Status | LED Color |
|-----------------|-----------|
| Full Power Mode | Blue |
| Active-off Mode | Orange |

Driver

Monitor Driver


Windows 10

- Start Windows® 10
- Right click START.
- Click "Control Panel".




Click on the "Display" icon.

•




• Click on the "Change display settings" button



Click the "Advanced Settings" button.

| Screen Resolution | | - | × |
|---|---|----------------------|---|
| $\leftrightarrow \rightarrow \checkmark \uparrow \square $ Control Panel File Edit View Tools Help | > All Control Panel Items > Display > Screen Resolution \checkmark \eth | Search Control Panel | Q |
| | Change the appearance of your display | | |
| | Detect Identify | | |
| | Display: 1. B24 	V Resolution: 1920 × 1080 (Recommended) V | | |
| | Orientation: Landscape V Advanced settings | | |
| | Make text and other items larger or smaller What display settings should I choose? | | |
| | OK Cancel Apply | | |
| | | | |
| | | | |

• Click the "Monitor" tab and then click the "Properties" button.



• Click the "Driver" tab.


| eneral Driver Details | |
|-----------------------|--|
| Generic PnP N | lonitor |
| Driver Provide | r. Microsoft |
| Driver Date: | 6/21/2006 |
| Driver Version | 6.1.7600.16385 |
| Digital Signer: | Microsoft Windows |
| Driver Details | To view details about the driver files. |
| Update Driver | To update the driver software for this device. |
| Roll Back Driver | If the device fails after updating the driver, roll back to the previously installed driver. |
| Disable | Disables the selected device. |
| Uninstall | To uninstall the driver (Advanced). |
| | OK Cancel |

• Open the "Update Driver Software-Generic PnP Monitor" window by clicking on "Update Driver... "and then

click the "Browse my computer for driver software" button.

| • | Search automatically for updated driver software Windows will search your computer and the Internet for the latest driver software for your device, unless you've disabled this feature in your device installation settings. | |
|---|--|--|
| | Browse my computer for driver software | |
| | Locate and install driver software manually. | |

• Select "Let me pick from a list of device drivers on my computer".



• Click the "Have Disk" button. Click on the "Browse" button and navigate to the following directory:

X:\Driver\module name(where X is the drive letter designator for the CD-ROM drive).

| Install Fro | t the manufacturer and model of your hardware device a m Disk | and then click Next If |
|-------------|---|------------------------|
| | Insert the manufacturer's installation disk, and then make sure that the correct drive is selected below. | OK Cancel |
| | Copy manufacturer's files from: F:\Drivers\e936Vw | Browse |

- Select the "xxx.inf" file and click the "Open" button. Click the "OK" button.
- Select your monitor model and click the "Next" button. The files will be copied from the CD to your hard disk drive.
- Close all open windows and remove the CD.
- Restart the system. The system will automatically select the maximum refresh rate and corresponding Color Matching Profiles.

Windows 8

- Start Windows® 8
- Right click and click **All apps** at the bottom-right of the screen.



- Click on the "Control Panel" icon
- Set the "View by" to "Large icons" or "Small icons".

| djust | your computer's settings | | | | | | | | Vie | wby: | arge icons 🔻 | |
|-------|--------------------------|----------|-----------------------|----|--------------------------------------|----|----------------------------|---|--------------------------------------|------|--------------------------------------|---------|
| n | Action Center | G | Administrative Tools | | AutoPlay | | BitLocker Drive Encryption | 3 | Color Management | • | Category Large icon Small icon | |
| | Credential Manager | ľ | Date and Time | | Default Programs | i. | Device Manager | - | Devices and Printers | | | |
| | Display | C | Ease of Access Center | 1 | Family Safety | | File History | ۶ | Flash Player (32-bit) | | | |
| 2 | Folder Options | A | Fonts | •3 | HomeGroup | P | Indexing Options | e | Internet Options | | | |
| 4 | Keyboard | S | Language | | Location Settings | 3 | Mouse | 4 | Network and Sharing Center | | | |
| | Notification Area Icons | | NVIDIA Control Panel | | Performance Information and Tools | 5 | Personalization | 4 | Phone and Modem | | | |
| 2 | Power Options | <u>a</u> | Programs and Features | 1 | Recovery | 9 | Region | ٠ | RemoteApp and Desktop Connections | | | |
| 9 | Sound | Ą | Speech Recognition | | Storage Spaces | ۲ | Sync Center | 1 | System | | | |
| | Taskbar | A | Troubleshooting | 82 | User Accounts | 4 | Windows 7 File Recovery | 龃 | Windows Defender | | | |
| 2 | Windows Firewall | - | Windows Update | | | | | | | | | |
| | | | | | | | | | | | | |
| | | | | | | | | | | | | |
| | | | | | | | | | | | | |
| | | | | | | | | | | | | |
| - | | | | | | | | | | | 5 % (b | 11:16 P |

• Click on the "Display"icon.

| Color Management Coloratin Management Derivers and Printers Derivers and Printers Destrop Gazystis Derivers Management Derivers and Printers Derivers and Printers Destrop Gazystis Derivers and Printers Derivers and Printers Derivers and Printers Destrop Gazystis Derivers and Printers Derivers and Printers Derivers and Printers Destrop Gazystis Derivers and Printers Derivers and Printers Derivers and Printers Destrop Gazystis Monoir Printers and Derivers Printers and Derivers Printers and Printers Printers and Notion Printers and Notion Printers and Notion Printers and Printers Printers and Notion Printers and Notion Printers and Notion Printers and Printers Printers and Notion Printers and Notion Printers and Notion Printers and Printers Printers and Notion Printers and Notion Printers and Notion Printers and Printers Printers and Notion Printers and Notion Printers and Notion Printers and Printers and Printers Printers and Notion Printers and Notion Printers and Printers Printers and Notion Printers and Notion Printers and Printers Printers and Notion Printers and Notion Printers and Notion Printers | Perice Manager via Devices and Printers Perice Manager via Devices Perice Manager via Device Perice Manager Via Device Perice Manager Via Device Manager Via Device Manager Perice Manager Via Device Manager | Destap Gadgets Improve Manager explores and Printers Implay Destap Gadgets Implay Implay Implay Implay Implay Implay Implay Implay Implay Implay Implay Implay | Destrop Gadgets Device Manager wij Devices and Printers Display © Exer of Access Center Tolaw Options Forms @ Centring Stanted WinderCloup Biolening Options Winderen Options Second Access Center @ Note Access Center WinderCloup Biolening Options Winderen Options Winder Options Winder Options WinderCloup Access Center @ Note Access Center Options @ Note Access Center Options @ Note Access Center Options WIDIA Control Finder Access Center Options @ Note Access Center Options @ Note Access Center Options Performance Enderport Contextors @ Reacter House Manager @ Recovery @ Report and Language @ Stemot Acting and Destrop Contextors @ Sound @ Speec Recovery @ Report and Language @ System @ Tabler Managers @ Stemote Access Teachers @ Speec Recovery | i kons |
|---|--|---|--|--------|
| Exe of Access Center IF Index Options Indexing Statuted Control model Indexing Statuted Indexing Statuted Control model Indexing Statuted Indexing Statuted Control model Moxel Indexing Statuted Control model Moxel Indexing Statuted MODA Control Privet Moxel Index Notice Proprim and Folder Moxel Index Notice Proprim and Folder Procesand Moxel Procesand Moxel Information and Tools Index Folder Statuted Procesand Moxel Information and Tools Index Folder Statuted Moxel Procesand Moxel Statuted products Procesand Moxel Index Notice Statuted products Statuted Statuted Moxel Index Notice Statuted products Index Folder Statuted Moxel Index Notice Statuted Products Index Notice Antralistical Index Notice Antralistical | Image: Folder Options Image: Folder Options Image: Folder Options Image: Image | Exer of Access Center In Folder Options In forms In Centors In Leardon and Disrong Options In Exerce Options In Resolution Actions In Location and Disrong Options In Exerce Options In Net Access Actions In Disrong Options In Resolution Actions In Net Access Actions In Disro Control Prived In Notal In Net Access Actions In Disrong Options In Net Access Actions In Net Access Actions In Disrong Options In Net Access Actions In Net Access Actions In Disrong Options In Net Access Actions In Net Access Actions In Disrong Actions In Net Access Actions In Net Actions In Disrong Actions In Net Actions In Net Actions In Options Actions Actions In Net Actions In Net Actions In Options Actions In Net Actions In Net Actions In Options Actions In Net Actions In Net Actions In Options Actions In Net Actions In Net Actions In Options Actions In Net Actions In Net Actions In Actions Actions Actions Actions Actions Actions In Net Actions In Actions Actions Actions Actions Actions Actions Actions In Net Actions | Bare of Access Center If Index Options If Index Optio | |
| HomeGroup Delexing Options Personal Enternet Options ■ Engloard Buckton Preci ■ Monze ■ Personal and Saving Center ■ Englocation And Saving Center ■ Englocation And Saving Center Buckton Preci ■ WUDB Aproxit ■ Personalization < | Boleving Options Descriptions | HomeGroup | HomeGroup Debening Options Thermet Options Keyboard Biostonia of Other Senson • Monae # Henorik and Daming Center Work Acress Print P | |
| Locator and Other Sensors • Mouze | Moure Interview and Sharing Center Interfaction Area loss MINDUA Physic Image Interfaction Centrols / Prevent Tochon Tools Process and Tochon Image Process and Tochon Process and tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon Image Process and Tochon | Locator and Other Sensors [®] Moure | Locaton and Otter Sensors | |
| WDDA Control Panel IM VDDA Physix Improvement and controls 7 Personalization Pertormanze Information and Programs and Features Improvement and Personalization Improvement and Personalization Improvement and Personalization Personalization Improvement and Personalization Improvement and Personalization Improvement and Personalization Improvement and Personalization Personalization Improvement and Personalization Improvement and Personalization Improvement and Personalization Improvement and Personalization Personalization Improvement and Personalization Improvement and Personalization Improvement and Personalization Improvement and Personalization Personalization Improvement and Personalization Improvement and Personalization Improvement and Personalization Improvement and Personalization Personalization Improvement and Personalization Improvement and Personalization Improvement and Personalization Improvement and Personalization Personalization Improvement and Personalization Improvement and Personalization Improvement and Personalization Improvement and Personalization Personalization Improvement and Personalization Improvement and Personalization Improve | M NDGA Physic A Parential Controls A Provide Address Address Address Address Addr | WIDA Control Panel MI NDDA PhysX Parental Controls / Pen and Touch Performance Internation and Tools Provide Optional Pen of Optional Penoman and Faces Panets-Into Advances Panets-Into Advances Panets and Modern Provide Optional Penoma International Tools Penoman and Tools Panets-Into Modernational Tools Penoma International Tools Penoman and Faces Panets-Into Advances Panets-International Tools Penoman and Tools Optional Speech Recognition Panets-International Tools System Table And Start Menu Panets-International Tools Lew Accountis Millional Anglines Upgoade Millional Configure | MODD Active Freed MID XXXX Arrowski Controls // Per aw Touch Performance Information and Tools Renormalization Arrow and Modem Prove and Modem Performance Information and Tools Renormalization Arrow and Modem Prove and Modem Performance Information Renote Active Activ | |
| Informate Normation and Tool Foreinatization Provide Addition Provide Additi | 2 Tools | Informate Montation and Tools Proposatization Programs and Features Programs and Programs | Performance Information and Tools Important and Features Important and Nodem Important and Nodem Program and Features Important and Nodem Important and Nodem Important and Nodem Program and Features Important and Nodem Important and Nodem Important and Nodem Remote/pp and Destrop Corrections Important and Analysis Important and State Meridian and State Merid | uage |
| Propams and Features ■ Restex HD Audio Manager ▲ Recovery ● Region and Language BremotAlge and Destago Connections ● Sound ● Specific Recognition ● Specific Recognition ● Specific Recognition System ■ Table RC Settings ■ Table and Spart Menu ■ Toublehooting ■ Modelehooting Lew Accounts ■ Windows Anytime Lipipade ■ Windows Castifysice ■ Windows Demotr | Beatrick HD Audo Manager Kincovery Report and Language Sound O Sound O Speech Recognition Tabler // Settings Linabar and Sam Menu Kindelenceting Windows Anytime Upgoud Windows Castifysee Millions Windows Castifysee | Programs and Features Reflect HD Audio Manager Recovery Programs and Features Recovery Bremotekage and Destado Connections ID Sound 0.5 Speece Recovery ID Recovery Programs and Language System Table To Settings II. Statian and State Menu In Toublemonting Unit Accounts Multidows Cardificate MUltidows Cardificate MUltidows Clearling | Programs and Features Implementary for the second sec | uage |
| j Remotivljep and Destop Connections 💿 Sond O Speech Recognition 🛞 Spric Center 8 speam 🦉 Taketer RC Settings 🗋 Taketer and Sant Maru 🕼 Touckehooting 10 wr. Kolonis A Windows Anytime Upginzel 🔃 Windows Centificaer | errection Sound Sound | j Remotivljop and Deistrop Convections | g RemoteApp and Desktop Connections | luage |
| ili System il Tablet PC Settings II Taskbar and Start Meru ili Toublehooting Buer Accounts & Windows Anytime Upgrade ili Windows CardSpace ili Windows Defender | 🗑 Tabler PC Settings 🛄 Talibair and Start Menu 🕞 Troubleshooting | ik System i Tablet PC Setsings La Takbar and Start Menu i Tabbarbooting Liber Accounts V Windows Anytime Upgrade it Windows CardSpace V W Windows Defender | System Tablet PC Settings | |
| 🖞 User Accounts 🦓 Windows Anytime Upgrade 👔 Windows CardSpace 🙀 Windows Defender | 🔩 Windows Anytime Upgrade 🕕 Windows CardSpace 🙀 Windows Defender | 🖁 User Accounts 🦓 Windows Anytime Upgrade 👔 Windows CardSpace 🙀 Windows Defender | | |
| | | | 🐁 User Accounts 🚳 Windows Anytime Upgrade 🧵 Windows CardSpace 🖓 Windows Defender | |
| | a Windows Update | Windows Firewall 🔮 Windows Update | | ier |
| 🕈 Windows Firewall 🖉 Windows Update | | | 🕈 Windows Firewall 💦 🖉 Windows Update | |
| | | | | |
| | | | | |
| | | | | |


• Click on the "Change display settings" button.

| 🕒 🕘 - 🔍 + Control Panel + | All Control Panel Items Display | | Search Control Panel |
|--|--|---|----------------------|
| Control Panel Home Adjust resolution Calibrate color | Make it easier to read what's of You can change the size of text and oth temporarily enlarge just part of the scre | her items on your screen by choosing one of these options. To | · |
| Change display settings Adjust ClearType text | Smaller - 100% | Preview | |
| Set custom text size (DPI) | Medium - 125% (default) | | |
| | Larger - 150% | | |
| | | Apply | |
| | | | |
| | | | |
| See also Personalization Devices and Printers | | | |

• Click the "Advanced Settings" button.

| 😧 🔊 - 🔍 + Control Panel + All Contr | not Panel Items + Doplay + Screen Resolution Change the appearance of your display | search Control Panel Detect | ٩ |
|-------------------------------------|--|------------------------------|---|
| | Display: I. Niskla Default Flast • Resolution: IS20 + 1000 (recommended) • | Liferentity | |
| | Orientation: Landscape Maile text and other items larger or smaller What display settings should I choose? | Advanced settings | |
| | | Carcol Apply | |

• Click the **"Monitor"** tab and then click the **"Properties"** button.




Click the "Driver" tab.

•




• Open the "Update Driver Software-Generic PnP Monitor" window by clicking on "Update Driver..."and then

click the "Browse my computer for driver software" button.



Select "Let me pick from a list of device drivers on my computer".



• Click the "Have Disk" button. Click on the "Browse" button and navigate to the following directory:

X:\Driver\module name (where X is the drive letter designator for the CD-ROM drive).

| Install Fro | the manufacturer and model of your hardware device a m Disk | nd then click Nev |
|-------------|--|-------------------|
| 4 | Insert the manufacturer's installation disk, and then make sure that the correct drive is selected below. | OK Cancel |
| | Copy manufacturer's files from: F\Drivers\e936Vw | Browse |


- Select the "xxx.inf" file and click the "Open" button. Click the "OK" button.
- Select your monitor model and click the "Next" button. The files will be copied from the CD to your hard disk

drive.

- Close all open windows and remove the CD.
- Restart the system. The system will automatically select the maximum refresh rate and corresponding Color Matching Profiles.

Windows 7


- Start Windows® 7
- Click on the "Start" button and then click on "Control Panel".



• Click on the "Display"icon.

| Adjust your computer's settings | | | | View by: Small icons - |
|-----------------------------------|---------------------------|----------------------------|-------------------------|------------------------|
| Action Center | C Administrative Tools | 🐻 AutoPlay | Backup and Restore | |
| Color Management | Credential Manager | 💣 Date and Time | 🕐 Default Programs | |
| Desktop Gadgets | Device Manager | mig Devices and Printers | 💐 Display | |
| Ease of Access Center | E Folder Options | 👗 Fonts | Getting Started | |
| HomeGroup | Indexing Options | Internet Options | - Keyboard | |
| Location and Other Sensors | I Mouse | Setwork and Sharing Center | Notification Area Icons | |
| NVIDIA Control Panel | S NVIDIA PhysX | 🍂 Parental Controls | / Pen and Touch | |
| Performance Information and Tools | Sersonalization | Phone and Modem | Power Options | |
| R Programs and Features | Prealtek HD Audio Manager | 🕷 Recovery | Region and Language | |
| RemoteApp and Desktop Connections | Sound | Ø Speech Recognition | Sync Center | |
| System | Tablet PC Settings | Taskbar and Start Menu | Troubleshooting | |
| Suser Accounts | 🍕 Windows Anytime Upgrade | Windows CardSpace | Windows Defender | |
| P Windows Firewall | a Windows Update | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |


• Click on the "Change display settings" button.



• Click the "Advanced Settings" button.

| 😋 🚭 🔹 Kontrol Panel 🕨 All Control Panel Items 🕨 D | splay + Screen Resolution | Search Centrel Panel |
|---|---|----------------------|
| Chan | ge the appearance of your display | |
| | 1 Detect | |
| Display | | |
| Nesolu Orienta | | |
| | Advanced settings | |
| | ext and other items larger or smaller isplay settings should I choose? | |
| | OK Cancel Apply | |
| | | |
| | | |
| | | |

Click the "Monitor" tab and then click the "Properties" button.




Click the "Driver" tab.

٠


•



• Open the **"Update Driver Software-Generic PnP Monitor"** window by clicking on **"Update Driver... "and** then click the **"Browse my computer for driver software"** button.




Select "Let me pick from a list of device drivers on my computer".



• Click the "Have Disk" button. Click on the "Browse" button and navigate to the following directory:

X:\Driver\module name(where X is the drive letter designator for the CD-ROM drive).



- Select the "xxx.inf" file and click the "Open" button. Click the "OK" button.
- Select your monitor model and click the "Next" button. The files will be copied from the CD to your hard disk

drive.

•

- Close all open windows and remove the CD.
- Restart the system. The system will automatically select the maximum refresh rate and corresponding Color Matching Profiles.

i-Menu



Welcome to "i-Menu" software by AOC. i-Menu makes it easy to adjust your monitor display setting by using on screen menus instead of the OSD button on the monitor. To complete installation, please follow the installation guide. The software Supported operating systems: Windows 10, Windows 8, Windows 7.



e-Saver



Welcome to use AOC e-Saver monitor power management software! The AOC e-Saver features Smart Shutdown functions for your monitors, allows your monitor to timely shutdown when PC unit is at any status (On, Off, Sleep or Screen Saver); the actual shutdown time depends on your preferences (see example below). Please click on "driver/e-Saver/setup.exe" to start installing the e-Saver software, follow the install wizard to complete software installation.

Under each of the four PC status, you may choose from the pull-down menu the desired time (in minutes) you're your monitor to automatically shut down. The example above illustrated:

- 1) The monitor will never shutdown when the PC is powered on.
- 2) The monitor will automatically shutdown 5 minutes after the PC is powered off.
- 3) The monitor will automatically shutdown 10 minutes after the PC is in sleep/stand-by mode.
- 4) The monitor will automatically shutdown 20 minutes after the screen saver appears.




You can click "RESET" to set the e-Saver to its default settings like below.



Screen+



Welcome to "Screen+" software by AOC. Screen+ software is a desktop screen splitting tool; it splits the desktop into different panels, and each panel displays a different window. You only need to drag the window to a corresponding panel when you want to access it. It supports multiple monitor display to make your task easier. Please follow the installation software to install it. The software Supported operating systems: Windows 10, Windows 8, Windows 7.



Troubleshoot

| Problem & Question | Possible Solutions |
|--|--|
| Power LED Is Not ON | Make sure the power button is ON and the Power Cord is properly connected to a grounded power outlet and to the monitor. |
| No images on the screen | Is the power cord connected properly? Check the power cord connection and power supply. Is the cable connected correctly? (Connected using the D-sub cable) Check the DB-15 cable connection. (Connected using the DVI cable) Check the DVI cable connection. * DVI input is not available on every model. If the power is on, reboot the computer to see the initial screen (the login screen), which can be seen. If the initial screen (the login screen) appears, boot the computer in the applicable mode (the safe mode for Windows ME/XP/2000) and then change the frequency of the video card. (Refer to the Setting the Optimal Resolution) If the initial screen (the login screen) does not appear, contact the Service Center or your dealer. Can you see "Input Not Supported" on the screen? You can see this message when the signal from the video card exceeds the maximum resolution and frequency that the monitor can handle properly. Adjust the maximum resolution and frequency that the monitor can handle properly. Make sure the AOC Monitor Drivers are installed. |
| Picture Is Fuzzy & Has Ghosting Shadowing Problem | Adjust the Contrast and Brightness Controls. Press to auto adjust. Make sure you are not using an extension cable or switch box. We recommend plugging the monitor directly to the video card output connector on the back. |
| Picture Bounces, Flickers Or Wave Pattern Appears In The Picture | Move electrical devices that may cause electrical interference as far away from the monitor as possible. Use the maximum refresh rate your monitor is capable of at the resolution you are using. |
| Monitor Is Stuck In Active Off-Mode" | The Computer Power Switch should be in the ON position. The Computer Video Card should be snugly fitted in its slot. Make sure the monitor's video cable is properly connected to the computer. Inspect the monitor's video cable and make sure no pin is bent. Make sure your computer is operational by hitting the CAPS LOCK key on the keyboard while observing the CAPS LOCK LED. The LED should either turn ON or OFF after hitting the CAPS LOCK key. |
| Missing one of the primary colors (RED, GREEN, or BLUE) | Inspect the monitor's video cable and make sure that no pin is damaged. Make sure the monitor's video cable is properly connected to the computer. |
| Screen image is not centered or sized properly | Adjust H-Position and V-Position or press hot-key (AUTO). |
| Picture has color defects (white does not look white) | Adjust RGB color or select desired color temperature. |
| Horizontal or vertical disturbances on the screen | Use Windows 95/98/2000/ME/XP shut-down mode to adjust CLOCK and FOCUS. Press to auto-adjust. |

Specification


General Specification

| | Model name | AG272FCX | | | | | |
|-----------------------------|-------------------------------|--|------------------|-----------------|--|--|--|
| | Driving system | TFT Color LCD | | | | | |
| | Viewable Image Size | 68.6 cm diagonal | 68.6 cm diagonal | | | | |
| Panel | Pixel pitch | 0.3114mm(H) x 0.3114mm(V) | | | | | |
| | Video | R, G, B Analog Interface & DVI interface & HDMI Interface & DP Interface | | | | | |
| | Separate Sync. | H/V TTL | | | | | |
| | Display Color | 16.7M Colors | | | | | |
| | Horizontal scan range | 30k-160kHz(D-Sub, HDM | I, DP) | | | | |
| | Horizontal scan Size(Maximum) | 597.88mm | | | | | |
| | Vertical scan range | 50-146Hz(D-Sub) 48-146Hz(HDMI, DP) | | | | | |
| | Vertical Scan Size(Maximum) | 336.31mm | | | | | |
| | Optimal preset resolution | 1920x1080@60Hz | | | | | |
| | Plug & Play | VESA DDC2B/CI | | | | | |
| Others | Input Connector | VGA//HDMIx2/DP | | | | | |
| | Input Video Signal | Analog: 0.7Vp-p(standard), 75 OHM, TMDS | | | | | |
| | Output Connector | Earphone out | | | | | |
| | Power Source | 20Vdc, 4.5A | | | | | |
| | | Typical(Brightness = 90,Contrast = 50) | | 40W | | | |
| | Power Consumption | Max. (brightness = 100, contrast =100) | | ≤75W | | | |
| | | Power saving | | ≪0.5W | | | |
| | Off timer | 0~24 hrs | | | | | |
| | Connector Type | VGA\HDMI\DP\Earphone | out | | | | |
| | Signal Cable Type | Detachable | | | | | |
| | Dimensions & Weight: | | | | | | |
| Physical Characteristics | Height(with Base) | 467~574mm | | | | | |
| | Width | 612mm | | | | | |
| | Depth | 266.5mm | | | | | |
| | Weight(Monitor only) | 7.4Kg | - | | | | |
| | Temperature | Operating | 0°~ 40° | | | | |
| | | Non-Operating | -25°~ 55° | | | | |
| Environmental | Humidity | Operating | 10% ~ 85% (| non-condensing) | | | |
| | | Non-Operating | 5% ~ 93% (n | on-condensing) | | | |
| | Altitude | Operating | 0~ 5000 m (0 |)∼ 16404ft) | | | |
| | | Non-Operating | 0~ 12192m ((| 0~ 40000ft) | | | |

Preset Display Modes


| STANDARD | RESOLUTION | HORIZONTAL FREQUENCY(kHz) | VERTICAL FREQUENCY(Hz) |
|----------|---------------------|------------------------------|---------------------------|
| VGA | 640x480@60Hz | 31.469 | 59.94 |
| VGA | 640x480@67Hz | 35 | 66.667 |
| VGA | 640x480@72Hz | 37.861 | 72.809 |
| VGA | 640x480@75Hz | 37.5 | 75 |
| VGA | 640x480@100Hz | 51.08 | 99.769 |
| VGA | 640x480@120Hz | 61.91 | 119.518 |
| DOS MODE | 720x400@70Hz | 31.469 | 70.087 |
| DOS MODE | 720x480@60Hz | 29.855 | 59.710 |
| SD | 720x576@50Hz | 31.25 | 50 |
| SVGA | 800x600@56Hz | 35.156 | 56.25 |
| SVGA | 800x600@60Hz | 37.879 | 60.317 |
| SVGA | 800x600@72Hz | 48.077 | 72.188 |
| SVGA | 800x600@75Hz | 46.875 | 75 |
| SVGA | 800x600@100Hz | 63.684 | 99.662 |
| SVGA | 800x600@120Hz | 76.302 | 119.97 |
| SVGA | 832x624@75Hz | 49.725 | 74.551 |
| XGA | 1024x768@60Hz | 48.363 | 60.004 |
| XGA | 1024x768@70Hz | 56.476 | 70.069 |
| XGA | 1024x768@75Hz | 60.023 | 75.029 |
| XGA | 1024x768@100Hz | 81.577 | 99.972 |
| XGA | 1024x768@120Hz | 97.551 | 119.989 |
| WXGA+ | 1440x900@60Hz | 55.935 | 59.887 |
| SXGA | 1280x1024@60Hz | 63.981 | 60.02 |
| SXGA | 1280x1024@75Hz | 79.975 | 75.025 |
| HD | 1280x720@50HZ | 37.071 | 49.827 |
| HD | 1280x720@60HZ | 45 | 60 |
| HD | 1280x1080@60Hz | 67.173 | 59.976 |
| Full HD | 1920x1080@60Hz | 67.5 | 60 |
| Full HD | 1920x1080@100Hz | 113.21 | 99.93 |
| Full HD | 1920x1080@120Hz | 137.26 | 119.982 |
| Full HD | 1920×1080@144Hz(RB) | 158.1 | 144 |

Pin Assignments




15-Pin Color Display Signal Cable

| Pin Number | 15-Pin Side of the Signal Cable | Pin Number | 15-Pin Side of the Signal Cable |
|------------|---------------------------------|------------|---------------------------------|
| 1 | Video-Red | 9 | +5V |
| 2 | Video-Green | 10 | Ground |
| 3 | Video-Blue | 11 | N.C. |
| 4 | N.C. | 12 | DDC-Serial data |
| 5 | Detect Cable | 13 | H-sync |
| 6 | GND-R | 14 | V-sync |
| 7 | GND-G | 15 | DDC-Serial clock |
| 8 | GND-B | | |




24-Pin Color Display Signal Cable

| Pin No. | Signal Name | Pin No. | Signal Name |
|---------|----------------------|---------|----------------------|
| 1 | TMDS data 2- | 13 | TMDS data 3+ |
| 2 | TMDS data 2+ | 14 | +5V Power |
| 3 | TMDS data 2/4 Shield | 15 | Ground (for+5V) |
| 4 | TMDS data 4- | 16 | Hot Plug Detect |
| 5 | TMDS data 4+ | 17 | TMDS data 0- |
| 6 | DDC Clock | 18 | TMDS data 0+ |
| 7 | DDC Data | 19 | TMDS data 0/5 Shield |
| 8 | N.C. | 20 | TMDS data 5- |
| 9 | TMDS data 1- | 21 | TMDS data 5+ |
| 10 | TMDS data 1+ | 22 | TMDS Clock Shield |
| 11 | TMDS data 1/3 Shield | 23 | TMDS Clock + |
| 12 | TMDS data 3- | 24 | TMDS Clock — |



| Pin No. | Signal Name | Pin No. | Signal Name | Pin No. | Signal Name |
|---------|--------------------|---------|---------------------------|---------|-----------------|
| 1. | TMDS Data 2+ | 9. | TMDS Data 0- | 17. | DDC/CEC Ground |
| 2. | TMDS Data 2 Shield | 10. | TMDS Clock + | 18. | +5V Power |
| 3. | TMDS Data 2- | 11. | TMDS Clock Shield | 19. | Hot Plug Detect |
| 4. | TMDS Data 1+ | 12. | TMDS Clock- | | |
| 5. | TMDS Data 1Shield | 13. | CEC | | |
| 6. | TMDS Data 1- | 14. | Reserved (N.C. on device) | | |
| 7. | TMDS Data 0+ | 15. | SCL | | |
| 8. | TMDS Data 0 Shield | 16. | SDA | | |



20-Pin Color Display Signal Cable

| Pin No. | Signal Name | Pin No. | Signal Name |
|---------|---------------|---------|-----------------|
| 1 | ML_Lane 3 (n) | 11 | GND |
| 2 | GND | 12 | ML_Lane 0 (p) |
| 3 | ML_Lane 3 (p) | 13 | CONFIG1 |
| 4 | ML_Lane 2 (n) | 14 | CONFIG2 |
| 5 | GND | 15 | AUX_CH(p) |
| 6 | ML_Lane 2 (p) | 16 | GND |
| 7 | ML_Lane 1 (n) | 17 | AUX_CH(n) |
| 8 | GND | 18 | Hot Plug Detect |
| 9 | ML_Lane 1 (p) | 19 | Return DP_PWR |
| 10 | ML_Lane 0 (n) | 20 | DP_PWR |

Plug and Play

Plug & Play DDC2B Feature

This monitor is equipped with VESA DDC2B capabilities according to the VESA DDC STANDARD. It allows the monitor to inform the host system of its identity and, depending on the level of DDC used, communicate additional information about its display capabilities.

The DDC2B is a bi-directional data channel based on the I2C protocol. The host can request EDID information over the DDC2B channel.

Regulation

FCC Notice

FCC Class B Radio Frequency Interference Statement WARNING: (FOR FCC CERTIFIED MODELS)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

NOTICE:

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modification to this equipment. It is the responsibilities of the user to correct such interference. It is the responsibility of the user to correct such interference.

WEEE Declaration

Disposal of Waste Equipment by Users in Private Household in the European Union.



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

RoHS Declaration

This product complies with all implemented RoHS type regulations worldwide, including but not limited to, EU, Korea, Japan, US States (e.g. California),Ukraine, Serbia, Turkey, Vietnam and India. We continue to monitor, influence and develop our processes to comply with upcoming proposed RoHS type regulations, including but not limited to, Brazil, Argentina, Canada

E-Waste Declaration for India



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about E –waste, please visit http://www.aocindia.com/ewaste.php and to know where you can drop off your waste equipment for recycling in India please contact on below given contact details. Helpline number: 080-6788-6788 / 080-3323-1313 (Monday to Saturday, 10 a.m. to 6 p.m.) Centralized E-waste collection center

Address: TPV Technology India Private Limited, 59, Maheswari Nagar, 1st Main Road, Mahadevapura Post, Whitefield Road, Bangalore, Karnataka, PIN: 560048, Tel: 080-3023-1000

E-mail: serviceindia@aoc.com

Reduction in the use of hazardous substances (India)

This product complies with the "E-Waste (Management) Rules, 2016" CHAPTER V, rule 16, sub-rule (1). Whereas New Electrical and Electronic Equipment and their components or consumables or parts or spares do not contain Lead, Mercury, Cadmium, Hexavalent Chromium, polybrominated biphenyls and polybrominated diphenyl ethers beyond a maximum concentration value of 0.1% by weight in homogenous materials for lead, mercury, hexavalent chromium, polybrominated diphenyl ethers and of 0.01% by weight in homogenous materials for cadmium except of exemptions set in Schedule 2 of the Rule.

EPA Energy Star



ENERGY STAR® is a U.S. registered mark. As an ENERGY STAR® Partner, AOC International (Europe) BV and Envision Peripherals, Inc. have determined that this product meets the ENERGY STAR® guidelines for energy efficiency. (FOR EPA CERTIFIED MODELS)

Service

Warranty Statement for Europe

LIMITED THREE-YEAR WARRANTY*

For AOC LCD Monitors sold within Europe, AOC International (Europe) B.V. warrants this product to be free from defects in material and workmanship for a period of Three (3) years after the original date of consumer purchase. During this period, AOC International (Europe) B.V. will, at its option, either repair the defective product with new or rebuilt parts, or replace it with a new or rebuilt product at no charge except as *stated below. In the absent of the proof of purchase, the warranty will start 3 months after the date of manufacturing indicated on the product.

If the product appears to be defective, please contact your local dealer or refer to the service and support section on <u>www.aoc-europe.com</u> for the warranty instructions in your country. The freight cost for the warranty is pre-paid by AOC for the delivery and return. Please ensure you provide a dated proof of purchase along with the product and deliver to the AOC Certified or Authorized Service Center under the following condition:

- Make sure the LCD Monitor is packed in a proper carton box (AOC prefers the original carton box to protects your monitor well enough during transport).
- Put the RMA number on the address label
- Put the RMA number on the shipping carton

AOC International (Europe) B.V. will pay the return shipping charges within one of the countries specified within this warranty statement. AOC International (Europe) B.V. is not responsible for any costs associated with the transportation of product across international borders. This includes the international border within the European Union. If the LCD Monitor is not available for collection when the currier attends, you will be charged a collection fee.

* This limited warranty does not cover any losses or damages that occur as a result of:

- Damages during transport due to improper packaging
- Improper installation or maintenance other then in accordance with AOC's user manual
- Misuse
- Neglect
- Any cause other than ordinary commercial or industrial application
- Adjustment by non-authorized source
- Repair, modification, or installation of options or parts by anyone other than an AOC Certified or Authorized Service Center
- Improper environments like humidity, water damage and dusts
- Damaged by violence, earthquake and terrorist attacks
- Excessive or inadequate heating or air conditioning or electrical powers failures, surges, or other irregularities

This limited warranty does not cover any of the product firmware or hardware that you or any third party have modified or altered; you bear the sole responsibility and liability for any such modifications or alteration.

All AOC LCD Monitors are produced according to the ISO 9241-307 Class 1 pixel policy standards.

If your warranty has expired, you still have access to all available service options, but you will be responsible for the cost of service, including parts, labor, shipping (if any) and applicable taxes. AOC Certified or Authorized Service Center will provide you with an estimate of service costs before receiving your authorization to perform service.

ALL EXPRESS AND IMPLIED WARRANTIES FOR THIS PRODUCT (INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) ARE LIMITED IN DURATION TO A PERIOD OF THREE (3) YEARS FOR PARTS AND LABOR FROM THE ORIGINAL DATE OF CONSUMER PURCHASE. NO WARRANTIES (EITHER EXPRESSED OR IMPLIED) APPLY AFTER THIS PERIOD. AOC INTERNATIONAL (EUROPE) B.V. OBLIGATIONS AND YOUR REMEDIES HEREUNDER ARE SOLELY AND EXCULSIVELY AS STATED HERE. AOC INTERNATIONAL (EUROPE) B.V. LIABILITY, WHETHER BASED ON CONTRACT, TORT, WARRANTY, STRICT LIABILITY, OR OTHER THEORY, SHALL NOT EXCEED THE PRICE OF THE INDIVIDUAL UNIT WHOSE DEFECT OR DAMAGE IS THE BASIS OF THE CLAIM. IN NO EVENT SHALL AOC INTERNATIONAL (EUROPE) B.V. BE LIABLE FOR ANY LOSS OF PROFITS, LOSS OF USE OR FACILITIES OR EQUIPMENT, OR OTHER INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. ALTHOUGH THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, YOU MAY HAVE OTHER RIGHTS, WHICH MAY VARY FROM COUNTRY TO COUNTRY. THIS LIMITED WARRANTY IS ONLY VALID FOR PRODUCTS PURCHASED IN THE MEMBER COUNTRIES OF THE EUROPEAN UNION.

Information in this document is subject to change without notice. For more information, please visit: <u>http://www.aoc-europe.com</u>

Warranty Statement for Middle East and Africa (MEA)

And

The Commonwealth of Independent States (CIS)

LIMITED ONE to THREE YEARS WARRANTY*

For AOC LCD Monitors sold within the Middle East and Africa (MEA) and the Commonwealth of Independent States (CIS), AOC International (Europe) B.V. warrants this product to be free from defects in material and workmanship for a period of One (1) to Three (3) years from the manufacture date depending on sale country. During this period, AOC International (Europe) B.V. offers a Carry-In (return to Service Center)Warranty Support at an AOC's Authorized Service Center or Dealer and at its option, either repair the defective product with new or rebuilt parts, or replace it with a new or rebuilt product at no charge except as *stated below. As a Standard Policy, the warranty will be calculated from the manufacture date identified from the product ID serial number, but the total warranty will be Fifteen (15) months to Thirty Nine (39) months from MFD (manufacture date) depending on sale country. Warranty will be considered for exceptional cases that are out of warranty as per the product ID serial number and for such exceptional cases; Original Invoice/Proof Of Purchase Receipt is mandatory.

If the product appears to be defective, please contact your AOC authorized dealer or refer to the service and support section on AOC's website for the warranty instructions in your country:

- Egypt: <u>http://aocmonitorap.com/egypt_eng</u>
- CIS Central Asia: <u>http://aocmonitorap.com/ciscentral</u>
- Middle East: <u>http://aocmonitorap.com/middleeast</u>
- South Africa: <u>http://aocmonitorap.com/southafrica</u>
- Saudi Arabia: <u>http://aocmonitorap.com/saudiarabia</u>

Please ensure you provide a dated proof of purchase along with the product and deliver to the AOC Authorized Service Center or Dealer under the following condition:

- Make sure the LCD Monitor is packed in a proper carton box (AOC prefers the original carton box to protects your monitor well enough during transport).
- Put the RMA number on the address label
- Put the RMA number on the shipping carton

* This limited warranty does not cover any losses or damages that occur as a result of:

- Damages during transport due to improper packaging
- Improper installation or maintenance other then in accordance with AOC's user manual
- Misuse
- Neglect
- Any cause other than ordinary commercial or industrial application
- Adjustment by non-authorized source
- Repair, modification, or installation of options or parts by anyone other than an AOC Certified or

Authorized Service Center

- Improper environments like humidity, water damage and dusts
- Damaged by violence, earthquakes and terrorist attacks
- Excessive or inadequate heating or air conditioning or electrical powers failures, surges, or other irregularities

This limited warranty does not cover any of the product firmware or hardware that you or any third party have modified or altered; you bear the sole responsibility and liability for any such modifications or alteration.

All AOC LCD Monitors are produced according to the ISO 9241-307 Class 1 pixel policy standards.

If your warranty has expired, you still have access to all available service options, but you will be responsible for the cost of service, including parts, labor, shipping (if any) and applicable taxes. AOC Certified, Authorized Service Center or dealer will provide you with an estimate of service costs before receiving your authorization to perform service.

ALL EXPRESS AND IMPLIED WARRANTIES FOR THIS PRODUCT (INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) ARE LIMITED IN DURATION TO A PERIOD OF ONE (1) to THREE (3) YEARS FOR PARTS AND LABOR FROM THE ORIGINAL DATE OF CONSUMER PURCHASE. NO WARRANTIES (EITHER EXPRESSED OR IMPLIED) APPLY AFTER THIS PERIOD. AOC INTERNATIONAL (EUROPE) B.V. OBLIGATIONS AND YOUR REMEDIES HEREUNDER ARE SOLELY AND EXCULSIVELY AS STATED HERE. AOC INTERNATIONAL (EUROPE) B.V. LIABILITY, WHETHER BASED ON CONTRACT, TORT, WARRANTY, STRICT LIABILITY, OR OTHER THEORY, SHALL NOT EXCEED THE PRICE OF THE INDIVIDUAL UNIT WHOSE DEFECT OR DAMAGE IS THE BASIS OF THE CLAIM. IN NO EVENT SHALL AOC INTERNATIONAL (EUROPE) B.V. BE LIABLE FOR ANY LOSS OF PROFITS, LOSS OF USE OR FACILITIES OR EQUIPMENT, OR OTHER INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. ALTHOUGH THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, YOU MAY HAVE OTHER RIGHTS, WHICH MAY VARY FROM COUNTRY TO COUNTRY. THIS LIMITED WARRANTY IS ONLY VALID FOR PRODUCTS PURCHASED IN THE MEMBER COUNTRIES OF THE EUROPEAN UNION.

Information in this document is subject to change without notice. For more information, please visit: http://www.aocmonitorap.com



AOC International (Europe) B.V. Prins Bernhardplein 200 / 6th floor, Amsterdam, The Netherlands Tel: +31 (0)20 504 6962 • Fax: +31 (0)20 5046933


AOC PIXEL POLICY ISO 9241-307 CLASS 1

July 25th, 2013

AOC strives to deliver the highest quality products. We use some of the industry's most advanced manufacturing processes and practice stringent quality control. However, pixel or sub pixel defects on the TFT monitor panels used in flat panel monitors are sometimes unavoidable. No manufacturer can guarantee that all panels will be free from pixel defects, but AOC guarantees that any monitor with an unacceptable number of defects will be repaired or replaced under warranty. This Pixel Policy explains the different types of pixel defects and defines acceptable defect levels for each type. In order to qualify for repair or replacement under warranty, the number of pixel defects on a TFT monitor panel must exceed these acceptable levels.

Pixels and Sub Pixel Definition

A pixel, or picture element, is composed of three sub pixels in the primary colors of red, green and blue. When all sub pixels of pixel are lit, the three colored sub pixel together appear as a single white pixel. When all are dark, the three colored sub pixels together appear as a single black pixel.



Types of Pixel Defects

- Bright Dot Defects: the monitor displays a dark pattern, sub pixels or pixels are always lit or "on"
- Black Dot Defects: the monitor displays a light pattern, sub pixels or pixels are always dark or "off".

| ISO 9241-307 | Defect Type | Defect Type 2 | Defect Type 3 | | Defect Type 4 |
|--------------------|---------------|---------------|------------------|---|-----------------|
| Pixel Defect Class | 1Bright Pixel | Black Pixel | Bright Sub pixel | | Black Sub pixel |
| | | | 2 | + | 1 |
| Classe 1 | 1 | 1 | 1 | + | 3 |
| | | | 0 | + | 5 |

AOC International (Europe) B.V.

Warranty Statement for North & South America (excluding Brazil)

WARRANTY STATEMENT

For AOC Color Monitors Including those Sold within North America as Specified

Envision Peripherals, Inc. warrants this product to be free from defects in material and workmanship for a period of three (3) years for parts & labor and one (1) year for CRT Tube or LCD Panel after the original date of consumer purchase. During this period, EPI (EPI is the abbreviation of Envision Peripherals, Inc.) will, at its option, either repair the defective product with new or rebuilt parts, or replace it with a new or rebuilt product at no charge except as *stated below. The parts or product that are replaced become the property of EPI.

In the USA to obtain service under this limited warranty, call EPI for the name of the Authorized Service Center closest to your area. Deliver the product freight pre-paid, along with the dated proof of purchase, to the EPI Authorized Service Center. If you cannot deliver the product in person:

- Pack it in its original shipping container (or equivalent)
- Put the RMA number on the address label
- Put the RMA number on the shipping carton
- Insure it (or assume the risk of loss/damage during shipment)
- Pay all shipping charges

EPI is not responsible for damage to inbound product that was not properly packaged. EPI will pay the return shipment charges within one of the countries specified within this warranty statement. EPI is not responsible for any costs associated with the transportation of product across international borders. This includes the international borders of the countries within this warranty statements.

In the United States and Canada contact your Dealer or EPI Customer Service, RMA Department at the toll free number (888) 662-9888. Or you can request an RMA Number online at www.aoc.com/na-warranty.

* This limited warranty does not cover any losses or damages that occur as a result of:

- Shipping or improper installation or maintenance
- Misuse
- Neglect
- Any cause other than ordinary commercial or industrial application
- Adjustment by non-authorized source
- Repair, modification, or installation of options or parts by anyone other than an EPI Authorized Service Center
- Improper environment
- Excessive or inadequate heating or air conditioning or electrical power failures, surges, or other irregularities

This three-year limited warranty does not cover any of the product's firmware or hardware that you or any third party have modified or altered; you bear the sole responsibility and liability for any such modification or alteration.

ALL EXPRESS AND IMPLIED WARRANTIES FOR THIS PRODUCT (INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) ARE LIMITED IN DURATION TO A PERIOD OF THREE (3) YEARS FOR PARTS AND LABOR AND ONE (1) YEAR FOR CRT TUBE OR LCD PANEL FROM THE ORIGINAL DATE OF CONSUMER PURCHASE. NO WARRANTIES (EITHER EXPRESSED OR IMPLIED) APPLY AFTER THIS PERIOD. IN THE UNITED STATES OF AMERICA, SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

EPI OBLIGATIONS AND YOUR REMEDIES HEREUNDER ARE SOLELY AND EXCLUSIVELY AS STATED HERE. EPI' LIABILITY, WHETHER BASED ON CONTRACT, TORT. WARRANTY, STRICT LIABILITY, OR OTHER THEORY, SHALL NOT EXCEED THE PRICE OF THE INDIVIDUAL UNIT WHOSE DEFECT OR DAMAGE IS THE BASIS OF THE CLAIM. IN NO EVENT SHALL ENVISION PERIPHERALS, INC. BE LIABLE FOR ANY LOSS OF PROFITS, LOSS OF USE OR FACILITIES OR EQUIPMENT OR OTHER INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGE. IN THE UNITED STATES OF AMERICA, SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. ALTHOUGH THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHER RIGHTS WHICH MAY VARY FROM STATE TO STATE.

In the United States of America, this limited warranty is only valid for Products purchased in the Continental United States, Alaska, and Hawaii.

Outside the United States of America, this limited warranty is only valid for Products purchased in Canada.

Information in this document is subject to change without notice. For more details, please visit:

USA: http://us.aoc.com/support/warranty ARGENTINA: http://ar.aoc.com/support/warranty BOLIVIA: http://bo.aoc.com/support/warranty CHILE: http://cl.aoc.com/support/warranty COLOMBIA: http://co.aoc.com/warranty COSTA RICA: http://cr.aoc.com/support/warranty DOMINICAN REPUBLIC: http://do.aoc.com/support/warranty ECUADOR: http://ec.aoc.com/support/warranty EL SALVADOR: http://sv.aoc.com/support/warranty GUATEMALA: http://gt.aoc.com/support/warranty HONDURAS: http://hn.aoc.com/support/warranty NICARAGUA: http://ni.aoc.com/support/warranty PANAMA: http://pa.aoc.com/support/warranty PARAGUAY: http://py.aoc.com/support/warranty **PERU:** http://pe.aoc.com/support/warranty URUGUAY: http://pe.aoc.com/warranty VENEZUELA: http://ve.aoc.com/support/warranty IF COUNTRY NOT LISTED: http://latin.aoc.com/warranty

EASE PROGRAME



Only for AOC branded monitors sold within the continental United States.

All AOC branded monitors are now covered by the EASE Program. If your monitor malfunctions at any time during the first three months, AOC will provide a replacement monitor within 72 hours after you are approved for our program. If your monitor qualifies for the EASE program, AOC will pay for freight both ways.

Step 1: Phone our TECH Department at 888.662.9888Step 2: Fill out and return EASE registration forms by mail or fax.Step 3: We will issue a Return Authorization Number upon verification into the program.Step 4: A monitor will be advance shipped to your location.Step 5: We will issue a UPS Call Tag to pick up the defective unit.Step 6: Please review the following chart to see your EASE program qualifications.

| WARRANTY PERIOD | COVERAGE AT NO CHARGE | CUSTOMER CHARGES |
|---|--|-----------------------------|
| Within the first three months of purchase: Covered by EASE | New AOC monitor Call tag dispatched and return freightcharges via UPS | - None* |
| Between 4 months – 1 Year | - All Parts & Labor Including CRT Tube & LCD Panel | - UPS Return Freight to AOC |
| Between 1 Year - 3 Years: Covered by standard limited warranty | - Parts & Labor (excluding CRT Tube & LCD Panel) | - UPS Return Freight to AOC |

*AOC will need to obtain a credit card number if you would like to get a new AOC monitor advanced shipped to your location, prior to the defective unit arriving at AOC's service center. If you do not wish to supply a credit card, AOC will only ship the new monitor, once the defective unit arrives at the AOC service center.



TCO DOCUMENT

Congratulations!

This product is designed for both you and the planet!



TCO Development works for sustainable IT manufacture, use and recycling of IT products reflecting environmental, social and economic responsibility.

TCO Certified is a third party verified program, where every product model is tested by an accredited impartial test laboratory. TCO

Certified represents one of the toughest certifications for ICT products worldwide.

Some of the Usability features of TCO Certified Displays:

- Visual Ergonomics for image quality is tested to ensure top performance and reduce sight and strain problems. Important parameters are Resolution, Luminance, Contrast, Reflection and Colour characteristics
- Products are tested according to rigorous safety standards at impartial laboratories
- Electric and magnetic fields emissions as low as normal household background levels
- Workload ergonomics to ensure a good physical environment

Some of the Environmental features of TCO Certified Displays:

- Production facilities have an Environmental Management System (EMAS or ISO 14001)
- Low energy consumption to minimize climate impact
- Restrictions on Chlorinated and Brominated flame retardants, plasticizers, plastics and heavy metals such as cadmium, mercury and lead (RoHS compliance)
- Both product and product packaging is prepared for recycling
- The brand owner offers take-back options

Corporate Social Responsibility

 The brand owner demonstrates the product is manufactured under working practices that promote good labour relations and working conditions.

The Criteria Document can be downloaded from our web site. The criteria included in this label have been developed by TCO Development in co-operation with scientists, experts, users as well as manufacturers all over the world. Since the end of the 1980s TCO has been involved in influencing the development of IT equipment in a more user and environmentally friendly direction. Our ICT product labeling system began in 1992 and is now requested by users and ICT-manufacturers all over the world.

For more information, please visit www.tcodevelopment.com

TCO Cartified Document for Displays version. 2.3



(FOR TCO CERTIFIED MODELS)