



ZH-S 用户手册 1 EN User manual 23

Environmental friendly paper used. Thanks for your contribution to save trees. 此说明书使用环保纸印制。 感谢您为保护森林作出贡献。



目录

1	重要事项 安全	4 4
2	您的空气净化器 产品概述 控件概览	6 6 7
3	使用入门 安装过滤网 Wi-Fi 设置(仅适用于	8 8
	AC5655 和 AC5660)	9
4	使用产品 了解空气质量指示灯 打开和关闭 更改自动模式设置 更改风扇速度 使用灯光开/关功能 切换显示指示灯 设置童锁	10 10 11 11 12 13 13 14
5	清洁 清洁计划 清洁产品机身 清洁出风口盖 清洁空气质量传感器 清洁预过滤网	15 15 15 15 16 16
6	更换空气净化滤网 了解健康空气智能锁 更换滤网	18 18 18
7	存放	19
8		20

9	保修与服务 订购部件或附件	22 22
10	注意事项	22
	电磁场 (EMF)	22
	回收	22
	注意	22

1 重要事项

安全

使用本产品之前,请仔细阅读本用户手册,并妥善保管以备日后参考。

危险

- · 切勿让水或任何其它液体或 易燃性清洁剂进入产品,以 免发生触电和/或火灾。
- · 切勿用水或任何其它液体或 (易燃性)清洁剂来清洁 产品,以免发生触电和/或 火灾。
- · 切勿在产品周围喷洒杀虫剂 或香水等任何可燃材料。

警告

- · 在将产品连接电源之前,请 先检查产品所标电压与当地 的供电电压是否相符。
- · 如果电源软线损坏,为避免 危险,必须由制造厂或其 维修部或类似的专职人员来 更换。
- ・ 如果插头、电源线或产品 本身受损,请勿再使用本 产品。
- · 本产品不可由肢体残障,精神障碍或缺乏相关经验和技能的人(包括8岁以上儿童)使用,除非有负责安全的人员对他们进行产品使用的相关指导或说明,方可使

- 用本产品。不得让儿童玩耍本产品。请勿让儿童在无人 监督的情况下清洁和保养产品。
- · 请勿堵塞进风和出风口,例如不要将物体放置在出风口上或进风口前方。
- · 确保异物未通过出风口进入 产品内部。

警告

- 本产品不能替代正常通风、 日常吸尘或者在烹饪时使用 的抽油烟机。
- · 如果连接产品的电源插座接触不良,则产品的插头可能会变得很热。确保所连接的电源插座接触良好。
- · 一定要在干燥、稳固、平整 且水平的表面上放置和使用 本产品。
- · 产品的后侧及两侧均要留出至少 20 厘米的空间,产品上方至少要留出 30 厘米的空间。
- · 切勿在本产品上放置任何 物品。
- · 请勿坐在或站在产品上面。 坐在或站在产品上面可能导 致潜在的人身伤害。
- · 切勿将产品直接放在空调 下方,以防冷凝水滴到 产品中。

- · 打开产品电源之前,务必 确保已经正确安装所有 过滤网。
- · 只能使用飞利浦专门为本产 品设计的原装过滤网。切勿 使用任何其它过滤网。
- · 燃烧滤网可能会造成不可逆 转的人体危害和/或危及其 他生命。请勿将滤网用作燃 料或类似用途。
- · 请勿用硬物敲击本产品(尤 其是进风口和出风口)。
- · 始终通过产品背面的手柄提 起或移动产品。
- · 请勿将手指或物体插入出风口或进风口,以防止产品出现物理损坏或发生故障。
- · 当您使用室内喷雾式驱虫剂 或在充满油污、易燃气体或 化学烟雾的地方时,请勿使 用本产品。
- · 请勿在气体用具、加热装置 或火炉附近使用本产品。
- · 使用之后和清洁产品或执行 其他维护或更换滤网之前, 请务必先拔掉产品的电源 插头。
- · 请勿在温度变化较大的房间 内使用本产品,因为这可能 导致产品内部的冷凝。


- · 为防止产生干扰,产品与使用无线电波的电器(例如电视机、收音机和无线电控制时钟)之间至少应保持2米距离。
- · 本产品仅限于家用并在正常 运行条件下使用。
- · 请勿在潮湿环境或高温环境中(例如浴室、卫生间或厨房)使用本产品。
- · 本产品不能去除一氧化碳 (CO) 或氡 (Rn),因此在 发生燃烧和危险化学品事故 时,不能作为安全设备 使用。
- · 如果需要移动产品,请先断 开产品的电源。
- · 请勿通过拉扯电源线来移动 产品。
- · 更换滤网后,请务必清洗 双手。

2 您的空气净化器

感谢您的惠顾,欢迎光临飞利浦!

为充分享受飞利浦提供的支持,请在 www.philips.com/welcome 注册您的产品本产品可与空气过滤系统一起使用。使用本产品之前,请仔细阅读本用户手册,并妥善保管以备日后参考。

产品概述



型号	过滤网
FY5186	纳米级劲护滤网S3型*

^{*}在下文统称为"空气净化滤网"。

控件概览





控制按钮

மு	电源开/关按钮	*	风扇速度按钮
,Ā,	光线开/关按钮	P o	童锁按钮
A	自动模式按钮	\rightarrow	过滤网重置按钮

显示面板

C.	睡眠模式	Gas	气体异常显示
~	速度1	PM2.5	PM2.5 指示
≈	速度 2	IAI	室内过敏原指数
≋	速度 3	PM2.5	去污染原模式
@	劲速模式	**	去过敏原模式
	过滤网更换提醒		去细菌和病毒模式
_	预过滤网清洁提醒	Po	童锁指示灯
\$	Wi-Fi 指示灯*		

^{*}仅限于 AC5655 和 AC5660。


3 使用入门

安装过滤网

在使用本产品之前,先拆掉过滤网的所有包装。请按以下所述拆掉过滤网的包装,然后将其放入产品中:

注意

- · 产品的两侧各有一组滤网。每侧均 配备一个预过滤网和一个空气净化 滤网。
- ·确保先放入空气净化滤网,再放置 预过滤网。
- ·安装空气净化滤网时,请确保带拉片的一面朝向您。
- **1** 拆掉空气净化滤网的所有包装 材料。




2 拉出侧面板的上半部分以将其从产品上卸下。



3 向下按两个固定夹,然后朝您自己的方向拉动预过滤网。



4 将无包装的空气净化滤网放回产品内。



5 将预过滤网放回产品内部。



注意

· 确保预过滤网的所有挂钩均已正确 连接到净化器上。 6 要重新安装侧面板,请先将面板安 装到产品的底部 (1)。然后,朝产品 机身方向轻推面板到位(2)。



7 重复上述步骤,组装产品另一侧的 滤网。

Wi-Fi 设置(仅适用于 AC5655 和 AC5660)

首次设置 Wi-Fi 连接

请从苹果应用程序商店或安卓应用 市场下载并安装 "Air Matters 在意空气"应用程序。



- 2 将空气净化器的插头插入插座, 然 后轻触()以打开空气净化器。
 - → 首次使用时, Wi-Fi 指示灯 🤝 呈橙色闪烁。
- 3 确保您的移动设备已成功连接至您 的 Wi-Fi 网络。
- 4 启动 "Air Matters 在意空气"应 用程序, 按照屏幕上的说明将空气 净化器连接到您的家庭网络。
- 5 配对和连接成功后, Wi-Fi 指示灯 奈 将呈白色亮起。如果配对未成 功,请参阅故障排除部分,或访 问 "Air Matters 在意空气"应用 程序中的帮助部分以获得大量最新 的故障排除技巧。

注意

- · 此说明仅在首次设置空气净化器时有效。如果网络已更改,或需要重新执行设置,请参阅第10页的"重新设置 Wi-Fi 连接"部分。
- · 您不能同时设置两个空气净化器。 如果您要设置多个空气净化器, 则只能逐个执行此操作。
- ·确保移动设备与空气净化器之间的 距离小于 10 米,且没有任何障碍 物。
- · App支持最新的iOS和安卓系统, 请到 www.philips.com/purifiercompatibility 查看支持的系统和设 备的更新。

重新设置 Wi-Fi 连接

注意

- · 当与空气净化器连接的默认网络已 更改时适用。
- · 网络更改后,需重新设置WIFI 连接。
- 1 将空气净化器的插头插入插座,然 后轻触 (少以打开空气净化器。
- **2** 同时长按 **①** 和 **貸** 3 秒钟,直至您 听到蜂鸣声。
 - → 空气净化器将进入配对模式。
 - → Wi-Fi 指示灯 令 呈橙色 闪烁。
- **3** 遵循 "首次设置 Wi-Fi 连接"一节中的步骤 4-5。

4 使用产品

了解空气质量指示灯

室内过敏原指数 (IAI) 是一个实时数字显示屏,可提供室内过敏原级别的视觉和即时反馈。

空气质量指示灯 颜色	空气质量级别
蓝色	良好
蓝紫色	一 般
紫红色	较差
红色	非常差

空气净化器打开后,空气质量指示灯将自动亮起,并按顺序亮起所有颜色。大约 30 秒后,空气质量传感器将选择与环境空气悬浮颗粒质量相对应的颜色。

PM2.5

即使是空气中最细微的颗粒变化, AeraSense 传感技术也可精确地检测 并快速响应。它提供实时的 PM2.5 反 馈,让您安枕无忧。

ΙΔΙ

专业级 AeraSense 传感器可检测室内空气过敏原的级别,然后用 1 至 12 之间的数字进行级别反馈,显示室内空气过敏原的潜在风险级别。1 表示空气质量最佳。

气体异常显示

使用高性能气体感应器,范围为 L1 至 L4 的显示值可显示潜在有害气体 (包括挥发性有机化合物、异味等)的密度级别。L1 表示空气质量最佳。

打开和关闭

注意

- · 务必将空气净化器置于稳固、水平 且平坦的表面上, 使装置的正面背 向墙壁或家具。
- · 为了获得出色的净化性能,请关闭
- ・使窗帘远离讲风口或出风口。
- 将空气净化器的插头插入插座。
 - → 空气净化器将发出蜂鸣音。
 - → 所有指示灯均亮起一次, 然后 再熄灭。
- 2 轻触 🛈 按钮启动产品。



- → 默认情况下,空气净化器在去污 染模式() 下运行。
- → 空气净化器预热时, 屏幕上会显 示"---"。
- → 约30秒后,空气净化器将显示 PM2.5 水平, 空气质量传感器 会自动选择相应的空气质量指 示灯颜色。



3 长按 (少 3 秒可关闭空气净化器。

注意

· 如果空气净化器关闭后仍与电源插 座连接,再次开机后,机器保持之 前的设置运行。


更改自动模式设置

您可以选择去污染模式()、去过敏 原模式(卷)或去细菌和病毒模式 (♣)。

去污染模式

专门设计的去污染模式可有效去除 PM2.5 等空气污染物。


- 轻触自动模式按钮 🔿 以选择去污染 模式。
 - 屏幕上。



去过敏原模式

超敏感的去过敏原模式经过精心设计, 旨在对周围空气中的微小过敏原等级变 化作出反应。


- · 轻触自动模式按钮 ① 以选择去过敏 原模式。
 - → 自动(**?**)和 **%** 将显示在 屏幕上。



去细菌和病毒模式

去细菌和病毒模式可加快气流流动以快速减少细菌和病毒。

- · 轻触自动模式按钮 ② 以选择去细菌 和病毒模式。
 - → 自动(**?**)和 ***** 将显示在 屏幕上。



更改风扇速度


提供了多种风速。

使用手动风扇速度设置时,净化器仍将 监控空气质量,但如果检测到空气质量 变化,它不会自动调节风扇速度。

睡眠模式(℃)


在睡眠模式下,空气净化器将以非常低 的速度安静地运行。

- 轻触风扇速度按钮 **③** 以选择睡眠模式。
 - → 5*L*将显示在屏幕上。
 - → 睡眠模式指示灯 🖰 将亮起。



丰动

- 反复轻触风扇速度按钮 **③** 以选择您需要的风速:
 - ~(速度1)
 - ≈(速度2)
 - ≋(速度3)




⊁ 提示

· 如果空气质量指示灯呈蓝色亮起, 表明空气质量良好,您可以选择较 低的风速。另一方面,如果空气质 量指示灯呈紫红色或红色亮起,则 表明空气质量不健康,您可以选 择较高的风速,以便更快地净化 空气。

劲速(t)

在劲速模式下,空气净化器会以最高速 度运行。

- · 轻触风扇速度按钮 ❸ 以选择劲速 模式(上)
 - → "上"将显示在屏幕上。
 - → 劲速指示灯 @ 将亮起。



使用灯光开/关功能

使用灯亮度调节按钮可打开或关闭空气 质量指示灯、显示屏和功能指示灯(如 果需要)。


- 轻触一次灯亮度调节按钮貸,空气 质量指示灯环将变暗。
- 2 再次轻触调光按钮貸,空气质量指示灯环将熄灭。
- **3** 第三次轻触灯亮度调节按钮 貸,所有指示灯环都将重新亮起。

切换显示指示灯


空气净化器具有三个显示指示灯: PM2.5 指数、IAI 指数和空气等级。

注意


- ·默认情况下,空气净化器显示 PM2.5 指数。
- **1** 长按灯亮度调节按钮 ♥ 3 秒可切换至 IAI 指数。
 - → IAI 指示灯和实际的 IAI 指数将 在屏幕上显示。



- 2 再次长按灯亮度调节按钮 貸 3 秒可 切换至 PM2.5 指数。
 - → PM2.5 指示灯和实际的 PM2.5 指数将在屏幕上显示。



- **3** 再次长按灯亮度调节按钮 貸 3 秒可切换至气体等级显示。
 - → 空气指示灯和实际的空气等级 将在屏幕上显示。




注意

·即使 PM2.5 指数非常低,空气质量指示灯可能仍然红色。这是正常的。这是因为至少一种指数(IAI指数或空气等级)很高时,空气质量指示灯将变为红色,机器将实时显示风险最高的空气质量指标。

设置童锁

- **1** 长按童锁按钮 **6** 3 秒可激活童 锁。
 - → 童锁图标 6 将显示在屏幕上。
 - → 当童锁已打开时,按其他任意按 钮均无反应。



- **2** 再次长按童锁按钮 **6** 3 秒可停用 童锁。
 - → 童锁图标 ♣ 消失。

注意

· 对于AC5655和AC5660,即使童 锁功能开启,您仍可以通过App来 控制空气净化器。

5 清洁

注意

- ·清洁产品前,务必先将电源插头 拔掉。
- · 切勿将本产品浸入水中或任何其它 液体中。
- · 切勿使用研磨性、腐蚀性或易燃性 清洁剂(例如漂白剂或酒精)清洁 本产品的任何部件。
- · 只有预过滤网可以用水清洗。空气 净化器滤网不可水洗,也不可用吸 尘器清洁。

清洁计划

频率	清洁方法
必要时	使用干软布擦拭产 品表面
	清洁出风口盖
每两个月	使用干棉签清洁空 气质量传感器
预过滤网清洁 指示灯 ➡ 会亮 起并在屏幕上 显示 F0	请清洁预过滤网

清洁产品机身

定期清洁产品的内侧和外侧, 防止灰尘积聚。

1 使用柔软的干布擦去产品机身上的灰尘。

清洁出风口盖

1 要解锁出风口盖,请握住盖子上的手柄,然后向上拉动。



2 用刷子清洁出风口盖。



3 将顶盖重新安装到位。




清洁空气质量传感器

每2个月清洁一次空气质量传感器,确保产品以最佳性能运行。如果产品用在多尘的环境中,请经常进行清洁。

注意


- ·如果将空气净化器用于多尘环境,则可能需要更频繁地进行清洁。
- · 如果室内的湿度非常高,则空气质量传感器上可能会形成冷凝水,即使空气质量确实很好,空气质量指示灯也可能会指示空气质量较差。如出现此情况,请清洁空气质量传感器或以手动速度设置使用空气净化器。
- 使用软刷清洁空气质量传感器的进风□和出风□。



2 打开空气质量感应器的保护盖。



3 使用湿棉签清洁空气质量传感器、 讲风□和出风□。




- 4 使用干棉签彻底擦干所有部件。
- **5** 重新装上空气质量感应器的保护盖。



清洁预过滤网

当 □ 亮起并在屏幕上显示 FO 时,清洁预过滤网。



1 关闭空气净化器,从电源插座上拔下插头。

2 拉出侧面板的上半部分以将其从产品上卸下。




3 向下按两个固定夹,然后朝您自己的方向拉动预过滤网。



4 请使用软刷清除上面的灰尘。然后,在水龙头下清洗预过滤网。



5 待预过滤网完全晾干后再将其装回 空气净化器中。 6 将预过滤网放回产品内部。



注意

- · 确保预过滤网完全干燥后再将其放回产品。如果仍然是湿的,细菌可能会乘虚而入,从而缩短预过滤网的使用寿命。
- **7** 要重新安装侧面板,请先将面板安装到产品的底部(1)。然后,朝产品机身方向轻推面板到位(2)。



- 8 将空气净化器的插头插入插座。
- 9 轻触 🛈 按钮启动产品。
- 10 长按重置按钮 → 3 秒可重置预过滤网清洁时间。
- 11 安装滤网后,彻底洗净双手。

6 更换空气净化 滤网

了解健康空气智能锁

该空气净化器配有滤网更换指示灯,旨在确保空气净化器运行时,空气净化滤网处于最佳工作状态。当滤芯需要更换时,会在屏幕上显示过滤网代码(请参阅过滤网提示图),且过滤网更换提醒(配)将呈红色亮起。

如果未及时更换滤网,则空气净化器将停止运行并自动锁定,以保护房间中的空气质量。应尽快根据过滤网代码更换过滤网。

更换滤网


注意

- · 过滤网不可水洗或循环使用。
- · 在更换过滤网之前,务必先关闭 空气净化器并从电源插座上拔下 插头。
- · 请勿用吸尘器清洁滤网。
- · 如果预过滤网已损毁、磨损或损坏,请勿使用。访问www.philips.com/support或与您所在国家/地区的客户服务中心联系购买。

滤网提示灯状态	动作
在屏幕上显示 A3,	更换纳米级劲
且过滤网更换提醒	护滤网S3型
公会亮起。	(FY5186)




- 1 取出产品两侧的预过滤网。
- 2 取出已过期的过滤网。丢弃用过的过滤网。




注意

·请勿接触滤网的褶皱面,或闻滤网的气味,因为其包含从空气中收集的污染物。

3 拆掉新滤网上的所有包装材料。



4 将不带包装的空气净化滤网放回产品内。



- 5 将空气净化器的插头插入插座。
- 6 轻触 ① 按钮启动产品。
- 7 长按重置按钮 → 3 秒可重置过滤 网使用寿命计数器

注意

· 更换滤网后,请洗净双手。

7 存放

- **1** 关闭空气净化器,从插座上拔下插头。
- 2 清洁空气滤网、空气质量传感器 和预过滤网(请参阅"清洁"一 章)。
- **3** 待所有部件完全晾干后再进行存放。
- 4 将滤网装入密封的塑料袋中。
- 5 将空气净化器、滤网和预过滤网存放在阴凉干燥处。
- 6 拆装滤网后,务必彻底洗净双手。

8 故障排除

本章归纳了您在使用产品时最常遇到的问题。如果您无法根据下面的信息解决问题,请与您所在国家/地区的客户服务中心联系。

问题	可能的解决方法
产品即使接通电源也无法工作。	请检查顶盖是否安装到位。滤网更换指示灯持续亮起,但您未更换相应的滤网。结果是本产品现在已被锁定。在此情况下,更换过滤网并重置过滤网使用寿命计数器。
出风口排出的气流比之前明显减弱。	• 预过滤网变脏。清洁预过滤网(请参阅"清洁"一章)。
即使在产品已经运行很长时间以后,空气质量也未见显著改善。	 请检查过滤网包装袋是否拆除。 某一过滤网可能没有放在产品内部。确保按以下顺序正确安装所有过滤网,首先从最里面的过滤网开始: 1)纳米级劲护滤网S3型; 2)预过滤网。 空气质量感应器湿了。室内湿度过高,因此形成了冷凝水。确保空气质量传感器清洁干燥(请参阅"清洁"一章)。
如何知道我的设备 是Wi-Fi 版本还是非 Wi-Fi版本 ?	• 请检查设备背面的型号铭牌,型号 AC5655 和 AC5660 是 Wi-Fi 版本,而型号 AC5656 是非Wi-Fi 版本。
空气质量指示灯的 颜色始终保持 不变。	· 空气质量感应器变脏。清洁空气质量传感器(请参阅"清洁"一章)。
产品散发出一种奇怪的味道。	 前几次使用产品时,其可能会产生塑料味。这是正常的。不过,如果产品发出烧焦的气味,请联系飞利浦经销商或经授权的飞利浦服务中心。滤网使用一段时间后可能会散发异味,这是因为吸附了室内的气味导致。建议您将滤网置于阳光底下晾晒后继续使用。如晾晒后异味仍较明显影响使用体验,建议更换滤网。
产品声音过大。	如果产品声音过大,您可以将风速更改为较低的风速级 别。当夜间在卧室使用本产品时,可选择静音低速。

问题	可能的解决方法
我已经更换过了过 滤网,但是产品还 是提示需要更换过 滤网。	・可能是您未重置滤网使用寿命计数器。启动产品。然后长按重置按钮(★)3秒钟。
错误代码 "E1 "出现在显示屏上。	机器马达出现故障。请与您所在国家/地区的客户服务中心 联系。
错误代码 "E2"、 "E3"、"E4" 或 "E5"	• 传感器出现故障。请与您所在国家/地区的客户服务中心 联系。

*仅限于 AC5655 和 AC5660

出现在屏幕上。

问题	可能的解决方法
我应该下载哪款应 用程序?	·请从苹果应用程序商店或安卓应用市场下载并安装"Air Matters 在意空气"应用程序。
Wi-Fi 设置不 成功。	 如果您的净化器连接到的路由器为双频段且当前未连接到2.4GHz 网络,请切换至同一路由器(2.4GHz)的另一频段并尝试再次将净化器配对。不支持5GHz 网络。 不支持Web 验证网络。 检查净化器是否在Wi-Fi 路由器的范围内。您可以尝试使空气净化器更靠近Wi-Fi 路由器。 检查网络名称是否正确。网络名称区分大小写。 检查Wi-Fi 密码是否正确。密码区分大小写。 按照"在网络更改后设置Wi-Fi 连接"部分中的说明重新设置。 Wi-Fi 连接可能被电磁或其他干扰中断。使本产品远离可能造成干扰的其他电子设备。 检查移动设备是否处于飞行模式。确保在连接Wi-Fi 网络时禁用飞行模式。 参阅应用程序中的帮助部分,以获得广泛和最新的故障排除技巧。

9 保修与服务

如果您需要了解信息或有任何疑问,请访问飞利浦网站www.philips.com或联系您所在国家/地区的飞利浦客户服务中心(可在全球保修卡中找到飞利浦客户服务中心的电话号码)。如果您所在的国家/地区没有飞利浦客户服务中心,请向当地的飞利浦经销商求助。

订购部件或附件

如果您必须更换部件或需要购买额外的部件,请转到您的飞利浦经销商或访问www.philips.com/support。

如果获取部件有问题,请与您所在国家/地区的飞利浦客户服务中心联系(可在全球保修卡中找到其电话号码)。

10 注意事项

电磁场 (EMF)

本飞利浦产品符合所有有关暴露于电磁场的适用标准和法规。

符合 EMF 标准

Koninklijke Philips N.V. 主要面向广大 消费者制造和销售各类产品,包括通 常能发射和接收电磁信号的各种电子 设备。

飞利浦的主要业务原则之一就是要对自己的产品采取各种必要的健康和安全措施,使其符合所有相应的法律要求,并在制造产品时严格遵照适用的 EMF标准。

飞利浦致力于开发、生产和销售对人体 健康无任何危害的产品。飞利浦确认, 据目前的科学证明,如果其产品使用得 当,则对人体毫无危害。

长期以来,Philips 始终在国际 EMF 和安全标准的制定工作中扮演着积极的角色,这就使 Philips 总能预知标准的发展趋势,并率先应用到其产品中去。

回收

弃置产品时,请不要将它与一般生活垃圾一同丢弃,应将其交给官方指定的回收中心。 这样做有利于环保。

请遵循您所在国家/地区的电器及电子 产品分类回收规定。 正确弃置产品有 助于避免对环境和人类健康造成负面 影响。

注意

该飞利浦设备以及Air Matters应用程序应用了多款开源软件,设备中使用的开源软件许可证文本副本可从网站 www.philips.com/purifier-compatibility获得。

Apple Store是Apple Inc.的服务商标。

Contents

1	Important Safety	24 24
2	Your air purifier	27
	Product Overview	27
	Controls overview	28
3	Getting started	29
	Installing filters	29
	Wi-Fi connection (for	
	AC5655 and AC5660 only)	30
4	Using the appliance	32
	Understanding the air quality	
	light	32
	Turning on and off	32
	Changing the Auto mode	22
	setting	33
	Changing the fan speed Using the light on/off	34
	function	35
	Switching the display	22
	indicator	35
	Setting the child lock	36
	Setting the child tock	
5	Cleaning	37
	Cleaning schedule	37
	Cleaning the body of the	
	appliance	37
	Cleaning the air outlet cover	37
	Cleaning the air quality	
	sensor	38
	Cleaning the pre-filter	39

6	Replacing the air purification filter Understanding the healthy	40
	air protect lock	40
	Replacing the filters	41
7	Storage	42
8	Troubleshooting	43
9	Guarantee and service	46
	Order parts or accessories	46
10	Notices	46
	Electromagnetic fields (EMF) Recycling Notice	46 47 47

1 Important

Safety

Read this user manual carefully before you use the appliance, and save it for future reference.

Danger

- Do not let water or any other liquid or flammable detergent enter the appliance to avoid electric shock and/or a fire hazard.
- Do not clean the appliance with water, any other liquid, or a (flammable) detergent to avoid electric shock and/ or a fire hazard
- Do not spray any flammable materials such as insecticides or fragrance around the appliance.

Warning

 Check if the voltage indicated on the appliance corresponds to the local power voltage before you connect the appliance.

- If the power cord is damaged, you must have it replaced by Philips, a service center authorized by Philips, or similarly qualified persons in order to avoid a hazard.
- Do not use the appliance if the plug, the power cord, or the appliance itself is damaged.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Child shall not play with the appliance. Cleaning and maintenance shall not be made by children without supervision.
- Do not block the air inlet and outlet, e.g. by placing items on the air outlet or in front of the air inlet

 Make sure that foreign objects do not fall into the appliance through the air outlet.

Caution

- This appliance is not a substitute for proper ventilation, regular vacuum cleaning, or use of an extractor hood or fan while cooking.
- If the power socket used to power the appliance has poor connections, the plug of the appliance becomes hot. Make sure that you plug the appliance into a properly connected power socket.
- Always place and use the appliance on a dry, stable, level, and horizontal surface.
- Leave at least 20cm free space behind and on both sides of the appliance and leave at least 30cm free space above the appliance.
- Do not place anything on top of the appliance.

- Do not sit or stand on the appliance. Sitting or standing on the appliance may lead to potential injuiry.
- Do not place the appliance directly below an air conditioner to prevent condensation from dripping onto the appliance.
- Make sure all filters are properly installed before you switch on the appliance.
- Only use the original Philips filters specially intended for this appliance. Do not use any other filters.
- Combustion of the filter may cause inreversible human hazard and/or jeopardize other lives. Do not use the filter as fuel or for similar purpose.
- Avoid knocking against the appliance (the air inlet and outlet in particular) with hard objects.
- Always lift or move the appliance by the handle on back side of the appliance.

- Do not insert your fingers or objects into the air outlet or the air inlet to prevent physical injury or malfunctioning of the appliance.
- Do not use this appliance when you have used indoor smoke-type insect repellents or in places with oily residues, burning incense, or chemical fumes.
- Do not use the appliance near gas appliances, heating devices or fireplaces.
- Always unplug the appliance after use and before cleaning, or carrying out other maintenance or replacing the filters.
- Do not use the appliance in a room with major temperature changes, as this may cause condensation inside the appliance.
- To prevent interference, place the appliance at least 2 meters away from electrical appliances that use airborne radio waves

- such as TVs, radios, and radio-controlled clocks.
- The appliance is only intended for household use under normal operating conditions.
- Do not use the appliance in wet surroundings or in surroundings with high ambient temperatures, such as the bathroom, toilet, or kitchen.
- The appliance does not remove carbon monoxide (CO) or radon (Rn). It cannot be used as a safety device in case of accidents with combustion processes and hazardous chemicals.
- If you need to move the appliance, disconnect the appliance from the power supply first.
- Do not move the appliance by pulling its power cord.
- Always cleanse your hands after changing the filters.


2 Your air purifier

Congratulations on your purchase, and welcome to Philips!

To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

This appliance works with an air filtration system. Read this user manual carefully before you use the appliance, and save it for future reference.


Product Overview



Type number	Filter
FY5186	NanoProtect filter Pro S3*

^{*}Hereinafter referred to as "air purification filter".

Controls overview



Control buttons

Ú	Power on/off button	%	Fan speed button
,Ā,	Light on/off button	Po	Child lock button
(A)	Auto mode button	₽	Filter reset button

Display panel

C.	Sleep mode	Gas	Gas display
~	Speed 1	PM2.5	PM2.5 display
≈	Speed 2	IAI	Indoor Allergen Index display
≋	Speed 3	PM2.5	Pollution mode
@	Turbo mode	***	Allergen mode
	Filter replacement alert	**	Bacteria&Virus mode
	Pre-filter cleaning alert	Po	Child lock indicator
©	Wi-Fi indicator*		

^{*}For AC5655 and AC5660 only.

3 Getting started


Installing filters

Remove all packaging of the filters before using the appliance. Unpack them and place them into the appliance described as follows:



Note

- There is one set of filters on each side of the appliance.
 Each side is equipped with one pre-filter and one air purification filter.
- Make sure that you place the air purification filter in the appliance first and then the prefilter.
- Make sure that the side with the tag is pointing towards you when installing the filter.
- 1 Remove all packaging materials of the air purification filters.




2 Pull the top part of the side panel to remove it from the appliance.



3 Press the two clips down and pull the pre-filter towards you.



4 Put the unpacked air purification filter back into the appliance.



5 Put the pre-filter back into the appliance.



=

Note

- Make sure that all hooks of the pre-filter are properly attached to the purifier.
- 6 To reattach the side panel, mount the panel onto the bottom of the appliance first (1). Then, gently push the panel against the body of the appliance (2).



7 Repeat the above steps and assemble the filter for the other side of the appliance.

Wi-Fi connection (for AC5655 and AC5660 only)

Setting up the Wi-Fi connection for the first time

1 Download and install the 'Air Matters' app from the App Store or Google Play.



- 2 Put the plug of the air purifier in the power socket and touch 0 to turn on the air purifier.
 - → The Wi-Fi indicator **?** blinks orange for the first time.
- 3 Make sure that your mobile device is successfully connected to your Wi-Fi network.
- 4 Launch the 'Air Matters' app and follow the onscreen instructions to connect the air purifier to your network.
- 5 After the successful pairing and connection, the Wi-Fi indicator will light up white. If pairing is not successful, consult the troubleshooting section, or the help section in the 'Air Matters' app for extensive and up-to-date troubleshooting tips.

Note

- This instruction is only valid when the air purifier is being set up for the first time. If the network has changed or the setup needs to be performed again, consult section "Setting up the Wi-Fi connection when the network has changed" on page 31.
- If you want to connect more than one air purifier to your smart device, you have to do this successively. Complete the set up of one air purifier before you turn on the other air purifier.
- Make sure that the distance between your mobile device and the air purifier is less than 10 m without any obstructions.
- This App supports the latest versions of Android and iOS. Please check www.philips.com/purifiercompatibility for the latest update of supported operating systems and devices.

Reset the Wi-Fi connection



Note

- This applies when the default network to which your purifier is connected has changed.
- Reset the Wi-Fi connection when your default network has changed.
- 1 Put the plug of the air purifier in the power socket and touch 0 to turn on the air purifier.
- 2 Touch 1 and 2 simultaneously for 3 seconds until you hear a beep.
 - → The air purifier goes to pairing mode.
 - → The Wi-Fi indicator **?** blinks orange.
- 3 Follow the steps 4-5 in "Setting up the Wi-Fi connection for the first time" section.

4 Using the appliance

Understanding the air quality light

IAI is a real-time numerical display that provides visual and immediate feedback on indoor allergen level.

Air quality light color	Air quality level
Blue	Good
Blue-purple	Fair
Purple-red	Poor
Red	Very poor

The air quality light automatically goes on when the air purifier is switched on, and lights up all colors in sequence. After approximately 30 seconds, the air quality sensors select the color that corresponds to the surrounding air quality of airborne particles.

PM2.5

AeraSense sensing technology accurately detects and quickly respond to even the slightest particle change in the air. It provides you with reassurance with real-time PM2.5 feedback.

IAI

The professional-grade **AeraSense** sensor detects the level of indoor air allergen and with numerical feedback from 1 to 12 the potential risk level of indoor air allergens can be displayed. 1 indicates best air quality.

GAS

With an advanced as sensor, a display ranging from L1 to L4 shows the density level of potential harmful gases (incl. VOC, odor, etc.) detected. L1 indicates best air quality.

Turning on and off



Note

- Always place the air purifier on a stable, horizontal, and level surface with the front of the unit facing away from walls or furniture.
- For optimum purification performance, close doors and windows.
- Keep curtains away from the air inlet or air outlet.
- 1 Put the plug of the air purifier in the wall outlet.
 - → The air purifier beeps.
 - → All lights go on once and then go out again.

2 Touch the \circlearrowleft button to switch on the appliance.



- The air purifier operates under the Pollution mode (♠) by default.
- When the air purifier is warming up, "---" displays on the screen.
- → After 30 seconds, the air purifier shows the PM2.5 level on the screen. The air quality sensor automatically selects the appropriate air quality light color.



3 Touch and hold the 0 button for 3 seconds to switch off the air purifier.



 If the air purifier stays connected to the electrical outlet after turning OFF, the air purifier will operate under the previous settings when turned ON again.


Changing the Auto mode setting

You can choose Pollution mode (), Allergen mode () or Bacteria & Virus mode ().

Pollution mode

The specially designed pollution mode can effectively remove airborne pollutants such as PM2.5.


- Touch the Auto mode button **(2)** to select Pollution mode .
 - → Auto (🖁) and 🖾 display on the screen.



Allergen mode

The extra-sensitive allergen mode is designed to react to even a small change in allergen levels in the surrounding air.


- Touch the Auto mode button to select Allergen mode.
 - → Auto (🛱) and 🐞 display on the screen.



Bacteria & Virus mode

The Bacteria & Virus mode boosts the airflow to quickly reduce bacteria & viruses.

- Touch the Auto mode button A to select Bacteria & Virus mode.
 - → Auto (🖁) and 🏶 display on the screen.



Changing the fan speed

There are several fan speeds available.


When using the manual fan speed settings, the purifier will still monitor the air quality, but it will not automatically adjust the fan speed if it detects changes in the air quality.

Sleep mode (C)

In sleep mode, the air purifier operates quietly at a very low speed.


- Touch the fan speed button **3** to select the sleep mode.
 - → The "5 L" displays on the screen.

→ The sleep mode indicator **C** goes on.



Manual

- Touch the fan speed button
 repeatedly to select the fan speed you need:
 - **∼** (Speed 1)
 - ≈(Speed 2)
 - **≋**(Speed 3)






 If the air quality light lights up blue, it indicates that the air quality is good, and you can select a lower fan speed. On the other hand, if the air quality light lights up red-purple or red, it indicates that the air quality is unhealthy, and you can select a higher fan speed to purify the air more quickly.

Turbo(t)

In Turbo mode, the air purifier operates on the highest speed.

- Touch the fan speed button **3** to select the Turbo mode (**b**).
 - → The " **L** " displays on the screen.
 - The turbo speed indicator **@** goes on.



Using the light on/off function

With the light dimming button, you can switch on or off the air quality light, the display screen and the function indicator if desired.


- 3 Touch the light dimming button $\dot{\mathbf{g}}$ for the third time, all lights will be on again.

Switching the display indicator


The air purifier has three display indicators, PM2.5 index, IAI index, and Gas level.




- The air purifier displays PM2.5 index by default.
- 1 Touch the light dimming button $\tilde{\mathbf{Y}}$ for 3 seconds to switch to IAI index.
 - → The IAI indicator and the actual IAI index display on the screen.



- 2 Touch the light dimming button $\dot{\mathbf{Y}}$ for 3 seconds again to switch to PM2.5 index.
 - → The PM2.5 indicator and the actual PM2.5 index display on the screen.



- 3 Touch the light dimming button $\tilde{\mathbf{y}}$ for 3 seconds again to switch to Gas level display.
 - → The Gas indicator and the actual Gas level display on the screen.






Note

• It is possible that the air quality light may still be red even if the PM2.5 index is very low. It's normal. This is because that at least one of the index (the IAI index or Gas level) is high that turns the air quality light to red. The appliance real-time displays the air quality index with the highest risk.

Setting the child lock

- 1 Touch and hold the child lock button ♠ for 3 seconds to activate child lock.
 - → The child lock icon ਿ displays on the screen.
 - → When the child lock is on, all the other buttons are not responsive.



- 2 Touch and hold the child lock button ♠ for 3 seconds again to deactivate child lock.
 - → The child lock icon to disappears.



Note

 For AC5655 and AC5660, you can still control the appliance through the App even child lock is activated.

5 Cleaning

Note

- Always unplug the appliance before you clean it.
- Never immerse the appliance in water or any other liquid.
- Never use abrasive, aggressive, or flammable cleaning agents such as bleach or alcohol to clean any part of the appliance.
- Only the pre-filter is washable.
 The air purifier filter is not washable nor vacuum cleanable.

Cleaning schedule

Frequency	Cleaning method		
When necessary	Wipe the surface of the appliance with a soft dry cloth		
	Clean the air outlet cover		
Every two months	Clean the air quality sensor with a dry cotton swab		
When the pre-filter cleaning indicator up and F0 displays on the screen	Clean the pre- filter		

Cleaning the body of the appliance

Regularly clean the inside and outside of the appliance to prevent dusts from collecting.

Wipe away dust with a soft dry cloth from the body of the appliance.

Cleaning the air outlet cover

To unlock the air outlet cover, grab the handle on the cover and pull the cover up.



2 Clean the cover with a brush.



3 Reattach the cover properly.




Cleaning the air quality sensor

Clean the air quality sensor every two months for optimal functioning of the appliance. Clean it more frequently if you use the appliance in a dusty environment.



- If the air purifier is used in a dusty environment, it may need to be cleaned more often.
- If the humidity level in the room is very high, condensation may develop on the air quality sensor and the air quality light may indicate a more poor air quality even though the air quality is actually good. If this occurs, clean the air quality sensor or use the air purifier on a manual speed setting.


1 Clean the inlet and outlet of the air quality sensor with a soft brush.



2 Remove the air quality sensor cover.



3 Clean the air quality sensor, the dust inlet and the dust outlet with a damp cotton swab.




4 Dry all parts thoroughly with a dry cotton swab.

5 Reattach the air quality sensor cover.



Cleaning the pre-filter

Clean the pre-filter when lights up and F0 is displayed on the screen.



- 1 Switch off the air purifier and unplug from the wall outlet.
- 2 Pull the top part of the side panel to remove it from the appliance.



3 Press the two clips down and pull the pre-filter towards you.



4 If the pre-filter is very dirty, use a soft brush to brush away the dust. Then wash the pre-filter under running tap water.



- **5** Allow the pre-filter to air dry thoroughly before placing back in the air purifier.
- 6 Put the pre-filter back into the appliance.



Note

- Make sure that the pre-filters are completely dry before you put them back in the appliance.
 If they are still wet, bacteria may multiply in them and shorten the lifetime of the pre-filters.
- 7 To reattach the side panel, mount the panel onto the bottom of the appliance first (1). Then, gently push the panel against the body of the appliance (2).



- 8 Put the plug of the air purifier in the wall outlet.
- 9 Touch the \circlearrowleft button to switch on the appliance.
- 10 Touch and hold the reset button for 3 seconds to reset the pre-filter cleaning time.
- **11** Wash your hands thoroughly after installing filters.

6 Replacing the air purification filter

Understanding the healthy air protect lock

This air purifier is equipped with a filter replacement indicator to make sure that the air purification filter is in optimal condition when the air purifier is operating. When the filters need to be replaced, the filter code displays on the screen (see Filter alert chart) and the filter replacement alert () lights up red.

If the filters are not replaced in time, the air purifier will stop operating and automatically lock to protect the air quality in the room. Replace the filters as soon as possible according to the filter code.


Replacing the filters




Note

- · The HEPA and AC filters are not washable or reusable.
- · Always turn off the air purifier and unplug from the electrical outlet before replacing the filters.
- · Do not clean the filters with a vacuum.
- · If the pre-filter is damaged, worn or broken, do not use. Visit www.philips.com/support or contact the Consumer Care Center in your country.

Filter alert light status	Action
A3 displays on the screen and the filter replacement alert 🗗 goes on.	Replace the NanoProtect filter Pro S3 (FY5186)




- Take out the pre-filters on both sides of the appliance.
- **2** Take out the expired filters. Discard used filters.






Note

- · Do not touch the pleated filter surface, or smell the filter as it has collected pollutants from the air.
- Remove all packaging material of the new filters



4 Put the unpacked air purification filters back into the appliance.



- 5 Put the plug of the air purifier in the wall outlet.
- 6 Touch the 0 button to switch on the appliance.
- 7 Touch and hold the reset button for 3 seconds to reset the filter lifetime counter



Note

Wash your hands after changing a filter

7 Storage

- 1 Turn off the air purifier and unplug from the wall outlet.
- 2 Clean the air purifier, air quality sensor and pre-filter (see chapter 'Cleaning').
- 3 Let all parts air dry thoroughly before storing.
- 4 Wrap the filters and pre-filter separately in air tight plastic bags.
- 5 Store the air purifier, filters and pre-filters in a cool, dry location.
- **6** Always thoroughly wash hands after handling filters.

8 Troubleshooting

This chapter summarizes the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, contact the Consumer Care Center in your country.

Problem	Possible solution
The appliance does not work even though it is plugged in.	 Check if the top cover is properly installed. The filter replacement light has been on continuously but you have not replaced the corresponding filter. As a result, the appliance is now locked. In this case, replace the filter and reset the filter lifetime counter.
The airflow that comes out of the air outlet is significantly weaker than before.	The pre-filter is dirty. Clean the pre-filter (see the chapter "Cleaning").
The air quality does not improve, even though the appliance has been operating for a long time.	 Check if the packing material is removed from the filters. One of the filters has not been placed in the appliance. Make sure that all filters are properly installed in the following order, starting with the innermost filter: NanoProtect filter Pro S3; pre-filter. The air quality sensor is wet. The humidity level in your room is high and causes condensation. Make sure that the air quality sensor is clean and dry (see the chapter "Cleaning").

Problem	Possible solution	
How can I know whether my device is Wi-Fi version or non Wi-Fi version?	 Please check the type plate at the backside of the device, model AC5655 and AC5660 are the Wi-Fi version while model AC5656 is non Wi-Fi version. 	
The color of the air quality light always stays the same.	The air quality sensor is dirty. Clean the air quality sensor (see the chapter "Cleaning").	
The appliance produces a strange smell.	• The first few times you use the appliance, it may produce a plastic smell. This is normal. However, if the appliance produces a burnt smell, contact your Philips dealer or an authorized Philips service center. The filter may produce smell after being used for a while because of the absorption of indoor gases. It's recommended that you reactivate the filter by putting it in direct sunlight for repeated use. If odor still exists, replace the filter.	
The appliance is extra loud.	 If the appliance is too loud, you can change the fan speed to a lower fan speed level. When using the appliance in a bedroom at night, choose the silent speed. 	
The appliance still indicates that I need to replace a filter, but I already did.	 Perhaps you did not reset the filter lifetime counter. Switch on the appliance. Then touch and hold the reset button () for 3 seconds. 	
Error code "E1" displays on the screeen.	The hall sensor is not working properly. Remove and then reattach the front panel. If the error code "E1" still exists, contact the Consumer Care Center in your country.	

Problem Possible solution Error codes "E2", "E3", "E4" or "E5" displays on the screen. • The appliance has malfunctions. Contact the Consumer Care Center in your country.

For AC5655 and AC5660 Wi-Fi version only

Which App I should download?	 Please download and install the 'Air Matters' App the App Store or Android market.
The Wi-Fi setup is not successful.	 If the router your purifier is connected to is dual – band and currently it is not connecting to a 2.4GHz network, please switch to another band of the same router (2.4GHz) and try to pair your purifier again. 5Ghz networks are not supported. Web authentication networks are not supported. Check if the purifier is within range of the Wi-Fi router. You can try to locate the air purifier closer to the Wi-Fi router. Check if the network name is correct. The network name is case-sensitive. Check if the Wi-Fi password is correct. The password is case-sensitive. Retry the setup with the instructions in section 'Set up the Wi-Fi connection when the network has changed'. The Wi-Fi connectivity can be interrupted by electromagnetic or other interferences. Keep the appliance away from other electronic devices that may cause interferences. Check if the mobile device is in airplane mode. Make sure to have the airplane mode deactivated when connecting to the Wi-Fi network. Consult the help section in the App for extensive and up-to-date troubleshooting tips.

9 Guarantee and service

If you need information or if you have a problem, please visit the Philips website at www.philips.com or contact the Philips Consumer Care Center in your country (you can find its phone number in the worldwide guarantee leaflet). If there is no Consumer Care Center in your country, go to your local Philips dealer.

Order parts or accessories

If you have to replace a part or want to purchase an additional part, go to your Philips dealer or visit www.philips.com/support.

If you have problems obtaining the parts, please contact the Philips Consumer Care Center in your country (you can find its phone number in the worldwide guarantee leaflet).

10 Notices

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Compliance with EMF

Koninklijke Philips N.V. manufactures and sells many products targeted at consumers, which, like any electronic apparatus, in general have the ability to emit and receive electromagnetic signals.

One of Philips' leading Business Principles is to take all necessary health and safety measures for our products, to comply with all applicable legal requirements and to stay well within the EMF standards applicable at the time of producing the products.

Philips is committed to develop, produce and market products that cause no adverse health effects. Philips confirms that if its products are handled properly for their intended use, they are safe to use according to scientific evidence available today.

Philips plays an active role in the development of international EMF and safety standards, enabling Philips to anticipate further developments in standardization for early integration in its products.

Recycling

Do not throw away the product with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

Follow your country's rules for the separate collection of electrical and electronic products. Correct disposal helps prevent negative consequences for the environment and human health.

Notice

This Philips appliance and Air Matters app applied multiple open source softwares, Copies of open source software license text used in this product can be derived from website- www.philips.com/purifier-compatibility.

App Store is a service mark of Apple Inc.



保修及服务:

此产品是一件设计精良,用高品质元件制造之家用电器,在 正常使用及保养下应能发挥其优越性能。在购买日期后二 年内,若发生任何因制造工艺或元器件造成之损坏,飞利浦 中国维修服务中心将为持证用户提供免费门市维修服务, 视情况更换零件或整个产品。

无论在保期中或保期后, 只要飞利浦正式行销该产品的任何国家皆可获得维修服务。

若飞利浦在当地无行销该项产品,飞利浦同样提供维修服务,但可能因未储备所需零件,维修时间可能较长,敬请见谅。 请联络当地飞利浦经销商,或飞利浦服务部门。

若您需洽询相关资讯,或遇困难事项时,请联络当地飞利浦 维修服务中心,或向飞利浦服务热线咨询。

中国顾客服务热线: 4008 800 008 (用户需承担本地通话费)。

网址: http://www.philips.com.cn

网上会员注册与产品注册:

- 1) 登陆 http://www.philips.com.cn/welcome
- 2) 点击"创建新账户", 创建您的飞利浦账号
- 3) 点击"注册产品",通过产品名称或产品型号查找产品, 完成产品注册

保修条例:

- * 在购买日期后二年内,凡经本公司特约维修站人员确认为 正常使用情况下,因制造工艺或元器件造成之损坏,您都 将获得免费保修服务。
- * 此免费服务不包括需时常更换的易耗零配件(吸尘机纸袋, 布袋,空气清新机滤网,滤芯,活性碳,咖啡壶过滤网)及 附件(如须刀网膜、刀头,咖啡杯,食品加工机杯/刀具等), 辅助装置,运输费及维修人员上门服务费。
- * 用户请保留此联。
- * 维修时请携同此证及发票正本。
- * 此证若经涂改即作废。
- * 此证须联同发票正本使用方为有效。
- * 以下情况将不能获得免费服务
- 使用不当引起的人为损坏,例如接入不适当电源、使用不适当配件、不适当之安装、不依说明书使用、错误使用或疏忽而造成损坏等。因运输及其他意外而造成之损坏。非经本公司认可之维修和改装。其他因不可抗力(如自然灾害、电压异常等)造成的损坏。
- 2.一般家庭以外使用(如工业、商业用)而造成的损坏。
- 3.正常使用引起的产品老化、磨损等, 但不影响产品的正常使用。
- * 此证仅在中国境内有效。
- * 保修证作为在规定期限及条件之内进行免费维修的保证, 并不限制消费者的法定权利。

服务须知

需要此产品的售后服务, 拨打服务热线:4008800008 在维修服务过程中有任何意见, 欢迎致函飞利浦优质生活 服务办事处解决疑难。 飞利浦(中国)投资有限公司 飞利浦优质生活客户服务部 中国上海市田林路888弄10号 飞利浦创新科技园1号楼 邮政编码: 200233 传真: (021)54452663 产品 : 飞利浦智能空气净化器 AC5655

型号 : KJ500F-E05 额定电压 : 220V~ : 50Hz 额定频率

额定输入功率: 65 W 生产日期 : 请见产品本体

产地 : 中国

本设备包含型号EMW3081-P,核准代码 CMIIT ID: 2017DP5054的无线发射模块

飞利浦(中国)投资有限公司 上海市天目西路 218 号 1602-1605 全国顾客服务热线: 4008 800 008

本产品根据国标 GB4706.1-2005, GB4706.45-2008, 信部无[2002]353制造

产品性能指标

目标污染物	洁净空气量(CADR)	累计净化量(CCM)	净化能效等级
颗粒物	600 m³/h	P4	高效级
甲醛 300 m³/h		F4	高效级
噪声(声功率级)	65 dB (A)	适用面积*	42 - 72 m²

*适用面积是按照国标GB/T18801-2015根据颗粒物洁净空气量计算得出 以上性能指标数据是在第三方试验室按照国标GB/T18801-2015,以特定 的烟尘颗粒物或气态污染物为目标污染物测试得出

: 飞利浦空气净化器 AC5656 : KJ500F-E06

额定电压 : 220V~ 额定频率 : 50Hz 额定输入功率: 65 W

产地

生产日期 : 请见产品本体 : 中国

产品维护及滤材更换或清洗说明信息详见 使用说明

飞利浦(中国)投资有限公司 上海市天目西路 218 号 1602-1605 全国顾客服务热线: 4008 800 008

本产品根据国标 GB4706.1-2005, GB4706.45-2008 制造

产品性能指标

目标污染物 洁净空气量(CADR)		累计净化量(CCM)	净化能效等级
颗粒物	颗粒物 600 m³/h		高效级
甲醛 300 m³/h		F4	高效级
四十/十五次(四)	GE AD (A)	注 四 表 和 *	42 - 72 m ²
【噪声(声功率级)		适用面积*	42 - 72 111-

*适用面积是按照国标GB/T18801-2015根据颗粒物洁净空气量计算得出 以上性能指标数据是在第三方试验室按照国标GB/T18801-2015,以特定 的烟尘颗粒物或气态污染物为目标污染物测试得出

: 飞利浦智能空气净化器 AC5660 产品

型号 : KJ500F-E07 额定电压 : 220V~ 额定频率 : 50Hz

额定输入功率: 65 W 生产日期 : 请见产品本体

产地 : 中国

本设备包含型号EMW3081-P,核准代码 CMIIT ID: 2017DP5042的无线发射模块

飞利浦(中国)投资有限公司 上海市天目西路 218 号 1602-1605 全国顾客服务热线: 4008 800 008

本产品根据国标 GB4706.1-2005,

GB4706.45-2008, 信部无[2002]353制造

产品性能指标

	百伊仝气里(CADR)	累计净化量(CCM)	净化能效等级
颗粒物	600 m³/h	P4	高效级
甲醛	300 m³/h	F4	高效级

噪声(声功率级) 适用面积* 65 dB (A) 42 - 72 m²

*适用面积是按照国标GB/T18801-2015根据颗粒物洁净空气量计算得出 以上性能指标数据是在第三方试验室按照国标GB/T18801-2015,以特定 的烟尘颗粒物或气态污染物为目标污染物测试得出

产品中有害物质的名称及含量

	有害物质					
部件名称	铅(Pb)	汞(Hg)	镉(Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
气体感应器	×	0	0	0	0	0
主控制电路板	×	0	0	0	0	0
马达	×	0	0	0	0	0
电源电路板	×	0	0	0	0	0

本表格依据SJ/T 11364的规定编制。

- 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572 规定的限量要求以下。
- × 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572规定的限量要求。
- *该表格中所显示的"有害物质"在产品正常使用情况下不会对人身和环境产生任何伤害。
- *该表格中所显示的"有害物质"及其存在的部件向消费者和回收处理从业者提供相关物质的存在信息,有助于产品废弃时的妥善处理。

保留备用

出版日期: 2017-09-05



© 2017 Koninklijke Philips N.V. 保留所有权利



