

A/V Connectivity Module for BOX4MODULE and BEZ4MOD

Product Diagram

Actual product may vary from photos.

Front View



Rear View



Package Contents

- A/V Module x 1
- Universal Power Adapter x 1
- Power Clips (NA, EU, UK) x 3
- Mounting Bracket x 1
- Mounting Bracket Screws (M5 x 20 mm) x 4
- Module Screws (#6-32 x 3/16") x 8
- Quick-Start Guide x 1

Requirements

• Power Source (i.e. AC Electrical Outlet)

Installation Requirements:

- Mounting Surface
- Mounting Bracket x 1
- Mounting Bracket Screws (M5 x 20 mm) x 4
- Module Screws (#6-32 x 3/16") x 4
- Writing Utensil x 1
- Phillips Head Screwdriver x 1

For the latest requirements, please visit: www.startech.com/MOD4AVHD.

Installation

See the Installation section in the Modular Conference Table Box (BOX4MODULE) or Single-Module Conference Table Box (BEZ4MOD) **User Manual** for instructions on how to install a **Module**.

These **User Manuals** can be found under the **Support** tab at: <u>www.startech.com/BOX4MODULE</u> <u>www.startech.com/BEZ4MOD</u>

(Optional) Mounting the Module

Note: StarTech.com is not responsible for any damages related to the installation of this product.

Note: Before mounting the **Module**, consider the desired orientation of the ports (front and rear).

 Align the Mounting Bracket with four Mounting Holes on the Module.

Note: There are four **Mounting Holes** on each side of the **Module**, which gives you two different mounting options.

- 2. Insert the **Module Screws** (x4) through the **Mounting Bracket** and into the **Mounting Holes**.
- 3. Tighten the **Module Screws** using a **Phillips Head Screwdriver**. Do not overtighten the **Module Screws**.
- Before installing the Mounting Bracket on or under your Mounting Surface, measure and position the Mounting Bracket in the desired location. The Module can be mounted on a vertical or horizontal Mounting Surface.
- (Optional) Depending on the Mounting Surface you are using to install the product, you may need to drill pilot holes prior to installing the Mounting Bracket Screws into the Mounting Surface.
- Mark the location of the Mounting Holes using a Writing Utensil. These marks can be used as a guide to indicate where the Mounting Bracket Screws will be installed in the surface.
- Install the Mounting Bracket Screws (x4) through the Mounting Bracket and into the Mounting Surface, using a Phillips Head Screwdriver. Do not overtighten the Mounting Bracket Screws.

Warning: To prevent the **Mounting Bracket Screws** from penetrating the opposite side of the **Mounting Surface**, be conscious of the length of the **Mounting Bracket Screws** compared to the depth of the **Mounting Surface**.

SKU #: MOD4AVHD

Powering the Module

- 1. On the bottom of the A/V Connectivity Module, connect the Universal Power Adapter to the DC 5V 2A Port.
- Tighten the Lock Screw on the Universal Power Adapter's **Barrel Connector**, to ensure connectivity.
- 3. Connect the other end of the **Universal Power Adapter** to an appropriate Power Source.

Connecting a Device to the Module

For instructions on how to connect devices to the **Module** see the Connecting Devices to the Top of the Module and Connecting Devices to the Bottom of the Module sections in the **User Manual**.

The **User Manual** can be found under the **Support** tab at: www.startech.com/MOD4AVHD.

LED Indicator

Power

Solid LED (White)

• Indicates that the A/V Connectivity Module is active (the Universal Power Adapter is correctly connected to an AC Electrical Outlet).

LED Off

 Indicates that the Universal Power Adapter is not correctly connected to an AC Electrical Outlet or the A/V Module is not receiving power from the AC Electrical Outlet.

Safety Measures

- If product has an exposed circuit board, do not touch the product under power.
- Wiring terminations should not be made with the product and/or electric lines under power.
- Product installation and/or mounting should be completed by a certified professional as per the local safety and building code guidelines.

 Cables (including power and charging cables) should be placed and routed to avoid creating electric, tripping or safety hazards. Mesures de sécurité

- Si l'un des circuits imprimés du produit est visible, ne pas touchez le produit lorsqu'il est sous tension.
- Les terminaisons de câblâge ne doivent pas être effectuées lorsque le produit et/ou les câbles électriques sont sous tension.
- L'installation et/ou le montage du produit doit être réalisé par un professionnel certifié et dans le respect des normes locales et du code de construction local.
- acheminés de façon à éviter tout risque électrique, de chute ou de sécurité 安全対策 Les câbles (y compris les câbles d'alimentation et de chargement) doivent être placés et

2.71 欠果 製品に裏出した状態の回路基盤が含まれる場合、電源が入っている状態で製品に触らないでください。 電源が入っている女態の製造または鍵盤の終端処理を行わないでください。 製品の設置やマックトは、使用地側の安全ガイトラインおよび建築基準に従い、有資体の専門署者が行うようにしてください。 ケーブル (電源ケーブルと充電ケーブルを含む) は、適切な配置と引き回しを行い、電気障害やつまづきの危険性など、安全上のリスクを回避するようにしてください。

Misure di sicurezza

- Se il prodotto ha un circuito stampato visibile, non toccare il prodotto quando è acceso.
- I terminiali dei fili elettrici non devono essere realizzate con il prodotto e/o le linee elettriche sotto tensione. L'installazione e/o il montaggio dei prodotti devono essere eseguiti da un tecnico
- professionale certificato che conosca le linee guida locali sulle norme edilizie e sulla sicurezza. I cavi (inclusi i cavi di alimentazione e di ricarica) devono essere posizionati e stesi in modo da evitare pericoli di inciampo, rischi di scosse elettriche o pericoli per la sicurezza.

Säkerhetsåtgärder

- Rör aldrig vid enheter med oskyddade kretskort när strömmen är påslagen. Montering av kabelavslutningar får inte göras när produkten och/eller elledningarna är strömförda.
- Installation och/eller montering får endast göras av behöriga yrkespersoner och enligt
- gällande lokala förordningar för säkerhet och byggnormer. Kablar (inklusive elkablar och laddningskablar) ska dras och placeras på så sätt att risk för snubblingsolyckor och andra olyckor kan undvikas.

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that intérference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment

on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is

- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC Rules. Operation is subject to the following two
- conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by StarTech.com could void the user's authority to operate the equipment.

Industry Canada Statement

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [B] est conforme à la norme NMB-003 du Canada. CAN ICES-3 (B)/NMB-3(B)

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) This device may not cause interference, and (2) This device must accept any interference,

including interference that may cause undesired operation of the device.

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

Technical Support

StarTech.com's lifetime technical support is an integral part of our commitment to provide industry-leading solutions. If you ever need help with your product, visit www.startech.com/ support and access our comprehensive selection of online tools, documentation, and downloads. For the latest drivers/software, please visit www.startech.com/downloads

Warranty InformationThis product is backed by a two-year warranty. StarTech.com warrants its products against defects in materials and workmanship for the periods noted, following the initial date of purchase. During this period, the products may be returned for repair, or replacement with equivalent products at our discretion. The warranty covers parts and labor costs only. StarTech.com does not warrant its products from defects or damages arising from misuse, abuse, alteration, or normal wear and tear.

Limitation of Liability
In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

Startech.com Ltd. 45 Artisans Cres. London, Ontario N5V 5E9 Canada

StarTech.com LLP 2500 Creekside Pkwy. Lockbourne, Ohio 43137 U.S.A.

StarTech.com Ltd. Unit B, Pinnacle 15 Gowerton Rd. Brackmills Northampton NN4 7BW United Kinadom

FR: fr.startech.com DE: de.startech.com FS: es startech com IT: it.startech.com JP: jp.startech.com NL: nl.startech.com